GENERAL

There are four main sections to moOde: Playback, Library, CoverView and Configuration.

Switching between Playback and the Library is accomplished by clicking on the cover art in Playback or on any open area of the Playbar in the Library.

PLAYBACK

The Playback screen includes the play queue (Queue), volume and time knobs, playback controls, cover art and metadata.

LIBRARY

The library provides Radio, Folder, Tag, Album and Playlist views for browsing and selecting content and a Playbar for displaying song information and controlling playback. Options for configuring various aspects of the Library including sort order, recently added and more are located in the Library section of Preferences.

SEARCHING THE LIBRARY

Powerful search features are available in Tag and Album view that allow the Library to be filtered based on entered text, tag value pairs or special, predefined filters. These are entered in the search field on the Library menu. There is also an Advanced search dialog that enables multiple tag value pairs to be submitted.

General

Searches are not case sensitive and partial matches are considered valid. Searches are cleared by clicking on the "Filtered by" heading.

filter. Tag value pairs

NOTE: The search field only supports a single tag value pair or a single Predefined

The following tags are supported: Any, Genre, Artist, Album, Title, Album Artist,

Date, Composer, Conductor, Performer, Work, Comment and File. Examples: genre rock | artist frank sinatra | artist mccartney | any zeppelin

The Any tag

The Any tag performs a search of all tags using an OR relationship. An Any search is

automatically invoked when the first word of text entered in the search field does not match any of the tag or predefined filter names. Examples: yellow submarine | all that you can't leave behind | frank sinatra | 1962

 Predefined filters The following predefined filters are available: Encoded [bits/rate], Format [.ext],

Folder [path], Hdonly, Lossless, Lossy and Year [yyyy] or [yyyy-yyyy]. Examples: encoded 24/96 | encoded 192 | hdonly | format .dsf | folder u2/achtung baby | lossy | year 1962 | year 1994-1998

COVERVIEW The CoverView screen saver provides a large sized cover art image or optional Analog

or Digital clock, a Playbar for controlling playback and several backdrop options that

can be selected in the CoverView section of Preferences.

CONFIGURATION

The Configuration screens are accessed via the Main Menu and provide settings for the Library, Audio, Network, System and Renderers. QUEUE

The Queue is displayed in Playback and CoverView and contains all items to be

item otherwise it does the same as Add and then begins play.

Queue or the selected track and all following tracks.

played. It's populated primarily by selecting an item from the Library and then clicking

one of the Queue commands listed on a context menu. It can also be populated automatically by Auto-shuffle. The Queue commands are listed below. Add | Play The "Add" command adds the item to the end of the Queue. The "Play" command

first checks to see if the item is already in the Queue and then plays the existing

Clear/Play

The "Clear/Play" command first clears the Queue then adds the item and begins play. Add next | Play next

The "Add next" command adds the item immediately after the currently playing or last played item. The "Play next" command first checks to see if the item is already in the Queue and then plays the existing item otherwise it does the same as "Add next" then begins play.

For the track list in Library Tag and Album views the Play and Clear/Play actions can

be configured via a Preferences option to either add the selected track to the

PLAYLISTS Creating, editing and managing playlists is done primarily in Library Playlist view.

Playlists can also be created via context menu items "Save Queue to playlist", "Set Favorites name" and "Add to playlist".

 Save Queue to playlist The "Save Queue to playlist" command displays a list of available playlists and adds the item to the end of the selected playlist or a new playlist if one is specified.

Set Favorites name

The "Set Favorites name" command displays an input form for specifying the name of the playlist that contains items favorited by clicking the Heart \heartsuit button. If the playlist does not already exist it will be created.

Add to playlist

The "Add to playlist" command displays a list of available playlists and adds the item to the end of the selected playlist or a new playlist if one is specified. MULTIROOM AUDIO

A moOde multiroom audio system consists of a Sender and Receivers. The Sender should be a dedicated moOde player configured to output to the integrated HDMI

port or optioally the Headphone jack but not connected to any speakers or headphones. It functions solely as a Music Server that Sends its audio output to one or more Receivers. For additional information View multiroom setup guide

Configuration

Sender and Receiver options are configured in Multiroom Config which is accessed via Menu/Configure or in the ALSA section of Audio Config. Audio sources including MPD, AirPlay and Spotify can be distributed by the Sender.

 Master volume The volume knob on the Sender system provides master volume control by sending the volume change to the Receivers which apply it to their own volume. Receivers can be configured to opt in or out of Master volume control via

Multiroom Config. Receiver control

Receivers can be centrally controlled from the Sender system via the Receivers panel which is accessed by the 🔊 button at the top of Playback view. Networking The performance of the system depends on having low latency, high throughput

networking and hosts. Discovery of Receivers relies on Multicast DNS. Addressing

for the audio distribution protocol relies on IP Multicast using a default address of

239.0.0.1. Audio format The system uses 16 bit 48 kHz PCM format encoded using the Opus CODEC.

➡ Players

Resampling if needed is handled by ALSA using the Speex converter. SPECIAL MENU ITEMS Most menu items are self explanatory but several perform unique functions.

This item is located on the Main menu. It displays a list of other moOde players

discovered on the network. Submit an action to apply to all the players listed or

click an individual player to open it. The Submit button will request a second click for confirmation. If a player is functioning as a Multiroom Receiver the 🔊 icon will appear next to its name.

Audio info This item is located on the Main menu and ellipsis context menus on Playback and Playbar. If its opened from the Main menu it displays hardware related information

CamillaDSP Quick Select

top of Playback view when CamillaDSP is On.

automatically enabled when Auto-shuffle is ON.

about the item currently being played and is divided into three sections including Input/Output, DSP and Audio Device. If its opened from the ellipsis context menu it displays metadata information about the station or track currently being played. SPECIAL BUTTONS Most buttons are self explanatory but several perform unique functions.

Display a menu of available CamillaDSP configurations. This button appears at the

CoverView Display full screen CoverView screen saver. clicking anywhere off of the Playbar dismisses CoverView.

↓ Consume

Repeat

Play randomly selected tracks from the Queue (default) or if Auto-shuffle is ON (see Audio Config) play randomly selected tracks or albums from the entire Music Library.

C Single Used in conjunction with Repeat to repeat a single track.

Select random album

Toggle between the currently playing item and the last played item.

★ Play a random album

Favorite

Add the currently selected item in the Queue to the Favorites playlist. Playlists are listed in Library Playlist view.

Select a random Album for review when in Tag or Album view.

There are several non-button elements in the UI that perform an action when tapped. One touch action

 Renderer Active screens clicking on the title in the center of Bluetooth, Analog Input or S/PDIF Input Active will launch their respective Configuration screens which allow the input/output

When clicking a cover in Library Radio or Album view, or clicking the "Play a

time up or down. clicking or dragging the time ring moves forward or backward in the song.

volume ring advances the volume by a maximum number of steps called the Volume step limit. This limit can be set via Audio Config. clicking the plus/minus buttons adjusts volume by 1 step. Extra metadata

clicking on the time while a song file is playing will toggle between counting the

In Playback clicking the extra metadata under the cover art opens the Station or Track tab on the Audio info screen.

In Playback clicking the song title under the cover art launches a search in a separate Browser tab. The search engine used can be selected in the Playback section of Preferences.

On Smartphones it scrolls the Queue to that item. Station or Artist name

In Playback clicking the Radio station name or the Artist name under the cover art switches to Radio or Tag view respectively. In Tag view the artist filter is applied. In Radio view the list is scrolled to the station.

Swipe gestures

On Smartphones swiping up scrolls the Queue into view and clicking on the Playbar returns to Playback. In Library tag view swiping sideways shows/hides the

Repeat the Queue or if Single is enabled then repeat the track.

Remove the track from the Queue after it finishes playing. Consume mode is

Randomly select an album from the Music Library and perform the action specified for the "One touch action" setting. This setting is in the Playback section of Preferences.

ACTIVE ELEMENTS

random album" * button in Playback, perform the action specified for the "One touch action" setting. This setting is in the Library section of Preferences.

Time knob

settings to be changed.

Volume knob

clicking on the numeric volume level toggles the mute state. clicking ahead on the

Song title

Genres column.

Close