### GENERAL

There are four main sections to moOde: Playback, Library, CoverView and Configuration.

Switching between Playback and the Library is accomplished by clicking on the cover art in Playback or on any open area of the Playbar in the Library.

## PLAYBACK

The Playback screen includes the play queue (Queue), volume and time knobs, playback controls, cover art and metadata.

LIBRARY

#### content and a Playbar for displaying song information and controlling playback. Options for configuring various aspects of the Library including sort order, recently added and more are located in the Library section of Preferences.

SEARCHING THE LIBRARY

The library provides Radio, Folder, Tag, Album and Playlist views for browsing and selecting

### Powerful search features are available that allow the Library to be filtered based on entered

text, tag value pairs or special, predefined filters. There is also an Advanced search dialog that enables multiple tag value pairs to be submitted. Tag and Album views

General

### Searches are not case sensitive and partial matches are the default unless one of the strict

comparison operators '==' or '!=' is used. The comparison operators '=~' or '!~' can also be used to perform searches based on PERL regular expressions. Searches are cleared by clicking on the "Filtered by" heading. NOTE: The "search" field only supports a single tag value pair or a single Predefined

 Tag value pairs The following tags are supported: Any, Genre, Artist, Album, Title, Album Artist, Date,

Composer, Conductor, Performer, Work, Comment and File. Examples: genre rock | artist frank sinatra | artist mccartney | any zeppelin

 The Any tag The Any tag performs a search of all tags using an OR relationship. An Any search is

### automatically invoked when the first word of text entered in the "search" field does not

match any of the tag or predefined filter names. Examples: yellow submarine | all that you can't leave behind | frank sinatra | 1962

The following predefined filters are available: Encoded [bits/rate | Nch | multichannel], Format [.ext], Folder [path], HDonly, Lossless, Lossy and Year [yyyy] or [yyyy-yyyy].

Examples: encoded 24/96 | encoded 192 | encoded 24 | encoded 6ch | encoded

#### multichannel | hdonly | format .dsf | folder u2/achtung baby | lossy | year 1962 | year 1994-1998

Saved searches

Searches can be saved and subsequently activated using the "Saved searches" item on the Library dropdown menu. Folder view

### General

### Searches are not case sensitive and partial matches are considered valid. Searches are

cleared by clicking on the Home icon. Search results talley Click the search tally to display a context menu containing Add, Play, Clear/Play.

## Radio and Playlist view

Searches are not case sensitive and a progressive Typedown search method is used on

## Click the Browse by header or the x icon in the "search" field to clear the search.

COVERVIEW The CoverView screen saver provides a large sized cover art image or optional Analog or

The Configuration screens are accessed via the Main Menu and provide settings for the Library, Audio, Network, System and Renderers.

populated primarily by selecting an item from the Library and then clicking one of the Queue commands listed on a context menu. It can also be populated automatically by Auto-shuffle. The Queue commands are listed below. Add | Play

The "Add" command adds the item to the end of the Queue. The "Play" command first

checks to see if the item is already in the Queue and then plays the existing item

otherwise it does the same as Add and then begins play.

### Clear/Play

The "Clear/Play" command first clears the Queue then adds the item and begins play.

## The "Add next" command adds the item immediately after the currently playing or last

played item. The "Play next" command first checks to see if the item is already in the Queue and then plays the existing item otherwise it does the same as "Add next" then begins play.

Add next | Play next

 For the track list in Library Tag and Album views the Play and Clear/Play actions can be configured via a Preferences option to either add the selected track to the Queue or the selected track and all following tracks. PLAYLISTS

Creating, editing and managing playlists is done primarily in Library Playlist view. Playlists can also be created via context menu items "Save Queue to playlist", "Set Favorites name" and "Add to playlist".

### The "Save Queue to playlist" command displays a list of available playlists and adds the item to the end of the selected playlist or a new playlist if one is specified.

Save Queue to playlist

 Set Favorites name The "Set Favorites name" command displays an input form for specifying the name of the playlist that contains items favorited by clicking the Heart  $\heartsuit$  button. If the playlist does

the end of the selected playlist or a new playlist if one is specified. MULTIROOM AUDIO A moOde multiroom audio system consists of a Sender and Receivers. The Sender should be

a dedicated moOde player configured to output to the integrated HDMI port or optically the

Headphone jack but not connected to any speakers or headphones. It functions solely as a

### Music Server that Sends its audio output to one or more Receivers. For additional information View multiroom setup guide

Menu/Configure or in the ALSA section of Audio Config. Audio sources including MPD, AirPlay and Spotify can be distributed by the Sender. Master volume The volume knob on the Sender system provides master volume control by sending the

volume change to the Receivers which apply it to their own volume. Receivers can be

 Networking The performance of the system depends on having low latency, high throughput networking and hosts. Discovery of Receivers relies on Multicast DNS. Addressing for the audio distribution protocol relies on IP Multicast using a default address of 239.0.0.1.

# SPECIAL MENU ITEMS

next to its name.

▶ Players This item is located on the Main menu. It displays a list of other moOde players discovered on the network. Submit an action to apply to all the players listed or click an

confirmation. If a player is functioning as a Multiroom Receiver the 🔊 icon will appear

This item is located on the Main menu and ellipsis context menus on Playback and

Playbar. If its opened from the Main menu it displays hardware related information about the item currently being played and is divided into three sections including Input/Output,

individual player to open it. The Submit button will request a second click for

# DSP and Audio Device. If its opened from the ellipsis context menu it displays metadata

್ಡ Audio info

Most buttons are self explanatory but several perform unique functions. □ CamillaDSP Quick Select Display a menu of available CamillaDSP configurations. This button appears at the top of Playback view when CamillaDSP is On.

Display full screen CoverView screen saver. clicking anywhere off of the Playbar dismisses

Play randomly selected tracks from the Queue (default) or if Auto-shuffle is ON (see

Audio Config) play randomly selected tracks or albums from the entire Music Library.

# automatically enabled when Auto-shuffle is ON.

C Single Used in conjunction with Repeat to repeat a single track.

Add the currently selected item in the Queue to the Favorites playlist. Playlists are listed in Library Playlist view.

There are several non-button elements in the UI that perform an action when tapped.

When clicking a cover in Library Radio or Album view, or clicking the "Play a random

Toggle between the currently playing item and the last played item.

Select a random Album for review when in Tag or Album view.

#### album" \* button in Playback, perform the action specified for the "One touch action" setting. This setting is in the Library section of Preferences. Renderer Active screens

launch their respective Configuration screens which allow the input/output settings to be changed.

## or down. clicking or dragging the time ring moves forward or backward in the song. Volume knob

Time knob

step limit. This limit can be set via Audio Config. clicking the plus/minus buttons adjusts volume by 1 step. Extra metadata In Playback clicking the extra metadata under the cover art opens the Station or Track tab

clicking on the time while a song file is playing will toggle between counting the time up

#### In Playback clicking the song title under the cover art launches a search in a separate Browser tab. The search engine used can be selected in the Playback section of Preferences.

On Smartphones it scrolls the Queue to that item.

 Swipe gestures On Smartphones swiping up scrolls the Queue into view and clicking on the Playbar returns to Playback. In Library tag view swiping sideways shows/hides the Genres

# filter.

Predefined filters

# General

the displayed items.

Clearing the search

Digital clock, a Playbar for controlling playback and several backdrop options that can be selected in the CoverView section of Preferences. CONFIGURATION

QUEUE The Queue is displayed in Playback and CoverView and contains all items to be played. It's

not already exist it will be created. Add to playlist The "Add to playlist" command displays a list of available playlists and adds the item to

 Configuration Sender and Receiver options are configured in Multiroom Config which is accessed via

configured to opt in or out of Master volume control via Multiroom Config. Receiver control Receivers can be centrally controlled from the Sender system via the Receivers panel which is accessed by the a button at the top of Playback view.

The system uses 16 bit 48 kHz PCM format encoded using the Opus CODEC. Resampling if needed is handled by ALSA using the Speex converter. Most menu items are self explanatory but several perform unique functions.

Audio format

information about the station or track currently being played. SPECIAL BUTTONS

CoverView

✓ Random

CoverView.

Remove the track from the Queue after it finishes playing. Consume mode is Repeat Repeat the Queue or if Single is enabled then repeat the track.

★ Play a random album Randomly select an album from the Music Library and perform the action specified for the "One touch action" setting. This setting is in the Playback section of Preferences. 

ACTIVE ELEMENTS

One touch action

Select random album

clicking on the title in the center of Bluetooth, Analog Input or S/PDIF Input Active will

clicking on the numeric volume level toggles the mute state. clicking ahead on the volume ring advances the volume by a maximum number of steps called the Volume

on the Audio info screen.

Song title

column.

 Station or Artist name In Playback clicking the Radio station name or the Artist name under the cover art switches to Radio or Tag view respectively. In Tag view the artist filter is applied. In Radio view the list is scrolled to the station.