

Project: Date:

Revision: Generator Description:

Input Summary

Equipment	Load Type	LRA	sc	FLC	Start Time (s)	
Geo system Vara 2 Plus	DOL	118	0	37.8	9	

Load Calculation

Equipment	T1	T2	Т3	T4	T5	T6	T7	T8	Т9	T10	T11	T12	T13	T14	T15
Geo system Vara 2 Plus	0	0	0	0	0	0	0	0	118	118	118	118	118	118	118
Total Load (A)	0	0	0	0	0	0	0	0	118	118	118	118	118	118	118
Total kVA	0	0	0	0	0	0	0	0	81.75	81.75	81.75	81.75	81.75	81.75	81.75

Equipment	T16	T17	T18	T19	T20	T21	T22	T23	T24	T25	T26	T27	T28	T29	T30
Geo system Vara 2 Plus	118	118	37.8	37.8	37.8	37.8	37.8	37.8	37.8	37.8	37.8	37.8	37.8	37.8	37.8
Total Load (A)	118	118	37.8	37.8	37.8	37.8	37.8	37.8	37.8	37.8	37.8	37.8	37.8	37.8	37.8
Total kVA	81.75	81.75	26.19	26.19	26.19	26.19	26.19	26.19	26.19	26.19	26.19	26.19	26.19	26.19	26.19

DISCLAIMER

This generator sizing tool is provided for informational purposes only. The calculations and recommendations produced by this tool are based on the data entered by the user and do not replace professional engineering judgment.

No Warranty or Guarantee: The results generated by this tool are estimates and do not guarantee compliance with local, state, or national electrical or safety codes. It is the responsibility of the user to verify all calculations and ensure compliance with applicable regulations and industry standards.

Limitation of Liability: The provider of this tool assumes no liability for damages, losses, or risks arising from its use. Users should consult a licensed electrical engineer or relevant authority before making any purchasing or installation decisions.

Code Compliance: Local codes, manufacturer specifications, and site conditions can significantly impact generator sizing. This tool does not account for all potential variables. Always confirm sizing requirements with a qualified professional before proceeding with installation.

powered by PROJECT DESIGN (IO)