LTSPICE2MATLAB

Table of Contents

| Calling Convention: | -1 |
|---------------------|----|
| Inputs: | 1 |
| Outputs: | |
| Examples | |

function raw_data = LTspice2Matlab(filename, varargin)

LTSPICE2MATLAB -- Reads an LTspice IV (21/03/19 Modified to work withLTspice XVII) .RAW waveform file containing data from a Transient Analysis (.tran) or AC Analysis (.ac) simulation, and converts voltages and currents vs. time into Matlab variables. This function can read compressed binary, uncompressed binary, and ASCII file formats. It does not currently support files saved in the Fast Access Format. In the case of compressed binary, the data is automatically uncompressed using fast quadratic point insertion.

LTspice IV is an excellent Spice III simulator & schematic capture tool freely avaliable for download at www.linear.com/designtools/software. It is optimized for simulation of switching regulators, but an simulate many other types of circuits as well and comes with a wide variety of component models. Note that the LTspice uses a lossy compression format (enabled by default) with user adjustable error bounds.

Use LTSPICE2MATLAB to import LTspice waveforms into Matlab for additional analysis or to compare with measured data.

This function has been tested with LTspice IV version 4.01p, and Matlab versions 6.1 and 7.5. Regression testing has been used to expose the function to a wide range of LTspice settings. Author: Paul Wagner 4/25/2009

Calling Convention:

RAW_DATA = LTSPICE2MATLAB(FILENAME); %Returns all variables found in FILENAME

(or)

RAW_DATA = LTSPICE2MATLAB(FILENAME, SELECTED_VARS); %Returns only those variables covered by SELECTED_VARS Set SELECTED_VARS to [] to quickly determine the number and names of variables present in FILENAME without actually loading the variables.

(or)

RAW_DATA = LTSPICE2MATLAB(FILENAME, SELECTED_VARS, N); Returns variables listed in SELECTED_VARS, with all waveforms downsampled by N. Set N>1 to load very large data files using less memory, at the price of degraded waveform accuracy and possible aliasing.

Inputs:

FILENAME is a string containing the name and path of the LTspiceIV .raw file to be converted.

SELECTED_VARS (optional) is a vector of indexes indicating which variables to extract from the .raw file. For example, if a .raw file has 14 variables and SELECTED_VARS is [1 8 9], then the output RAW_DATA.VARIABLE_MAT will be a 3 x NUM_DATA_PNTS matrix containing waveforms for variables 1, 8, and 9 only. Note that SELECTED_VARS does not cover the time (or frequency) variable (index 0), which is returned separately in RAW_DATA.TIME_VECT (or RAW_DATA.FREQ_VECT). Extracting only of subset of variables is a way to use less memory when loading very large simulation files.

If this parameter is not specified, then all variables are returned by default. Setting SELECTED_VARS to 'all' will also cause all variables to be returned.

• To quickly determine the number and names of variables present in a .raw file, call LTspice2Matlab with SELECTED_VARS set to []. In this case, all fields in RAW_DATA will be populated, except .TIME_VECT (or .FREQ_VECT) and .VARIABLE_MAT, which will both be empty ([]). Since only the header is read, the function call should execute very quickly, even for large files.

N (optional) must be a positive integer >= 1. If N is specified, then SELECTED_VARS must also be specified. If N is unspecified, it defaults to 1, which does not change the sampling rate. If this value is 2 or larger, the returned voltage, current, and time data will be downsampled by keeping every N-th sample in the original data, starting with the first. Caution: No lowpass filtering is applied prior to downsampling, so aliasing may occur. Also, in many cases LTspice saves data with a non-constant sampling rate, in which case downsampling can result in substantial waveform distortion. This option should only be used if the waveform of interest is initially oversampled.

Outputs:

RAW_DATA is a Matlab structure containing the following fields ...

title: String containing the title appearing in the .RAW file header.

date: String containing the date appearing in the .RAW file header.

plotname: String indicating simulation type ('Transient Analysis', 'AC Analysis')

conversion_notes: Description of modifications (if any) done to the data during conversion.

num_variables: Number of variables (does not include the "time" or "frequency" variable)

variable_type_list: A cell of strings indicating the variable type (i.e. voltage, current etc.)

variable_name_list: A cell of strings indicating the name of each variable.

selected_vars: A vector of indicies referencing VARIABLE_TYPE_LIST cells, corresponding to each row in VARIABLE_MAT.

num data pnts: Number of data points for each variable.

variable_mat: Double precision matrix with NUM_VARIABLES rows and NUM_DATA_PNTS columns. This matrix contains node voltages (in Volts) and device currents (in Amps) for each variable and each time point listed in TIME_VECT (or FREQ_VECT). For AC Analysis simulations, VARIABLE_MAT will have complex values showing the real and imaginary components of the voltage or current at the corresponding frequency. To convert this to log magnitude and normalized phase representation used in LTspice plots, use the following formulas: Log_Magnitude_dB = 20*log10(abs(variable_mat)) Norm_Phase_degrees = angle(variable_mat)*180/pi

time_vect: [Field returned for Transient Analysis only] Double precision row vector of time values (in seconds) at each simulation point

(or)

freq_vect: [Field returned for AC Analysis only] Double precision row vector of frequency values (in Hz) at each simulation point

Currently this function is able to import results from Transient Analysis (.tran) and AC Analysis (.ac) simulations only.

Examples

These examples assume you've run a .TRAN simulation in LTspice for a hypothetical file called BASIC_CIRCUIT.ASC, and that an output file called BASIC_CIRCUIT.RAW has been created. It also assumes your current Matlab directory is pointing to the directory where the .RAW file is located (or that you prepended the full path to the input parameter FILENAME).

To import BASIC_CIRCUIT.RAW into Matlab and create a labeled plot of a single variable vs. time:

```
raw_data = LTspice2Matlab('BASIC_CIRCUIT.RAW');
variable_to_plot = 1; %This example plots the first variable in the
plot(raw_data.time_vect, raw_data.variable_mat(variable_to_plot,:), '
title(sprintf('Waveform %s', raw_data.variable_name_list{variable_to_
ylabel(raw_data.variable_type_list{variable_to_plot}} );
xlabel('Time (sec)' );
```

To superimpose all variables in BASIC_CIRCUIT.RAW on a single graph with a legend:

```
raw_data = LTspice2Matlab('BASIC_CIRCUIT.RAW');
plot(raw_data.time_vect, raw_data.variable_mat);
title(sprintf( 'File: %s', raw_data.title));
legend(raw_data.variable_name_list);
ylabel('Voltage (V) or Current (A)');
xlabel('Time (sec)');
```

To quickly determine the number and names of variables in BASIC_CIRCUIT.RAW without loading the entire file:

raw_data = LTspice2Matlab('BASIC_CIRCUIT.RAW', []);

```
disp(sprintf( '\n\nThis file contains %.0f variables:\n', raw_data.nu
                                       TYPE\n-----'));
            disp(sprintf('NAME
            disp([char(raw_data.variable_name_list), char(zeros(raw_data.num_vari
%%Code
function raw_data = LTspice2Matlab( filename, varargin )
   raw_data = []; %Initialize the output structure.
   if nargin==0,
       error( 'LTspice2Matlab takes 1, 2, or 3 input parameters.
Type "help LTspice2Matlab" for details' );
   elseif nargin==1,
       selected_vars = 'all';
       downsamp_N = 1;
   elseif nargin==2,
       selected_vars = varargin{1};
       if ischar(selected_vars), selected_vars =
lower(selected_vars); end
       downsamp_N = 1;
   elseif nargin==3,
       selected_vars = varargin{1};
       if ischar(selected_vars), selected_vars =
lower(selected_vars); end
       downsamp_N = varargin{2};
   else
```

```
error( 'LTspice2Matlab takes only 1, 2, or 3 input parameters.
Type "help LTspice2Matlab" for details' );
   end
   if length(downsamp_N)~=1 | ~isnumeric(downsamp_N) |
isnan(downsamp_N) | mod(downsamp_N,1)~=0.0 | downsamp_N<=0,
      error( 'Optional parameter DOWNSAMP N must be a positive
integer >= 1' );
   end
   leading and trailing spaces from filename.
%fid = fopen(filename, 'rb'); %ltspiceiv
fid = fopen(filename, 'rb', 'n', 'UTF16LE');
   if length(fid)==1 & isnumeric(fid) & fid==-1,
      %try to append ".raw" to the file name ...
      %fid = fopen(sprintf( '%s.raw', filename ), 'rb'); %ltspice iv
fid = fopen(sprintf( '%s.raw', filename ), 'rb', 'n', 'UTF16LE');
      if length(fid)==1 & isnumeric(fid) & fid==-1,
          error( sprintf( 'Could not open file "%s"', filename ) );
      end
   end
[filename, the_permission, machineformat] = fopen(fid);
   %Load header tags & information
  variable_name_list = {}; variable_type_list = {}; %These
include voltages and currents only. Does not include the time
vector.
  variable_flag = 0;
  file_format = '';
  while 1,
      the line = fgetl(fid);
      if length(the_line) == 1 & isnumeric(the_line) &
double(the line) == -1,
          try fclose( fid ); catch end
          error( sprintf( 'Format error in LTspice file "%s" ... End
of file unexpectedly encountered', filename ));
      the_line = char(the_line);
      if length(strfind( the_line, 'Binary:' ))~=0, file_format
= 'binary'; break; end
      if length(strfind( the_line, 'Values:' ))~=0, file_format
= 'ascii'; break; end
      if variable flag==0, %Non-variable header section
          if length(the_line)==0, colon_index = [];
          else, colon index = find( the line == ':' ); end
          if length(colon_index)==0,
              try fclose( fid ); catch end
```

```
error( sprintf( 'Format error in LTspice file "%s"',
filename ));
           end
           var name = the line(1:(colon index(1)-1));
           var_value =
fliplr(deblank(fliplr(deblank(the line((colon index(1)+1):end))));
           vn_keep_index = find( var_name~=' ' & var_name~='.' &
var name~=char(9) & var name~=char(10) & var name~=char(13) );
           var_name = lower(var_name(vn_keep_index));
           if length(var_name) == 0 | (var_name(1) >= '0' &
var_name(1)<='9'),</pre>
               try fclose( fid ); catch end
               error( sprintf('Format error in LTspice file "%s" ...
Bad tag name found', filename ));
           end
           if strcmpi( var_name, 'variables' )
strcmpi( var_name, 'variable' ), variable_flag = 1; continue; end
           value_try = str2num(var_value);
               if length(value try)==0, raw data =
setfield( raw_data, var_name, var_value );
               else raw_data = setfield( raw_data, var_name,
value_try ); end
           catch
               try fclose( fid ); catch end
               error( sprintf('Format error in LTspice file "%s" ...
Bad tag name found', filename ));
           end
       else %Variable header section
           leading ch index = find( (the line(1:end-1)=='
the_line(1:end-1)==char(9)) & (the_line(2:end)~=' ' &
the_line(2:end)~=char(9)) );
           if length(leading_ch_index)~=3,
               try fclose( fid ); catch end
               error( sprintf('Format error in LTspice file "%s" ...
Wrong number of columns in the variable define section', filename ));
           end
           part1 =
fliplr(deblank(fliplr(deblank(the line( (leading ch index(1)+1) :
leading_ch_index(2) ))));
           part2 =
fliplr(deblank(fliplr(deblank(the_line( (leading_ch_index(2)+1) :
leading_ch_index(3) ))));
           part3 =
fliplr(deblank(fliplr(deblank(the_line( (leading_ch_index(3)+1) :
end )))));
           if str2num(part1)~=length(variable name list),
               try fclose( fid ); catch end
               error( sprintf('Format error in LTspice file "%s" ...
Inconsistency found in the variable define section', filename ));
           end
```

```
variable_name_list{end+1} = part2;
           variable type list{end+1} = part3;
       end
   end
   %Check raw data structure for required fields
   expected_tags
{'title', 'date', 'plotname', 'flags', 'novariables', 'nopoints'
 };
   expected_tags_full = {'Title', 'Date', 'Plotname', 'Flags', 'No.
Variables', 'No. Points' };
   for q=1:length(expected_tags),
       if ~isfield( raw data, lower(expected tags{q}) ),
           try fclose( fid ); catch end
           error( sprintf('Format error in LTspice file "%s" ... tag
"%s" not found', filename, expected_tags_full{q} ));
       end
   end
  raw data.conversion notes = '';
  raw_data.num_data_pnts = raw_data.nopoints; raw_data =
rmfield( raw_data, 'nopoints' );
  raw_data.num_variables = raw_data.novariables-1; raw_data =
rmfield( raw data, 'novariables' );
   %"raw_data.num_variables" does not include the time vector (index
0 in the .raw file)
   if isfield( raw_data, 'command' ), raw_data =
rmfield( raw_data, 'command' ); end
   if isfield( raw_data, 'backannotation' ), raw_data =
rmfield( raw data, 'backannotation' ); end
   if isfield( raw data, 'offset' ),
       general_offset = raw_data.offset; %(sec)
      raw_data = rmfield( raw_data, 'offset' );
   else
      general offset = 0.0;
   end
   raw_data.variable_name_list = {variable_name_list{2:end}};
 %cut off the time variable.
  raw_data.variable_type_list = {variable_type_list{2:end}};
   simulation_type = '';
         length(strfind( lower(raw_data.plotname), 'transient
analysis'))~=0,
                          simulation_type = '.tran'; %SUPPORTED
   elseif length(strfind( lower(raw_data.plotname), 'ac analysis'
                       simulation_type = '.ac';
                                                   %SUPPORTED
   elseif length(strfind( lower(raw_data.plotname), 'dc transfer
characteristic'))~=0,
                        simulation_type = '.dc';
                                                   %This is a DC
sweep (Not supported)
   elseif length(strfind( lower(raw_data.plotname), 'operating point'
                   operating point (Not supported)
   end
```

```
if length(simulation type) == 0 |
~(strcmpi(simulation_type, '.tran') |
strcmpi(simulation type, '.ac')),
       try fclose( fid ); catch end
       error( 'Currently LTspice2Matlab is only able to import
results from Transient Analysis (.tran) and AC Analysis (.ac)
simulations.');
   end
   if length(strfind( lower(raw_data.flags), 'fastaccess' ))~=0,
       try fclose( fid ); catch end
       error( 'LTspice2Matlab cannot convert files saved in the "Fast
Access format. ');
   end
   if strcmpi(simulation type, '.tran') &
length(strfind( lower(raw_data.flags), 'real' ))==0,
       try fclose( fid ); catch end
       error( 'Expected to find "real" flag for a Transient Analysis
(.tran) simulation. Unsure how to convert the data');
   end
   if strcmpi(simulation_type, '.tran') &
length(strfind( lower(raw_data.flags), 'forward' ))==0,
       try fclose( fid ); catch end
       error( 'Expected to find "forward" flag for a Transient
Analysis (.tran) simulation. Unsure how to convert the data' );
   end
   if strcmpi(simulation type, '.ac') &
length(strfind( lower(raw_data.flags), 'complex' ))==0,
       try fclose( fid ); catch end
       error( 'Expected to find "complex" flag for an AC Analysis
(.ac) simulation. Unsure how to convert the data');
   end
   if strcmpi(simulation_type, '.ac') &
length(strfind( lower(raw data.flags), 'forward' ))==0,
       try fclose( fid ); catch end
       error( 'Expected to find "forward" flag for an AC Analysis
(.ac) simulation. Unsure how to convert the data');
   end
   if isfield( raw_data, 'flags' ), raw_data =
rmfield( raw data, 'flags' ); end
   if ischar(selected vars),
       if strcmpi(selected_vars, 'all')
| strcmpi(selected_vars, 'everything') |
strcmpi(selected vars, 'complete') | strcmpi(selected vars, 'all
variables') | ...
               strcmpi(selected vars, 'all
vars') | strcmpi(selected_vars, 'every thing') |
strcmpi(selected_vars, 'every'),
          selected_vars = 1:raw_data.num_variables; %Return all
variables
       else
           try fclose( fid ); catch end
```

```
error( 'Bad value for optional input parameter
SELECTED VARS');
      end
  end
   if size(selected_vars,1)==0 | size(selected_vars,2)==0,
      raw data.selected vars = [];
      raw data.variable mat = [];
      raw data.time vect = [];
      try fclose( fid ); catch end
      return;
   end
   if size(selected_vars,1)>1 & size(selected_vars,2)>1,
      try fclose( fid ); catch end
      error( 'SELECTED_VARS must be a row or column vector, not a
matrix' );
  end
  if length(find(selected vars==0))~=0,
      try fclose( fid ); catch end
      error( 'The time vector (index 0) is returned separately. \n
Values in input parameter SELECTED_VARS must be positive integers >=
1 and <= NUM_VARIABLES' );</pre>
  non integer index = find(isnan(selected vars) |
~isnumeric(selected vars) | mod( selected vars, 1 )~=0.0);
   if length(non_integer_index)~=0,
      try fclose( fid ); catch end
      error( 'Values in input parameter SELECTED_VARS must be
positive integers >= 1 and <= NUM VARIABLES' );
  missing_index = find( ~ismember( selected_vars,
1:raw_data.num_variables ) );
   if length(missing_index)~=0,
      try fclose( fid ); catch end
      error( 'Error in input parameter SELECTED_VARS ... Out of
range value(s) found' );
  end
  sort in ascending order.
  raw_data.selected_vars = selected_vars;
  NumPnts = raw_data.num_data_pnts;
  NumPnts_DS = floor(NumPnts/downsamp_N);
  raw data.num data pnts = NumPnts DS;
                                     %Updated # of points
  NumVars = raw_data.num_variables+1;
   %READ IN THE ACTUAL WAVEFORM DATA
   if strcmpi(file_format, 'binary'),
      if strcmpi( simulation_type, '.tran' ),
```

```
% For Transient Analysis simulations, the time data is
stored in double precision floating point binary format,
          % and everything else is stored in single precision
format.
           %Extract the binary data in the fewest possible number of
contiquous blocks
           if length(selected_vars)>1,
              g border = find( [2, diff(selected vars), 2]~=1 );
              block list = {};
              for k=1:length(g_border)-1, block_list{k} =
g_border(k):(g_border(k+1)-1); end
          else
              block list = {1:length(selected vars)};
           end
          raw data.variable mat = zeros(length(selected vars),
NumPnts_DS); %Initialize.
           for k=1:length(block_list),
              target_var_index = selected_vars(block_list{k});
              fseek(fid, binary start +
(target_var_index(1)+1)*4, 'bof');
              TVIL = length(target_var_index);
              bytes_skip = (NumVars+1-TVIL)*4 +
(downsamp_N-1) * (NumVars+1) * 4;
              precision str = sprintf('%.0f*float',TVIL);
              raw_data.variable_mat(block_list{k},:) =
reshape( fread(fid, NumPnts DS*TVIL, precision str, bytes skip,
machineformat), TVIL, NumPnts_DS );
           end
           extract the time vector.
          raw_data.time_vect = fread( fid, NumPnts_DS, 'double',
(NumVars-1)*4 + (downsamp_N-1)*(NumVars+1)*4, machineformat ).';
          if downsamp_N==1, raw_data.conversion_notes = 'Converted'
from Binary format';
          else raw data.conversion notes = sprintf( 'Converted from
Binary format. Downsampled from %.0f to %.0f points', NumPnts,
NumPnts DS ); end
       elseif strcmpi( simulation_type, '.ac' ),
          % For AC Analysis simulations, the frequency data is
stored in double precision floating point binary format (8 bytes),
          % and the variables are stored as complex double precision
arrays (8 bytes real followed by 8 bytes imag)
          %Extract the binary data in the fewest possible number of
contiquous blocks
          if length(selected_vars)>1,
              g_border = find( [2, diff(selected_vars), 2]~=1 );
              block_list = {};
              for k=1:length(g_border)-1, block_list{k} =
g_border(k):(g_border(k+1)-1); end
              block_list = {1:length(selected_vars)};
           end
```

```
raw_data.variable_mat = zeros(length(selected_vars),
NumPnts_DS); %Initialize.
            if prod(size(raw_data.variable_mat))~=0,
raw data.variable mat(1,1) = 0.0 + j*0.0; end %Allocate memory for
 complex double.
            for k=1:length(block list),
                target_var_index = selected_vars(block_list{k});
                fseek(fid, binary_start +
 target_var_index(1)*16, 'bof');
               TVIL = length(target_var_index);
               bytes_skip = (NumVars-TVIL)*16 +
 (downsamp_N-1)*NumVars*16;
               precision str = sprintf('%.0f*double',TVIL*2);
                temp_buff = reshape(fread(fid, NumPnts_DS*TVIL*2,
precision str, bytes skip, machineformat), TVIL*2, NumPnts DS );
                raw_data.variable_mat(block_list{k},:) =
 temp_buff(1:2:end-1,:) + j*temp_buff(2:2:end,:);
                clear temp_buff;
            end
            fseek(fid, binary_start, 'bof');
                                               %rewind to start, then
 extract the time vector.
           raw_data.freq_vect = fread( fid, NumPnts_DS, 'double',
 (NumVars-1)*16 + 8 + (downsamp_N-1)*NumVars*16, machineformat ).';
       else
            try fclose( fid ); catch end
            error( sprintf('Simulation type (%s) not currently
 supported', simulation_type ));
       end
    elseif strcmpi(file format, 'ascii' ),
       if strcmpi( simulation_type, '.tran' ),
            %Format: point number, time value, var1, var2, var3 ...
varN
           raw data.variable mat = fscanf( fid, '%g',
 [raw_data.num_variables+2, raw_data.num_data_pnts] );
                                                         %matrix is
 filled in column order.
            if (size(raw_data.variable_mat,1)~=raw_data.num_variables
+2) | (size(raw data.variable mat,2)~=raw data.num data pnts),
                error( sprintf('Format error in ASCII Transient
Analysis LTspice file "%s" ... Incorrect number of data values read',
filename ));
            end
            raw data.time vect =
raw_data.variable_mat(2,1:downsamp_N:end);
           raw data.variable mat =
raw_data.variable_mat(2+selected_vars,1:downsamp_N:end);
       elseif strcmpi( simulation_type, '.ac' ),
            %Format: point number, freq value, 0, var1 real, var1
 imag, var2 real, var2 imag, var3 real, var3 imag ... varN real, varN
 imaq
```

```
all_data = fread( fid, inf, 'uchar' );
          all_data( find( all_data == ',' ) ) = sprintf( '\t' );
 %Replace commas with tab characters
          raw data.variable mat = sscanf( char(all data), '%g',
[3+2*raw_data.num_variables, raw_data.num_data_pnts]);
          clear all data;
          %raw_data.variable_mat = fscanf( fid, '%g',
[3+2*raw data.num variables, raw data.num data pnts]);
                                                      %matrix is
filled in column order.
          i f
(size(raw_data.variable_mat,1)~=(3+2*raw_data.num_variables)) |
(size(raw data.variable mat,2)~=raw data.num data pnts),
              error( sprintf('Format error in ASCII AC Analysis
LTspice file "%s" ... Incorrect number of data values read',
filename ));
          raw_data.freq_vect =
raw data.variable mat(2,1:downsamp N:end);
          raw_data.variable_mat =
raw_data.variable_mat(3+selected_vars*2-1,1:downsamp_N:end) +
j*raw_data.variable_mat(3+selected_vars*2,1:downsamp_N:end);
      else
          try fclose( fid ); catch end
          error( sprintf('Simulation type (%s) not currently
supported', simulation_type ));
      end
      if downsamp N==1, raw data.conversion notes = 'Converted from
ASCII format';
      else raw_data.conversion_notes = sprintf( 'Converted from
ASCII format. Downsampled from %.0f to %.0f points', NumPnts,
NumPnts_DS ); end
   else
      try fclose( fid ); catch end
      error( sprintf('Format error in LTspice file "%s" ... Data
type ID tag not found', filename ));
   try fclose( fid ); catch end
   %Deal with potential compression in Transient Analysis simulations
   if strcmpi( simulation_type, '.tran' ) &
vector is monotonically increasing.
       if downsamp_N~=1, %If we have already downsampled then we
can't uncompress.
          raw_data.time_vect = abs(raw_data.time_vect);
      else
```

```
The binary file contains 2nd order compression ...
use 2nd-order interpolation to add data points in the vicinity of
negative time points
           t vect = raw data.time vect; %We will add in the offset
 later.
           neg_pnt_index = find( t_vect < 0.0 &</pre>
 [0,ones(1,length(t_vect)-1)] );
            t vect = abs(t vect);
           x1 = t_vect(neg_pnt_index-1); x2 = t_vect(neg_pnt_index);
 x3 = t_vect(neg_pnt_index+1);
            x_new = [(2*x1 + x2)/3; (x1 + 2*x2)/3; (2*x2 + x3)/3;
 (x2 + 2*x3)/3;
                  %New sample points
            t vect big = NaN*zeros(6,length(t vect));
            t_vect_big(1,:) = t_vect;
            t vect big(4,neg pnt index) = t vect(neg pnt index);
            t_vect_big(1,neg_pnt_index) = NaN;
            t_vect_big([2 3 5 6],neg_pnt_index) = x_new;
           full_index = find(~isnan(t_vect_big));
           time vect new = t vect big(full index).'; %This is the
new time vector with the inserted points.
           t_{vect_big([1,4],:)} = NaN;
           nan_vect = isnan(t_vect_big(full_index));
           new_index = find( ~nan_vect ); %Index into time_vect_new
 indicating the new points only.
           old_index = find( nan_vect );
           clear t vect t vect big full index nan vect;
           x1sqr = repmat(x1.^2, [4,1]); x2sqr = repmat(x2.^2,
 [4,1] ); x3sqr = repmat(x3.^2, [4,1]);
           x1 = repmat(x1, [4,1]); x2 = repmat(x2, [4,1]); x3 =
repmat( x3, [4,1] );
           denom = (x1sqr-x2sqr).*(x2-x3) - (x2sqr-x3sqr).*(x1-x2);
           r1 = (x_new.^2 - x1sqr)./denom;
           r2 = (x_new - x1)./denom;
           p1 = (x2-x3).*r1 - (x2sqr-x3sqr).*r2;
           p3 = (x1-x2).*r1 - (x1sqr-x2sqr).*r2;
           p2 = -p1 - p3;
           p1 = p1 + 1;
           clear x_new x1sqr x2sqr x3sqr x1 x2 x3 denom r1 r2;
           raw_data.variable_mat(:,end+1:length(time_vect_new)) =
 0.0;
       %Init the memory
            for k=1:size(raw_data.variable_mat,1),
               y_vect =
raw_data.variable_mat(k,1:length(raw_data.time_vect));
               raw_data.variable_mat(k,old_index) = y_vect;
               y_new = repmat(y_vect(neg_pnt_index-1),
[4,1]).*p1 + repmat(y vect(neg pnt index),[4,1]).*p2 +
repmat(y_vect(neg_pnt_index+1),[4,1]).*p3;
               raw_data.variable_mat(k,new_index) = y_new(:).';
            end
           raw_data.time_vect = time_vect_new;
 clear time_vect_new y_vect y_new new_index old_index neg_pnt_index p1 p2 p3;
```

Published with MATLAB® R2018b