## LTSPICE2MATLAB

#### **Table of Contents**

Calling Convention:	. 1
Inputs:	1
Outputs:	. 2
Examples	-

function raw\_data = LTspice2Matlab( filename, varargin )

21/03/19 Modified to work with LTspice XVII (fopen 'UTF16LE') This could be causing some data to corrupt and appear as NaN - This codification is no available Disabled warnings ecause of the non availability.

LTSPICE2MATLAB -- Reads an LTspice IV .RAW waveform file containing data from a Transient Analysis (.tran) or AC Analysis (.ac) simulation, and converts voltages and currents vs. time into Matlab variables. This function can read compressed binary, uncompressed binary, and ASCII file formats. It does not currently support files saved in the Fast Access Format. In the case of compressed binary, the data is automatically uncompressed using fast quadratic point insertion.

LTspice IV is an excellent Spice III simulator & schematic capture tool freely avaliable for download at www.linear.com/designtools/software. It is optimized for simulation of switching regulators, but an simulate many other types of circuits as well and comes with a wide variety of component models. Note that the LTspice uses a lossy compression format (enabled by default) with user adjustable error bounds.

Use LTSPICE2MATLAB to import LTspice waveforms into Matlab for additional analysis or to compare with measured data.

This function has been tested with LTspice IV version 4.01p, and Matlab versions 6.1 and 7.5. Regression testing has been used to expose the function to a wide range of LTspice settings. Original Author: Paul Wagner 4/25/2009 https://www.mathworks.com/matlabcentral/fileexchange/23394-fast-import-of-compressed-binary-raw-files-created-with-ltspice-circuit-simulator Modified by JCCopyrights Summer 2019

# **Calling Convention:**

RAW\_DATA = LTSPICE2MATLAB( FILENAME ); %Returns all variables found in FILENAME

(or)

RAW\_DATA = LTSPICE2MATLAB( FILENAME, SELECTED\_VARS ); %Returns only those variables covered by SELECTED\_VARS Set SELECTED\_VARS to [] to quickly determine the number and names of variables present in FILENAME without actually loading the variables.

(or)

RAW\_DATA = LTSPICE2MATLAB( FILENAME, SELECTED\_VARS, N ); Returns variables listed in SELECTED\_VARS, with all waveforms downsampled by N. Set N > 1 to load very large data files using less memory, at the price of degraded waveform accuracy and possible aliasing.

### Inputs:

FILENAME is a string containing the name and path of the LTspiceIV .raw file to be converted.

SELECTED\_VARS (optional) is a vector of indexes indicating which variables to extract from the .raw file. For example, if a .raw file has 14 variables and SELECTED\_VARS is [1 8 9], then the output RAW\_DATA.VARIABLE\_MAT will be a 3 x NUM\_DATA\_PNTS matrix containing waveforms for variables 1, 8, and 9 only. Note that SELECTED\_VARS does not cover the time (or frequency) variable (index 0), which is returned separately in RAW\_DATA.TIME\_VECT (or RAW\_DATA.FREQ\_VECT). Extracting only of subset of variables is a way to use less memory when loading very large simulation files.

If this parameter is not specified, then all variables are returned by default. Setting SELECTED\_VARS to 'all' will also cause all variables to be returned.

• To quickly determine the number and names of variables present in a .raw file, call LTspice2Matlab with SELECTED\_VARS set to []. In this case, all fields in RAW\_DATA will be populated, except .TIME\_VECT (or .FREQ\_VECT) and .VARIABLE\_MAT, which will both be empty ([]). Since only the header is read, the function call should execute very quickly, even for large files.

N (optional) must be a positive integer >= 1. If N is specified, then SELECTED\_VARS must also be specified. If N is unspecified, it defaults to 1, which does not change the sampling rate. If this value is 2 or larger, the returned voltage, current, and time data will be downsampled by keeping every N-th sample in the original data, starting with the first. Caution: No lowpass filtering is applied prior to downsampling, so aliasing may occur. Also, in many cases LTspice saves data with a non-constant sampling rate, in which case downsampling can result in substantial waveform distortion. This option should only be used if the waveform of interest is initially oversampled.

### **Outputs:**

RAW\_DATA is a Matlab structure containing the following fields ...

title: String containing the title appearing in the .RAW file header.

date: String containing the date appearing in the .RAW file header.

plotname: String indicating simulation type ('Transient Analysis', 'AC Analysis')

conversion\_notes: Description of modifications (if any) done to the data during conversion.

num\_variables: Number of variables (does not include the "time" or "frequency" variable)

variable\_type\_list: A cell of strings indicating the variable type (i.e. voltage, current etc.)

variable\_name\_list: A cell of strings indicating the name of each variable.

selected\_vars: A vector of indicies referencing VARIABLE\_TYPE\_LIST cells, corresponding to each row in VARIABLE\_MAT.

num\_data\_pnts: Number of data points for each variable.

variable\_mat: Double precision matrix with NUM\_VARIABLES rows and NUM\_DATA\_PNTS columns. This matrix contains node voltages (in Volts) and device currents (in Amps) for each variable and each time point listed in TIME\_VECT (or FREQ\_VECT). For AC Analysis simulations, VARIABLE\_MAT will have complex values showing the real and imaginary components of the voltage or current at the corresponding frequency. To convert this to log magnitude and normalized phase representation used in LTspice plots, use the following formulas: Log\_Magnitude\_dB = 20\*log10(abs(variable\_mat)) Norm\_Phase\_degrees = angle(variable\_mat)\*180/pi

time\_vect: [Field returned for Transient Analysis only] Double precision row vector of time values (in seconds) at each simulation point

(or)

freq\_vect: [Field returned for AC Analysis only] Double precision row vector of frequency values (in Hz) at each simulation point

Currently this function is able to import results from Transient Analysis (.tran) and AC Analysis (.ac) simulations only.

### **Examples**

These examples assume you've run a .TRAN simulation in LTspice for a hypothetical file called BASIC\_CIRCUIT.ASC, and that an output file called BASIC\_CIRCUIT.RAW has been created. It also assumes your current Matlab directory is pointing to the directory where the .RAW file is located (or that you prepended the full path to the input parameter FILENAME).

To import BASIC\_CIRCUIT.RAW into Matlab and create a labeled plot of a single variable vs. time:

To superimpose all variables in BASIC\_CIRCUIT.RAW on a single graph with a legend:

```
raw_data = LTspice2Matlab('BASIC_CIRCUIT.RAW');
plot(raw_data.time_vect, raw_data.variable_mat);
title(sprintf( 'File: %s', raw_data.title));
legend(raw_data.variable_name_list);
ylabel('Voltage (V) or Current (A)');
xlabel('Time (sec)');
```

To quickly determine the number and names of variables in BASIC\_CIRCUIT.RAW without loading the entire file:

error( 'LTspice2Matlab takes 1, 2, or 3 input parameters.

Type "help LTspice2Matlab" for details' );

selected\_vars = 'all';

if nargin==0,

elseif nargin==1,

```
downsamp_N = 1;
   elseif nargin==2,
      selected_vars = varargin{1};
       if ischar(selected_vars), selected_vars =
lower(selected_vars);
                      end
      downsamp N = 1;
   elseif nargin==3,
      selected vars = varargin{1};
       if ischar(selected_vars), selected_vars =
lower(selected_vars); end
      downsamp_N = varargin{2};
   else
      error( 'LTspice2Matlab takes only 1, 2, or 3 input parameters.
 Type "help LTspice2Matlab" for details' );
   if length(downsamp_N)~=1 | ~isnumeric(downsamp_N) |
isnan(downsamp N) | mod(downsamp N,1)~=0.0 | downsamp N<=0,
      error( 'Optional parameter DOWNSAMP_N must be a positive
integer >= 1' );
   end
   leading and trailing spaces from filename.
%fid = fopen(filename, 'rb'); %ltspiceiv
warning('off');
fid = fopen(filename, 'rb', 'n', 'UTF16LE');
warning('on') %Just to avoid the non sense warning
   if length(fid)==1 & isnumeric(fid) & fid==-1,
       %try to append ".raw" to the file name ...
      %fid = fopen(sprintf( '%s.raw', filename ), 'rb'); %ltspice iv
 warning('off');
 fid = fopen(sprintf( '%s.raw', filename ), 'rb', 'n', 'UTF16LE');
 warning('on') %Just to avoid the non sense warning
       if length(fid)==1 & isnumeric(fid) & fid==-1,
          error( sprintf( 'Could not open file "%s"', filename ) );
      end
   end
[filename, the_permission, machineformat] = fopen(fid);
   %Load header tags & information
   variable_name_list = {}; variable_type_list = {};
include voltages and currents only. Does not include the time
vector.
  variable flag = 0;
  file_format = '';
  while 1,
      the_line = fgetl(fid);
      if length(the_line)==1 & isnumeric(the_line) &
double(the line) == -1,
          try fclose( fid ); catch end
```

```
error( sprintf( 'Format error in LTspice file "%s" ... End
of file unexpectedly encountered', filename ));
       end
      the_line = char(the_line);
      if length(strfind( the_line, 'Binary:' ))~=0, file_format
= 'binary'; break; end
       if length(strfind( the_line, 'Values:' ))~=0, file_format
= 'ascii'; break; end
       if variable_flag==0, %Non-variable header section
          if length(the line)==0, colon index = [];
          else, colon_index = find( the_line == ':' ); end
          if length(colon index)==0,
              try fclose( fid ); catch end
              error( sprintf( 'Format error in LTspice file "%s"',
filename ));
          var_name = the_line(1:(colon_index(1)-1));
          var value =
fliplr(deblank(fliplr(deblank(the_line((colon_index(1)+1):end)))));
          vn_keep_index = find( var_name~=' ' & var_name~='.' &
var name~=char(9) & var name~=char(10) & var name~=char(13) );
          var_name = lower(var_name(vn_keep_index));
          if length(var name) == 0 | (var name(1) >= '0' &
var_name(1)<='9'),</pre>
              try fclose( fid ); catch end
              error( sprintf('Format error in LTspice file "%s" ...
Bad tag name found', filename ));
          end
          if strcmpi( var_name, 'variables' )
strcmpi( var_name, 'variable' ), variable_flag = 1; continue; end
          value_try = str2num(var_value);
          try
              if length(value_try)==0, raw_data =
setfield( raw data, var name, var value );
              else raw_data = setfield( raw_data, var_name,
value_try ); end
          catch
              try fclose( fid ); catch end
              error( sprintf('Format error in LTspice file "%s" ...
Bad tag name found', filename ));
          end
      else %Variable header section
          leading ch index = find( (the line(1:end-1)=='
the_line(2:end)~=char(9)) );
          if length(leading_ch_index)~=3,
              try fclose( fid ); catch end
              error( sprintf('Format error in LTspice file "%s" ...
Wrong number of columns in the variable define section', filename ));
          end
```

```
part1 =
fliplr(deblank(fliplr(deblank(the_line( (leading_ch_index(1)+1) :
leading ch index(2) ))));
           part2 =
fliplr(deblank(fliplr(deblank(the line( (leading ch index(2)+1) :
leading_ch_index(3) ))));
           part3 =
fliplr(deblank(fliplr(deblank(the line( (leading ch index(3)+1) :
end )))));
           if str2num(part1)~=length(variable_name_list),
               try fclose( fid ); catch end
               error( sprintf('Format error in LTspice file "%s" ...
Inconsistency found in the variable define section', filename ));
           end
           variable_name_list{end+1} = part2;
           variable_type_list{end+1} = part3;
       end
   end
   %Check raw_data structure for required fields
   expected_tags
{'title', 'date', 'plotname', 'flags', 'novariables',
                                                       'nopoints'
 };
   expected_tags_full = { 'Title', 'Date', 'Plotname', 'Flags', 'No.
Variables', 'No. Points' };
   for g=1:length(expected tags),
       if ~isfield( raw_data, lower(expected_tags{q}) ),
           try fclose( fid ); catch end
           error( sprintf('Format error in LTspice file "%s" ... tag
"%s" not found', filename, expected_tags_full{q} ));
       end
   end
   raw_data.conversion_notes = '';
   raw data.num data pnts = raw data.nopoints; raw data =
rmfield( raw_data, 'nopoints' );
   raw_data.num_variables = raw_data.novariables-1; raw_data =
rmfield( raw_data, 'novariables' );
   %"raw data.num variables" does not include the time vector (index
0 in the .raw file)
   if isfield( raw_data, 'command' ), raw_data =
rmfield( raw_data, 'command' ); end
   if isfield( raw_data, 'backannotation' ), raw_data =
rmfield( raw data, 'backannotation' ); end
   if isfield( raw_data, 'offset' ),
       general offset = raw data.offset; %(sec)
       raw_data = rmfield( raw_data, 'offset' );
       general_offset = 0.0;
   end
```

```
raw_data.variable_name_list = {variable_name_list{2:end}};
 %cut off the time variable.
  raw_data.variable_type_list = {variable_type_list{2:end}};
   simulation_type = '';
         length(strfind( lower(raw_data.plotname), 'transient
analysis'))~=0,
                          simulation_type = '.tran'; %SUPPORTED
   elseif length(strfind( lower(raw_data.plotname), 'ac analysis'
                       simulation type = '.ac';
                                                   %SUPPORTED
) )~=0,
   elseif length(strfind( lower(raw_data.plotname), 'dc transfer
characteristic' ))~=0, simulation_type = '.dc';
                                                   %This is a DC
sweep (Not supported)
   elseif length(strfind( lower(raw data.plotname), 'operating point'
                   operating point (Not supported)
   end
   if length(simulation_type)==0 |
~(strcmpi(simulation type, '.tran') |
strcmpi(simulation_type, '.ac')),
      try fclose( fid ); catch end
       error( 'Currently LTspice2Matlab is only able to import
results from Transient Analysis (.tran) and AC Analysis (.ac)
simulations.');
   end
   if length(strfind( lower(raw data.flags), 'fastaccess' ))~=0,
       try fclose( fid ); catch end
       error( 'LTspice2Matlab cannot convert files saved in the "Fast
Access format. ');
   end
   if strcmpi(simulation_type, '.tran') &
length(strfind( lower(raw_data.flags), 'real' ))==0,
      try fclose( fid ); catch end
       error( 'Expected to find "real" flag for a Transient Analysis
(.tran) simulation. Unsure how to convert the data');
   end
   if strcmpi(simulation type, '.tran') &
length(strfind( lower(raw_data.flags), 'forward' ))==0,
       try fclose( fid ); catch end
      error( 'Expected to find "forward" flag for a Transient
Analysis (.tran) simulation. Unsure how to convert the data' );
   end
   if strcmpi(simulation_type, '.ac') &
length(strfind( lower(raw_data.flags), 'complex' ))==0,
       try fclose( fid ); catch end
      error( 'Expected to find "complex" flag for an AC Analysis
(.ac) simulation. Unsure how to convert the data');
   end
   if strcmpi(simulation_type, '.ac') &
length(strfind( lower(raw_data.flags), 'forward' ))==0,
       try fclose( fid ); catch end
       error( 'Expected to find "forward" flag for an AC Analysis
(.ac) simulation. Unsure how to convert the data' );
```

```
end
   if isfield( raw data, 'flags' ), raw data =
rmfield( raw data, 'flags' ); end
   if ischar(selected_vars),
       if strcmpi(selected vars, 'all')
strcmpi(selected_vars, 'everything')
strcmpi(selected vars, 'complete') | strcmpi(selected vars, 'all
variables') | ...
              strcmpi(selected_vars, 'all
vars') | strcmpi(selected_vars, 'every thing') |
strcmpi(selected_vars, 'every'),
          variables
           try fclose( fid ); catch end
           error( 'Bad value for optional input parameter
SELECTED_VARS' );
      end
   end
   if size(selected_vars,1)==0 | size(selected_vars,2)==0,
      raw data.selected vars = [];
      raw_data.variable_mat = [];
      raw data.time vect = [];
      try fclose( fid ); catch end
      return;
   end
   if size(selected vars,1)>1 & size(selected vars,2)>1,
      try fclose( fid ); catch end
      error( 'SELECTED VARS must be a row or column vector, not a
matrix' );
  end
   if length(find(selected vars==0))~=0,
      try fclose( fid ); catch end
      error( 'The time vector (index 0) is returned separately. \n
Values in input parameter SELECTED_VARS must be positive integers >=
1 and <= NUM VARIABLES' );</pre>
   end
  non integer index = find(isnan(selected vars) |
~isnumeric(selected_vars) | mod( selected_vars, 1 )~=0.0);
   if length(non_integer_index)~=0,
      try fclose( fid ); catch end
      error( 'Values in input parameter SELECTED_VARS must be
positive integers >= 1 and <= NUM VARIABLES' );
  missing index = find( ~ismember( selected vars,
1:raw_data.num_variables ) );
   if length(missing_index)~=0,
      try fclose( fid ); catch end
      error ( 'Error in input parameter SELECTED VARS ... Out of
range value(s) found' );
   end
```

```
sort in ascending order.
  raw data.selected vars = selected vars;
  NumPnts = raw data.num data pnts;
  NumPnts_DS = floor(NumPnts/downsamp_N);
  raw data.num data pnts = NumPnts DS;
                                      %Updated # of points
  NumVars = raw data.num variables+1;
   %READ IN THE ACTUAL WAVEFORM DATA
  if strcmpi(file format, 'binary'),
      binary_start = ftell(fid); %start of binary data section.
      if strcmpi( simulation_type, '.tran' ),
          % For Transient Analysis simulations, the time data is
stored in double precision floating point binary format,
          % and everything else is stored in single precision
format.
          %Extract the binary data in the fewest possible number of
contiquous blocks
          if length(selected_vars)>1,
              g border = find( [2, diff(selected vars), 2]~=1 );
              block_list = {};
              for k=1:length(g_border)-1, block_list{k} =
g_border(k):(g_border(k+1)-1); end
          else
              block_list = {1:length(selected_vars)};
          end
          raw_data.variable_mat = zeros(length(selected_vars),
NumPnts DS); %Initialize.
          for k=1:length(block_list),
              target_var_index = selected_vars(block_list{k});
              fseek(fid, binary start +
(target_var_index(1)+1)*4, 'bof');
              TVIL = length(target var index);
              bytes_skip = (NumVars+1-TVIL)*4 +
(downsamp_N-1)*(NumVars+1)*4;
              precision_str = sprintf('%.0f*float',TVIL);
              raw data.variable mat(block list{k},:) =
reshape( fread(fid, NumPnts_DS*TVIL, precision_str, bytes_skip,
machineformat), TVIL, NumPnts_DS );
          end
          extract the time vector.
          raw_data.time_vect = fread( fid, NumPnts_DS, 'double',
(NumVars-1)*4 + (downsamp N-1)*(NumVars+1)*4, machineformat ).';
          if downsamp_N==1, raw_data.conversion_notes = 'Converted'
from Binary format';
          else raw_data.conversion_notes = sprintf( 'Converted from
Binary format. Downsampled from %.0f to %.0f points', NumPnts,
NumPnts DS ); end
```

```
elseif strcmpi( simulation_type, '.ac' ),
           % For AC Analysis simulations, the frequency data is
stored in double precision floating point binary format (8 bytes),
           % and the variables are stored as complex double precision
arrays (8 bytes real followed by 8 bytes imag)
          %Extract the binary data in the fewest possible number of
contiquous blocks
           if length(selected_vars)>1,
              g_border = find( [2, diff(selected_vars), 2]~=1 );
              block_list = {};
              for k=1:length(g_border)-1, block_list{k} =
g border(k):(g border(k+1)-1); end
          else
              block list = {1:length(selected vars)};
          end
          raw_data.variable_mat = zeros(length(selected_vars),
NumPnts_DS); %Initialize.
          if prod(size(raw data.variable mat))~=0,
raw_data.variable_mat(1,1) = 0.0 + j*0.0; end %Allocate memory for
complex double.
          for k=1:length(block_list),
              target_var_index = selected_vars(block_list{k});
              fseek(fid, binary start +
target_var_index(1)*16, 'bof');
              TVIL = length(target var index);
              bytes_skip = (NumVars-TVIL)*16
(downsamp_N-1)*NumVars*16;
              precision_str = sprintf('%.0f*double',TVIL*2);
              temp buff = reshape(fread(fid, NumPnts DS*TVIL*2,
precision_str, bytes_skip, machineformat), TVIL*2, NumPnts_DS );
              raw_data.variable_mat(block_list{k},:) =
temp_buff(1:2:end-1,:) + j*temp_buff(2:2:end,:);
              clear temp_buff;
           end
           extract the time vector.
          raw_data.freq_vect = fread( fid, NumPnts_DS, 'double',
(NumVars-1)*16 + 8 + (downsamp N-1)*NumVars*16, machineformat ).';
      else
           try fclose( fid ); catch end
          error( sprintf('Simulation type (%s) not currently
supported', simulation_type ));
      end
   elseif strcmpi(file format, 'ascii' ),
       if strcmpi( simulation_type, '.tran' ),
           %Format: point number, time value, var1, var2, var3 ...
varN
```

```
raw_data.variable_mat = fscanf( fid, '%g',
 [raw data.num variables+2, raw data.num data pnts] );
                                                        %matrix is
 filled in column order.
            if (size(raw data.variable mat,1)~=raw data.num variables
+2) | (size(raw_data.variable_mat,2)~=raw_data.num_data_pnts),
                error( sprintf('Format error in ASCII Transient
Analysis LTspice file "%s" ... Incorrect number of data values read',
filename ));
           end
           raw_data.time_vect =
raw_data.variable_mat(2,1:downsamp_N:end);
           raw_data.variable_mat =
raw data.variable mat(2+selected vars,1:downsamp N:end);
       elseif strcmpi( simulation type, '.ac' ),
           %Format: point number, freq value, 0, var1 real, var1
 imag, var2 real, var2 imag, var3 real, var3 imag ... varN real, varN
 imag
            all data = fread( fid, inf, 'uchar' );
           all_data( find( all_data == ',' ) ) = sprintf( '\t' );
 %Replace commas with tab characters
           raw_data.variable_mat = sscanf( char(all_data), '%g',
 [3+2*raw_data.num_variables, raw_data.num_data_pnts]);
            clear all data;
            %raw_data.variable_mat = fscanf( fid, '%g',
 [3+2*raw data.num variables, raw data.num data pnts]);
 filled in column order.
 (size(raw data.variable mat,1)~=(3+2*raw data.num variables))
 (size(raw_data.variable_mat,2)~=raw_data.num_data_pnts),
                error( sprintf('Format error in ASCII AC Analysis
LTspice file "%s" ... Incorrect number of data values read',
 filename ));
            end
           raw_data.freq_vect =
raw data.variable mat(2,1:downsamp N:end);
           raw_data.variable_mat =
raw_data.variable_mat(3+selected_vars*2-1,1:downsamp_N:end) +
 j*raw_data.variable_mat(3+selected_vars*2,1:downsamp_N:end);
       else
           try fclose( fid ); catch end
           error( sprintf('Simulation type (%s) not currently
 supported', simulation_type ));
       end
        if downsamp N==1, raw data.conversion notes = 'Converted from
ASCII format';
       else raw_data.conversion_notes = sprintf( 'Converted from
ASCII format. Downsampled from %.0f to %.0f points', NumPnts,
NumPnts DS ); end
    else
```

```
try fclose( fid ); catch end
      error( sprintf('Format error in LTspice file "%s" ... Data
type ID tag not found', filename ));
  try fclose( fid ); catch end
  %Deal with potential compression in Transient Analysis simulations
   if strcmpi( simulation_type, '.tran' ) &
vector is monotonically increasing.
      if downsamp_N~=1, %If we have already downsampled then we
can't uncompress.
          raw_data.time_vect = abs(raw_data.time_vect);
      else
          The binary file contains 2nd order compression ...
use 2nd-order interpolation to add data points in the vicinity of
negative time points
          later.
          neg pnt index = find( t vect < 0.0 &</pre>
[0,ones(1,length(t_vect)-1)] );
          t vect = abs(t vect);
          x1 = t_vect(neg_pnt_index-1); x2 = t_vect(neg_pnt_index);
x3 = t_vect(neg_pnt_index+1);
          x_new = [(2*x1 + x2)/3; (x1 + 2*x2)/3; (2*x2 + x3)/3;
(x2 + 2*x3)/3;
               %New sample points
          t_vect_big = NaN*zeros(6,length(t_vect));
          t_vect_big(1,:) = t_vect;
          t_vect_big(4,neg_pnt_index) = t_vect(neg_pnt_index);
          t_vect_big(1,neg_pnt_index) = NaN;
          t vect big([2 3 5 6], neg pnt index) = x new;
          full_index = find(~isnan(t_vect_big));
          time vect new = t vect big(full index).'; %This is the
new time vector with the inserted points.
          t_vect_big([1,4],:) = NaN;
          nan_vect = isnan(t_vect_big(full_index));
          new index = find( ~nan vect ); %Index into time vect new
indicating the new points only.
          old_index = find( nan_vect );
          clear t_vect t_vect_big full_index nan_vect;
          x1sqr = repmat(x1.^2, [4,1]); x2sqr = repmat(x2.^2,
[4,1]); x3sqr = repmat(x3.^2, [4,1]);
          x1 = repmat(x1, [4,1]); x2 = repmat(x2, [4,1]); x3 =
repmat( x3, [4,1] );
          denom = (x1sqr-x2sqr).*(x2-x3) - (x2sqr-x3sqr).*(x1-x2);
          r1 = (x_new.^2 - x1sqr)./denom;
          r2 = (x_new - x1)./denom;
          p1 = (x2-x3).*r1 - (x2sqr-x3sqr).*r2;
          p3 = (x1-x2).*r1 - (x1sqr-x2sqr).*r2;
          p2 = -p1 - p3;
```

```
p1 = p1 + 1;
           clear x new x1sqr x2sqr x3sqr x1 x2 x3 denom r1 r2;
           raw_data.variable_mat(:,end+1:length(time_vect_new)) =
 0.0;
       %Init the memory
            for k=1:size(raw_data.variable_mat,1),
               y vect =
raw_data.variable_mat(k,1:length(raw_data.time_vect));
               raw data.variable mat(k,old index) = y vect;
               y_new = repmat(y_vect(neg_pnt_index-1),
           + repmat(y_vect(neg_pnt_index),[4,1]).*p2 +
[4,1]).*p1
repmat(y_vect(neg_pnt_index+1),[4,1]).*p3;
               raw_data.variable_mat(k,new_index) = y_new(:).';
            end
           raw_data.time_vect = time_vect_new;
clear time_vect_new y_vect y_new new_index old_index neg_pnt_index p1 p2 p3;
           raw_data.conversion_notes = sprintf( 'Converted from
Binary format with 2nd Order compression. Upsampled waveforms from
 %.0f to %.0f points', ...
               raw_data.num_data_pnts, length(raw_data.time_vect) );
           raw_data.num_data_pnts = length(raw_data.time_vect);
       end
   end
   if isfield( raw data, 'time vect' ),
                                             raw_data.time_vect =
raw_data.time_vect + general_offset;
    elseif isfield( raw_data, 'freq_vect' ), raw_data.freq_vect =
raw_data.freq_vect + general_offset;
   end
```

Published with MATLAB® R2019a