# 

# RomWBW Hardware

Version 3.5

Updated 09 Apr 2025

RetroBrew Computers Group www.retrobrewcomputers.org

Wayne Warthen wwarthen@gmail.com

## **Contents**

1	Supp	orted Hardware Platforms	1
2	Platfo	orm Configurations	4
	2.1	RetroBrew Z80 SBC	4
	2.2	RetroBrew Z80 SimH	6
	2.3	RetroBrew N8 Z180 SBC	7
	2.4	Zeta Z80 SBC	8
	2.5	Zeta V2 Z80 SBC	9
	2.6	Mark IV Z180 SBC	10
	2.7	RCBus Z80 CPU Module	11
	2.8	RCBus Z180 CPU Module	15
	2.9	RCBus Z280 CPU Module	19
	2.10	RCBus eZ80 CPU Module	23
	2.11	Easy Z80 SBC	24
	2.12	Tiny Z80 SBC	26
	2.13	Z80-512K CPU/RAM/ROM Module	28
	2.14	Small Computer SC126 Z180 SBC	30
	2.15	Small Computer SC130 Z180 SBC	32
	2.16	Small Computer SC131 Z180 Pocket Comp	34
	2.17	Small Computer SC140 Z180 CPU Module	35
	2.18	Small Computer SC503 Z180 CPU Module	37
	2.19	Small Computer SC700 Z180 CPU Module	39
	2.20	Dyno Z180 SBC	41
	2.21	Nhyodyne Z80 MBC	42
	2.22	Rhyophyre Z180 SBC	44
	2.23	Z80 ZRC CPU Module	45
	2.24	Z80 ZRC512 CPU Module	49
	2.25	Z80 EaZy80-512 CPU Module	51
	2.26	Z80 K80W CPU Module	52
	2.27	Z180 Z1RCC CPU Module	54
	2.28	Z280 ZZRCC CPU Module	56

Contents	RomWBW Hardware

	2.30	Z280 ZZ80MB SBC	
	2.31	S100 Computers Z180	63
	2.32	Duodyne Z80 System	64
	2.33	Heath H8 Z80 System	66
	2.34	EP Mini-ITX Z180	67
	2.35	NABU w/ RomWBW Option Board	68
	2.36	\$100 FPGA Z80	69
	2.37	Genesis STD Z180	69
3	Devic	ee Drivers	71
	3.1	Character	71
	3.2	Disk	72
	3.3	Video	72
	3.4	Keyboard	73
	3.5	Audio	73
	3.6	RTC (RealTime Clock)	73
	3.7	DsKy (DiSplay KeYpad)	74
	3.8	System	74
4	UNA	Hardware BIOS	75
	4.1	UNA Usage Notes	76
5	Frrata		77

# **Chapter 1**

# **Supported Hardware Platforms**

This section contains a summary of the system configuration target for each of the pre-built ROM images included in the RomWBW distribution.

It is intended to help you select the correct ROM image and understand the basic hardware components supported. Detailed hardware system configuration information should be obtained from your system provider/designer.

The table below summarizes the hardware platforms currently supported by RomWBW along with the standard pre-built ROM image(s).

Description	Bus	ROM Image File	Baud Rate
RetroBrew Z80 SBC <sup>1</sup>	ECB	SBC_std.rom	38400
RetroBrew Z80 SimH <sup>1</sup>	-	SBC_simh.rom	38400
RetroBrew N8 Z180 SBC <sup>1</sup> (date >= 2312)	ECB	N8_std.rom	38400
Zeta Z80 SBC <sup>2</sup> , ParPortProp	-	ZETA_std.rom	38400
Zeta V2 Z80 SBC <sup>2</sup> , ParPortProp	-	ZETA2_std.rom	38400
Mark IV Z180 SBC <sup>3</sup>	ECB	MK4_std.rom	38400
RCBus Z80 CPU Module <sup>4</sup> , 512K RAM/ROM	RCBus	RCZ80_std.rom	115200
RCBus Z80 CPU Module <sup>4</sup> , 512K w/KIO	RCBus	RCZ80_kio_std.rom	115200
RCBus Z180 CPU Module <sup>4</sup> w/ ext banking	RCBus	RCZ180_ext_std.rom	115200
RCBus Z180 CPU Module <sup>4</sup> w/ native banking	RCBus	RCZ180_nat_std.rom	115200
RCBus Z280 CPU Module <sup>4</sup> w/ ext banking	RCBus	RCZ280_ext_std.rom	115200
RCBus Z280 CPU Module <sup>4</sup> w/ native banking	RCBus	RCZ280_nat_std.rom	115200
RCBus eZ80 CPU Module <sup>13</sup> , 512K RAM/ROM	RCBus	RCEZ80_std.rom	115200
Easy Z80 SBC <sup>2</sup>	RCBus	RCZ80_easy_std.rom	115200
Tiny Z80 SBC <sup>2</sup>	RCBus	RCZ80_tiny_std.rom	115200

Description	Bus	ROM Image File	Baud Rate
Z80-512K CPU/RAM/ROM Module <sup>2</sup>	RCBus	RCZ80_skz_std.rom	115200
Small Computer SC126 Z180 SBC <sup>5</sup>	BP80	SCZ180_sc126_std.rom	115200
Small Computer SC130 Z180 SBC <sup>5</sup>	RCBus	SCZ180_sc130_std.rom	115200
Small Computer SC131 Z180 Pocket Comp <sup>5</sup>	-	SCZ180_sc131_std.rom	115200
Small Computer SC140 Z180 CPU Module <sup>5</sup>	Z50	SCZ180_sc140_std.rom	115200
Small Computer SC503 Z180 CPU Module <sup>5</sup>	Z50	SCZ180_sc503_std.rom	115200
Small Computer SC700 Z180 CPU Module <sup>5</sup>	RCBus	SCZ180_sc700_std.rom	115200
Dyno Z180 SBC <sup>6</sup>	Dyno	DYNO_std.rom	38400
Nhyodyne Z80 MBC <sup>1</sup>	MBC	MBC_std.rom	38400
Rhyophyre Z180 SBC <sup>1</sup>	-	RPH_std.rom	38400
Z80 ZRC CPU Module <sup>7</sup>	RCBus	RCZ80_zrc_std.rom	115200
Z80 ZRC CPU Module <sup>7</sup> ROMless	RCBus	RCZ80_zrc_ram_std.rom	115200
Z80 ZRC512 CPU Module <sup>7</sup>	RCBus	RCZ80_zrc512_std.rom	115200
Z80 EaZy80-512 CPU Module <sup>7</sup>	RCBus	RCZ80_ez512_std.rom	115200
Z80 K80W CPU Module <sup>7</sup>	RCBus	RCZ80_k80w_std.rom	115200
Z180 Z1RCC CPU Module <sup>7</sup>	RCBus	RCZ180_z1rcc_std.rom	115200
Z280 ZZRCC CPU Module <sup>7</sup>	RCBus	RCZ280_zzrcc_std.rom	115200
Z280 ZZRCC CPU Module <sup>7</sup> ROMless	RCBus	RCZ280_zzrcc_ram_std.re	om 115200
Z280 ZZ80MB SBC <sup>7</sup>	RCBus	RCZ280_zz80mb_std.rom	n 115200
Z80-Retro SBC <sup>8</sup>	-	Z80RETRO_std.rom	38400
S100 Computers Z180 <sup>9</sup>	S100	S100_std.rom	57600
Duodyne Z80 System <sup>1</sup>	Duo	DUO_std.rom	38400
Heath H8 Z80 System <sup>10</sup>	H8	HEATH_std.rom	115200
EP Mini-ITX Z180 <sup>11</sup>	RCBus?	EPITX_std.rom	115200
NABU w/ RomWBW Option Board <sup>10</sup>	NABU	NABU_std.rom	115200
S100 FPGA Z80 <sup>9</sup>	S100	FZ80_std.rom	9600
Genesis STD Z180 <sup>12</sup>	STD	GMZ180_std.rom	115200

<sup>&</sup>lt;sup>1</sup>Designed by Andrew Lynch

<sup>&</sup>lt;sup>2</sup>Designed by Sergey Kiselev

<sup>&</sup>lt;sup>3</sup>Designed by John Coffman

<sup>&</sup>lt;sup>4</sup>RCBus compliant (multiple products/designers)

<sup>&</sup>lt;sup>5</sup>Designed by Stephen Cousins

<sup>&</sup>lt;sup>6</sup>Designed by Steve Garcia

<sup>&</sup>lt;sup>7</sup>Designed by Bill Shen

<sup>&</sup>lt;sup>8</sup>Designed by Peter Wilson

<sup>&</sup>lt;sup>9</sup>Designed by John Monahan

RCBus refers to Spencer Owen's RC2014 bus specification and derivatives including RC26, RC40, RC80, and BP80.

The RCBus Z180 & Z280 require a separate RAM/ROM memory module. There are two types of these modules and you must pick the correct ROM for your type of memory module. The first option is the same as the 512K RAM/ROM module for RC/BP80 Bus. This is called external ("ext") because the bank switching is performed externally from the CPU. The second type of RAM/ROM module has no bank switching logic – this is called native ("nat") because the CPU itself provides the bank switching logic. Only Z180 and Z280 CPUs have the ability to do bank switching in the CPU, so the ext/nat selection only applies to them. Z80 CPUs have no built-in bank switching logic, so they are always configured for external bank switching.

The standard ROM images will detect and install support for certain devices and peripherals that are on-board or frequently used with each platform. If the device or peripheral is not detected at boot, the ROM will simply bypass support appropriately.

In some cases, support for multiple hardware components with potentially conflicting resource usage are handled by a single ROM image. It is up to the user to ensure that no conflicting hardware is in use.

All pre-built ROM images are pure binary files (they are not "hex" files). They are intended to be programmed starting at the very start of the ROM chip (address 0). Most of the pre-built images are 512KB in size. If your system utilizes a larger ROM, you can just program the image into the first 512KB of the ROM for now.

<sup>&</sup>lt;sup>10</sup>Designed by Les Bird

<sup>&</sup>lt;sup>11</sup>Designed by Alan Cox

<sup>&</sup>lt;sup>12</sup>Designed by Doug Jackson

<sup>&</sup>lt;sup>13</sup>Designed by Dean Netherton

# **Chapter 2**

# **Platform Configurations**

### 2.1 RetroBrew Z80 SBC

ROM Image File: SBC\_std.rom

Default CPU Speed	8.000 MHz
Interrupts	None
System Timer	None
Serial Default	38400 Baud
Memory Manager	SBC
ROM Size	512 KB
RAM Size	512 KB

### **Supported Hardware**

• DSRTC: MODE=STD, IO=112

• UART: MODE=SBC, IO=104

• UART: MODE=CAS, IO=128

• UART: MODE=MFP, IO=104

• UART: MODE=4UART, IO=192

• UART: MODE=4UART, IO=200

• UART: MODE=4UART, IO=208

• UART: MODE=4UART, IO=216

VGA: IO=224, KBD MODE=PS/2, KBD IO=224

• CVDU: MODE=ECB, IO=224, KBD MODE=PS/2, KBD IO=226

• CVDU occupies 905 bytes.

KBD: ENABLEDPRP: IO=168

PRPCON: ENABLEDPRPSD: ENABLEDMD: TYPE=RAMMD: TYPE=ROM

FD: MODE=DIO, IO=54, DRIVE 0, TYPE=3.5" HD
FD: MODE=DIO, IO=54, DRIVE 1, TYPE=3.5" HD

PPIDE: IO=96, MASTERPPIDE: IO=96, SLAVE

### Notes:

• CPU speed will be dynamically measured at startup if DSRTC is present

### 2.2 RetroBrew Z80 SimH

ROM Image File: SBC\_simh.rom

Default CPU Speed 8.000 MHz
Interrupts Mode 1
System Timer SimH
Serial Default 38400 Baud
Memory Manager SBC
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

SIMRTC: IO=254SSER: IO=109MD: TYPE=RAMMD: TYPE=ROM

HDSK: IO=253, DEVICE COUNT=2

- · Image for SimH emulator
- CPU speed and Serial configuration not relevant in emulator

### 2.3 RetroBrew N8 Z180 SBC

ROM Image File: N8\_std.rom

Default CPU Speed 18.432 MHz
Interrupts Mode 2
System Timer Z180
Serial Default 38400 Baud
Memory Manager N8
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

• DSRTC: MODE=STD, IO=136

ASCI: IO=64, INTERRUPTS ENABLED

• ASCI: IO=65, INTERRUPTS ENABLED

• TMS: MODE=N8, IO=152, SCREEN=40X24, KEYBOARD=PPK

PPK: ENABLEDMD: TYPE=RAMMD: TYPE=ROM

• FD: MODE=N8, IO=140, DRIVE 0, TYPE=3.5" HD

• FD: MODE=N8, IO=140, DRIVE 1, TYPE=3.5" HD

• SD: MODE=CSIO, IO=136, UNITS=1

AY38910: MODE=N8, IO=156, CLOCK=1789772 HZ

- · CPU speed will be dynamically measured at startup if DSRTC is present
- SD Card interface is configured for CSIO (N8 date code >= 2312)

### 2.4 Zeta Z80 SBC

ROM Image File: ZETA\_std.rom

Default CPU Speed 8.000 MHz
Interrupts None
System Timer None
Serial Default 38400 Baud
Memory Manager SBC
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

• DSRTC: MODE=STD, IO=112

UART: IO=104PPP: IO=96

PPPCON: ENABLEDPPPSD: ENABLEDMD: TYPE=RAMMD: TYPE=ROM

• FD: MODE=DIO, IO=54, DRIVE 0, TYPE=3.5" HD

- · CPU speed will be dynamically measured at startup if DSRTC is present
- If ParPortProp is installed, initial console output is determined by JP1:
  - Shorted: console to on-board serial port
  - Open: console to ParPortProp video and keyboard

### 2.5 Zeta V2 Z80 SBC

ROM Image File: ZETA2\_std.rom

Default CPU Speed 8.000 MHz
Interrupts Mode 2
System Timer CTC
Serial Default 38400 Baud
Memory Manager Z2
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

• DSRTC: MODE=STD, IO=112

UART: IO=104PPP: IO=96

PPPCON: ENABLEDPPPSD: ENABLEDMD: TYPE=RAMMD: TYPE=ROM

• FD: MODE=ZETA2, IO=48, DRIVE 0, TYPE=3.5" HD

 CTC: IO=32, TIMER MODE=COUNTER, DIVISOR=18432, HI=256, LO=72, INTERRUPTS ENABLED

- · CPU speed will be dynamically measured at startup if DSRTC is present
- If ParPortProp is installed, initial console output is determined by JP1:
  - Shorted: console to on-board serial port
  - Open: console to ParPortProp video and keyboard

### 2.6 Mark IV Z180 SBC

ROM Image File: MK4\_std.rom

Default CPU Speed 18.432 MHz
Interrupts Mode 2
System Timer Z180
Serial Default 38400 Baud
Memory Manager Z180
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

• DSRTC: MODE=STD, IO=138

ASCI: IO=64, INTERRUPTS ENABLED
 ASCI: IO=65, INTERRUPTS ENABLED

UART: IO=24UART: IO=128UART: IO=192

• UART: IO=200

UART: IO=208UART: IO=216

VGA: IO=224, KBD MODE=PS/2, KBD IO=224

CVDU: MODE=ECB, IO=224, KBD MODE=PS/2, KBD IO=226

KBD: ENABLEDPRP: IO=168

PRPCON: ENABLEDPRPSD: ENABLED

• MD: TYPE=RAM

MD: TYPE=ROM

• FD: MODE=DIDE, IO=42, DRIVE 0, TYPE=3.5" HD

FD: MODE=DIDE, IO=42, DRIVE 1, TYPE=3.5" HD

• IDE: MODE=MK4, IO=128, MASTER

IDE: MODE=MK4, IO=128, SLAVE

SD: MODE=MK4, IO=137, UNITS=1

### Notes:

· CPU speed will be dynamically measured at startup if DSRTC is present

### 2.7 RCBus Z80 CPU Module

ROM Image File: RCZ80\_std.rom

Default CPU Speed 7.372 MHz
Interrupts Mode 1
System Timer None
Serial Default 115200 Baud
Memory Manager Z2
ROM Size 512 KB

512 KB

### **Supported Hardware**

FP: LEDIO=0, SWIO=0LCD: IO=218, SIZE=20X4

• DSRTC: MODE=STD, IO=192

UART: IO=128UART: IO=136UART: IO=160UART: IO=168

• SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED

**RAM Size** 

• SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED

SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED

· SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED

ACIA: IO=128, INTERRUPTS ENABLED

CH: IO=62CH: IO=60CHUSB: IO=62CHUSB: IO=60

MD: TYPE=RAM

MD: TYPE=ROM

• FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD

• FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD

IDE: MODE=RC, IO=16, MASTER

IDE: MODE=RC, IO=16, SLAVE

PPIDE: IO=32, MASTER

• PPIDE: IO=32, SLAVE

SD: MODE=PIO, IO=105, UNITS=1

• CPU speed will be dynamically measured at startup if DSRTC is present

### ROM Image File: RCZ80\_kio\_std.rom

Default CPU Speed 7.372 MHz
Interrupts Mode 2
System Timer CTC
Serial Default 115200 Baud
Memory Manager Z2
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

FP: LEDIO=0, SWIO=0LCD: IO=218, SIZE=20X4

• DSRTC: MODE=STD, IO=192

INTRTC: ENABLED

• UART: IO=128

• UART: IO=136

• UART: IO=160

UART: IO=168

- SIO MODE=STD, IO=136, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=STD, IO=136, CHANNEL B, INTERRUPTS ENABLED

• CH: IO=62

• CH: IO=60

• CHUSB: IO=62

CHUSB: IO=60

• MD: TYPE=RAM

• MD: TYPE=ROM

- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=PIO, IO=105, UNITS=1
- KIO: IO=128
- CTC: IO=132, TIMER MODE=TIMER/16, DIVISOR=9216, HI=256, LO=36, INTERRUPTS ENABLED

- CPU speed will be dynamically measured at startup if DSRTC is present
- SIO Serial baud rate managed by CTC

### 2.8 RCBus Z180 CPU Module

ROM Image File: RCZ180\_ext\_std.rom

Default CPU Speed 18.432 MHz
Interrupts Mode 2
System Timer Z180
Serial Default 115200 Baud
Memory Manager Z2
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

• FP: LEDIO=0, SWIO=0

• DSRTC: MODE=STD, IO=12

INTRTC: ENABLED

ASCI: IO=192, INTERRUPTS ENABLED
 ASCI: IO=192, INTERRUPTS ENABLED

ASCI: IO=193, INTERRUPTS ENABLED

UART: IO=128

• UART: IO=136

• UART: IO=160

UART: IO=168

• SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED

• SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED

SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED

• SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED

• CH: IO=62

• CH: IO=60

• CHUSB: IO=62

• CHUSB: IO=60

• MD: TYPE=RAM

MD: TYPE=ROM

• FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD

• FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD

• IDE: MODE=RC, IO=16, MASTER

IDE: MODE=RC, IO=16, SLAVE

PPIDE: IO=32, MASTER

• PPIDE: IO=32, SLAVE

• SD: MODE=PIO, IO=105, UNITS=1

- For use with Z2 bank switched memory board (Z2 external memory management)
- CPU speed will be dynamically measured at startup if DSRTC is present

### ROM Image File: RCZ180\_nat\_std.rom

Default CPU Speed 18.432 MHz
Interrupts Mode 2
System Timer Z180
Serial Default 115200 Baud
Memory Manager Z180
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

- FP: LEDIO=0, SWIO=0
- DSRTC: MODE=STD, IO=12
- INTRTC: ENABLED
- ASCI: IO=192, INTERRUPTS ENABLED
- ASCI: IO=193, INTERRUPTS ENABLED
- UART: IO=128
- UART: IO=136
- UART: IO=160
- UART: IO=168
- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=PIO, IO=105, UNITS=1

- For use with linear memory board (Z180 native memory management)
- CPU speed will be dynamically measured at startup if DSRTC is present

### 2.9 RCBus Z280 CPU Module

ROM Image File: RCZ280\_ext\_std.rom

Default CPU Speed 12.000 MHz
Interrupts Mode 1
System Timer None
Serial Default 115200 Baud
Memory Manager Z2
ROM Size 512 KB

512 KB

### **Supported Hardware**

FP: LEDIO=0, SWIO=0
LCD: IO=218, SIZE=20X4
DSRTC: MODE=STD, IO=192

• INTRTC: ENABLED

Z2U: IO=16UART: IO=128UART: IO=136UART: IO=160UART: IO=168

SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED

**RAM Size** 

- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- ACIA: IO=128, INTERRUPTS ENABLED

CH: IO=62CH: IO=60CHUSB: IO=62CHUSB: IO=60

• MD: TYPE=RAM

MD: TYPE=ROM

- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE

PPIDE: IO=32, MASTERPPIDE: IO=32, SLAVE

• SD: MODE=PIO, IO=105, UNITS=1

### Notes:

• For use with Z2 bank switched memory board (Z2 external memory management)

### ROM Image File: RCZ280\_nat\_std.rom

Default CPU Speed 12.000 MHz
Interrupts Mode 3
System Timer Z280
Serial Default 115200 Baud
Memory Manager Z280
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

FP: LEDIO=0, SWIO=0

• LCD: IO=218, SIZE=20X4

• DSRTC: MODE=STD, IO=192

· INTRTC: ENABLED

• Z2U: IO=16, INTERRUPTS ENABLED

• UART: IO=128

• UART: IO=136

• UART: IO=160

• UART: IO=168

- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=PIO, IO=105, UNITS=1

• For use with linear memory board (Z280 native memory management)

### 2.10 RCBus eZ80 CPU Module

ROM Image File: RCEZ80\_std.rom

Default CPU Speed 20.000 MHz
Interrupts Mode 1
System Timer EZ80
Serial Default 115200 Baud
Memory Manager Z2
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

• FP: LEDIO=0, SWIO=0

• LCD: IO=218, SIZE=20X4

CH: IO=62CH: IO=60CHUSB: IO=62CHUSB: IO=60

• MD: TYPE=RAM

MD: TYPE=ROM

• FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD

• FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD

• IDE: MODE=RC, IO=16, MASTER

• IDE: MODE=RC, IO=16, SLAVE

PPIDE: IO=32, MASTERPPIDE: IO=32, SLAVE

• EZ80: CPU DRIVER

• EZ80: SYS TIMER DRIVER

EZ80: RTC DRIVEREZ80: UART DRIVER

### 2.11 Easy Z80 SBC

ROM Image File: RCZ80\_easy\_std.rom

Default CPU Speed 10.000 MHz
Interrupts Mode 2
System Timer CTC
Serial Default 115200 Baud
Memory Manager Z2
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

FP: LEDIO=0, SWIO=0
 LCD: IO=218, SIZE=20X4
 DSRTC: MODE=STD, IO=192

INTRTC: ENABLED
UART: IO=128
UART: IO=136
UART: IO=160
UART: IO=168

- SIO MODE=STD, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=STD, IO=128, CHANNEL B, INTERRUPTS ENABLED
- · SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=PIO, IO=105, UNITS=1

 CTC: IO=136, TIMER MODE=COUNTER, DIVISOR=18432, HI=256, LO=72, INTERRUPTS ENABLED

### Notes:

• CPU speed will be dynamically measured at startup if DSRTC is present

### 2.12 Tiny Z80 SBC

ROM Image File: RCZ80\_tiny\_std.rom

Default CPU Speed 16.000 MHz
Interrupts Mode 2
System Timer CTC
Serial Default 115200 Baud
Memory Manager Z2
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

FP: LEDIO=0, SWIO=0
 LCD: IO=218, SIZE=20X4
 DSRTC: MODE=STD, IO=192

INTRTC: ENABLED
UART: IO=128
UART: IO=136
UART: IO=160
UART: IO=168

- SIO MODE=STD, IO=24, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=STD, IO=24, CHANNEL B, INTERRUPTS ENABLED
- · SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62CH: IO=60CHUSB: IO=62
- CHUSB: IO=60MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=144, MASTER
- IDE: MODE=RC, IO=144, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=PIO, IO=105, UNITS=1

 CTC: IO=16, TIMER MODE=COUNTER, DIVISOR=18432, HI=256, LO=72, INTERRUPTS ENABLED

### Notes:

• CPU speed will be dynamically measured at startup if DSRTC is present

### 2.13 Z80-512K CPU/RAM/ROM Module

ROM Image File: RCZ80\_skz\_std.rom

Default CPU Speed 7.372 MHz
Interrupts Mode 1
System Timer None
Serial Default 115200 Baud

Memory Manager Z2
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

• FP: LEDIO=0, SWIO=0

LCD: IO=218, SIZE=20X4

DSRTC: MODE=STD, IO=192

• UART: IO=128

UART: IO=136

• UART: IO=160

• UART: IO=168

- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- · SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- ACIA: IO=128, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=PIO, IO=105, UNITS=1

• CPU speed will be dynamically measured at startup if DSRTC is present

### 2.14 Small Computer SC126 Z180 SBC

ROM Image File: SCZ180\_sc126\_std.rom

Default CPU Speed 18.432 MHz
Interrupts Mode 2
System Timer Z180
Serial Default 115200 Baud
Memory Manager Z180
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

FP: LEDIO=13, SWIO=0DSRTC: MODE=STD, IO=12

ASCI: IO=192, INTERRUPTS ENABLED
 ASCI: IO=193, INTERRUPTS ENABLED

UART: IO=128UART: IO=136UART: IO=160UART: IO=168

• SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED

• SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED

· SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED

SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED

CH: IO=62CH: IO=60

CHUSB: IO=62CHUSB: IO=60MD: TYPE=RAM

• MD: TYPE=ROM

FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD

• FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD

• IDE: MODE=RC, IO=16, MASTER

• IDE: MODE=RC, IO=16, SLAVE

• PPIDE: IO=32, MASTER

• PPIDE: IO=32, SLAVE

• SD: MODE=SC, IO=12, UNITS=1

- CPU speed will be dynamically measured at startup if DSRTC is present
- When disabled, watchdog requires /IM to be pulsed. If an RCBus module holds the CPU in WAIT for more than this, the watchdog will fire when disabled with random consequences. The Pico SD does this at power-on.

### 2.15 Small Computer SC130 Z180 SBC

ROM Image File: SCZ180\_sc130\_std.rom

Default CPU Speed 18.432 MHz
Interrupts Mode 2
System Timer Z180
Serial Default 115200 Baud
Memory Manager Z180
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

• FP: LEDIO=0, SWIO=0

• DSRTC: MODE=STD, IO=12

INTRTC: ENABLED

ASCI: IO=192, INTERRUPTS ENABLED
 ASCI: IO=192, INTERRUPTS ENABLED

ASCI: IO=193, INTERRUPTS ENABLED

UART: IO=128

• UART: IO=136

UART: IO=160

UART: IO=168

• SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED

• SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED

SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED

• SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED

• CH: IO=62

• CH: IO=60

• CHUSB: IO=62

• CHUSB: IO=60

• MD: TYPE=RAM

MD: TYPE=ROM

• FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD

• FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD

• IDE: MODE=RC, IO=16, MASTER

IDE: MODE=RC, IO=16, SLAVE

PPIDE: IO=32, MASTER

• PPIDE: IO=32, SLAVE

SD: MODE=SC, IO=12, UNITS=1

• CPU speed will be dynamically measured at startup if DSRTC is present

# 2.16 Small Computer SC131 Z180 Pocket Comp

ROM Image File: SCZ180\_sc131\_std.rom

Default CPU Speed 18.432 MHz
Interrupts Mode 2
System Timer Z180
Serial Default 115200 Baud
Memory Manager Z180
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

• INTRTC: ENABLED

ASCI: IO=192, INTERRUPTS ENABLED
ASCI: IO=193, INTERRUPTS ENABLED

MD: TYPE=RAMMD: TYPE=ROM

· SD: MODE=SC, IO=12, UNITS=1

## 2.17 Small Computer SC140 Z180 CPU Module

ROM Image File: SCZ180\_sc140\_std.rom

Default CPU Speed 18.432 MHz
Interrupts Mode 2
System Timer Z180
Serial Default 115200 Baud
Memory Manager Z180
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

FP: LEDIO=160, SWIO=160

• DSRTC: MODE=STD, IO=12

· INTRTC: ENABLED

ASCI: IO=192, INTERRUPTS ENABLED

• ASCI: IO=193, INTERRUPTS ENABLED

UART: IO=128

• UART: IO=136

UART: IO=160

UART: IO=168

• SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED

• SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED

SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED

• SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED

• CH: IO=62

• CH: IO=60

• CHUSB: IO=62

• CHUSB: IO=60

• MD: TYPE=RAM

MD: TYPE=ROM

• FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD

• FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD

• IDE: MODE=RC, IO=144, MASTER

IDE: MODE=RC, IO=144, SLAVE

PPIDE: IO=32, MASTER

• PPIDE: IO=32, SLAVE

• SD: MODE=SC, IO=12, UNITS=1

### 2.18 Small Computer SC503 Z180 CPU Module

ROM Image File: SCZ180\_sc503\_std.rom

Default CPU Speed 18.432 MHz
Interrupts Mode 2
System Timer Z180
Serial Default 115200 Baud
Memory Manager Z180
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

FP: LEDIO=160, SWIO=160

• DSRTC: MODE=STD, IO=12

· INTRTC: ENABLED

ASCI: IO=192, INTERRUPTS ENABLED

• ASCI: IO=193, INTERRUPTS ENABLED

UART: IO=128

• UART: IO=136

UART: IO=160

UART: IO=168

- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=144, MASTER
- IDE: MODE=RC, IO=144, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=SC, IO=12, UNITS=1

### 2.19 Small Computer SC700 Z180 CPU Module

ROM Image File: SCZ180\_sc700\_std.rom

Default CPU Speed 18.432 MHz
Interrupts Mode 2
System Timer Z180
Serial Default 115200 Baud
Memory Manager Z180
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

• FP: LEDIO=0

LCD: IO=170, SIZE=20X4
 DSRTC: MODE=STD, IO=12

INTRTC: ENABLED

ASCI: IO=192, INTERRUPTS ENABLED
 ASCI: IO=193, INTERRUPTS ENABLED

UART: IO=128UART: IO=136UART: IO=160UART: IO=168

- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED

• CH: IO=62

• CH: IO=60

• CHUSB: IO=62

• CHUSB: IO=60

MD: TYPE=RAM

MD: TYPE=ROM

• FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD

• FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD

• IDE: MODE=RC, IO=16, MASTER

• IDE: MODE=RC, IO=16, SLAVE

• PPIDE: IO=32, MASTER

• PPIDE: IO=32, SLAVE

• SD: MODE=SC, IO=12, UNITS=1

### Notes:

# 2.20 Dyno Z180 SBC

ROM Image File: DYNO\_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	38400 Baud
Memory Manager	Z180
ROM Size	512 KB
RAM Size	512 KB

### **Supported Hardware**

• BQRTC: IO=80

ASCI: IO=192, INTERRUPTS ENABLED
ASCI: IO=193, INTERRUPTS ENABLED

MD: TYPE=RAMMD: TYPE=ROM

FD: MODE=DYNO, IO=132, DRIVE 0, TYPE=3.5" HD
FD: MODE=DYNO, IO=132, DRIVE 1, TYPE=3.5" HD

PPIDE: IO=76, MASTERPPIDE: IO=76, SLAVE

## 2.21 Nhyodyne Z80 MBC

ROM Image File: MBC\_std.rom

Default CPU Speed 8.000 MHz
Interrupts None
System Timer None
Serial Default 38400 Baud
Memory Manager MBC
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

PKD: IO=96, SIZE=8X1

• DSRTC: MODE=STD, IO=112

UART: IO=104UART: IO=128UART: IO=136

SIO MODE=ZP, IO=176, CHANNEL A

SIO MODE=ZP, IO=176, CHANNEL B

• PIO: IO=184, CHANNEL A

PIO: IO=184, CHANNEL B

PIO: IO=188, CHANNEL A

• PIO: IO=188, CHANNEL B

• LPT: MODE=SPP, IO=232

CVDU: MODE=MBC, IO=224, KBD MODE=PS/2, KBD IO=226

TMS: MODE=MBC, IO=152, SCREEN=80X24, KEYBOARD=KBD

KBD: ENABLED

• ESP: IO=156

· ESPCON: ENABLED

• ESPSER: DEVICE=0

• ESPSER: DEVICE=1

MD: TYPE=RAM

• MD: TYPE=ROM

• FD: MODE=MBC, IO=48, DRIVE 0, TYPE=3.5" HD

• FD: MODE=MBC, IO=48, DRIVE 1, TYPE=3.5" HD

• PPIDE: IO=96, MASTER

PPIDE: IO=96, SLAVE

• SPK: IO=112

# 2.22 Rhyophyre Z180 SBC

ROM Image File: RPH\_std.rom

Default CPU Speed 18.432 MHz
Interrupts None
System Timer None
Serial Default 38400 Baud
Memory Manager RPH
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

• DSRTC: MODE=STD, IO=132

ASCI: IO=64ASCI: IO=65

• GDC: MODE=RPH, DISPLAY=EGA, IO=144

KBD: ENABLEDMD: TYPE=RAMMD: TYPE=ROM

PPIDE: IO=136, MASTERPPIDE: IO=136, SLAVE

### Notes:

### 2.23 Z80 ZRC CPU Module

ROM Image File: RCZ80\_zrc\_std.rom

Default CPU Speed 14.745 MHz
Interrupts Mode 1
System Timer None
Serial Default 115200 Baud
Memory Manager ZRC
ROM Size 512 KB

1536 KB

#### **Supported Hardware**

FP: LEDIO=0, SWIO=0
LCD: IO=218, SIZE=20X4
DSRTC: MODE=STD, IO=192

UART: IO=128UART: IO=136UART: IO=160UART: IO=168

• SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED

**RAM Size** 

- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- ACIA: IO=128, INTERRUPTS ENABLED
- VRC: IO=0, KBD MODE=VRC, KBD IO=244
- KBD: ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- · IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE

• SD: MODE=PIO, IO=105, UNITS=1

- ZRC is actually contains no ROM and 2MB of RAM. The first 512KB of RAM is loaded from disk and then handled like ROM.
- CPU speed will be dynamically measured at startup if DSRTC is present

### ROM Image File: RCZ80\_zrc\_ram\_std.rom

Default CPU Speed 14.745 MHz
Interrupts Mode 1
System Timer None
Serial Default 115200 Baud
Memory Manager ZRC
ROM Size 0 KB
RAM Size 512 KB

#### **Supported Hardware**

FP: LEDIO=0, SWIO=0
LCD: IO=218, SIZE=20X4
DSRTC: MODE=STD, IO=192

UART: IO=128UART: IO=136UART: IO=160UART: IO=168

- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- ACIA: IO=128, INTERRUPTS ENABLED
- VRC: IO=0, KBD MODE=VRC, KBD IO=244
- KBD: ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=PIO, IO=105, UNITS=1

- ROMless boot HBIOS is loaded from disk at boot
- CPU speed will be dynamically measured at startup if DSRTC is present

### 2.24 Z80 ZRC512 CPU Module

ROM Image File: RCZ80\_zrc512\_std.rom

Default CPU Speed 22.000 MHz
Interrupts Mode 1
System Timer None
Serial Default 115200 Baud
Memory Manager ZRC
ROM Size 0 KB
RAM Size 512 KB

### **Supported Hardware**

• FP: LEDIO=0, SWIO=0

• LCD: IO=218, SIZE=20X4

• DSRTC: MODE=STD, IO=192

UART: IO=128

• UART: IO=136

• UART: IO=160

• UART: IO=168

- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- ACIA: IO=128, INTERRUPTS ENABLED
- VRC: IO=0, KBD MODE=VRC, KBD IO=244
- KBD: ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=PIO, IO=105, UNITS=1

- ROMless boot HBIOS is loaded from disk at boot
- CPU speed will be dynamically measured at startup if DSRTC is present

## 2.25 Z80 EaZy80-512 CPU Module

ROM Image File: RCZ80\_ez512\_std.rom

Default CPU Speed 22.000 MHz
Interrupts Mode 2
System Timer None
Serial Default 115200 Baud
Memory Manager EZ512
ROM Size 0 KB
RAM Size 512 KB

### **Supported Hardware**

• DSRTC: MODE=STD, IO=192

• SIO MODE=STD, IO=8, CHANNEL A, INTERRUPTS ENABLED

• SIO MODE=STD, IO=8, CHANNEL B, INTERRUPTS ENABLED

MD: TYPE=RAM

· MD occupies 409 bytes.

• SD: MODE=EZ512, IO=2, UNITS=1

KIO: IO=0CTC: IO=4

- · HBIOS is loaded from disk at boot by ROM monitor
- CPU speed will be dynamically measured at startup if DSRTC is present

### 2.26 Z80 K80W CPU Module

ROM Image File: RCZ80\_k80w\_std.rom

Default CPU Speed 22.000 MHz
Interrupts Mode 2
System Timer None
Serial Default 115200 Baud
Memory Manager Z2
ROM Size 512 KB
RAM Size 512 KB

#### **Supported Hardware**

• FP: LEDIO=0, SWIO=0

LCD: IO=218, SIZE=20X4

DSRTC: MODE=K80W, IO=192

• UART: IO=128

UART: IO=136

• UART: IO=160

UART: IO=168

- SIO MODE=STD, IO=136, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=STD, IO=136, CHANNEL B, INTERRUPTS ENABLED
- VRC: IO=0, KBD MODE=VRC, KBD IO=244
- KBD: ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- MD: TYPE=ROM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=EZ512, IO=130, UNITS=1
- KIO: IO=128
- CTC: IO=132

### 2.27 Z180 Z1RCC CPU Module

ROM Image File: RCZ180\_z1rcc\_std.rom

Default CPU Speed 18.432 MHz
Interrupts Mode 2
System Timer Z180
Serial Default 115200 Baud
Memory Manager Z180
ROM Size 0 KB
RAM Size 512 KB

### **Supported Hardware**

• FP: LEDIO=0, SWIO=0

• DSRTC: MODE=STD, IO=12

INTRTC: ENABLED

• ASCI: IO=192, INTERRUPTS ENABLED

ASCI: IO=193, INTERRUPTS ENABLED

• UART: IO=128

• UART: IO=136

• UART: IO=160

• UART: IO=168

- SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED
- CH: IO=62
- CH: IO=60
- CHUSB: IO=62
- CHUSB: IO=60
- MD: TYPE=RAM
- FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD
- FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD
- IDE: MODE=RC, IO=16, MASTER
- IDE: MODE=RC, IO=16, SLAVE
- PPIDE: IO=32, MASTER
- PPIDE: IO=32, SLAVE
- SD: MODE=PIO, IO=105, UNITS=1

- ROMless boot HBIOS is loaded from disk at boot
- CPU speed will be dynamically measured at startup if DSRTC is present

### 2.28 Z280 ZZRCC CPU Module

ROM Image File: RCZ280\_zzrcc\_std.rom

Default CPU Speed 14.745 MHz
Interrupts Mode 3
System Timer Z280
Serial Default 115200 Baud
Memory Manager Z280
ROM Size 256 KB
RAM Size 256 KB

#### **Supported Hardware**

FP: LEDIO=0, SWIO=0LCD: IO=218, SIZE=20X4

• DSRTC: MODE=STD, IO=192

• INTRTC: ENABLED

• Z2U: IO=16, INTERRUPTS ENABLED

UART: IO=128 UART: IO=136 UART: IO=160

UART: IO=168

SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED

• SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED

• SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED

SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED

VRC: IO=0, KBD MODE=VRC, KBD IO=244

KBD: ENABLED

• CH: IO=62

• CH: IO=60

• CHUSB: IO=62

• CHUSB: IO=60

MD: TYPE=RAM

• MD: TYPE=ROM

• FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD

• FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD

• IDE: MODE=RC, IO=16, MASTER

IDE: MODE=RC, IO=16, SLAVE

• PPIDE: IO=32, MASTER

• PPIDE: IO=32, SLAVE

- ZZRCC actually contains no ROM and 512KB of RAM. The first 256KB of RAM is loaded from disk and then handled like ROM.
- CPU speed will be dynamically measured at startup if DSRTC is present

### ROM Image File: RCZ280\_zzrcc\_ram\_std.rom

Default CPU Speed	14.745 MHz
Interrupts	Mode 3
System Timer	Z280
Serial Default	115200 Baud
Memory Manager	Z280
ROM Size	0 KB
RAM Size	512 KB

### **Supported Hardware**

FP: LEDIO=0, SWIO=0LCD: IO=218, SIZE=20X4

• DSRTC: MODE=STD, IO=192

INTRTC: ENABLED

Z2U: IO=16, INTERRUPTS ENABLED

UART: IO=128UART: IO=136UART: IO=160UART: IO=168

• SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED

SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED

• SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED

• SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED

VRC: IO=0, KBD MODE=VRC, KBD IO=244

KBD: ENABLED

• CH: IO=62

• CH: IO=60

CHUSB: I0=62CHUSB: I0=60MD: TYPE=RAM

• FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD

• FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD

• IDE: MODE=RC, IO=16, MASTER

• IDE: MODE=RC, IO=16, SLAVE

PPIDE: IO=32, MASTERPPIDE: IO=32, SLAVE

- ROMless boot HBIOS is loaded from disk at boot
- CPU speed will be dynamically measured at startup if DSRTC is present

### 2.29 Z280 ZZ80MB SBC

ROM Image File: RCZ280\_zz80mb\_std.rom

Default CPU Speed 12.000 MHz
Interrupts Mode 3
System Timer Z280
Serial Default 115200 Baud
Memory Manager Z280
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

FP: LEDIO=0, SWIO=0LCD: IO=218, SIZE=20X4

• DSRTC: MODE=STD, IO=192

INTRTC: ENABLED

• Z2U: IO=16, INTERRUPTS ENABLED

UART: IO=128UART: IO=136UART: IO=160UART: IO=168

SIO MODE=RC, IO=128, CHANNEL A, INTERRUPTS ENABLED

• SIO MODE=RC, IO=128, CHANNEL B, INTERRUPTS ENABLED

• SIO MODE=RC, IO=132, CHANNEL A, INTERRUPTS ENABLED

SIO MODE=RC, IO=132, CHANNEL B, INTERRUPTS ENABLED

VRC: IO=0, KBD MODE=VRC, KBD IO=244

KBD: ENABLED

• CH: IO=62

• CH: IO=60

• CHUSB: IO=62

• CHUSB: IO=60

MD: TYPE=RAM

• MD: TYPE=ROM

• FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD

• FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD

• IDE: MODE=RC, IO=16, MASTER

IDE: MODE=RC, IO=16, SLAVE

• PPIDE: IO=32, MASTER

• PPIDE: IO=32, SLAVE

### Notes:

### 2.30 Z80-Retro SBC

ROM Image File: Z80RETRO\_std.rom

14.745 MHz
Mode 2
None
38400 Baud
Z2
512 KB
512 KB

### **Supported Hardware**

- SIO MODE=Z80R, IO=128, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=Z80R, IO=128, CHANNEL B, INTERRUPTS ENABLED
- MD: TYPE=RAM
- MD: TYPE=ROM
- SD: MODE=Z80R, IO=104, UNITS=1

# 2.31 S100 Computers Z180

ROM Image File: S100\_std.rom

Default CPU Speed	18.432 MHz
Interrupts	Mode 2
System Timer	Z180
Serial Default	57600 Baud
Memory Manager	Z180
ROM Size	512 KB
RAM Size	512 KB

### **Supported Hardware**

• INTRTC: ENABLED

ASCI: IO=192, INTERRUPTS ENABLED
ASCI: IO=193, INTERRUPTS ENABLED

SCON: IO=0MD: TYPE=RAMMD: TYPE=ROM

• SD: MODE=SC, IO=12, UNITS=1

### Notes:

• Z180 SBC SW2 (IOBYTE) Dip Switches:

Bit	Setting	Function
0	Off On	Use Z180 ASCI Channel A for console Use Propeller Console
1	Off On	Boot to RomWBW Boot Loader Boot to S100 Monitor

## 2.32 Duodyne Z80 System

**ROM Image File: DUO\_std.rom** 

Default CPU Speed 8.000 MHz
Interrupts Mode 2
System Timer CTC
Serial Default 38400 Baud
Memory Manager Z2
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

FP: LEDIO=66, SWIO=66DSRTC: MODE=STD, IO=148

PCF: IO=86UART: IO=88UART: IO=168UART: IO=112UART: IO=120

- SIO MODE=ZP, IO=96, CHANNEL A, INTERRUPTS ENABLED
- SIO MODE=ZP, IO=96, CHANNEL B, INTERRUPTS ENABLED
- LPT: MODE=SPP, IO=72
- DMA: MODE=DUO, IO=64CH: IO=78

CHUSB: IO=78CHSD: IO=78MD: TYPE=RAM

MD: TYPE=ROM

• FD: MODE=DUO, IO=128, DRIVE 0, TYPE=3.5" HD

FD: MODE=DUO, IO=128, DRIVE 1, TYPE=3.5" HD

• PPIDE: IO=136, MASTER

• PPIDE: IO=136, SLAVE

• SD: MODE=MT, IO=140, UNITS=1

• SPK: IO=148

• CTC: IO=96, TIMER MODE=COUNTER, DIVISOR=18432, HI=256, LO=72, INTERRUPTS ENABLED

## 2.33 Heath H8 Z80 System

ROM Image File: HEATH\_std.rom

Default CPU Speed 16.384 MHz
Interrupts Mode 1
System Timer None
Serial Default 115200 Baud
Memory Manager Z2
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

• H8P: IO=240

INTRTC: ENABLED

UART: IO=232

• UART: IO=224

• UART: IO=216

• UART: IO=208

• TMS: MODE=MSX, IO=152, SCREEN=80X24, KEYBOARD=NONE

• MD: TYPE=RAM

• MD: TYPE=ROM

• FD: MODE=RCWDC, IO=80, DRIVE 0, TYPE=3.5" HD

• FD: MODE=RCWDC, IO=80, DRIVE 1, TYPE=3.5" HD

• PPIDE: IO=32, MASTER

• PPIDE: IO=32, SLAVE

AY38910: MODE=MSX, IO=160, CLOCK=1789772 HZ

### 2.34 EP Mini-ITX Z180

ROM Image File: EPITX\_std.rom

Default CPU Speed 18.432 MHz
Interrupts Mode 2
System Timer Z180
Serial Default 115200 Baud
Memory Manager Z180
ROM Size 512 KB
RAM Size 512 KB

### **Supported Hardware**

INTRTC: ENABLED

ASCI: IO=192, INTERRUPTS ENABLED
ASCI: IO=193, INTERRUPTS ENABLED

UART: IO=160UART: IO=168

• TMS: MODE=MSX, IO=152, SCREEN=40X24, KEYBOARD=NONE

MD: TYPE=RAMMD: TYPE=ROM

- FD: MODE=EPFDC, IO=72, DRIVE 0, TYPE=3.5" HD

• FD: MODE=EPFDC, IO=72, DRIVE 1, TYPE=3.5" HD

• SD: MODE=EPITX, IO=66, UNITS=1

#### NABU w/ RomWBW Option Board 2.35

ROM Image File: NABU\_std.rom

Default CPU Speed 3.580 MHz Interrupts Mode 2 System Timer **TMS** Serial Default 115200 Baud

Memory Manager Z2 **ROM Size** 512 KB **RAM Size** 512 KB

### **Supported Hardware**

• NABU: IO=64 · INTRTC: ENABLED • UART: IO=72

• TMS: MODE=NABU, IO=160, SCREEN=80X24, KEYBOARD=NABU, INTERRUPTS EN-**ABLED** 

 NABUKB: IO=144 MD: TYPE=RAM MD: TYPE=ROM

• PPIDE: IO=96, MASTER • PPIDE: IO=96, SLAVE

AY38910: MODE=NABU, IO=65, CLOCK=1789772 HZ

### Notes:

• TMS video assumes F18A replacement for TMS9918

### 2.36 S100 FPGA Z80

ROM Image File: FZ80\_std.rom

Default CPU Speed 8.000 MHz
Interrupts None
System Timer None
Serial Default 9600 Baud
Memory Manager Z2
ROM Size 0 KB
RAM Size 512 KB

### **Supported Hardware**

• FP: LEDIO=255

• DS5RTC: RTCIO=104, IO=104

SSER: IO=52

• LPT: MODE=S100, IO=199

• FV: IO=192, KBD MODE=FV, KBD IO=3

KBD: ENABLEDSCON: IO=0MD: TYPE=RAM

PPIDE: IO=48, MASTERPPIDE: IO=48, SLAVE

SD: MODE=FZ80, IO=108, UNITS=2

### Notes:

· Requires matching FPGA code

### 2.37 **Genesis STD Z180**

### ROM Image File: GMZ180\_std.rom

Default CPU Speed 18.432 MHz Interrupts Mode 2 System Timer Z180

Serial Default 115200 Baud

Memory Manager Z180

ROM Size	512 KB
RAM Size	512 KB

### **Supported Hardware**

• GM7303: IO=48

• DSRTC: MODE=STD, IO=132

INTRTC: ENABLED

ASCI: IO=192, INTERRUPTS ENABLED
ASCI: IO=193, INTERRUPTS ENABLED

MD: TYPE=RAMMD: TYPE=ROM

IDE: MODE=GIDE, IO=32, MASTER
IDE: MODE=GIDE, IO=32, SLAVE
SD: MODE=GM, IO=132, UNITS=1

### Notes:

# **Chapter 3**

# **Device Drivers**

This section briefly describes each of the possible devices that may be discovered by RomWBW in your system.

### 3.1 Character

ID	Description
ACIA	MC68B50 Asynchronous Communications Interface Adapter
ASCI	Zilog Z180 CPU Built-in Serial Ports
DUART	SCC2681 or compatible Dual UART
ESPCON	ESP32 Firmware-based Video Console
ESPSER	ESP32 Firmware-based Serial Interface
EZ80UART	eZ80 Serial Interface
LPT	Parallel I/O Controller
PIO	Zilog Parallel Interface Controller
PPPCON	ParPortProp Serial Console Interface
PRPCON	PropIO Serial Console Interface
SCON	S100 Console
SIO	Zilog Serial Port Interface
SSER	Simple Serial Interface
UART	16C550 Family Serial Interface
USB-FIFO	FT232H-based ECB USB FIFO
Z2U	Zilog Z280 CPU Built-in Serial Ports

By default, RomWBW will use the first available character device it discovers for the initial

console. The following character devices are scanned in the order shown. The available character devices depend on the active platform and configuration.

- 1. SSER: Simple Serial Interface
- 2. ASCI: Zilog Z180 CPU Built-in Serial Ports
- 3. Z2U: Zilog Z280 CPU Built-in Serial Ports
- 4. UART: 16C550 Family Serial Interface
- 5. DUART: SCC2681 or compatible Dual UART
- 6. SIO: Zilog Serial Port Interface
- 7. EZ80UART: eZ80 Serial Port Interface
- 8. ACIA: MC68B50 Asynchronous Communications Interface Adapter
- 9. USB-FIFO: FT232H-based ECB USB FIFO

### **3.2** Disk

ID	Description
CHSD	CH37x SD Card Interface
CHUSB	CH37x USB Drive Interface
FD	8272 or compatible Floppy Disk Controller
HDSK	SIMH Simulator Hard Disk
IDE	IDE/ATA/ATAPI Hard Disk Interface
IMM	Zip Drive on PPI (IMM variant)
MD	ROM/RAM Disk
PPA	Zip Drive on PPI (PPA variant)
PPIDE	8255 IDE/ATA/ATAPI Hard Disk Interface
PPPSD	ParPortProp SD Card Interface
PRPSD	PropIO SD Card Interface
RF	RAM Floppy Disk Interface
SD	SD Card Interface
SYQ	Iomega SparQ Drive on PPI

### 3.3 Video

ID	Description
CVDU	MC8563-based Video Display Controller
EF	EF9345 Video Display Controller
FV	S100 FPGA Z80 Onboard VGA/Keyboard

ID	Description
GDC	uPD7220 Video Display Controller
TMS	TMS9918/38/58 Video Display Controller
VDU	MC6845 Family Video Display Controller
VGA	HD6445CP4-based Video Display Controller
VRC	VGARC Video Display Controller

# 3.4 Keyboard

ID	Description
KBD	8242 PS/2 Keyboard Controller
MSXKYB	MSX Compliant Matrix Keyboard
NABUKB	NABU Keyboard
PPK	Matrix Keyboard

## 3.5 Audio

ID	Description
AY	AY-3-8910/YM2149 Programmable Sound Generator
SN76489	SN76489 Programmable Sound Generator
SPK	Bit-bang Speaker
YM	YM2612 Programmable Sound Generator

# 3.6 RTC (RealTime Clock)

ID	Description
BQRTC	BQ4845P Real Time Clock
DS5RTC	Maxim DS1305 SPI Real-Time Clock w/ NVRAM
DS7RTC	Maxim DS1307 PCF I2C Real-Time Clock w/ NVRAM
DS1501RTC	Maxim DS1501/DS1511 Watchdog Real-Time Clock
DSRTC	Maxim DS1302 Real-Time Clock w/ NVRAM
EZ80RTC	eZ80 Real-Time Clock
INTRTC	Interrupt-based Real Time Clock

ID	Description
PCF	PCF8584-based I2C Real-Time Clock
RP5C01	Ricoh RPC01A Real-Time Clock w/ NVRAM
SIMRTC	SIMH Simulator Real-Time Clock

# 3.7 DsKy (DiSplay KeYpad)

ID	Description
FP	Simple LED & Switch Front Panel
GM7303	Prolog 7303 derived Display/Keypad
H8P	Heath H8 Display/Keypad
ICM	ICM7218-based Display/Keypad on PPI
LCD	Hitachi HD44780-based LCD Display
PKD	P8279-based Display/Keypad on PPI

# 3.8 System

ID	Description
СН	CH375/376 USB Interface Controller
CTC	Zilog Clock/Timer
DMA	Zilog DMA Controller
ESP	ESP32 Firmware-based interface
EZ80TIMER	eZ80 System Timer
KIO	Zilog Serial/ Parallel Counter/Timer
PPP	ParPortProp Host Interface Controller
PRP	PropIO Host Interface Controller

# **Chapter 4**

## **UNA Hardware BIOS**

John Coffman has produced a new generation of hardware BIOS called UNA. The standard RomWBW distribution includes its own hardware BIOS. However, RomWBW can alternatively be constructed with UNA as the hardware BIOS portion of the ROM. If you wish to use the UNA variant of RomWBW, then just program your ROM with the ROM image called "UNA\_std.rom" in the Binary directory. This one image is suitable on **all** of the platforms and hardware UNA supports.

UNA is customized dynamically using a ROM based setup routine and the setup is persisted in the system NVRAM of the RTC chip. This means that the single UNA-based ROM image can be used on most of the RetroBrew platforms and is easily customized. UNA also supports FAT file system access that can be used for in-situ ROM programming and loading system images.

While John is likely to enhance UNA over time, there are currently a few things that UNA does not support:

- Floppy Drives
- · Terminal Emulation
- Zeta 1, N8, RCBus, Easy Z80, and Dyno Systems
- Some older support boards

The UNA version embedded in RomWBW is the latest production release of UNA. RomWBW will be updated with John's upcoming UNA release with support for VGA3 as soon as it reaches production status.

Please refer to the UNA BIOS Firmware Page for more information on UNA.

### 4.1 UNA Usage Notes

· At startup, UNA will display a prompt similar to this:

```
Boot UNA unit number or ROM? [R,X,0..3] (R):
```

You generally want to choose 'R' which will then launch the RomWBW loader. Attempting to boot from a disk using a number at the UNA prompt will only work for the legacy (hd512) disk format. However, if you go to the RomWBW loader, you will be able to perform a disk boot on either disk format.

- The disk images created and distributed with RomWBW do not have the correct system
  track code for UNA. In order to boot to disk under UNA, you must first use SYSCOPY to
  update the system track of the target disk. The UNA ROM disk has the correct system
  track files for UNA: CPM. SYS and ZSYS. SyS. So, you can boot a ROM OS and then use
  one of these files to update the system track.
- The only operating systems supported at this time are CP/M 2 and ZSDOS. NZ-COM
  is also supported because it uses the ZSDOS CBIOS. None of the other RomWBW
  operating systems are supported such as CP/M 3, ZPM3, and p-System.
- · Some of the RomWBW-specific applications are not UNA compatible.

# **Chapter 5**

## **Errata**

The following errata apply to RomWBW Version 3.5:

- The use of high density floppy disks requires a CPU speed of 8 MHz or greater.
- The PropIO support is based on RomWBW specific firmware. Be sure to program/update your PropIO firmware with the corresponding firmware image provided in the Binary directory of the RomWBW distribution.
- Reading bytes from the video memory of the VDU board (not Color VDU) appears to be problematic. This is only an issue when the driver needs to scroll a portion of the screen which is done by applications such as WordStar or ZDE. You are likely to see screen corruption in this case.
- The RomWBW TUNE application will detect an AY-3-8910/YM2149 Sound Module regardless of whether support for it is included in the RomWBW HBIOS configuration.