

计算机组成与设计

Computer Organization & Design The Hardware/Software Interface

Chapter 2

Instructions: Language of the Machine

Ma De 马德

College of Computer Science and Technology Zhejiang University made@zju.edu.cn

The process of compiling



- Machine language(机器语言)
 - Computers only understands electrical signalson/off
 - Binary numbers express machine instructions
 - ex. 1000110010100000 means to add two numbers
- □ Assembly language(汇编语言)
 - Symbolic notations ex. add A, B
 - The assembler translates them into machine instruction
- □ High-level programming language(高级编程语言)
 - Notations more closer to the natural language ex. A + B
 - The compiler translates into assembly language
 - Advantages over assembly language
 - □ Think in a more natural language
 - Programs can be independent of hardware

High-level language program (in C)

Assembly language program (for MIPS)

Binary machine

language

program

(for MIPS)

temp = v[k]; v[k] = v[k+1]; v[k+1] = temp; } C compiler swap: muli \$2, \$5,4 add \$2, \$4,\$2 lw \$15, 0(\$2) lw \$16, 4(\$2)

swap(int v∏, int k)

{int temp;



ir \$31

\$16, 0(\$2) \$15, 4(\$2)

浙江大学系统结构与网络安全研究所

Outline



- **■** Introduction
- □ Operations of the computer hardware (计算机硬件的操作)
- □ Operands of the computer hardware(计算机硬件的操作数)
- □ Signed and unsigned numbers (有符号和无符号数)
- □ Representing instructions in the computer(计算机中指令的表示)
- □ Logical operations(逻辑操作)
- □ Instructions for making decision(决策指令)
- □ Supporting procedures in computer hardware(计算机对过程的支持)
- □ Instruction addressing (指令的寻址)



2.1 Introduction



- **□** Language of the machine
 - Instructions → Statement
 - Instruction set \rightarrow Syntax
- Design goals
 - Maximize performance
 - Minimize cost
 - Reduce design time
- **□** Our chosen instruction set: RISC-V
 - Developed at Berkeley starting in 2010



The RISC-V Instruction Set



- □ Used as the example throughout the book
- **□** Developed at UC Berkeley as open ISA
- □ Now managed by the RISC-V Foundation (<u>riscv.org</u>)
- **□** Typical of many modern ISAs
 - See RISC-V Reference Data tear-out card
- □ Similar ISAs have a large share of embedded core market
 - Applications in consumer electronics, network/storage equipment, cameras, printers, ...




Instruction characteristics wide variety



Op	Operands
Operators	wide variety

- **■** Type of internal storage in processor
- **■** The number of the memory operand In the instruction
- **□** Operations in the instruction Set
- **□** Type and Size of Operands
- **□** Representing Instructions in the Computer
 - Encoding





系统结构与网络安全研究所

Stored-program concept



- □ Today's computers are built on 2 key principles: (Stored-program concept)
 - ①Instruction are represented as numbers.
 - ②Programs can be stored in memory to be read or written just like numbers.

Von Neumann' Computer



2.2 Operations

of the Computer Hardware



- Every computer must be able to perform arithmetic
 - Only one operation per instruction
 - Exactly three variables add a,b,c a←b+c
- All arithmetic operations have this form
- □ Design Principle 1: Simplicity favors regularity
 - Regularity makes implementation simpler
 - Simplicity enables higher performance at lower cost



Arithmetic



■ Example 2.2 Compiling a complex C statement

C code:

$$f = (g + h) - (i + j);$$

RISC-V code:

```
add t0, g, h # temporary variable t0 contains g + h add t1, i, j # temporary variable t1 contains i + j sub f, t0, t1 # f gets t0 - t1
```

RISC-V assembly language

Category	Instruction	Example	Meaning	Comments
Arithmetic	add	add a,b,c	a←b+c	Always three operand
Anumeuc		sub a,b,c	a←b - c	Always three operand



2.3 Operands of the Computer Hardware



□ Arithmetic instructions use register operands

□ RISC-V has a 32 × 64-bit register file

- Use for frequently accessed data
- 64-bit data is called a "doubleword"
 32 x 64-bit general purpose registers x0 to x31
- 32-bit data is called a "word"

□ *Design Principle 2:* Smaller is faster

• c.f. main memory: millions of locations



RISC-V Registers



Name	Register	Usage	Preserved
	name		On call?
x0	0	The constant value 0	n.a.
x1(ra)	1	Return address(link register)	yes
x2(sp)	2	Stack pointer	yes
x3(gp)	3	Global pointer	yes
x4(tp)	4	Thread pointer	yes
x5-x7	5-7	Temporaries	no
x8-x9	8-9	Saved	yes
x10-x17	10-17	Arguments/results	no
x18-x27	18-27	Saved	yes
x28-x31	28-31	Temporaries	no



Register Operand Example



□ C code:

$$f = (g + h) - (i + j);$$

• f, ..., j in x19, x20, ..., x23

□ Compiled RISC-V code:


```
add x5, x20, x21
add x6, x22, x23
sub x19, x5, x6
```

Memory Operands



- **■** Main memory used for composite data
 - Arrays, structures, dynamic data
- **□** To apply arithmetic operations
 - Load values from memory into registers
 - Store result from register to memory
- **■** Memory is byte addressed
 - Each address identifies an 8-bit byte
- **□** RISC-V is Little Endian
 - Least-significant byte at least address of a word
 - c.f. Big Endian: most-significant byte at least address
- RISC-V does not require words to be aligned in memory
 - Unlike some other ISAs





Memory Alignment



正确

struct {
 int a;
 char b;
 char c[2];
 char d[3]
 float e;

e					
d[1]	d[2]	No use	No use		
b	c[0]	d[0]			
a					

错误

e		No use	No use		
d[1]	d[2]	e			
b	c[0]	c[1] d[0]			
a					


因为一次只能读出4字 节内存中的一行 这样布局,e变量不能 一次读出




Endianness/byte order



- □ Big end: Left Least Addr.
 - PowerPC
 - Byte1:01 Byte0:02 = 513
- □ Little end: Right Least Addr.
 - RISC-V
 - Byte1:01 Byte0:02 = 258
- **□** Bi-endian
 - MIPS, ARM, Alpha, SPARC



Memory





Memory Operand Example



□ C code:

$$A[12] = h + A[8];$$

h in x21, base address of A in x22

□ Compiled RISC-V code:

- Index 8 requires offset of 64
 - 8 bytes per doubleword
- Offset: the constant in a data transfer instruction
- Base register: the register added to form the address

```
1d x9, 64(x22)
add x9, x21, x9
sd x9, 96(x22)
```



Register vs. Memory



- □ Registers are faster to access than memory
- □ Operating on memory data requires loads and stores
 - More instructions to be executed
- □ Compiler must use registers for variables as much as possible
 - Only spill to memory for less frequently used variables
 - Register optimization is important!



Discussion: How to represent?



Constant

g = h + 55


Many time a program will use a constant in an operation

Constant or immediate Operands



- Many time a program will use a constant in an operation
 - Incrementing index to point to next element of array
 - Add the constant 4 to register x9
 - Assuming AddrConstants 4 is address pointer of constant 4

ld x9, AddrConstant4(x3) // x9=constant 4 add x22, x22, x9



x3

- **■** Immediate: Other method for adding constant 4 to x22
 - Avoids the load instruction
 - Offer versions of the instruction

addi x22, x22, 4 // x22 = x22 + 4

- Constant zero: a register x0
- **■** Design Principle 3: Make common case fast (Why?)



Brief summary



RISC-V operands

Name	Example	Comments
32 register	x0~x31	Fast locations for data. In RISC-V, data must be in registers to perform arithmetic.
		Register x0 always equals 0.
2 ⁶¹	Memory[0], Memory[8],,	Accessed only by data transfer instructions. RISC-V uses byte addresses,
memory double words	Memory[18446744073709 551608]	so sequential doubleword accesses differ by 8. Memory holds data structures, arrays, and spilled registers.

RISC-V assembly language

Category	Instruction	Example	Meaning	Comments
	add	add x5,x6,x7	x5=x6 + x7	Add two source register operands
Arithmetic	subtract	sub x5,x6,x7	x5=x6 - x7	First source register subtracts second one
	add immediate	addi x5,x6,20	x5=x6+20	Used to add constants
Data transfer	load doubleword	ld x5, 40(x6)	x5=Memory[x6+40]	doubleword from memory to register
Data transfer	store doubleword	sd x5, 40(x6)	Memory[x6+40]=x5	doubleword from register to memory



沙人曾系统结构与网络安全研究所

2.4 Signed and unsigned numbers



- Bits are just bits (no inherent meaning): conventions define relationship between bits and numbers
- □ Binary numbers (base 2) 0000 0001 0010 0011 0100 0101 0110 0111 1000 1001... decimal: 0...2ⁿ-1
- □ Of course it gets more complicated: numbers are finite (overflow) fractions and real numbers negative numbers
- How do we represent negative numbers? which bit patterns will represent which numbers?



Unsigned Binary Integers



☐ Given an n-bit number

$$x = x_{n-1} 2^{n-1} + x_{n-2} 2^{n-2} + \dots + x_1 2^1 + x_0 2^0$$

- \square Range: 0 to $+2^n 1$
- **■** Example
 - **0000 0000 ... 0000 1011**₂ $= 0 + ... + 1 \times 2^3 + 0 \times 2^2 + 1 \times 2^1 + 1 \times 2^0$ $= 0 + ... + 8 + 0 + 2 + 1 = 11_{10}$
- □ Using 64 bits: 0 to +18,446,774,073,709,551,615

2s-Complement Signed Integers



☐ Given an n-bit number

$$x = -x_{n-1}2^{n-1} + x_{n-2}2^{n-2} + \dots + x_12^1 + x_02^0$$

- □ Range: -2^{n-1} to $+2^{n-1}-1$
- **■** Example
 - 1111 1111 ... 1111 1100₂ $=-1\times2^{31}+1\times2^{30}+...+1\times2^{2}+0\times2^{1}+0\times2^{0}$ $=-2,147,483,648+2,147,483,644=-4_{10}$
- □ Using 64 bits: -9,223,372,036,854,775,808 to 9,223,372,036,854,775,807



2s-Complement Signed Integers



- □ Bit 63 is sign bit
 - 1 for negative numbers
 - 0 for non-negative numbers
- \Box -(-2ⁿ⁻¹) can't be represented
- Non-negative numbers have the same unsigned and 2s-complement representation
- **□** Some specific numbers
 - **0**: 0000 0000 ... 0000
 - −1: 1111 1111 ... 1111
 - Most-negative: 1000 0000 ... 0000
 - Most-positive: 0111 1111 ... 1111



Signed Negation



□ Complement and add 1

■ Complement means $1 \rightarrow 0, 0 \rightarrow 1$

$$x + x = 1111...111_2 = -1$$

 $x + 1 = -x$

■ Example: negate +2

 $- +2 = 0000 \ 0000 \ \dots \ 0010_{\text{two}}$

$$-2 = 1111 \ 1111 \dots 1101_{\text{two}} + 1$$

= 1111 1111 \dots 1110_{\text{two}}



2.5 Representing Instructions in the computer



- □ All information in computer consists of binary bits
- **□** Instructions are encoded in binary
 - Called machine code
- **■** Mapping registers into numbers
 - map registers x0 to x31 onto registers 0 to 31

□ RISC-V instructions

- Encoded as 32-bit instruction words
- Small number of formats encoding operation code (opcode), register numbers, ...
- Regularity



Example: Translating assembly code



■ (p81) Translating assembly into machine instruction

RISC-V code

add x9, x20, x21

Decimal version of machine code

0 21 20 0 9 51

Binary version of machine code



Hexadecimal



□ Base 16

- Compact representation of bit strings
- 4 bits per hex digit

0	0000	4	0100	8	1000	С	1100
1	0001	5	0101	9	1001	d	1101
2	0010	6	0110	а	1010	е	1110
3	0011	7	0111	b	1011	f	1111

■ Example: eca8 6420

1110 1100 1010 1000 0110 0100 0010 0000



RISC-V R-Format Instructions



funct7	rs2	rs1	funct3	rd	opcode
7 bits	5 bits	5 bits	3 bits	5 bits	7 bits

■ Instruction fields

- opcode: operation code
- rd: destination register number
- funct3: 3-bit function code (additional opcode)
- rs1: the first source register number
- rs2: the second source register number
- funct7: 7-bit function code (additional opcode)
- Design Principle 3
 - Good design demands good compromises
- All instructions in RISC-V have the same length
 - Conflict: same length ←--→ single instruction



R-format Example



funct7	rs2	rs1	funct3	rd	opcode
7 bits	5 bits	5 bits	3 bits	5 bits	7 bits

add x9, x20, x21

0	21	20	0	9	51
0000000	10101	10100	000	01001	0110011

0000 0001 0101 1010 0000 0100 1011 $0011_{two} = 015A04B3_{16}$



RISC-V I-Format Instructions



immediate	rs1	funct3	rd	opcode
12 bits	5 bits	3 bits	5 bits	7 bits

■ Immediate arithmetic and load instructions

- rs1: source or base address register number
- immediate: constant operand, or offset added to base address
 - 2s-complement, sign extended

□ Design Principle 3: Good design demands good compromises

- Different formats complicate decoding, but allow 32-bit instructions uniformly
- Keep formats as similar as possible

\square Example: Id x9, 64(x22)

- 22 (x22) is placed rs1;
- 64 is placed immediate
- 9 (x9) is placed rd



RISC-V S-Format Instructions



imm[11:5]	rs2	rs1	funct3	imm[4:0]	opcode
7 bits	5 bits	5 bits	3 bits	5 bits	7 bits

□ Different immediate format for store instructions

- rs1: base address register number
- rs2: source operand register number
- immediate: offset added to base address
 - □ Split so that rs1 and rs2 fields always in the same place

\square Example: sd x9, 64(x22)

- 22 (x22) is placed rs1;
- 64 is placed immediate
- 9 (x9) is placed rs2



RISC-V instruction encoding



Name	Format	Example					Comment	
add	R	0	3	2	0	1	51	add x1, x2, x3
sub	R	32	3	2	0	1	51	sub x1, x2, x3
addi	I	10	000	2	0	1	19	addi x1,x2,1000
ld	I	1000		2	3	1	3	ld x1, 1000(x2)
sd	S	31	1	2	3	8	35	sd x1, 1000(x2)

Example



■ Example(p85) Translating assembly into machine instruction

C code:

```
A[30] = h + A[30] + 1;
(Assume: h ---- x21 base address of A ---- x10)
```

RISC-V assembly code:

```
ld x9, 240(x10)  // temporary reg x9 gets A[30]
add x9, x21, x9  // temporary reg x9 gets h + A[30]
addi x9, x9, 1  // temporary reg x9 gets h + A[30] + 1
sd x9, 240(x10)  // stores h + A[30] + 1 back into A[30]
```

RISC-V machine language code:

Decimal version

ld	immediate	rs1	funct3	rd	opcode
	240	10	3	9	3





add	funct7	rs2	rs1	l fur	ict3	rd	opcode
	0	9	21	0		9	51
addi	immedia	te r	s1 f	unct3	rd	opco	ode
	1	9		0	9	19	
sd	im[11:5]	rs2	rs1	funct	3	im[4:0]	opcode
	7	9	10	3		16	35

■ Two key principles of today's computers

- Instructions are represented as numbers
- Programs can be stored in memory like numbers





RISC-V fields (format)

THE UNITED

Imm Region: ±2¹¹

Name		Comments					
Field size	31 7bits 25	24 <i>5bits</i> 20	19 <i>5bits</i> 15	14 3bits 12	11 5bits 7	$_6$ 7bits $_0$	All RISC-V instruction 32 bits
R-type	funct7	rs2	rs1	funct3	rd	opcode	Arithmetic instruction format
I-type	immediate[11:0]		rs1	funct3	rd	opcode	Loads & immediate arithmetic
S-type	immed[11:5]	rs2	rs1	funct3	immed[4:0]	opcode	Stores
SB-type	imm[12,10:5]	rs2	rs1	funct3	imm[4:1,11]	opcode	Conditional branch format
UJ-type	immed	iate[20,10:	1,11,19:12	rd	opcode	Unconditional jump format	
U-type	iı	mmediate[3	31:12]		rd	opcode	Upper immediate format

op: basic operation of the instruction, traditionally called the opcode.

rd: *destination register number.*

funct3: 3-bit function code (additional opcode).

rs1: *the first register source operand.*

rs2: the second register source operand.

□ **funct7** 7-bit function code (additional opcode).



MIPS fields (format)



Field size	6bits	5bits	5bits	5bits	5bits	6bits	All MIPS instruction 32 bits
R-format	ор	rs	rt	rd shamt funct Arithmetic instruction		Arithmetic instruction format	
i-format	ор	rs	rt	Imm	Imm/Word address		Data transfer ,branch format
J-format	ор		target address (word) Unconditional jump			Unconditional jump	

Region: ±2¹⁵

□ op: basic operation of the instruction, traditionally called the opcode.

□ rs: the first register source operand.

the second register source operand.

rd: the register destination operand.

□ shamt: shift amount.

■ **funct**: function, this field selects the specific variant of the operation in the op field.



Stored Program Computer



The BIG Picture

Memory Accounting program (machine code) Editor program (machine code) C compiler (machine code) Payroll data Book text Source code in C for editor program

■ Instructions represented in binary, just like data

■ Instructions and data stored in memory

Programs can operate on programs

• e.g., compilers, linkers, ...

■ Binary compatibility allows compiled programs to work on different computers

Standardized ISAs



Processor

2.6 Logical Operations



■ Instructions for bitwise manipulation

Operation	С	Java	RISC-V
Shift left	<<	<<	slli
Shift right	>>	>>>	srli
Bit-by-bit AND	&	&	and, andi
Bit-by-bit OR			or, ori
Bit-by-bit XOR	٨	۸	xor, xori
Bit-by-bit NOT	~	~	

□ Useful for extracting and inserting groups of bits in a word



Shift Operations



funct6	immed	rs1	funct3	rd	opcode
6 bits	6 bits	5 bits	3 bits	5 bits	7 bits

- □ immed: how many positions to shift
- □ Shift left logical
 - Shift left and fill with 0 bits
 - slli by *i* bits multiplies by 2^i
- □ Shift right logical
 - Shift right and fill with 0 bits
 - **srli** by *i* bits divides by 2^i (unsigned only)



AND Operations



□ Useful to mask bits in a word

Select some bits, clear others to 0

and x9,x10,x11

x10	00000000 00000000 00000000 00000000 0000	0011	01 11000000
4.4			
x11	00000000 00000000 00000000 00000000 0000	1111	00 00000000
	00000000 00000000 00000000 00000000 0000	<u></u>	00 0000000
x9	0000000 0000000 0000000 0000000 0000000	0011	00 0000000



OR Operations



□ Useful to include bits in a word

Set some bits to 1, leave others unchanged

or x9, x10, x11

x10	00000000 00000000 00000000 00000000 0000	001101 11	000000
x11	00000000 00000000 00000000 00000000 0000	111100 00	000000
x9	00000000 00000000 00000000 00000000 0000	111101 110	000000



XOR Operations



□ Differencing operation

Set some bits to 1, leave others unchanged

xor x9, x10, x12 // NOT operation

x10	0000000	00000000	00000000	00000000	00000000	00000000	0000	1101	11(000000
x12	11111111	11111111	11111111	11111111	11111111	11111111	1111	1111	11 ⁻	111111
x9	11111111	11111111	11111111	11111111	11111111	11111111	1111	0010	00	111111



RISC-V operands

Name	Example	Comments
32 registers	x0-x31	Fast locations for data. In RISC-V, data must be in registers to perform arithmetic. Register x0 always equals 0.
2 ⁶¹ memory double words	Memory[0], Memory[8],, Memory[18,446,744,073,7 09,551,608]]	Accessed only by data transfer instructions. RISC-V uses byte addresses, so sequential double word accesses differ by 8. Memory holds data structures, arrays, and spilled registers.

RISC-V assembly language

			. · · · · · · · · · · · · · · · · · · ·	
Category	Instruction	Example	Meaning	Comments
	and	and x5, x6, 3	x5=x6 & 3	Arithmetic shift right by register
	inclusive or	or x5,x6,x7	x5=x6 x7	Bit-by-bit OR
	exclusive or	xor x5,x6,x7	x5=x6 ^ x7	Bit-by-bit XOR
Logical	and immediate	andi x5,x6,20	x5=x6 & 20	Bit-by-bit AND reg. with constant
	inclusive or immediate	ori x5,x6,20	x5=x6 20	Bit-by-bit OR reg. with constant
	exclusive or immediate	xori x5,x6,20	X5=x6 ^ 20	Bit-by-bit XOR reg. with constant
	shift left logical	sll x5, x6, x7	x5=x6 << x7	Shift left by register
Shift	shift right logical	srl x5, x6, x7	x5=x6 >> x7	Shift right by register
	shift right arithmetic	sra x5, x6, x7	x5=x6 >> x7	Arithmetic shift right by register
	shift left logical immediate	slli x5, x6, 3	x5=x6 << 3	Shift left by immediate



浙江人乡系统结构与网络安全研究所

2.7 Instructions for making decisions



■ Branch instructions

- beq register1, register2, L1
- bne register1, register2, L1

■ Example 2.9 Compiling an *if* statement to a branch (Assume: $f \sim j - x19 \sim x23$)

C code:

```
if(i == j) goto L1;

f = g + h;

L1: f = f - i;
```

RISC-V assembly code:

```
beq x21, x22, L1 # go to L1 if i equals j add x19, x20, x21 # f = g + h (skipped if i equals j) L1: sub x19, x19, x22 # f = f - i (always executed)
```



Branch



 $i \uparrow j$

F=g-h

i==j?

□ Example 2.10

Compiling *if-then-else* into Conditional Branches

(Assume: $f \sim j$ ---- x19 ~ x23)

C code:

(RISCV assembly code:

beq x0, x0, EXIT / # go to Exit

..... statement

bne x22, x23, Else
$$/\#$$
 go to Else if i != j $/\#$ Exit:
add x19, x20, x21 $/\#$ f = g + h (Executed if i == j $/\#$ if)

F=g+h

Else: sub x19, x20, x21 # f = g - h (Executed if $i \neq j$ else)

the first instruction of the next C



Exit:

Supports LOOPs



■ Example 2.11 Compiling a loop with variable array index

```
(Assume: g \sim j ---- x19 \sim x23 base of A[i] ---- x25)
```

C code:

```
Loop: g = g + A[i]; // A is an array of 100 words i = i + j; if (i != h) goto Loop;
```

RISC-V assembly code:

```
Loop: slli x10, x22, 3 # temp reg x10 = 8 * i

add x10, x10, x25 # x10 = address of A[i]

ld x19, 0(x10) # temp reg x19 = A[i]

add x20, x20, x19 # g = g + A[i]

add x22, x22, x23 # i = i + j

bne x22, x21, Loop # go to Loop if i != h
```

Supports while



■ Example 2.12 Compiling a while loop

```
(Assume: i \sim k---- x22 and x24 base of save ---- x25)
```

C code:

```
while ( save[i] = = k )

i = +i;
```

RISCV assembly code:

```
Loop: slli x10, x22, 3
add x10, x10, x25
ld x9, 0(x10)
bne x9, x24, Exit
addi x22, x22, 1
beq x0, x0, Loop

Exit:
```

```
# temp reg $t1 = 8 * i
# x10 = address of save[i]
# x9 gets save[i]
# go to Exit if save[i] != k
# i += 1
# go to Loop
```

Most popular Compare Operation



-- set on less than : slt

- □ set on less than -slt
 - If the first reg. is less than second reg. then sets third reg to 1 slt x5, x19, x20 # x5=1 if x19 < x20
- Example 2.13 Compiling a less than test

```
(Assume: a - s0 b - s1)
```

C language:

if
$$(a < b)$$
, goto Less

RISCV assembly code:

```
slt x5, x8, x9 \#x5 = 1 if x8 < x9 (a < b)
bne x5, zero, Less \# go to Less if x5 != 0 (that is, if a < b)
```

Less:



More Conditional Operations



- □ blt rs1, rs2, L1
 - if (rs1 < rs2) branch to instruction labeled L1
- **□** bge rs1, rs2, L1
 - if $(rs1 \ge rs2)$ branch to instruction labeled L1
- **■** Example
 - if (a > b) a += 1;
 - a in x22, b in x23
 bge x23, x22, Exit # branch if b >= a
 addi x22, x22, 1

Exit:



Signed vs. Unsigned



- □ Signed comparison: blt, bge
- □ Unsigned comparison: bltu, bgeu
- **■** Example

 - x22 < x23 # signed □-1 < +1

Hold out Case/Switch




- used to select one of many alternatives
- **■ Example 2.14**

```
Compiling a switch using jump address table (Assume: f \sim k --x20 \sim x25 x5 contains 4/8)

C code:
   switch ( k ) {
      case 0: f = i + j; break; /* k = 0 */
      case 1: f = g + h; break; /* k = 1 */
      case 2: f = g - h; break; /* k = 2 */
      case 3: f = i - j; break; /* k = 3 */
}
```

Jump register & jump address table





RISC-V assembly code:



```
x25, x0, Exit
                                              # test if k < 0
     Boundary
                      bge x25, x5, Exit
                                              \# if k \ge 4, go to Exit
                                              # temp reg x7 = 8 * k (0 \le k \le 3)
                      slli
                           x7, x25, 3
                      add x7, x7, x6
                                             \# x7 = address of JumpTable[k]
                           x7, 0(x7)
                                              # temp reg x7 gets JumpTable[k]
                      ld
                     jalr x1, 0(x7)
                                              # jump based on register x7(entrance)
              Exit:
jump address table
 x7 = x6 + 8 * k:
                     L0:
                          add
                               $s0,<mark>\$</mark>s3, $s4
                                                   \# k = 0 so f gets i + j
                                                   # end of this case so go to Exit
                               x0, 0(x1)
                          jalr
  L0:address
                          add
                               $s0, $s1, $s2
                                                   \# k = 1 so f gets g + h
  L1:address
                               x0, 0(x1)
                                                  # end of this case so go to Exit
                          jalr
                     L2:
                               $s0, $s1, $s2
                                                  \# k = 2 so f gets g - h
                          sub
  L2: address
                               x0, 0(x1)
                                                  # end of this case so go to Exit
                     L3:
                          sub $s0, $s3, $s4
                                                  \# k = 3 so f gets i - j
  L3:address
                          jalr x0, 0(x1) Memo
                                                  # end of switch statement
```




系统结构与网络安全研究所

Important conception-Basic Blocks



■ A basic block is a sequence of instructions with

- No embedded branches (except at end)
- No branch targets/branch lables (except at beginning)



- A compiler identifies basic blocks for optimization
- An advanced processor can accelerate execution of basic blocks

2.8 Supporting Procedures



in Computer Hardware

Procedure/function be used to structure programs

- A stored subroutine that performs a specific task based on the parameters with which it is provided
 - easier to understand, allow code to be reused
- Six step
- 1. Place Parameters in a place where the procedure can access them
- 2. Transfer control to the procedure: jump to
- 3. Acquire the storage resources needed for the procedure
- 4. **Perform** the desired task
- 5. Place the result value in a place where the calling program can access it
- 6. Return control to the point of origin



Procedure Call Instructions



- Instruction for procedures: jal (jump-and-link)Caller jal x1, ProcedureAddress
 - Address of following instruction put in x1
 - Jumps to target address

PC+4 → ra

- □ Procedure return: jump and link register
 Callee jalr x0, 0(x1)
 - Like jal, but jumps to $0 + address in x \hat{1}$
 - Use x0 as rd (x0 cannot be changed)
 - Can also be used for computed jumps
 - e.g., for case/switch statements

Special registers



Using More Registers



■ More Registers for procedure calling

- $a0 \sim a7(x10-x17)$: eight argument registers to pass parameters & return values
- ra/x1: one return address register to return to origin point

addi sp,sp,-8 sd ...,8(sp)

□ Stack

- ideal data structure for spilling registers
 - □ Push, pop
 - □ Stack pointer (sp)
- Stack grow from higher address to lower address
 - Push: sp= sp 8
 - Pop: sp = sp + 8 $\begin{cases} ld & ..., 8(sp) \\ addi & sp, sp, 8 \end{cases}$

High address



Low address



沙人学系统结构与网络安全研究所



■ Example 2.15 Compiling a leaf procedure

(Assume: g, ..., j in x10, ..., x13 and f in x20) **High address** C code: (\$t1) long long int leaf example ((\$t0) long long int g, long long int h, (\$s0) \$sp(-24) long long int i, long long int j){ long long int f; f = (g + h) - (i + j);Low address return f; Save value **Return value**

RISC-V assembly code:

adjust stack to make room for 3 items sd $\times 5$, 16(sp) #These three instructions save three sd $\times 6$, 8(sp) # register $\times 5$, $\times 6$, $\times 20$, 0(sp) # Let's consider why it need to be done.





```
add x5,x10,x11 # register x5contains g + h
add x6,x12,x1 # register x6 contains i + j
sub x20,x5,x6 # f = x5-x6, which is (g + h)-(i + j)
addi x10,x20,0 # copy f to return register (x10 = x20 + 0)
```

But maybe some of the three are not used by the caller

- So, this way might be inefficient to save x5, x6, x20 on stack
- Two classes of registers
 - \Box t0 ~ t6: 7 temporary registers, by the callee not preserved
 - $= s0 \sim s11$: 12 saved registers, must be preserved If used



RISC-V operands




Name	Example	Comments
32 registers	x0-x31	Fast locations for data. In RISC-V, data must be in registers to perform arithmetic. Register x0 always equals 0.
2 ⁶¹ memory words	Memory[0], Memory[8],, Memory[18,446,744,073,7 09,551,608]]	Accessed only by data transfer instructions. RISC-V uses byte addresses, so sequential double word accesses differ by 8. Memory holds data structures, arrays, and spilled registers.

Name	Register no.	Usage	Preserved on call
x0(zero)	0	The constant value 0	n.a.
<i>x</i> 1(ra)	1	Return address(link register)	yes
$x2(\mathbf{sp})$	2	Stack pointer	yes
<i>x</i> 3(gp)	3	Global pointer	yes
<i>x</i> 4(tp)	4	Thread pointer	yes
x5-x7(t0-t2)	5-7	Temporaries	no
x8(s0/fp)	8	Saved/frame point	Yes
<i>x</i> 9(s1)	9	Saved	Yes
<i>x</i> 10- <i>x</i> 17(a0-a7)	10-17	Arguments/results	no
<i>x</i> 18- <i>x</i> 27(s2-s11)	18-27	Saved	yes
<i>x</i> 28- <i>x</i> 31(t3-t6)	28-31	Temporaries No	
PC	-	Program counter	Yes

ZheJiang University

The values of the stack pointer and stack before, during and after procedure call in Example 2.15





Nested Procedures



■ Example 2.16 Compiling a recursive procedure (Assume: n -- a0)

```
C code for n!
 int fact (int n)
                                            Argument n in a0
     if (n < 1) return (1);
                                            Result in a0
        else return (n * fact(n - 1));
RISC-V assembly code
 fact: addi sp, sp, 16
                                    # adjust stack for 2 items
        ra, 8(sp)
                                    # save the return address: x1
        sd a0, 0(\$sp)
                                    # save the argument n: x10
        addi t0, a0, -1
                                    \# x5 = n - 1
                                    \# if n \ge 1, go to L1(else)
        bge t0, zero, L1
        addi a0, zero, 1
                                    # return 1 if n < 1
       addi sp, sp, 16
                                # Recover sp (Why not recover x1and x10?)
       jalr zero, 0(ra)
                                     # return to caller
```

Nested Procedures-Continue



```
\# n \ge 1: argument gets (n - 1)
L1: addi a0, a0, -1
                                \# call fact with (n - 1)
    jal
        ra, fact
                                #move result of fact(n - 1) to x6(t1)
    add t1, a0, zero
                              # return from jal: restore argument n
    1d a0, 0(sp)
    ld ra, 8(sp)
                              # restore the return address
    add sp, sp, 16
                                # adjust stack pointer to pop 2 items
    mul a0, a0, t1
                              # return n*fact(n-1)
          zero, 0(ra)
                               # return to the caller
     jalr
```

- Why a0 is saved? Why ra is saved?
- Preserved things across a procedure call

Saved registers ($s0 \sim s11$), stack pointer register (sp), return address register (ra/x1), stack above the stack pointer

■ Not preserved things across a procedure call

Temporary registers ($t0 \sim t7$), argument registers ($a0 \sim a7$), return value registers ($a0 \sim a7$), stack below the stack pointer




What is and what is not preserved across a procedure call



Preserved	Not preserved
Saved registers: x8-x9, x18-x27	Temporary registers: x5-x7, x28-x31
Stack pointer register: x2(sp)	Argument/result registers: x10-x17
Frame pointer: x8(fp)	
Return address: x1(ra)	
Stack above the stack pointer	Stack below the stack pointer







C.

Memory Layout



- **□** Text: program code
- **□** Static data: global variables
 - e.g., static variables in C, constant arrays and strings
 - x3 (global pointer) initialized to address allowing ± offsets into this segment

 SP → 0000 003f ffff fff0hex Stock
- Dynamic data: heap
 - E.g., malloc in C, new in Java
- **■** Stack: automatic storage
- **■** Storage class of C variables
 - automatic
 - static



0

PC → 0000 0000 0040 0000_{hex}

Text

Reserved






Local Data on the Stack



□ Allocating Space for New Data on the **Stack**

- Procedure frame/activation record
 - The segment of stack containing a procedure's saved registers and local variables
- Frame pointer
 - A value denoting the location of saved register and local variables for a given procedure

 High address





系统结构与网络安全研究所

RISC-V operands



Name	Example	Comments
32 registers	x0-x31	Fast locations for data. In RISC-V, data must be in registers to perform arithmetic. Register x0 always equals 0.
2 ⁶¹ memory words	Memory[0], Memory[8],, Memory[18,446,744,073,7 09,551,608]]	Accessed only by data transfer instructions. RISC-V uses byte addresses, so sequential double word accesses differ by 8. Memory holds data structures, arrays, and spilled registers.

Name	Register no.	Usage	Preserved on call
x0(zero)	0	The constant value 0	n.a.
<i>x</i> 1(ra)	1	Return address(link register)	yes
$x2(\mathbf{sp})$	2	Stack pointer	yes
<i>x</i> 3(gp)	3	Global pointer	yes
<i>x</i> 4(tp)	4	Thread pointer	yes
x5-x7(t0-t2)	5-7	Temporaries no	
x8(s0/fp)	8	Saved/frame point Yes	
<i>x</i> 9(s1)	9	Saved Yes	
<i>x</i> 10- <i>x</i> 17(a0-a7)	10-17	Arguments/results no	
<i>x</i> 18- <i>x</i> 27(s2-s11)	18-27	Saved yes	
<i>x</i> 28- <i>x</i> 31(t3-t6)	28-31	Temporaries No	
PC	-	Auipc(Add Upper Immediate to PC)	Yes

ZheJiang University

RISC-V assembly language



Category	Instruction	Example	Meaning	Comments
Arithmetic	add	add x5,x6,x7	x5=x6 + x7	Add two source register operands
	subtract	sub x5,x6,x7	x5=x6 - x7	First source register subtracts second one
	add immediate	addi x5,x6,20	x5=x6+20	Used to add constants
Data transfer	load doubleword	ld x5, 40(x6)	x5=Memory[x6+40]	doubleword from memory to register
	store doubleword	sd x5, 40(x6)	Memory[x6+40]=x5	doubleword from register to memory
	load word	lw x5, 40(x6)	x5=Memory[x6+40]	word from memory to register
	load word, unsigned	lwu x5, 40(x6)	x5=Memory[x6+40]	Unsigned word from memory to register
	store word	sw x5, 40(x6)	Memory[x6+40]=x5	word from register to memory
	load halfword	lh x5, 40(x6)	x5=Memory[x6+40]	Halfword from memory to register
Data transfer	load halfword, unsigned	lhu x5, 40(x6)	x5=Memory[x6+40]	Unsigned halfword from memory to register
	store halfword	sh x5, 40(x6)	Memory[x6+40]=x5	halfword from register to memory
	load byte	lb x5, 40(x6)	x5=Memory[x6+40]	byte from memory to register
	load word, unsigned	lbu x5, 40(x6)	x5=Memory[x6+40]	Unsigned byte from memory to register
	store byte	sb x5, 40(x6)	Memory[x6+40]=x5	byte from register to memory
	load reserved	lr.d x5,(x6)	x5=Memory[x6]	Load;1st half of atomic swap
	store conditional	sc.d x7,x5,(x6)	Memory[x6]=x5; x7 = 0/1	Store;2nd half of atomic swap
	Load upper immediate	lui x5,0x12345	x5=0x12345000	Loads 20-bits constant shifted left 12 bits

RISC-V assembly language

Category	Instruction	Example	Meaning	Comments
Logical	and	and x5, x6, 3	x5=x6 & 3	Arithmetic shift right by register
	inclusive or	or x5,x6,x7	x5=x6 x7	Bit-by-bit OR
	exclusive or	xor x5,x6,x7	x5=x6 ^ x7	Bit-by-bit XOR
	and immediate	andi x5,x6,20	x5=x6 & 20	Bit-by-bit AND reg. with constant
	inclusive or immediate	ori x5,x6,20	x5=x6 20	Bit-by-bit OR reg. with constant
	exclusive or immediate	xori x5,x6,20	X5=x6 ^ 20	Bit-by-bit XOR reg. with constant
Shift	shift left logical	sll x5, x6, x7	x5=x6 << x7	Shift left by register
	shift right logical	srl x5, x6, x7	x5=x6 >> x7	Shift right by register
	shift right arithmetic	sra x5, x6, x7	x5=x6 >> x7	Arithmetic shift right by register
	shift left logical immediate	slli x5, x6, 3	x5=x6 << 3	Shift left by immediate
Shift	shift right logical immediate	srli x5,x6,3	x5=x6 >> 3	Shift right by immediate
	shift right arithmetic immediate	srai x5,x6,3	x5=x6 >> 3	Arithmetic shift right by immediate
Conditional branch	branch if equal	beq x5, x6, 100	if(x5 == x6) go to $PC+100$	PC-relative branch if registers equal
	branch if not equal	bne x5, x6, 100	if(x5 != x6) go to $PC+100$	PC-relative branch if registers not equal
	branch if less than	blt x5, x6, 100	if($x5 < x6$) go to PC+100	PC-relative branch if registers less
	branch if greater or equal	bge x5, x6, 100	if(x5 >= x6) go to PC+100	PC-relative branch if registers greater or equal
	branch if less, unsigned	bltu x5, x6, 100	if($x5 \ge x6$) go to PC+100	PC-relative branch if registers less, unsigned
	branch if greater or equal, unsigned	bgeu x5, x6, 100	if($x5 \ge x6$) go to PC+100	PC-relative branch if registers greater or equal, unsigned
Unconditional branch	jump and link	jal x1, 100	x1 = PC + 4; go to $PC+100$	PC-relative procedure call
	jump and link register	jalr x1, 100(x5)	x1 = PC + 4; go to $x5+100$	procedure return; indirect call



■ Byte-encoded character sets

- ASCII (American Standard Code for Information Interchange)
 - 128 characters: 95 graphic, 33 control
- Latin-1: 256 characters
 - ASCII, +96 more graphic characters

□ Unicode: 32-bit character set

- Used in Java, C++ wide characters, ...
- Most of the world's alphabets, plus symbols
- UTF-8, UTF-16: variable-length encodings



Byte/Halfword/Word Operations



■ RISC-V byte/halfword/word load/store

- Load byte/halfword/word: Sign extend to 64 bits in rd
 - □ lb rd, offset(rs1)
 - □ lh rd, offset(rs1)
 - □ lw rd, offset(rs1)
- Load byte/halfword/word unsigned: 0 extend to 64 bits in rd
 - □ lbu rd, offset(rs1)
 - □ lhu rd, offset(rs1)
 - □ lwu rd, offset(rs1)
- Store byte/halfword/word: Store rightmost 8/16/32 bits
 - □ sb rs2, offset(rs1)
 - □ sh rs2, offset(rs1)
 - □ sw rs2, offset(rs1)



沙 系统结构与网络安全研究所

String Copy Example



■ Example 2.17 Compiling a string copy procedure

(Assume: base addresses for i - x19, x's base --x10, y's base --x11)

C code: Y→X
void strcpy(char x[], char y[])
{ size_t i;
 i = 0;
 while((x[i] = y[i]) != '\0') /* copy and test byte */
 i += 1;

RISC-V assembly code:



系统结构与网络安全研究所



```
beq t1, zero, L2 \# if y[i] == 0 then exit addi s3, s3, 1 \# i = i + 1 \# next iteration of loop L2: ld s3, 0(sp) \# restore saved old s3 addi sp, sp, 8 \# pop 1 double word from stack jalr zero 0(x1) \# return
```

Optimization for example 2.17

- strcpy is a leaf procedure
- Allocate i to a temporary register t3/x28

■ For a leaf procedure

- The compiler exhausts all temporary registers
- Then use the registers it must save



2.10 RISC V Addressing for 32-Bit Immediate and Addresses



- Wide Bit Immediate addressing
 - most constants is short and fit into 12-bit field
 - Set upper 20 bits of a constants in a register with load upper immediate (lui rd, constant)
- □ instruction format (U-type)

_	31		12 11	76	0
		immediate[31:12]		rd	Opcode
		20bits		5bits	7bits
	lui	x19, 976 # 0x003D0			
		31	12	11 7	6 0
Instru	action	0000 0000 0011 1101 0000		10011	011 0111
		•		Fil	ling zero
Regis	ster	0000 0000 0011 1101 0000		00000	0000000



系统结构与网络安全研究所

32-bit Constants



- Example 2.19 Loading a 32-bit constant
 - The 32-bit constant:

RISC V code:

The value of s3 afterward is:

■ Note: Why does it need two steps?



Branch Addressing



- Addressing in branches
 - Branch instructions specify
 - Opcode, two registers, target address
 - Most branch targets are near branch
 - □ Forward or backward

SB-type: bne x10, x11, 2000, $\frac{1}{2000} = 0111 \ 1101 \ 0000$

inst[31:0]

0	111110	01011	01010	001	1000	0	1100011
imm[12]	imm[10:5]	rs2	rs1	funct3	imm[4:1]	imm[11]	opcode

imm[31:0]

			· · · · · · · · · · · · · · · · · · ·	
Inst[31] signextension	Inst[7]	Inst[30:25]	Inst[11:8]	1'B0

PC-relative addressing

$$=$$
 PC + immediate \times 2



系统结构与网络安全研究所

Jump Addressing



- □ Jump and link (jal)
 - target uses 20-bit immediate for larger range
- UJ = {{11{inst[31]}}, inst[19:12], inst[20], inst[30:21],1'b0};

 31 1bit 10bits 1bit 8bits 1211 7 6 0 inn[20] imm[10:1] imm[11] imm[19:12] rd Opcode

 20bit 5bit 7bit
 - \square jal x0, 2000 # 2000₁₀ = (0 00000000 0 111 1101 000₀)₂

31 1bit	10bits	1bit	8bits 12	211 7	6 0
0	1111101000	0	00000000	00000	1101111
	20bit			5bit	7bit

- □ For more long jumps: eg, to 32-bit absolute address
 - lui: load address[31:12] to temp register
 - jalr: add address[11:0] and jump to target



Show branch offset in machine language



■ Example 2.20 P116/p94

C language:

```
while (save[i]==k) i=i+1;
```

RISC-V assembler code in Example 2.12:

```
Loop: slli a0, s6, 3  # temp reg x10 = 8 * i

add a0, a0, s9  # x10 = address of save[i]

ld s1, 0(a0)  # temp reg x9 = save[i]

bne s1, s8, Exit  # go to Exit if save[i] != k

addi s6, s6, 1  # i = i + j

beq zero,zero, Loop # go to Loop

Exit:
```

Instructions Addressing and their Offset



		instructions Code with Binary					Hex	
	Address	fun7	rs2	rs1	fun3	rd/offset	OP	1100
Loop: slli	80000	000000	00011	10110	001	01010	0010011	003B1513
add	80004	0000000	11001	01010	000	01010	0110011	01950533
ld	80008	0000000	00000	01010	011	01001	0000011	00053483
bne	80012	0000000	11000	01001	001	01100	1100011	01849663
addi	80016	0000000	00001	10110	000	10110	0010011	001B0B13
beq	80020	1111111	00000	00000	000	. 0110 1	1100011	FE0006E3
Exit:	80024	•••••						
	•	-10			_		6 ₹0110	

-20 = 80000 - 80020

PC + offset : 12 = 80024 - 80012

Modification:

- □ All RISC-V instructions are 4 bytes long
- PC-relative addressing refers to the number of halfwords
 - The address field at 80012 above should be 6 instead of 12



系统结构与网络安全研究所

While branch target is far away



- □ Inserts an unconditional jump to target
 - Invert the condition so that the branch decides whether to skip the jump
- Example 2.21 p117: Branching far away
 - Given a branch:

```
beq a0, zero, L1
```

Rewrite it to offer a much greater branching distance:

```
bne a0, zero, L2 jal zero, L1
```



L2:

Summary of RISC-V architecture in Ch. 2




RISC-V Instruction Format and Their Operands

Name				Comments				
Field size	31 <i>7</i>	bits 25 24	5bits 20	19 5bits 1	5 14 3bits 12	11 5bits 7	6 7bits 0	All RISC-V instruction 32 b
R-type	fuı	nct7	rs2	rs1	funct3	rd	opcode	Arithmetic instruction format
I-type	in	nmediate[1	1:0]	rs1	funct3	rd	opcode	Loads & immediate arithmetic
S-type	imm	ned[11:5]	rs2	rs1	funct3	immed[4:0]	opcode	Stores
SB-type	imm	[12,10:5]	rs2	rs1	funct3	imm[4:1,11]	opcode	Conditional branch format
UJ-type		immedi	iate[20,1	0:1,11,19:1	2]	rd	opcode	Unconditional jump format
U-type		ir	nmediate	e[31:12]		rd	opcode	Upper immediate format
Name						erands		
32 register						p, t0-t6, s0~s11		
Mem word	S	Mer	nory[0], N	/lemory[8], N	[8], Memory[10], , Memory[18,446,744,07			3,709,551,608]
x0(zero)		0 The constant v			constant va	lue 0		n.a.
<i>x</i> 1(ra)		1 Return a			n address(li	nk register)		yes
x2(sp)		2 Stack point			k pointer		yes	
<i>x</i> 3(gp)			3	Globa	Global pointer			yes
x4(tp)			4	Threa	Thread pointer			yes
x5-x7(t0-t)	2)		5-7	Temporaries			no	
x8(s0/fp))		8 Saved/frame po		d/frame poir			Yes
x9(s1)	` ' '			Saved			Yes	
<i>x</i> 10- <i>x</i> 17(a0-a7) 10-17		Argur	Arguments/results			no		
x18-x27(s2-	` '		Save	Saved			yes	
<i>x</i> 28- <i>x</i> 31(t3-t6) 28-31		Temp	Temporaries			No		
` '			-	Auipo	c(Add Upper	Immediate to P	C)	

RISC-V Addressing Summary

统结构与网络安全研究





RISC-V Disassembly



- **Example 2.22 P120: Decoding machine code**
 - Machine instruction(0x00578833)

Decoding

□ Determine the operation from opcode
 opcode: 0110011 → R-type arithmetic instruction

funct7	rs2	rs1	funct3	rd	opcode
000 0000	00101	01111	000	10000	0110011
-		-)		/

funct7 and funct3 are all $0 \rightarrow add$ instruction

p107-P119

□ Determine other fields

rs2: x5/t0; rs1: x15/a5; rd: x16/a7

■ Show the assembly instruction:

add a7, a5, t0 (Note: add rd,rs,rt)



系统结构与网络安全研究所

Summary of RISC-V instruction encoding



Format	Instruction	Opcode	Funct3	Funct6/7
	add	0110011	000	0000000
	sub	0110011	000	0100000
	sll	0110011	001	0000000
	xor	0110011	100	0000000
D type	srl	0110011	101	0000000
R-type	sra	0110011	101	0000000
	or	0110011	110	0000000
	and	0110011	111	0000000
	lr.d	0110011	011	0001000
	sc.d	0110011	011	0001100



Summary of RISC-V instruction encoding



Format	Instruction	Opcode	Funct3	Funct6/7
	lb	0000011	000	n.a.
	lh	0000011	001	n.a.
	lw	0000011	010	n.a.
	ld	0000011	011	n.a.
	lbu	0000011	100	n.a.
	lhu	0000011	101	n.a.
	lwu	0000011	110	n.a.
l-type	addi	0010011	000	n.a.
	slli	0010011	001	000000
	xori	0010011	100	n.a.
	srli	0010011	101	000000
	srai	0010011	101	010000
	ori	0010011	110	n.a.
	andi	0010011	111	n.a.
	jalr	1100111	000	n.a.



Summary of RISC-V instruction encoding



Format	Instruction	Opcode	Funct3	Funct6/7
	sb	0100011	000	n.a.
C tuno	sh	0100011	001	n.a.
S-type	SW	0100011	010	n.a.
	sd	0100011	111	n.a.
	beq	1100111	000	n.a.
	bne	1100111	001	n.a.
SP type	blt	1100111	100	n.a.
SB-type	bge	1100111	101	n.a.
	bltu	1100111	110	n.a.
	bgeu	1100111	111	n.a.
U-type	lui	0110111	n.a.	n.a.
UJ-type	jal	1101111	n.a.	n.a.



2.11 Synchronization in RISC-V



- **□** Two processors sharing an area of memory
 - P1 writes, then P2 reads
 - Data race if P1 and P2 don't synchronize
 - Result depends of order of accesses

□ Hardware support required

- Atomic read/write memory operation
- No other access to the location allowed between the read and write

□ Could be a single instruction

- E.g., atomic swap of register \leftrightarrow memory
- Or an atomic pair of instructions



Synchronization in RISC-V



- □ Load reserved: lr.d rd, (rs1)
 - Load from address in rs1 to rd
 - Place reservation on memory address
- □ Store conditional: sc.d rd, (rs1), rs2
 - Store from rs2 to address in rs1
 - Succeeds if location not changed since the lr.d
 - □ Returns 0 in rd
 - Fails if location is changed
 - □ Returns non-zero value in rd

Synchronization in RISC-V



■ Example 1: atomic swap (to test/set lock variable)

```
again: lr.d x10,(x20)
sc.d x11,(x20),x23 // x11 = status
bne x11,x0,again // branch if store failed
addi x23,x10,0 // x23 = loaded value
```

■ Example 2: lock

```
addi x12,x0,1 // copy locked value
again: lr.d x10,(x20) // read lock
bne x10,x0,again // check if it is 0 yet
sc.d x11,(x20),x12 // attempt to store
bne x11,x0,again // branch if fails
```


□ Unlock:

```
sd x0.0(x20) // free lock
```



2.12 Translating and starting a program







Producing an Object Module



- Assembler (or compiler) translates program into machine instructions
- □ Provides information for building a complete program from the pieces
 - Header: described contents of object module
 - Text segment: translated instructions
 - Static data segment: data allocated for the life of the program
 - Relocation info: for contents that depend on absolute location of loaded program
 - Symbol table: global definitions and external refs
 - Debug info: for associating with source code






Object file head	ler		
	Name	Procedure A	
	Text size	100 _{hex}	
	Data size	20 _{hex}	
Text segment	Address	instruction	
	0	ld x10, 0(gp)	
	4	jal x1, 0	
Data segment	0	(X)	
Relocation information	Address	Instruction type	Dependency
	0	ld	X
	4	jal	В
Symbol table	label	Address	
	х		
	В		



Link



- Object modules(including library routine) → executable program
- 3 step of Link
 - Place code and data modules symbolically in memory
 - Determine the addresses of data and instruction labels
 - Patch both the internal and external references (Address of invoke)





Loading a Program



■ Load from image file on disk into memory

- 1. Read header to determine segment sizes
- 2. Create virtual address space
- 3. Copy text and initialized data into memory
 - □ Or set page table entries so they can be faulted in
- 4. Set up arguments on stack
- 5. Initialize registers (including sp, fp, gp)
- 6. Jump to startup routine
 - □ Copies arguments to x10, ... and calls main
 - When main returns, do exit syscall



Dynamic Linking




□ Only link/load library procedure when it is called

- Requires procedure code to be relocatable
- Avoids image bloat caused by static linking of all (transitively) referenced libraries
- Automatically picks up new library versions

Starting Java Applications







machine

2.13 A C Sort Example To Put it All Together



- □ Three general steps for translating C procedures
 - Allocate registers to program variables
 - Produce code for the body of the procedures
 - Preserve registers across the procedures invocation

□ Procedure swap

```
C code
void swap (long long v[], size_t k)
{
    long lon temp;
    temp = v[k];
    v[k] = v[k+1];
    v[k+1] = temp;
```



The Procedure Swap



Register allocation for swap

```
v ---- x10 k ---- x11 temp ---- x5
```

- swap is a leaf procedure, nothing to preserve
- RISC-V code for the procedure swap

□ Procedure body

The Sort Procedure in C



□ Procedure *sort*

C code

```
void sort(long long v[], size_t n)
{
    size_t i, j;
    for(i = 0; i < n; i+= 1) {
        for(j = i - 1; j >= 0 && v[j] > v[j+1]; j == 1)
            swap(v, j);
    }
}
```

Register allocation for sort

- Passing parameters in sort
- Preserving registers in sort x1, x19, x20, x21, x22



The Outer Loop



□ Skeleton of outer loop:

```
• for (i = 0; i < n; i += 1)
  1i \quad x19,0 \quad // i = 0
for1tst:
  bge x19,x11,exit1 // go to exit1 if x19 \geq x11 (i\geqn)
  (body of outer for-loop)
  addi x19, x19, 1 // i += 1
       for1tst
                       // branch to test of outer loop
exit1:
```

The Inner Loop



□ Skeleton of inner loop:

```
• for (i = i - 1; i >= 0 \&\& v[i] > v[i + 1]; i -= 1)
     addi x20, x19, -1 // j = i -1
for2tst:
   blt x20,x0,exit2 // go to exit2 if x20 < 0 (j < 0)
   slli x5,x20,3 // reg x5 = j * 8
   add x5,x10,x5 // reg x5 = v + (j * 8)
   1d x6,0(x5) // reg x6 = v[j]
   1d x7,8(x5) // reg x7 = v[j + 1]
   ble x6,x7,exit2 // go to exit2 if x6 \leq x7
   mv x21, x10 // copy parameter x10 into x21
   mv x22, x11 // copy parameter x11 into x22
   mv x10, x21 // first swap parameter is v
        x11, x20 // second swap parameter is j
   mv
     jal x1, swap // call swap
      addi x20, x20, -1 // j -= 1
          for2tst // branch to test of inner loop
 exit2:
```

Preserving Registers



Saving registers

```
addi sp, sp, -40
                            // make room on stack for 5 registers
sort:
             x1, 32(sp)
                            // save return address on stack
        sd
            x22, 24(sp) // save x22 on stack
        sd
        sd
            x21, 16(sp) // save x21 on stack
            x20, 8(sp) // save x20 on stack
        sd
              x19, 0(sp) // save x19 on stack
        sd
```

Procedure body{Outer loop {Inner loop} }

Restoring registers

```
exit1: ld x19, 0(sp)
                               // restore x19 from stack
           x20, 8(sp)
                               // restore x20 from stack
        1d
                               // restore x21 from stack
        1d x21, 16(sp)
                               // restore x22 from stack
        1d x22, 24(sp)
             x1, 32(sp)
                                // restore return address from stack
        ld
        addi sp, sp, 40
                               // restore stack pointer
```

Procedure return

```
jalr x0, 0(x0)
                        // return to calling routine
```

2.14 Arrays versus Pointers



- **□** Array indexing involves
 - Multiplying index by element size
 - Adding to array base address
- □ Pointers correspond directly to memory addresses
 - Can avoid indexing complexity

Example: Clearing an Array



```
clear1(int array[], int size) {
                                        clear2(int *array, int size) {
 int i:
                                          int *p:
 for (i = 0; i < size; i += 1)
                                          for (p = \&array[0]; p < \&array[size];
   array[i] = 0;
                                               p = p + 1
                                            p = 0;
       x5.0 // i = 0
  lί
                                           mv x5, x10 // p = address
loop1:
                                                          // of array[0]
  x6, x5, 3 // x6 = i * 8
                                           slli x6, x11, 3 // x6 = size * 8
  add x7,x10,x6 // x7 = address
                                           add x7, x10, x6 // x7 = address
                 // of array[i]
                                                          // of array[size]
  x0,0(x7) // array[i] = 0
                                        loop2:
                                           sd x0,0(x5) // Memory[p] = 0
  addi x5, x5, 1 // i = i + 1
  blt x5,x11,loop1 // if (i<size)
                                           addi x5, x5, 8 // p = p + 8
                                           bltu x5,x7,loop2
                     // go to loop1
                                                          // if (p<&array[size])</pre>
                                                          // go to loop2
```

Comparison of Array vs. Ptr



- Multiply "strength reduced" to shift
- □ Array version requires shift to be inside loop
 - Part of index calculation for incremented i
 - c.f. incrementing pointer
- □ Compiler can achieve same effect as manual use of pointers
 - Induction variable elimination
 - Better to make program clearer and safer



2.16 Real Stuff: MIPS Instructions



- **MIPS: commercial predecessor to RISC-V**
- **□** Similar basic set of instructions
 - 32-bit instructions
 - 32 general purpose registers, register 0 is always 0
 - 32 floating-point registers
 - Memory accessed only by load/store instructions
 - □ Consistent use of addressing modes for all data sizes

□ Different conditional branches

- For <, <=, >, >=
- RISC-V: blt, bge, bltu, bgeu
- MIPS: slt, sltu (set less than, result is 0 or 1)
 - □ Then use beq, bne to complete the branch



Instruction Encoding



_							
ĸ	ല	191	ei	-re	ומי	IST	ei
	~ ~					-	•

	31	25 2	24 20	19	15	14 12	11	7	6		0
RISC-V	funct7(7)		rs2(5)	rs1(5)		funct3(3)	rd(5)			opcode(7)	
	31	26 25	21 20	16	15		11 10		6	5	0
MIPS	Op(6)		Rs1(5)	Rs2(5)		Rd(5)	Const(5	5)		Opx(6)	

Load

	31		20	19 1	5 14	12 11	7	6		0
RISC-V	immed	iate(12)		rs1(5)	funct3	(3)	rd(5)		opcode(7)	
	31 26	25 21	20	16 1	5					0
MIPS	Op(6)	Rs1(5)		Rs2(5)			Const(1	6)		

Store

	31	25 24	20 19	15 14 12	11 7	6 0
RISC-V	immediate(7)	rs2(5)	rs1(5)	funct3(3)	immediate(5)	opcode(7)
	31 26	25 21	20 16	15		0
MIPS	Op(6)	Rs1(5)	Rs2(5)		Const(16	5)

Branch

	31	25 24	20 19	15 14 12	11 7	6 0
RISC-V	immediate(7)	rs2(5)	rs1(5)	funct3(3)	immediate(5)	opcode(7)
	31 26	25 21	20 16	15		0
MIPS	Op(6)	Rs1(5)	Opx/Rs2(5)		Const(16	6)



2.17 Real Stuff: The Intel x86 ISA



■ Evolution with backward compatibility

- 8080 (1974): 8-bit microprocessor
 - Accumulator, plus 3 index-register pairs
- 8086 (1978): 16-bit extension to 8080
 - □ Complex instruction set (CISC)
- 8087 (1980): floating-point coprocessor
 - Adds FP instructions and register stack
- 80286 (1982): 24-bit addresses, MMU
 - Segmented memory mapping and protection
- 80386 (1985): 32-bit extension (now IA-32)
 - Additional addressing modes and operations
 - □ Paged memory mapping as well as segments



The Intel x86 ISA



□ Further evolution...

- i486 (1989): pipelined, on-chip caches and FPU
 - □ Compatible competitors: AMD, Cyrix, ...
- Pentium (1993): superscalar, 64-bit datapath
 - Later versions added MMX (Multi-Media eXtension) instructions
 - □ The infamous FDIV bug
- Pentium Pro (1995), Pentium II (1997)
 - New microarchitecture (see Colwell, *The Pentium Chronicles*)
- Pentium III (1999)
 - Added SSE (Streaming SIMD Extensions) and associated registers
- Pentium 4 (2001)
 - New microarchitecture
 - Added SSE2 instructions



The Intel x86 ISA




□ And further...

- AMD64 (2003): extended architecture to 64 bits
- EM64T Extended Memory 64 Technology (2004)
 - AMD64 adopted by Intel (with refinements)
 - Added SSE3 instructions
- Intel Core (2006)
 - □ Added SSE4 instructions, virtual machine support
- AMD64 (announced 2007): SSE5 instructions
 - □ Intel declined to follow, instead...
- Advanced Vector Extension (announced 2008)
 - Longer SSE registers, more instructions
- ☐ If Intel didn't extend with compatibility, its competitors would!
 - Technical elegance ≠ market success



Basic x86 Registers





Basic x86 Addressing Modes



■ Two operands per instruction

Source/dest operand	Second source operand
Register	Register
Register	Immediate
Register	Memory
Memory	Register
Memory	Immediate


■ Memory addressing modes

- Address in register
- \blacksquare Address = R_{base} + displacement
- Address = $R_{base} + 2^{scale} \times R_{index}$ (scale = 0, 1, 2, or 3)
- Address = $R_{base} + 2^{scale} \times R_{index} + displacement$



x86 Instruction Encoding





□ Variable length encoding

- Postfix bytes specify addressing mode
- Prefix bytes modify operation
 - Operand length, repetition, locking, ...

Implementing IA-32



□ Complex instruction set makes implementation difficult

- Hardware translates instructions to simpler microoperations
 - Simple instructions: 1–1
 - □ Complex instructions: 1—many
- Microengine similar to RISC
- Market share makes this economically viable
- **□** Comparable performance to RISC
 - Compilers avoid complex instructions



2.18 Other RISC-V Instructions



□ Base integer instructions (RV64I)

- Those previously described, plus
- auipc rd, immed // rd = (imm<<12) + pc
 follow by jalr (adds 12-bit immed) for long jump
- slt, sltu, slti, sltui: set less than (like MIPS)
- addw, subw, addiw: 32-bit add/sub
- sllw, srlw, srlw, slliw, srliw, sraiw: 32-bit shift

□ 32-bit variant: RV32I

registers are 32-bits wide, 32-bit operations



Instruction Set Extensions



- M: integer multiply, divide, remainder
- **□** A: atomic memory operations
- □ F: single-precision floating point
- **□ D**: double-precision floating point
- □ C: compressed instructions
 - 16-bit encoding for frequently used instructions

Fallacies



\square Powerful instruction \Rightarrow higher performance

- Fewer instructions required
- But complex instructions are hard to implement
 - May slow down all instructions, including simple ones
- Compilers are good at making fast code from simple instructions

□ Use assembly code for high performance

- But modern compilers are better at dealing with modern processors
- More lines of code \Rightarrow more errors and less productivity




Fallacies



■ Backward compatibility ⇒ instruction set doesn't change

But they do accrete more instructions



x86 instruction set



Pitfalls



- Sequential words are not at sequential addresses
 - Increment by 4, not by 1!
- □ Keeping a pointer to an automatic variable after procedure returns
 - e.g., passing pointer back via an argument
 - Pointer becomes invalid when stack popped

Summary



□ Design principles

- 1. Simplicity favors regularity
- 2. Smaller is faster
- 3. Good design demands good compromises
- Make the common case fast
- **■** Layers of software/hardware
 - Compiler, assembler, hardware
- **□ RISC-V:** typical of RISC ISAs
 - c.f. x86



Homework



 \square 2.4, 2.8, 2.12, 2.14, 2.17, 2.22, 2.24, 2.29