Dynamic_Aperture Program

David Sagan September 24, 2022

Contents

1	Introduction	1
2	Running the Dynamic Aperture Program	2
3	Time Ramping — Time Varying Element Parameters	3
4	Fortran Namelist Input	4
5	Master Input File	5
6	Tracking Methods	9
7	Map Tracking	9
8	Tuning Map and PTC Tracking Parameters	0
9	Correcting the Orbit when Radiation is Present	1
10	Data Output and Plotting	2

1 Introduction

The *dynamic_aperture* program is for measuring the dynamic aperture. The concept of *dynamic aperture* is that a particle reaching a certain amplitude will quickly be resonantly driven to large amplitude where it is lost. This amplitude where the particle becomes unstable is the dynamic aperture. This is to be contrasted by the *physical aperture* which is the aperture where a particle strikes the wall of the beam chamber. The general idea in designing lattices is to make sure that the dynamic aperture is large enough so that, in the normal course of events, particles in the beam have a very small probability of getting lost due to their amplitude exceeding the dynamic aperture. For long term stability, a common rule of thumb is to design lattices such that the

dynamic aperture is 10 times the beam sigma.¹ For injection studies, the minimum dynamic aperture will be determined in part by the size of the injected beam. In any case, if the dynamic aperture is larger than the physical aperture, increasing the dynamic aperture further will not help beam stability.

If there are no apertures set in lattice used by the *dynamic_aperture* program, the calculated aperture will be the dynamic aperture. If apertures are set in the lattice, the calculated aperture will be the minimum of the dynamic and physical apertures.

The *dynamic_aperture* program is built atop the Bmad software toolkit [1]. The Bmad toolkit is a library, developed at Cornell, for the modeling relativistic charged particles in storage rings and Linacs, as well as modeling photons in x-ray beam lines.

For historical reasons, the *Tao* program (another Bmad based program) is also capable of calculating the dynamic aperture. In fact both programs use the same underlying code for the aperture analysis. The basic difference is that the *dynamic_aperture* program is more flexible in terms of tracking. For example, the *dynamic_aperture* program can handle *ramper* elements and track with maps.

2 Running the Dynamic Aperture Program

The *dynamic_aperture* program comes with the "Bmad Distribution" which is a package which contains the Bmad toolkit library along with a number of Bmad based programs. See the Bmad web site for more details.

If the Bmad Distribution is compiled with *OpenMP* enabled (see the documentation on the Bmad Distribution "Off-Site" setup for more details), the *dynamic_aperture* program can be run parallel. With OpenMP the computation load is distributed over a number of cores on the machine you are using. To set the number of cores set the *OMP_NUM_THREADS* environment variable. Example:

```
export OMP_NUM_THREADS=8
```

And run the program as normal as detailed below.

See the documentation for setting up the Bmad environment variables at

```
https://wiki.classe.cornell.edu/ACC/ACL/RunningPrograms
```

Once the Bmad environment variables have been set, the syntax for invoking the program is:

```
dynamic aperture {<master input file name >}
```

Example:

```
dynamic_aperture my_input_file.init
```

¹While this might seem excessive, this rule of thumb gives some safety margin which is desirable since designs are never exact.

The <master_input_file_name> optional argument is used to set the master input file name. The default value is "dynamic_aperture.init". The syntax of the master input file is explained in §5.

Example input files are in the directory (relative to the root of a Distribution):

bsim/dynamic_aperture/example

3 Time Ramping — Time Varying Element Parameters

"Ramping" is the situation where lattice parameters are changing as a function of time over many turns. Ramping examples include changing magnet and RF strengths to ramp the beam energy or changing magnet strengths to squeeze beta at the interaction pont of a colliding beam machine.

Ramping is accomplished by defining *ramper* elements in the lattice file and setting *ramping_on* to True in the master input file (§5). Ramper elements will be applied to each lattice element in turn before particles are tracked through them. See the Bmad manual for documentation on *ramper* syntax.

Example:

The "*[e_tot]" construct in the definition of ramp_e means that the ramper will be applied all elements (since the wild card character "*" will match to any element name), and it is the element's e tot attribute (the element's reference energy) that will be varied.

In the above example, the *ramp_rf* ramper will be applied to all *ricavity* elements with the cavity voltage and phase (*phi0*) being varied.

Important restriction: Only those ramper elements that have *time* as the first variable will be used and it will be this variable that is varied over time.

In the case where the reference energy e_tot or reference momentum p0c is being varied, the effect on an element will depend upon the setting of the element's $field_master$ parameter. For example:

```
q1: quadrupole, k1 = 0.3
q2: quadrupole, k1 = 0.3, field_master = T
```

In this example, q1 will have its $field_master$ parameter set to False since the quadrupole strength was specified using the normalized strength k1. With q1, since $field_master$ is False, varying the reference energy or momentum will result in the normalized strength k1 remaining fixed

and the unnormalized strength *B1_gradient* varying in proportion to the reference momentum. With *q2*, since *field_master* is True, the unnormalized strength *B1_gradient* will remain fixed and normalized *k1* will vary inversely with the reference momentum.

Before a simulation, individual ramper elements may be toggled on or off by setting the element's *is on* attribute in the lattice file:

```
ramp_rf: ramper = ... ! Ramper element defined.
ramp_rf[is_on] = F     ! Ramper element turned off.
```

4 Fortran Namelist Input

Fortran namelist syntax is used for parameter input in the master input file. The general form of a namelist is

```
&<namelist_name>
     <var1> = ...
     <var2> = ...
     /
```

The tag "&<namelist_name>" starts the namelist where <namelist_name> is the name of the namelist. The namelist ends with the slash "/" tag. Anything outside of this is ignored. Within the namelist, anything after an exclamation mark "!" is ignored including the exclamation mark. <var1>, <var2>, etc. are variable names. Example:

```
&place
  section = 0.0, "arc_std", "elliptical", 0.045, 0.025
/
```

here *place* is the namelist name and *section* is a variable name. Notice that here *section* is a "structure" which has five components – a real number, followed by two strings, followed by two real numbers.

Everything is case insensitive except for quoted strings.

Logical values are specified by *True* or *False* or can be abbreviated *T* or *F*. Avoid using the dots (periods) that one needs in Fortran code.




Figure 1: The calculation of a dynamic aperture curve in the x-y plane at a given initial p_z value involves calculating aperture curve points (blue dots) along a set of "rays" (dashed lines) having a common origin point (\mathcal{O}) which is taken to be the reference orbit. The line segments between points is simply for visualization purposes. The calculation of an aperture curve point along a given ray involves iteratively tracking particles with different starting (x,y) position values to find the boundary between stable (green dots) and unstable (red dots) motion.

5 Master Input File

The *master input file* holds the parameters needed for running the *dynamic_aperture* program. The master input file must contain a single namelist (§4) named *params*. Example:

```
&params
  dat_file = "da.dat"
  Itt%lat file
                         = "lat.bmad"
                                           ! Bmad lattice file
  Itt%ramping on
                         = False
  Itt%ramping_start_time = 0
                         = True
  Itt%rfcavity_on
                         = "BMAD"
  Itt%tracking_method
  ltt%ele_start
  Itt%map order
                         = 5
  Itt%random seed
                         = 0
  Itt%ptc aperture
                         = 0.1, 0.1
  ltt%exclude from maps = "beambeam::*"
  Itt%symplectic_map_tracking = False
  Itt%set_beambeam_z_crossing = False
  ltt%use_rf_clock
  bmad com%radiation damping on = F
  bmad_com%radiation_fluctuations_on = F
```

```
dpz = 0.000, 0.005, 0.010
da_param%min_angle = 0
da_param%max_angle = 3.1415926
da_param%n_angle = 0
da_param%n_turn = 2000
da_param%x_init = 1e-3
da_param%y_init = 1e-3
da_param%rel_accuracy = 1e-2
da_param%abs_accuracy = 1e-5
//
```

Note: The parameters beginning with "Itt" are parameters that are common with the long_term_-tracking program. The parameters beginning with "da_param" are parameters that are common with the dynamic aperture tracking in the Tao program

The parameters in the master input file are:

bmad com%...

The <code>bmad_com</code> structure contains various parameters that affect tracking. For example, whether radiation damping is included in tracking. A full list of <code>bmad_com</code> parameters is detailed in the Bmad reference manual. Note: <code>bmad_com</code> parameters can be set in the Bmad lattice file as well. <code>Bmad_com</code> parameter set in the master input file will take precedence over parameters set in the lattice file.

da param%n turn

Number of turns to track.

da param%n angle

The number of boundary points calculated for a scan is set by the *da_param%n_angle* parameter.

da param%min angle, da param%max angle

These parameters set the ray minimum and maximum angles, labeled θ in Fig 1, in a scan. In the example above the angle ranges from 0 to pi. That is, the upper half-plane. These are typical settings since typically storage rings are vertically symmetric so the aperture curves should vertically symmetric as well.

The angles between adjacent rays is not uniform but are rather calculated to give a roughly equal spacing between boundary points. This is done by looking at the aperture points on a horizontal and a vertical ray and then scaling the ray angles appropriately).

da param%rel accuracy, da param%abs accuracy

These parameters set the relative and absolute accuracies that determine when the search for a boundary point is considered accurate enough.

If $r=\sqrt{(x-x_0)^2+(y-y_0)^2}$ is the distance along any ray of the computed boundary point, where (x_0,y_0) are the coordinates of the origin point, the search for the boundary point will stop then the accuracy of the boundary point is below the desired accuracy σ_{cut} which is computed from

$$\sigma_{cut} = \sigma_a + r \,\sigma_r \tag{1}$$

with σ_a begin the absolute accuracy and σ_r being the relative accuracy.

da_param%x_init, da_param%y_init

These parameters set the initial x and y values used in the first two boundary point searches. The values of these parameters will not affect significantly affect the computed curve but will affect the computation time. If not set, these parameters will default to 0.001 meter.

dat file

Name of the data output file. This name is required.

dpz

The dpz parameter array is a list of p_z values to use. The number of scans (dynamic aperture curves) that are produced is equal to the number of pz values.

ele start

Name or element index of the element to start the tracking. Examples:

```
ele_start = "Q3##2" ! 2nd element named Q3 in the lattice.
ele_start = 37 ! 37th element in the lattice.
```

The default is to start at the beginning of the lattice. Notice that the tracking starts at the downstream end of the element so the first element tracked through is the element after the chosen one.

Itt%ele start

Name or element index of the element to start the tracking. Examples:

```
ele_start = "Q3##2" ! 2nd element named Q3 in the lattice.
ele_start = 37 ! 37th element in the lattice.
```

The default is to start at the beginning of the lattice. Notice that the tracking starts at the downstream end of the element so the first element tracked through is the element after the chosen one. Also see <a href="https://linear.ncbi.nlm.ncbi

Itt%exclude from maps

List of elements to exclude when constructing maps for *SLICK* tracking. These elements will be individually tracking. The default value is "beambeam::*" which excludes any beambeam element. See the Bmad manual section on "Matching to Lattice Element Names" for details on the format for such lists.

Itt%lat file

Name of the Bmad lattice file to use. This name is required. Note: In an old, deprecated format this parameter was called *lat file*.

Itt%map_order

Map order. See Section §6. The default is what is set in the lattice file and if not set in the lattice file the default is 3. Note: *ltt%map_order* is only used when generating a map. When a map is read in from a file, the order of this map is independent of the current setting of *ltt%map_order*.

Itt%ptc_aperture

The PTC code does not have apertures. This being the case, for *ltt%tracking_method* set to *"MAP"* or *"PTC"*, *ltt%ptc_aperture*, which is a 2-vector, defines *x* and *y* apertures. The default is 0.1 meter in both the horizontal and vertical. When used, the aperture is applied at the beginning/end of the lattice. PTC has an internal aperture of 1.0 meter. To be safe, the *long_term_tracking* program will additionally impose a 0.9 meters aperture independent of the setting of *ltt%ptc_aperture*.

Itt%ramping on

If set to True, *ramper* control elements will be use to modify the lattice during tracking (§3). Default is False. Note: In an old, deprecated format this parameter was called *ramping_on*.

Itt%ramping start time

The starting (offset) time used to set *ramper* elements. This enables simulations to start in the middle of a ramp cycle. Default is 0.

Itt%random seed

The random number seed used by the random number generator. If set to 0, the system clock will be used. That is, if set to 0, the output results will vary from run to run.

Itt%rfcavity_on

If set to *False*, the voltage on all RF cavity elements will be turned off. Default is *True*. Note: In an old, deprecated format the corresponding parameter was called *set_rf_off*.

Itt%set beambeam z crossing

If True (default is false), set the $z_crossing$ parameter of any beambeam element in the lattice to the phase space z value of the closed orbit? See the Bmad manual for a discussion of the $z_crossing$ parameter. Generally, $ltt\%set_beambeam_z_crossing$ should be set True.

Itt%symplectic map tracking

If False (the default), the maps used for tracking will be a set of truncated Taylor series polynomials. If True, the tracking maps will be derived from the Taylor map by partially inverting it forming an implicit symplectic map. The advantage of the symplectic map is that it is symplectic. The disadvantage is that, being an implicit map, the computation time will be longer.

Itt%use rf clock

The $Itt\%use_rf_clock$ logical is only relavent if Bmad tracking is being used in conjunction with absolute time tracking and the discussion here assumes Bmad tracking with absolute time tracking. If $Itt\%use_rf_clock$ is set to False (the default), the time used to calculate the phase of any varying fields is the absolute time which increases turn-by-turn. Over many turns this may lead to round-off error. For example, with a 10 GHz cavity, if the phase needs to be measured to one part in 10^5 , it will not be possible to run a simulation past 10 seconds since the double precision numbers used in the code have an accuracy of 10^{-16} .

²See the Bmad manual for a discussion of absolute versus relative time tracking.

There are several possible ways to avoid this round-off problem. If all the frequencies of all the time varying fields are commensurate with the length of the lattice, relative time tracking can be used which uses the particle's z phase space coordinate as the effective clock. If all frequencies are commensurate with each other, but are not commensurate with the lattice length, time patches (patch elements that shift the reference time) can be used with relative time tracking. Finally, if all the frequencies are commensurate, the "RF clock" can be used with absolute time tracking by setting $Itt%use_rf_clock$ to True. The RF clock is simply a clock whose time is reset periodically to be in the range $[0, t_{rf}]$ where t_{rf} is a time period chosen by Bmad to be commensurate with the frequencies of the time varying fields.

6 Tracking Methods

The setting of the parameter *ltt%tracking_method* determines how particles are tracked. Possible settings are:

```
"MAP" ! Tracking using maps.

"PTC" ! Element-by-element tracking with PTC. Slow.

"BMAD" ! Element-by-element tracking using Bmad. Default. Slow.
```

which is used to determine if tracking is done using a map or not. If a map is used, the order of the map (the degree at which the Taylor series comprising the map are truncated) is given by *ltt%map_order* parameter. A larger map order will mean better accuracy at the expense of more computation time. Tracking using a map will be extremely quick compared to element-by-element tracking. However, map tracking can be inaccurate if the map order is too small or the particle amplitude is too large.

Only the *BMAD* method is able to handle a machine that is being ramped (§3). That is, when *Itt%ramping_on* set to True. The program will detect if there is a conflict and issue an error message and stop.

7 Map Tracking

The *long_term_tracking* program uses the PTC/FPP library of Étienne Forest to handle Taylor maps which can be constructed to any arbitrary order. In particular, PTC is used for constructing the map(s) used for tracking when the *ltt%tracking_method* parameter is set to "*MAP*" (§??). PTC tracking is also used when *ltt%tracking_method* is set to "*PTC*". In this case, tracking is done element-by-element using symplectic integration.

Note: Using maps is not compatible when a machine is being ramped (§3).

³Note: Absolute time tracking is not available with PTC. That is, any PTC based tracking is relative time tracking.

⁴If not all the frequencies are commensurate, Bmad will make a best choice and the fields that have frequencies that are not commensurate with the RF clock will use the standard clock instead.

Sometimes it is convenient to exclude certain lattice elements from a map. For example, the beam-beam interaction is highly non-linear so excluding any *beambeam* elements can improve map accuracy at larger amplitudes. Which elements are excluded is determined by the setting of *ltt%exclude_from_maps* which is a list of what elements are to be excluded. Elements can be excluded for a number of reasons. When an element is excluded, multiple maps are created, one for each of the sections of the lattice where there are no excluded elements. In this case, tracking consists of using a map to track from one excluded element to the next followed by tracking through the excluded element.

Important! Maps cannot model RF elements that have a frequency not commensurate with the one-turn frequency. The reason for this is that a map is just a function that maps the particle's starting phase space coordinates to the particle's ending coordinates independent of how many turns the particle has been tracked. But if an RF element has a frequency not commensurate with the one-turn frequency the kick given a particle going through the element will depend upon the turn index. Maps can be used to model a lattice with such RF elements, but in this case such elements must be excluded from be incorporated in any map by setting htt%exclude_from_maps appropriately.

Depending upon how things are setup, a *PTC* map can include radiation damping and fluctuations effects. ⁵ Damping and excitation are controlled by two parameters that can be set in the master input file:

```
bmad_com%radiation_damping_on
bmad_com%radiation_fluctuations_on
```

Maps are saved to a file for use if the program is rerun. For linear maps, an ASCII file can be produced by setting *ltt%map ascii output file*.

8 Tuning Map and PTC Tracking Parameters

When tracking using maps or element-by-element with PTC there are a few points to keep in mind. First is that *PTC* tracks through a lattice element step by step. This is true for both map creation and symplectic integration. This means that the setting of the element parameter *integrator_order*⁶ or *num_steps* (or *ds_step*) for each element will affect the accuracy and speed of the computations. Bmad tries to choose reasonable default settings for the integrator order and number of steps however the calculation is not perfect. To make sure that the integrator order and number of steps is set properly, vary both and choose values (which can be different for different elements) such that the number of steps and integrator order is minimal (to minimize computation time) while at the same time is large enough so that results do not change significantly if the number of steps or is varied. Generally it is much better to use a large integrator order and a small step size rather than vice versa with the proviso that for elements with a longitudinally varying field (think wigglers or undulators), the step size must be small compared to the typical

⁵Radiation fluctuations are included by actually using two maps to track a particle from one point to the next. One map represents the transport with damping and the second map represents the fluctuations. When a particle is tracked, the first map with damping is applied and then the second map is applied using six random numbers.

⁶Note: Valid settings for integrator_order are 2, 4, and 6

longitudinal length scale over which the field is varying (this length scale is the pole period length with wigglers and undulators).

Another thing to keep in mind is that whether a map will give accurate results is dependent on a number of factors. One factor is the order of the map. Generally higher order is better but will take more computation time. When the lattice is tracked using a single map, the tracking is only valid when the tracked particles are far from any strong resonances. That is, if you are interested in tracking halo particles, you probably should not be using a single map.

In terms of speed, using maps will be the fastest, using standard Bmad tracking will be much slower, and using PTC element-by-element tracking will be slowest.

In terms of symplecticity, both the PTC tracking and map tracking will be symplectic. Bmad is not symplectic but the deviation from symplecticity is generally fairly small. If the radiation effects are large enough, the radiative stochastic noise will negate any non-symplectic effects and standard Bmad tracking can be used. A very rough rule of thumb is that if the damping times or the number of turns tracked are under 100,000 turns then Bmad standard tracking can be used.

PTC element-by-element tracking cannot be done when using the MPI version of the *long_term_tracking* program.

9 Correcting the Orbit when Radiation is Present

In storage rings, When radiation damping is simulated, the orbit that is flat when there is no radiation will show a "sawtooth" pattern" in a plot of beam energy versus position. This will lead to a nonzero orbit. In an actual ring, the non-zero orbit will be compensated using steerings. Thus, to simulate the actual ring, compensating steerings should be added to the simulated lattice as well. How to do this is covered in the Bmad and Tao Cookbook available from the Bmad web site.




Figure 2: Example dynamic aperture plot using *gnuplot*.

10 Data Output and Plotting

The data output file whose name is set by dat file will look like:

```
# lat_file
                         = chess_arc_pretzel_20150106.lat
# set_rf_off
                         = T
# da_param%min_angle
                         =
                            0.0000000
# da_param%max_angle
                         =
                            3.1415926
# da_param%rel_accuracy =
                            1.00E-02
... etc. ...
# da_param%n_angle
                         = 37
# gnuplot plotting command:
    plot for [IDX=1:3] "da.dat" index (IDX-1) u 1:2 w lines ...
"dpz = 0.000000"
"x_ref_orb =
              0.000124"
"y_ref_orb =
              0.000037"
                                     Hit +X Side
                           544
                                                        Q11E
   0.068125
              0.000000
   0.033668
              0.002675
                           442
                                     Hit -Y Side
                                                        Q06E
              0.005414
   0.033807
                           717
                                    Hit +Y Side
                                                        Q26W
                                    Hit +X Side
                           410
                                                        B28W
   0.033673
              0.008195
                                    Hit -X Side
   0.033759
              0.011160
                           119
                                                        SEX_08E
                           855
                                    Hit +Y Side
                                                        SEX_21W
   0.034006
              0.014403
... etc. ...
dpz = 0.005000"
```

```
"x ref orb = 0.006591"
"y_ref_orb = 0.006591"
                                    Hit -Y Side
                                                       SEX 16W
   0.073979
              0.000000
                          904
                                    Hit -Y Side
                                                       SEX 19E
   0.050379
              0.004234
                          554
                                    Hit -X Side
                                                       SEX 39E
   0.038989
                          987
              0.006603
                                                       SEX 15W
                                    Hit +Y Side
                          447
   0.038242
              0.009842
                                    Hit +X Side
                                                       SEX 41E
   0.037746
              0.013196
                          365
... etc. ...
```

The top part of the data file will be a record of input parameter values. This is followed by a number of data blocks, one for each setting of *dpz*. The five columns of these data blocks are:

```
    1 & 2: x_aperture, y_aperture
    3: Number of turns a particle initially at the aperture limit survived.
    4: Transverse location where particle died.
    5: Lattice element where particle died.
```

Note that a particle will "die" if it hits an aperture or its amplitude is beyond the setting of bmad_com%max_aperture_limit. The default value of this maximum aperture is 1000 meters.

One way to plot the data is to use the *gnuplot* program (documentation for gnuplot is available using a web search). Run *gnuplot* and use the command printed in the top section of the data file. An example of what such a plot looks like is shown in Fig. 2.

References

[1] D. Sagan, "Bmad: A Relativistic Charged Particle Simulation Library" Nuc. Instrum. & Methods Phys. Res. A, **558**, pp 356-59 (2006).