
Virtual Panel

Quick Reference

Arduino Experiment Control Panel



^{*}Default 250ms

OpenFile 'x' (1..4) send char* file path string*

	Receive
int32	line count if open
void	if file not open

- *- dir. path only, sets dialog path.
- filename or wildcard + ext. opens or creates file via dialog.
- ext. sets dialog file filter.

Message Log Panel

- /f forces open/create w/o dialog if specified dir. / dialog dir. valid.

Records panel incoming (R) and

panel outgoing (S) messages.

FileOpenDialogTitle 'x' (1..4) send

char*	set dialog title

ReadLineFile_'x' (1..4) send

void	read next line
int32	set next read line nr.

		Receive
char*	line read *	
void	end of file	

^{*} Truncates to 60 chars.


WriteLineFile 'x' (1..4) char* write next line int32 set next write line nr.

ClearFile_'x' (14)		send	
	void	clear open file	•

DeleteFile_'x' (14)		send	
	void	delete open file	

Monitor Panel

Provides a log panel and additional displays and inputs



Message Log

Format:

146 R Display_2 vp_string Test {MessageNumber} {Send/Receive} {channel} {VarType} {Value}

Monitor channels / events

Monitor	send
bool	win. visible/invisible

MonitorField_'x' (16)		send	
	any	display as text	

MonitorInput_'x' (1..6) static/volatile bool any* value receive

	TCCCIVC
any*	value
void	discard

^{*}Type same as sent type

MonitorInput	Label_'x' (12) send
any	Input label text

MinMonitorInput_'x' (1..6) send MaxMonitorInput_'x' (1..6) send num* value

114111	value
*Int16, int32	, uint32, float32.

When string: min/max length.

MonitorLog


send

any	display as text
\$CLEAR ¹	clear Log

¹See special strings

Info Panel

Application dependent help panel.



Info channels/ events

Info send win. visible/invisible bool \$CLEAR1 Resets to default.


InfoTitle any* title text *Also clears InfoText

InfoText char* Info text*

max 60 char per send. Can be repeated for larger text

Graph Panel

Graphic display functions (rolling/static graph, draw) panel, including additional labels and buttons.



Graph channels/events

Graph	send
bool	win. visible/invisible
\$CLEAR1	clear graph*

*Not values

GraphGrid	send
int16	vert, grid count

GraphDrawLine send

void	line start
uint16 ²	line point (x,y)
uint32 ²	line segment
	(x,y,x ['] ,y ['])
color1	line color
width ¹	line width

GraphDrawPixel send

uint16 ²	point (x,y)
color1	pixel color
width ¹	pixel width

GraphDrawCircle send

params ²	circle parameters
color1	circle color
width ¹	circle width

GraphCaption_'x' (12)		send
any	Caption text	

Data types and Panel Variables

Data types

Data types	
vp_type::vp_void	void
vp_type::vp_boolean	bool
vp_type::vp_string	char*
vp_type::vp_byte	byte
vp_type::vp_int	int16
vp_type::vp_uint	uint16
vp_type::vp_long	int32
vp_type::vp_ulong	uint32
vp_type::vp_float	float

Event data type received in:

Panel.vpr_type	vpr_type	

Graph Panel 255(x) X 220(y) Actual 263(x) for GraphValue

GraphText	send	
color ¹	text color	
uint16 ²	point 2 x byte (x,y)	
char*	text	

GraphValue 'x' (1..5) send

byte	graph value (0-255)
color1	graph color
width ¹	line width string
type ¹	rolling/static
\$CLEAR ¹	clear sent values

GraphValueCount_'x' (1..5) send int16 hor. value count*

¹See: Special strings

² See: Helper functions Draw: _Point(), _Line(), _Circle().

GraphButton 'x' (1..4) send

any	button text	
color ¹	button color	
size ¹	text size	
	•	receive

void on button click

Panel variables

(Event data received)

(Lvent data received)	1
Panel.vpr_void	void
Panel.vpr_bool	bool
Panel.vpr_string	char*
Panel.vpr_byte	byte
Panel.vpr_int	int16_t
Panel.vpr_uint	unint16_t
Panel.vpr_long	int32_t
Panel.vpr_ulong	unit32_t
Panel.vpr_float	float32_t

GraphClick receive
GraphRightClick receive
GraphDoubleClick* receive

uint16**	click position

* occurs together with GraphClick **uint 2 x byte (X,Y)

(same as -DrawPixel and -DrawLine)

GraphLabel_'x' (1..5) send

bool	visible/invisible
any	label text
color ¹	color bar color*

^{* \$}OFF (color bar invisible)

GraphInput_'x' (1..5) send

bool	static/volatile
any*	set value
	receive

any*	value
void	discard

^{*}Type same as sent type

GraphInputLabel_'x' (1..5) send any Input label text

MinGraphInput_'x' (1..5) send
MaxGraphInput 'x' (1..5) send

Maxorapinin	ut_ x (1)	Seria
num*	min/max va	lue

^{**}Int16, int32, uint32, float32. When string min/max length.

vpr_void DynamicDisplay (timer),
Button, GraphButton (click),
ReadLineFile (eof),
Display (double click), PanelInput,
MonitorInput, GraphInput (discard)
vpr_bool OpenFile, WriteLineFile
vpr_string ReadLineFile (line read)
vpr_int Slider (slider value)
vpr_long UnixTime (timecode)
OpenFile (linecount)
any type: PanelInput, MonitorInput ,
GraphInput (send)

Code example:

if (Panel.vpr_type==vp_type::vp_int)
MyInt = Panel.vpr_int;

^{*}Default value 50.

Special strings

Color strings

For: ApplicationName, Display, Led, Button, GraphButton, GraphValue, GraphDrawLine,

GraphDrawPixel, GraphDrawCircle.

\$DEL(ETE)*	
\$OFF**	
\$BLACK	
\$GRAY	•
\$PURPLE	
\$DPURPLE***	į
\$PINK	
\$LBLUE***	
\$BLUE	
\$DBLUE***	į
\$GREEN	•
\$YELLOW	_
\$ORANGE	•
\$RED	•
\$BROWN	
\$WHITE	

^{*}draw only **led only ***not panel

(Helper) Functions

Panel Delay function

bool Panel.Delay(int16 t milliseconds, bool receive) Allows to check for incoming messages during delay. If receive is true. Panel receive is called. If an incoming message was detected true is returned.

Panel Synchronous request

bool PanelSyncRequest(event) Request event and waits for answer. Only for ReadLineFile_x and UnixTime events. Concurrent use blocked! On success true : PanelSrqStatus = vpsrq_Success else false : vpsrq_Timeout / vpsrq_InvalidChannel / vpsrq_ConcurrencyErr.

Helper function Sound

uint32 t Sound(int freq, int dur) Combines two int16_t (frequency Hz, duration mS) into one uint32 t.

Helper functions Draw

Point() uint16 t Point(byte x, byte y) combines 2 bytes into uint16 t

(x,y) for a point. When sent to GraphDrawLine consecutive points are connected in a line.

Line() uint32 t Line(byte Fx, Fy, Tx, Ty) Combines four bytes into uint32_t (x from, y from, x to, y to) Circle()

Graph Type strings

Set graph type for: GraphValue. Rolling values are added right and move to left. Static waits until all values have been sent then displays.

\$ROLING*	Set rolling graph
\$STATIC	Set static graph

^{*} default

Pen size strings Draw

Size for: GraphDrawPixel, GraphDrawLine, GraphDrawCircle, GraphValue.

\$1PX*	1 pixel
\$2PX	2x2 pixels
\$3PX	3x3 pixels
\$4PX	4x4 pixels
\$8PX**	8x8 pixels
\$16PX**	16x16 pixels

^{*} default **draw only

char * _Circle(byte x, byte y, byte rad, int angle, int arc) Center (x,y) rad (radius), start angle, arc angle. Omitting angle and arc draws a full circle.

_VPoint() /_VLine() /_VCircle() uint16_t _VPoint(byte x, byte y) uint32_t _VLine(byte Fx, Fy, Tx, Ty) char * _VCircle(byte x, byte y, byte rad, int angle, int arc) Same as _Point, _Line and _Circle but transforms y values from value (0-255) to coordinate (0-220).

Sendf() / Printf formatting %[flags][width][length]specifier

cnacifiare (limited list)

specifiers (limited list)			
%с	ascii char	byte	
%d	signed dec.	int16	
%ld	signed dec.	int32	
%u	unsigned dec.	uint16	
%lu	unsigned dec.	uint32	
%o	unsigned octal	any	
%x	uns. hex lc/uc	any	
%s	string	char[]	
%f*	float	float	

^{*}Not AVR supported. see: sendf() float

flaas

jiugs	
-	left justify
+	force sign
0	pad zero's

Examples:

Panel.sendf (Display_1, "Test %d", 10) // output: Test 10

Text attributes/size strings

For: Display, Button, GraphButton.

\$SMALL	font size small	
\$NORMAL*	font size normal	
\$BIG	font size big	
\$BOLD	bold text	
\$xPT**	point size	

*Default. Resets bold and big **Buttons x = 6, $\underline{7}^{s}$, $\underline{8}^{n}$, 9, 10, $\underline{11}^{b}$, 12, 14, 16, 18 - Displays x = 10, 11, 12°, 13, <u>14</u>ⁿ, 16, <u>18</u>^b

Clear Function

MonitorLog, Info. Graph, GraphValue.

wiorintorlog, iiiio, drapir, drapirvalac.	
\$CLEAR	clear/reset entity

Button repeat Function

Button.

Dattoill	
\$REPEAT	set button rep.
\$NOREPEAT*	set button click

^{*}default

Panel.sendf(Display_1, "Test %03d", 10) // output: Test 010 Panel.sendf(Display_1, "Test %+d", 10) // output: Test +10 Helper function Float string char * FString(floatNumber, length, decimals);

sendf() float

Float not supported on AVR (Uno, Nano, Mega ...) Use _FString() helper function. char* _FString(floatNumber, length, decimals); again with Panel.sendf using "%s"

Example:

Panel.sendf(Display_1, "Value %s", FString(FloatValue, 5, 2)); Prints FloatValue using 5 chars, 3 of which are a '.' and 2 decimals.

Unicode characters

Using send() or sendf() to send a string, Unicode characters can be used. Simply copy and paste into the string.

F() Macro

In both send() and sendf() the F() macro for strings is allowed. This will force the string to be placed in program memory. (not Due) Example:

Panel.sendf (Display_1, F("Value %d"), 10);