OPL1000_WIFI_BLE_API_GUIDE MP2.12

Generated by Doxygen 1.8.14

Contents

1	Mod	odule Index 1					
	1.1	Module	es		1		
2	Data	Structi	ure Index		3		
	2.1	Data S	tructures		3		
3	Mod	ule Doc	umentatio	on	7		
	3.1	BLE AI	LL APIs .		7		
		3.1.1	Detailed	Description	7		
		3.1.2	Function	Documentation	7		
			3.1.2.1	LeSmpGetBondIdFromAddr()	7		
	3.2	BLE C	M APIs .		8		
		3.2.1	Detailed	Description	9		
		3.2.2	Typedef I	Documentation	9		
			3.2.2.1	LE_CM_MSG_ADD_TO_RESOLVING_LIST_CFM_T	9		
			3.2.2.2	LE_CM_MSG_ADD_TO_WHITE_LIST_CFM_T	9		
			3.2.2.3	LE_CM_MSG_CANCEL_CONNECTION_CFM_T	10		
			3.2.2.4	LE_CM_MSG_CLEAR_RESOLVING_LIST_CFM_T	10		
			3.2.2.5	LE_CM_MSG_CLEAR_WHITE_LIST_CFM_T	10		
			3.2.2.6	LE_CM_MSG_CREATE_CONNECTION_CFM_T	10		
			3.2.2.7	LE_CM_MSG_ENTER_ADVERTISING_CFM_T	10		
			3.2.2.8	LE_CM_MSG_ENTER_SCANNING_CFM_T	10		
			3.2.2.9	LE_CM_MSG_EXIT_ADVERTISING_CFM_T	10		
			3.2.2.10	LE CM MSG EXIT SCANNING CFM T	10		

ii CONTENTS

		3.2.2.11	LE_CM_MSG_PHY_UPDATE_COMPLETE_IND_T	11
		3.2.2.12	LE_CM_MSG_REMOVE_FROM_RESOLVING_LIST_CFM_T	11
		3.2.2.13	LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM_T	11
		3.2.2.14	LE_CM_MSG_SET_ADVERTISING_DATA_CFM_T	11
		3.2.2.15	LE_CM_MSG_SET_ADVERTISING_PARAMS_CFM_T	11
		3.2.2.16	LE_CM_MSG_SET_CHANNEL_MAP_CFM_T	11
		3.2.2.17	LE_CM_MSG_SET_DEFAULT_PHY_CFM_T	11
		3.2.2.18	LE_CM_MSG_SET_RANDOM_ADDRESS_CFM_T	11
		3.2.2.19	LE_CM_MSG_SET_RPA_TIMEOUT_CFM_T	12
		3.2.2.20	LE_CM_MSG_SET_SCAN_PARAMS_CFM_T	12
		3.2.2.21	LE_CM_MSG_SET_SCAN_RSP_DATA_CFM_T	12
	3.2.3	Enumera	tion Type Documentation	12
		3.2.3.1	anonymous enum	12
	3.2.4	Function	Documentation	13
		3.2.4.1	LeCmInit()	13
3.3	BLE G	AP APIs		15
	3.3.1	Detailed	Description	17
	3.3.2	Macro De	efinition Documentation	17
		3.3.2.1	GAP_ADTYPE_128BIT_COMPLETE	17
		3.3.2.2	GAP_ADTYPE_128BIT_MORE	17
		3.3.2.3	GAP_ADTYPE_16BIT_COMPLETE	18
		3.3.2.4	GAP_ADTYPE_16BIT_MORE	18
		3.3.2.5	GAP_ADTYPE_32BIT_COMPLETE	18
		3.3.2.6	GAP_ADTYPE_32BIT_MORE	18
		3.3.2.7	GAP_ADTYPE_3D_INFO_DATA	18
		3.3.2.8	GAP_ADTYPE_ADV_INTERVAL	18
		3.3.2.9	GAP_ADTYPE_APPEARANCE	18
		3.3.2.10	GAP_ADTYPE_FLAGS	18
				40
		3.3.2.11	GAP_ADTYPE_FLAGS_BREDR_NOT_SUPPORTED	19

3.3.2.13	GAP_ADTYPE_FLAGS_LIMITED	19
3.3.2.14	GAP_ADTYPE_LE_BD_ADDR	19
3.3.2.15	GAP_ADTYPE_LE_ROLE	19
3.3.2.16	GAP_ADTYPE_LOCAL_NAME_COMPLETE	19
3.3.2.17	GAP_ADTYPE_LOCAL_NAME_SHORT	19
3.3.2.18	GAP_ADTYPE_MANUFACTURER_SPECIFIC	19
3.3.2.19	GAP_ADTYPE_OOB_CLASS_OF_DEVICE	20
3.3.2.20	GAP_ADTYPE_OOB_SIMPLE_PAIRING_HASHC	20
3.3.2.21	GAP_ADTYPE_OOB_SIMPLE_PAIRING_RANDR	20
3.3.2.22	GAP_ADTYPE_POWER_LEVEL	20
3.3.2.23	GAP_ADTYPE_PUBLIC_TARGET_ADDR	20
3.3.2.24	GAP_ADTYPE_RANDOM_TARGET_ADDR	20
3.3.2.25	GAP_ADTYPE_SERVICE_DATA	20
3.3.2.26	GAP_ADTYPE_SERVICE_DATA_128BIT	20
3.3.2.27	GAP_ADTYPE_SERVICE_DATA_32BIT	21
3.3.2.28	GAP_ADTYPE_SERVICES_LIST_128BIT	21
3.3.2.29	GAP_ADTYPE_SERVICES_LIST_16BIT	21
3.3.2.30	GAP_ADTYPE_SIGNED_DATA	21
3.3.2.31	GAP_ADTYPE_SIMPLE_PAIRING_HASHC_256	21
3.3.2.32	GAP_ADTYPE_SIMPLE_PAIRING_RANDR_256	21
3.3.2.33	GAP_ADTYPE_SLAVE_CONN_INTERVAL_RANGE	21
3.3.2.34	GAP_ADTYPE_SM_OOB_FLAG	21
3.3.2.35	GAP_ADTYPE_SM_TK	22
3.3.2.36	GAP_PUBLIC_ADDR	22
3.3.2.37	GAP_RAND_ADDR_NRPA	22
3.3.2.38	GAP_RAND_ADDR_RPA	22
3.3.2.39	GAP_RAND_ADDR_STATIC	22
3.3.2.40	GAP_SCAN_TYPE_ACTIVE	22
3.3.2.41	GAP_SCAN_TYPE_PASSIVE	22
3.3.2.42	GAP_TX_PWR_CURR_VAL	22

iv CONTENTS

	3.3.2.43	GAP_TX_PWR_MAX_VAL	23
	3.3.2.44	GAPBOND_IO_CAP_DISPLAY_ONLY	23
	3.3.2.45	GAPBOND_IO_CAP_DISPLAY_YES_NO	23
	3.3.2.46	GAPBOND_IO_CAP_KEYBOARD_DISPLAY	23
	3.3.2.47	GAPBOND_IO_CAP_KEYBOARD_ONLY	23
	3.3.2.48	GAPBOND_IO_CAP_NO_INPUT_NO_OUTPUT	23
	3.3.2.49	GAPBOND_PAIRING_MODE_INITIATE	23
	3.3.2.50	GAPBOND_PAIRING_MODE_NO_PAIRING	23
	3.3.2.51	GAPBOND_PAIRING_MODE_WAIT_FOR_REQ	24
	3.3.2.52	LE_GAP_ADV_MAX_SIZE	24
3.3.3	Function	Documentation	24
	3.3.3.1	LeGapAddToResolvingList()	24
	3.3.3.2	LeGapAddToWhiteList()	24
	3.3.3.3	LeGapAdvertisingEnable()	25
	3.3.3.4	LeGapCentralConnectReq()	25
	3.3.3.5	LeGapCentralSetDataChannel()	25
	3.3.3.6	LeGapClearResolvingList()	27
	3.3.3.7	LeGapClearWhiteList()	27
	3.3.3.8	LeGapConnectCancelReq()	27
	3.3.3.9	LeGapConnParaRequestRsp()	27
	3.3.3.10	LeGapConnUpdateRequest()	28
	3.3.3.11	LeGapConnUpdateResponse()	28
	3.3.3.12	LeGapDisconnectReq()	29
	3.3.3.13	LeGapGenRandAddr()	29
	3.3.3.14	LeGapGetBtAddr()	29
	3.3.3.15	LeGapReadAdvChannelTxPower()	30
	3.3.3.16	LeGapReadChannelMap()	30
	3.3.3.17	LeGapReadPhy()	30
	3.3.3.18	LeGapReadResolvingListSize()	30
	3.3.3.19	LeGapReadRssi()	30

		3.3.3.20	LeGapReadTxPower()	31
		3.3.3.21	LeGapReadWhiteListSize()	31
		3.3.3.22	LeGapRemoveFromWhiteList()	31
		3.3.3.23	LeGapScanningReq()	32
		3.3.3.24	LeGapSetAdvData()	32
		3.3.3.25	LeGapSetAdvParameter()	33
		3.3.3.26	LeGapSetConnParameter()	33
		3.3.3.27	LeGapSetDataChannelPduLen()	33
		3.3.3.28	LeGapSetDefaultPhy()	34
		3.3.3.29	LeGapSetPhy()	34
		3.3.3.30	LeGapSetRandAddr()	34
		3.3.3.31	LeGapSetRpaTimeout()	35
		3.3.3.32	LeGapSetStaticAddr()	35
		3.3.3.33	LeSetScanParameter()	35
		3.3.3.34	LeSetScanRspData()	36
3.4	BLE G	ATT APIs		37
	3.4.1	Detailed	Description	41
	3.4.2	Macro De	efinition Documentation	41
	3.4.2	Macro De 3.4.2.1	CHAR_AGGREGATE_DESCRIPTOR	41 41
	3.4.2			
	3.4.2	3.4.2.1	CHAR_AGGREGATE_DESCRIPTOR	41
	3.4.2	3.4.2.1 3.4.2.2	CHAR_AGGREGATE_DESCRIPTOR	41 42
	3.4.2	3.4.2.1 3.4.2.2 3.4.2.3	CHAR_AGGREGATE_DESCRIPTOR	41 42 42
	3.4.2	3.4.2.1 3.4.2.2 3.4.2.3 3.4.2.4	CHAR_AGGREGATE_DESCRIPTOR	41 42 42 42
	3.4.2	3.4.2.1 3.4.2.2 3.4.2.3 3.4.2.4 3.4.2.5	CHAR_AGGREGATE_DESCRIPTOR CHAR_CLIENT_CONFIG_DESCRIPTOR CHAR_DECL_UUID16_ATTR_VAL CHAR_EXT_PROP_DESCRIPTOR CHAR_PRESENT_FORMAT_DESCRIPTOR	41 42 42 42 42
	3.4.2	3.4.2.1 3.4.2.2 3.4.2.3 3.4.2.4 3.4.2.5 3.4.2.6	CHAR_AGGREGATE_DESCRIPTOR. CHAR_CLIENT_CONFIG_DESCRIPTOR. CHAR_DECL_UUID16_ATTR_VAL. CHAR_EXT_PROP_DESCRIPTOR. CHAR_PRESENT_FORMAT_DESCRIPTOR. CHAR_SERVER_CONFIG_DESCRIPTOR.	41 42 42 42 42 42
	3.4.2	3.4.2.1 3.4.2.2 3.4.2.3 3.4.2.4 3.4.2.5 3.4.2.6 3.4.2.7	CHAR_AGGREGATE_DESCRIPTOR. CHAR_CLIENT_CONFIG_DESCRIPTOR. CHAR_DECL_UUID16_ATTR_VAL. CHAR_EXT_PROP_DESCRIPTOR. CHAR_EXT_PROP_DESCRIPTOR. CHAR_PRESENT_FORMAT_DESCRIPTOR. CHAR_SERVER_CONFIG_DESCRIPTOR. CHAR_USER_DESC_DESCRIPTOR.	411 422 422 422 422 423
	3.4.2	3.4.2.1 3.4.2.2 3.4.2.3 3.4.2.4 3.4.2.5 3.4.2.6 3.4.2.7 3.4.2.8	CHAR_AGGREGATE_DESCRIPTOR CHAR_CLIENT_CONFIG_DESCRIPTOR CHAR_DECL_UUID16_ATTR_VAL CHAR_EXT_PROP_DESCRIPTOR CHAR_PRESENT_FORMAT_DESCRIPTOR CHAR_SERVER_CONFIG_DESCRIPTOR CHAR_USER_DESC_DESCRIPTOR CHARACTERISTIC_DECL_UUID128	41 42 42 42 42 42 43
	3.4.2	3.4.2.1 3.4.2.2 3.4.2.3 3.4.2.4 3.4.2.5 3.4.2.6 3.4.2.7 3.4.2.8 3.4.2.9	CHAR_AGGREGATE_DESCRIPTOR CHAR_CLIENT_CONFIG_DESCRIPTOR CHAR_DECL_UUID16_ATTR_VAL CHAR_EXT_PROP_DESCRIPTOR CHAR_PRESENT_FORMAT_DESCRIPTOR CHAR_SERVER_CONFIG_DESCRIPTOR CHAR_USER_DESC_DESCRIPTOR CHARACTERISTIC_DECL_UUID128 CHARACTERISTIC_DECL_UUID16	41 42 42 42 42 42 43 43

vi

3.4.2.13	GATT_CHAR_EXT_PROPS_UUID	43
3.4.2.14	GATT_CHAR_FORMAT_UUID	44
3.4.2.15	GATT_CHAR_USER_DESC_UUID	44
3.4.2.16	GATT_CHARACTERISTIC_UUID	44
3.4.2.17	GATT_CLIENT_CHAR_CFG_UUID	44
3.4.2.18	GATT_EXT_REPORT_REF_UUID	44
3.4.2.19	GATT_INCLUDE_UUID	44
3.4.2.20	GATT_PRIMARY_SERVICE_UUID	44
3.4.2.21	GATT_REPORT_REF_UUID	44
3.4.2.22	GATT_SECONDARY_SERVICE_UUID	45
3.4.2.23	GATT_SERV_CHAR_CFG_UUID	45
3.4.2.24	GATT_VALID_RANGE_UUID	45
3.4.2.25	INCLUDE_DECL_UUID128	45
3.4.2.26	INCLUDE_DECL_UUID128_ATTR_VAL	45
3.4.2.27	INCLUDE_DECL_UUID16_ATTR_VAL	45
3.4.2.28	INCLUDE_DECL_UUINT16	45
3.4.2.29	LE_ATT_UUID_SIZE	46
3.4.2.30	LE_GATT_CHAR_PROP_AUTH	46
3.4.2.31	LE_GATT_CHAR_PROP_BCAST	46
3.4.2.32	LE_GATT_CHAR_PROP_EXT_PROP	46
3.4.2.33	LE_GATT_CHAR_PROP_IND	46
3.4.2.34	LE_GATT_CHAR_PROP_NTF	46
3.4.2.35	LE_GATT_CHAR_PROP_RD	46
3.4.2.36	LE_GATT_CHAR_PROP_WR	47
3.4.2.37	LE_GATT_CHAR_PROP_WR_NO_RESP	47
3.4.2.38	LE_GATT_CLIENT_CFG_INDICATION	47
3.4.2.39	LE_GATT_CLIENT_CFG_NOTIFICATION	47
3.4.2.40	LE_GATT_EXT_PROP_RELIABLE_WR	47
3.4.2.41	LE_GATT_EXT_PROP_WR_AUX	47
3.4.2.42	LE_GATT_FLAG_PREPARE_WRITE	47

CONTENTS vii

	3.4.2.43	LE_GATT_FLAG_WRITE_CMD	47
	3.4.2.44	LE_GATT_FLAG_WRITE_REQ	48
	3.4.2.45	LE_GATT_PERM_AUTH_READABLE	48
	3.4.2.46	LE_GATT_PERM_AUTH_WRITABLE	48
	3.4.2.47	LE_GATT_PERM_NONE	48
	3.4.2.48	LE_GATT_PERM_READ	48
	3.4.2.49	LE_GATT_PERM_RELIABLE_WRITE	48
	3.4.2.50	LE_GATT_PERM_WRITE_CMD	48
	3.4.2.51	LE_GATT_PERM_WRITE_REQ	48
	3.4.2.52	LE_GATT_PERMIT_AUTHEN_READ	49
	3.4.2.53	LE_GATT_PERMIT_AUTHEN_WRITE	49
	3.4.2.54	LE_GATT_PERMIT_AUTHOR_READ	49
	3.4.2.55	LE_GATT_PERMIT_AUTHOR_WRITE	49
	3.4.2.56	LE_GATT_PERMIT_ENCRYPT_READ	49
	3.4.2.57	LE_GATT_PERMIT_ENCRYPT_WRITE	49
	3.4.2.58	LE_GATT_PERMIT_READ	49
	3.4.2.59	LE_GATT_PERMIT_READABLE	49
	3.4.2.60	LE_GATT_PERMIT_SC_AUTHEN_READ	50
	3.4.2.61	LE_GATT_PERMIT_SC_AUTHEN_WRITE	50
	3.4.2.62	LE_GATT_PERMIT_WRITABLE	50
	3.4.2.63	LE_GATT_PERMIT_WRITE	50
	3.4.2.64	PRIMARY_SERVICE_DECL_UUID128	50
	3.4.2.65	PRIMARY_SERVICE_DECL_UUID16	50
	3.4.2.66	SECONDARY_SERVICE_DECL_UUID128	50
	3.4.2.67	SECONDARY_SERVICE_DECL_UUID16	51
3.4.3	Enumera	tion Type Documentation	51
	3.4.3.1	anonymous enum	51
3.4.4	Function	Documentation	52
	3.4.4.1	LeGattAccessReadRsp()	52
	3.4.4.2	LeGattAccessWriteRsp()	52

viii CONTENTS

3.4.4.3	LeGattChangeAttrVal()	53
3.4.4.4	LeGattCharValConfirmation()	53
3.4.4.5	LeGattCharValIndicate()	54
3.4.4.6	LeGattCharValNotify()	54
3.4.4.7	LeGattExchangeMtuReq()	55
3.4.4.8	LeGattExchangeMtuRsp()	55
3.4.4.9	LeGattExecuteWriteCharValReliable()	56
3.4.4.10	LeGattFindAllCharacteristic()	56
3.4.4.11	LeGattFindAllCharDescriptor()	56
3.4.4.12	LeGattFindAllPrimaryService()	57
3.4.4.13	LeGattFindCharacteristicByUuid()	57
3.4.4.14	LeGattFindIncludedService()	58
3.4.4.15	LeGattFindPrimaryServiceByUuid()	58
3.4.4.16	LeGattGetAttrHandle()	59
3.4.4.17	LeGattGetAttrVal()	59
3.4.4.18	LeGattGetAttrValLen()	59
3.4.4.19	LeGattGetAttrValMaxLen()	61
3.4.4.20	LeGattInit()	61
3.4.4.21	LeGattModifyAttrVal()	62
3.4.4.22	LeGattPrepareWriteCharValReliable()	62
3.4.4.23	LeGattReadCharValByUuid()	63
3.4.4.24	LeGattReadCharValue()	63
3.4.4.25	LeGattReadLongCharVal()	64
3.4.4.26	LeGattReadMultipleCharVal()	64
3.4.4.27	LeGattRegisterIncludeService()	64
3.4.4.28	LeGattRegisterService()	65
3.4.4.29	LeGattSignedWriteNoRsp()	65
3.4.4.30	LeGattStopCurrentProcedure()	66
3.4.4.31	LeGattWriteCharVal()	66
3.4.4.32	LeGattWriteCharValReliable()	67

		3.4.4.33	LeGattWriteLongCharVal()	67
		3.4.4.34	LeGattWriteNoRsp()	68
	3.4.5	Variable	Documentation	68
		3.4.5.1	gcCharacteristicUuid	68
		3.4.5.2	gcCharAggregateUuid	68
		3.4.5.3	gcCharExtPropUuid	69
		3.4.5.4	gcCharFormatUuid	69
		3.4.5.5	gcCharUserDescUuid	69
		3.4.5.6	gcClientCharConfigUuid	69
		3.4.5.7	gcExtReportRefUuid	69
		3.4.5.8	gcIncludeUuid	69
		3.4.5.9	gcPrimaryServiceUuid	69
		3.4.5.10	gcReportRefUuid	69
		3.4.5.11	gcSecondaryServiceUuid	70
		3.4.5.12	gcServerCharConfigUuid	70
		3.4.5.13	gcValidRangeUuid	70
3.5	BLE M	SG APIs		71
	3.5.1	Detailed	Description	72
	3.5.2	Macro De	efinition Documentation	72
		3.5.2.1	LE_ATT_MSG_BASE	72
		3.5.2.2	LE_CM_MSG_BASE	72
		3.5.2.3	LE_GATT_MSG_BASE	73
		3.5.2.4	LE_HCI_MSG_BASE	73
		3.5.2.5	LE_L2CAP_MSG_BASE	73
		3.5.2.6	LE_SMP_MSG_BASE	73
		3.5.2.7	LE_SYS_MSG_BASE	73
		3.5.2.8	MESSAGE_ALLOCATE	73
		3.5.2.9	MESSAGE_BULID	73
		3.5.2.10	MESSAGE_DATA_BULID	74
		3.5.2.11	MESSAGE_OFFSET	74

	3.5.2.12	T_HOUR	. 74
	3.5.2.13	T_MIN	. 74
	3.5.2.14	T_SEC	. 74
3.5.3	Typedef I	Documentation	. 74
	3.5.3.1	MESSAGE	. 74
	3.5.3.2	MESSAGEID	. 75
	3.5.3.3	MsgData	. 75
	3.5.3.4	MsgLock	. 75
	3.5.3.5	MSGLOCK	. 75
	3.5.3.6	MSGSUBID	. 75
	3.5.3.7	MSGTIMER	. 75
	3.5.3.8	Task	. 75
	3.5.3.9	TASK	. 75
	3.5.3.10	TASKHANDLER	. 76
	3.5.3.11	TASKPACK	. 76
3.5.4	Enumera	ation Type Documentation	. 76
	3.5.4.1	anonymous enum	. 76
3.5.5	Function	Documentation	. 76
	3.5.5.1	LeCancelAllMessage()	. 76
	3.5.5.2	LeCancelAllSubMessage()	. 77
	3.5.5.3	LeCancelFirstMessage()	. 77
	3.5.5.4	LeCancelFirstSubMessage()	. 78
	3.5.5.5	LeGetSubMsgld()	. 78
	3.5.5.6	LeHostCreateTask()	. 78
	3.5.5.7	LeHostMessageLoop()	. 79
	3.5.5.8	LeSendMessage()	. 79
	3.5.5.9	LeSendMessageAfter()	. 79
	3.5.5.10	LeSendMessageUnlock()	. 80
	3.5.5.11	LeSendSubMessage()	. 80
	3.5.5.12	LeSendSubMessageAfter()	. 81

CONTENTS xi

		3.5.5.13	LeSendSubMessageUnlock()	81
3.6	BLE SI	MP APIs		83
	3.6.1	Detailed	Description	84
	3.6.2	Macro De	efinition Documentation	84
		3.6.2.1	LE_MAX_BOND_COUNT	84
		3.6.2.2	LE_SM_IO_CAP_DISP_ONLY	84
		3.6.2.3	LE_SM_IO_CAP_DISP_YES_NO	84
		3.6.2.4	LE_SM_IO_CAP_KEYBOARD_DISP	85
		3.6.2.5	LE_SM_IO_CAP_KEYBOARD_ONLY	85
		3.6.2.6	LE_SM_IO_CAP_NO_IO	85
		3.6.2.7	LE_SM_PAIR_MITM_NO	85
		3.6.2.8	LE_SM_PAIR_MITM_YES	85
		3.6.2.9	LE_SM_PAIR_OOB_NO	85
		3.6.2.10	LE_SM_PAIR_OOB_YES	85
		3.6.2.11	LE_SM_PAIR_SC_NO	85
		3.6.2.12	LE_SM_PAIR_SC_YES	86
	3.6.3	Enumera	tion Type Documentation	86
		3.6.3.1	anonymous enum	86
		3.6.3.2	anonymous enum	86
	3.6.4	Function	Documentation	87
		3.6.4.1	LeSmpInit()	87
		3.6.4.2	LeSmpOobAuthDataRsp()	87
		3.6.4.3	LeSmpOobPresent()	87
		3.6.4.4	LeSmpPasskeyInput()	88
		3.6.4.5	LeSmpScOobComputeConfirmVal()	88
		3.6.4.6	LeSmpScOobDataRsp()	89
		3.6.4.7	LeSmpSecurityReq()	89
		3.6.4.8	LeSmpSecurityRsp()	89
		3.6.4.9	LeSmpSetDefaultConfig()	90
		3.6.4.10	LeSmpUserConfirmRsp()	90

xii CONTENTS

3.7	WIFI A	Pls		. 91
	3.7.1	Detailed Descr	iption	. 92
	3.7.2	Macro Definition	on Documentation	. 92
		3.7.2.1 WIF	I_BEACON_INTERVAL_LENGTH	. 92
		3.7.2.2 WIF	I_CAPABILITY_INFO_LENGTH	. 93
		3.7.2.3 WIF	I_LENGTH_802_11	. 93
		3.7.2.4 WIF	I_LENGTH_PASSPHRASE	. 93
		3.7.2.5 WIF	I_MAC_ADDRESS_LENGTH	. 93
		3.7.2.6 WIF	I_MAC_NUM_OF_CHANNELS	. 93
		3.7.2.7 WIF	I_MAX_LENGTH_OF_SSID	. 93
		3.7.2.8 WIF	I_MAX_SCAN_AP_NUM	. 94
		3.7.2.9 WIF	I_MAX_SUPPORTED_RATES	. 94
	3.7.3	Typedef Docum	nentation	. 94
		3.7.3.1 wifi_	ap_record_t	. 94
		3.7.3.2 wifi_	event_notify_cb_t	. 94
	3.7.4	Enumeration T	ype Documentation	. 94
		3.7.4.1 wifi_	auto_connet_mode_e	. 94
	3.7.5	Function Docu	mentation	. 95
		3.7.5.1 wifi_	event_process_handler()	. 95
		3.7.5.2 wifi_	install_default_event_handlers()	. 95
		3.7.5.3 wifi_	register_event_handler()	. 96
3.8	WIFI	common APIs .		. 97
	3.8.1	Detailed Descr	iption	. 97
	3.8.2	Typedef Docum	nentation	. 97
		3.8.2.1 wifi_	event_cb_t	. 97
	3.8.3	Function Docu	mentation	. 97
		3.8.3.1 wifi_	event_loop_init()	. 97
		3.8.3.2 wifi_	event_loop_send()	. 98
		3.8.3.3 wifi_	event_loop_set_cb()	. 98
		3.8.3.4 wifi_	event_process_handler()	. 99

CONTENTS xiii

3.9	WIFI S	TA APIs			 	100
	3.9.1	Detailed Description			 	104
	3.9.2	Macro Definition Documentation	on		 	104
		3.9.2.1 WIFI_READY_TIME	·		 	104
	3.9.3	Typedef Documentation			 	104
		3.9.3.1 wifi_auto_connect_c	clear_ap_info_fp_t		 	105
		3.9.3.2 wifi_auto_connect_c	get_ap_info_fp_t		 	105
		3.9.3.3 wifi_auto_connect_c	get_ap_num_fp_t		 	105
		3.9.3.4 wifi_auto_connect_c	get_mode_fp_t		 	105
		3.9.3.5 wifi_auto_connect_c	get_saved_ap_num_fp_t		 	105
		3.9.3.6 wifi_auto_connect_i	nit_fp_t		 	105
		3.9.3.7 wifi_auto_connect_r	reset_fp_t		 	105
		3.9.3.8 wifi_auto_connect_s	set_ap_num_fp_t		 	106
		3.9.3.9 wifi_auto_connect_s	set_mode_fp_t		 	106
		3.9.3.10 wifi_auto_connect_s	start_fp_t		 	106
		3.9.3.11 wifi_auto_connect_u	update_ch_fp_t		 	106
		3.9.3.12 wifi_config_get_ban	dwidth_fp_t		 	106
		3.9.3.13 wifi_config_get_bss	id_fp_t		 	106
		3.9.3.14 wifi_config_get_cha	nnel_fp_t		 	106
		3.9.3.15 wifi_config_get_dtim	n_interval_fp_t		 	106
		3.9.3.16 wifi_config_get_liste	n_interval_fp_t		 	107
		3.9.3.17 wifi_config_get_mad	c_address_fp_t		 	107
		3.9.3.18 wifi_config_get_mad	c_tx_data_rate_fp_t		 	107
		3.9.3.19 wifi_config_get_opm	node_fp_t		 	107
		3.9.3.20 wifi_config_get_skip	_dtim_fp_t		 	107
		3.9.3.21 wifi_config_get_ssid	l_fp_t		 	107
		3.9.3.22 wifi_config_get_sta_	_mac_address_from_flas	sh_fp_t	 	107
		3.9.3.23 wifi_config_set_ban	dwidth_fp_t		 	107
		3.9.3.24 wifi_config_set_bssi	d_fp_t		 	108
		3.9.3.25 wifi_config_set_cha	nnel_fp_t		 	108

xiv CONTENTS

3.9.3.26	wifi_config_set_dtim_interval_fp_t	108
3.9.3.27	wifi_config_set_listen_interval_fp_t	108
3.9.3.28	wifi_config_set_mac_address_fp_t	108
3.9.3.29	wifi_config_set_mac_tx_data_rate_fp_t	108
3.9.3.30	wifi_config_set_opmode_fp_t	108
3.9.3.31	wifi_config_set_skip_dtim_fp_t	108
3.9.3.32	wifi_config_set_ssid_fp_t	109
3.9.3.33	wifi_connection_connect_fp_t	109
3.9.3.34	wifi_connection_connect_from_ac_index_fp_t	109
3.9.3.35	wifi_connection_connect_from_ac_list_fp_t	109
3.9.3.36	wifi_connection_disconnect_ap_fp_t	109
3.9.3.37	wifi_connection_disconnect_sta_fp_t	109
3.9.3.38	wifi_connection_get_rssi_fp_t	109
3.9.3.39	wifi_connection_register_event_handler_fp_t	110
3.9.3.40	wifi_connection_scan_start_fp_t	110
3.9.3.41	wifi_connection_unregister_event_handler_fp_t	110
3.9.3.42	wifi_convert_auth_mode_fp_t	110
3.9.3.43	wifi_deinit_fp_t	110
3.9.3.44	wifi_event_handler_t	110
3.9.3.45	wifi_fast_connect_get_mode_fp_t	111
3.9.3.46	wifi_fast_connect_set_mode_fp_t	111
3.9.3.47	wifi_fast_connect_start_fp_t	111
3.9.3.48	wifi_get_config_fp_t	111
3.9.3.49	wifi_init_complete_cb_t	111
3.9.3.50	wifi_init_fp_t	112
3.9.3.51	wifi_result_t	112
3.9.3.52	wifi_scan_get_ap_list_fp_t	112
3.9.3.53	wifi_scan_get_ap_num_fp_t	112
3.9.3.54	wifi_scan_get_ap_records_fp_t	112
3.9.3.55	wifi_scan_start_fp_t	112

CONTENTS xv

	3.9.3.56	wifi_scan_stop_fp_t	112
	3.9.3.57	wifi_set_config_fp_t	113
	3.9.3.58	wifi_sta_get_ap_info_fp_t	113
	3.9.3.59	wifi_start_fp_t	113
	3.9.3.60	wifi_stop_fp_t	113
3.9.4	Function	Documentation	113
	3.9.4.1	wifi_auto_connect_clear_ap_info()	113
	3.9.4.2	wifi_auto_connect_get_ap_info()	114
	3.9.4.3	wifi_auto_connect_get_ap_num()	114
	3.9.4.4	wifi_auto_connect_get_mode()	115
	3.9.4.5	wifi_auto_connect_get_saved_ap_num()	115
	3.9.4.6	wifi_auto_connect_init()	116
	3.9.4.7	wifi_auto_connect_reset()	116
	3.9.4.8	wifi_auto_connect_set_ap_num()	116
	3.9.4.9	wifi_auto_connect_set_mode()	117
	3.9.4.10	wifi_auto_connect_start()	117
	3.9.4.11	wifi_auto_connect_update_ch()	118
	3.9.4.12	wifi_config_get_bandwidth()	118
	3.9.4.13	wifi_config_get_bssid()	119
	3.9.4.14	wifi_config_get_channel()	119
	3.9.4.15	wifi_config_get_dtim_interval()	120
	3.9.4.16	wifi_config_get_listen_interval()	120
	3.9.4.17	wifi_config_get_mac_address()	120
	3.9.4.18	wifi_config_get_mac_tx_data_rate()	121
	3.9.4.19	wifi_config_get_opmode()	121
	3.9.4.20	wifi_config_get_skip_dtim()	121
	3.9.4.21	wifi_config_get_ssid()	122
	3.9.4.22	wifi_config_get_sta_mac_address_from_flash()	122
	3.9.4.23	wifi_config_set_bandwidth()	122
	3.9.4.24	wifi_config_set_bssid()	123

xvi CONTENTS

3.9.4.25	wifi_config_set_channel()	123
3.9.4.26	wifi_config_set_dtim_interval()	124
3.9.4.27	wifi_config_set_listen_interval()	124
3.9.4.28	wifi_config_set_mac_address()	124
3.9.4.29	wifi_config_set_mac_tx_data_rate()	125
3.9.4.30	wifi_config_set_opmode()	125
3.9.4.31	wifi_config_set_skip_dtim()	125
3.9.4.32	wifi_config_set_ssid()	126
3.9.4.33	wifi_connection_connect()	127
3.9.4.34	wifi_connection_connect_from_ac_index()	127
3.9.4.35	wifi_connection_connect_from_ac_list()	128
3.9.4.36	wifi_connection_disconnect_ap()	128
3.9.4.37	wifi_connection_disconnect_sta()	128
3.9.4.38	wifi_connection_get_rssi()	129
3.9.4.39	wifi_connection_register_event_handler()	129
3.9.4.40	wifi_connection_scan_start()	130
3.9.4.41	wifi_connection_unregister_event_handler()	130
3.9.4.42	wifi_convert_auth_mode()	131
3.9.4.43	wifi_deinit()	131
3.9.4.44	wifi_fast_connect_get_mode()	131
3.9.4.45	wifi_fast_connect_set_mode()	132
3.9.4.46	wifi_fast_connect_start()	132
3.9.4.47	wifi_get_config()	133
3.9.4.48	wifi_init()	133
3.9.4.49	wifi_scan_get_ap_list()	134
3.9.4.50	wifi_scan_get_ap_num()	134
3.9.4.51	wifi_scan_get_ap_records()	135
3.9.4.52	wifi_scan_start()	135
3.9.4.53	wifi_scan_stop()	136
3.9.4.54	wifi_set_config()	136

CONTENTS xvii

	3.9.4.55	wifi_sta_get_ap_info()	137
	3.9.4.56	wifi_start()	137
	3.9.4.57	wifi_stop()	137
3.9.5	Variable I	Documentation	138
	3.9.5.1	wifi_auto_connect_clear_ap_info_api	138
	3.9.5.2	wifi_auto_connect_get_ap_info_api	138
	3.9.5.3	wifi_auto_connect_get_ap_num_api	138
	3.9.5.4	wifi_auto_connect_get_mode_api	138
	3.9.5.5	wifi_auto_connect_get_saved_ap_num_api	138
	3.9.5.6	wifi_auto_connect_init_api	138
	3.9.5.7	wifi_auto_connect_reset_api	138
	3.9.5.8	wifi_auto_connect_set_ap_num_api	139
	3.9.5.9	wifi_auto_connect_set_mode_api	139
	3.9.5.10	wifi_auto_connect_start_api	139
	3.9.5.11	wifi_auto_connect_update_ch_api	139
	3.9.5.12	wifi_config_get_bandwidth_api	139
	3.9.5.13	wifi_config_get_bssid_api	139
	3.9.5.14	wifi_config_get_channel_api	139
	3.9.5.15	wifi_config_get_dtim_interval_api	139
	3.9.5.16	wifi_config_get_listen_interval_api	140
	3.9.5.17	wifi_config_get_mac_address_api	140
	3.9.5.18	wifi_config_get_mac_tx_data_rate_api	140
	3.9.5.19	wifi_config_get_opmode_api	140
	3.9.5.20	wifi_config_get_skip_dtim_api	140
	3.9.5.21	wifi_config_get_ssid_api	140
	3.9.5.22	wifi_config_get_sta_mac_address_from_flash_api	140
	3.9.5.23	wifi_config_set_bandwidth_api	140
	3.9.5.24	wifi_config_set_bssid_api	141
	3.9.5.25	wifi_config_set_channel_api	141
	3.9.5.26	wifi_config_set_dtim_interval_api	141

xviii CONTENTS

3.9.5.27	wifi_config_set_listen_interval_api	141
3.9.5.28	wifi_config_set_mac_address_api	141
3.9.5.29	wifi_config_set_mac_tx_data_rate_api	141
3.9.5.30	wifi_config_set_opmode_api	141
3.9.5.31	wifi_config_set_skip_dtim_api	141
3.9.5.32	wifi_config_set_ssid_api	142
3.9.5.33	wifi_connection_connect_api	142
3.9.5.34	wifi_connection_connect_from_ac_index_api	142
3.9.5.35	wifi_connection_connect_from_ac_list_api	142
3.9.5.36	wifi_connection_disconnect_ap_api	142
3.9.5.37	wifi_connection_disconnect_sta_api	142
3.9.5.38	wifi_connection_get_rssi_api	142
3.9.5.39	wifi_connection_register_event_handler_api	142
3.9.5.40	wifi_connection_scan_start_api	143
3.9.5.41	wifi_connection_unregister_event_handler_api	143
3.9.5.42	wifi_convert_auth_mode_api	143
3.9.5.43	wifi_deinit_api	143
3.9.5.44	wifi_fast_connect_get_mode_api	143
3.9.5.45	wifi_fast_connect_set_mode_api	143
3.9.5.46	wifi_fast_connect_start_api	143
3.9.5.47	wifi_get_config_api	143
3.9.5.48	wifi_init_api	144
3.9.5.49	wifi_scan_get_ap_list_api	144
3.9.5.50	wifi_scan_get_ap_num_api	144
3.9.5.51	wifi_scan_get_ap_records_api	144
3.9.5.52	wifi_scan_start_api	144
3.9.5.53	wifi_scan_stop_api	144
3.9.5.54	wifi_set_config_api	144
3.9.5.55	wifi_sta_get_ap_info_api	144
3.9.5.56	wifi_start_api	144

CONTENTS xix

			3.9.5.57	wifi_stop_api	144
	3.10	Enume	ration		145
		3.10.1	Detailed I	Description	145
		3.10.2	Enumera	tion Type Documentation	145
			3.10.2.1	wifi_auth_mode_t	146
			3.10.2.2	wifi_bandwidth_t	146
			3.10.2.3	wifi_cipher_type_t	146
			3.10.2.4	wifi_event_t	147
			3.10.2.5	wifi_mac_data_rate_t	147
			3.10.2.6	wifi_mode_t	147
			3.10.2.7	wifi_reason_code_t	148
			3.10.2.8	wifi_scan_method_t	149
			3.10.2.9	wifi_scan_type_t	149
			3.10.2.10	wifi_sort_method_t	149
	_				454
4	Data	Structu	ire Docun	nentation	151
4			ire Docun		151
4	Data 4.1	_wpa_i	e_data Str	ruct Reference	151
4			e_data Str	ruct Reference	151 151
4		_wpa_i	e_data Str Field Doc 4.1.1.1	ruct Reference	151 151 151
4		_wpa_i	e_data Str Field Doo 4.1.1.1 4.1.1.2	ruct Reference	151 151 151 151
4		_wpa_i	e_data Str Field Doo 4.1.1.1 4.1.1.2 4.1.1.3	ruct Reference	151 151 151 151 152
4		_wpa_i	e_data Str Field Doo 4.1.1.1 4.1.1.2 4.1.1.3 4.1.1.4	ruct Reference	151 151 151 151 152 152
4		_wpa_i	e_data Str Field Doo 4.1.1.1 4.1.1.2 4.1.1.3 4.1.1.4 4.1.1.5	ruct Reference	151 151 151 151 152 152
4		_wpa_i	e_data Str Field Doo 4.1.1.1 4.1.1.2 4.1.1.3 4.1.1.4 4.1.1.5 4.1.1.6	ruct Reference	151 151 151 151 152 152 152
4		_wpa_i	e_data Str Field Doo 4.1.1.1 4.1.1.2 4.1.1.3 4.1.1.4 4.1.1.5 4.1.1.6 4.1.1.7	ruct Reference	151 151 151 152 152 152 152
4	4.1	_wpa_i	e_data Str Field Doo 4.1.1.1 4.1.1.2 4.1.1.3 4.1.1.4 4.1.1.5 4.1.1.6 4.1.1.7 4.1.1.8	ruct Reference	151 151 151 151 152 152 152 152 152
4		_wpa_i 4.1.1	e_data Str Field Doo 4.1.1.1 4.1.1.2 4.1.1.3 4.1.1.4 4.1.1.5 4.1.1.6 4.1.1.7 4.1.1.8	ruct Reference	151 151 151 152 152 152 152 152 152
4	4.1	_wpa_i	e_data Str Field Doo 4.1.1.1 4.1.1.2 4.1.1.3 4.1.1.4 4.1.1.5 4.1.1.6 4.1.1.7 4.1.1.8 lata Struct Field Doo	ruct Reference	151 151 151 152 152 152 152 152 152 153
4	4.1	_wpa_i 4.1.1	e_data Str Field Doo 4.1.1.1 4.1.1.2 4.1.1.3 4.1.1.4 4.1.1.5 4.1.1.6 4.1.1.7 4.1.1.8 lata Struct Field Doo 4.2.1.1	ruct Reference cumentation capabilities group_cipher key_mgmt mgmt_group_cipher num_pmkid pairwise_cipher pmkid proto Reference cumentation eap_workaround	151 151 151 152 152 152 152 152 153 153
4	4.1	_wpa_i 4.1.1	e_data Str Field Doo 4.1.1.1 4.1.1.2 4.1.1.3 4.1.1.4 4.1.1.5 4.1.1.6 4.1.1.7 4.1.1.8 lata Struct Field Doo	ruct Reference	151 151 151 152 152 152 152 152 153 153

		4.2.1.4	key_mgmt	153
		4.2.1.5	leap	153
		4.2.1.6	mgmt_group_cipher	154
		4.2.1.7	non_leap	154
		4.2.1.8	pairwise_cipher	154
		4.2.1.9	passphrase	154
		4.2.1.10	proto	154
		4.2.1.11	psk	154
		4.2.1.12	psk_set	154
4.3	auto_c	onn_info_t	t Struct Reference	154
	4.3.1	Field Doo	cumentation	155
		4.3.1.1	ap_channel	155
		4.3.1.2	beacon_interval	155
		4.3.1.3	bssid	155
		4.3.1.4	capabilities	155
		4.3.1.5	dtim_prod	156
		4.3.1.6	fast_connect	156
		4.3.1.7	free_ocpy	156
		4.3.1.8	hid_ssid	156
		4.3.1.9	hid_ssid_len	156
		4.3.1.10	latest_beacon_rx_time	156
		4.3.1.11	passphrase	156
		4.3.1.12	psk	156
		4.3.1.13	rsn_ie	157
		4.3.1.14	rssi	157
		4.3.1.15	ssid	157
		4.3.1.16	ssid_len	157
		4.3.1.17	supported_rates	157
		4.3.1.18	wpa_data	157
		4.3.1.19	wpa_ie	157

CONTENTS xxi

4.4	auto_c	onnect_cf	g_t Struct Reference	. 157
	4.4.1	Field Do	cumentation	. 158
		4.4.1.1	flag	. 158
		4.4.1.2	front	. 158
		4.4.1.3	max_save_num	. 158
		4.4.1.4	pFCInfo	. 158
		4.4.1.5	rear	. 158
		4.4.1.6	retryCount	. 159
		4.4.1.7	targetldx	. 159
		4.4.1.8	uFCApNum	. 159
4.5	event_	msg_t Stru	uct Reference	. 159
	4.5.1	Detailed	Description	. 159
	4.5.2	Field Doo	cumentation	. 159
		4.5.2.1	event	. 159
		4.5.2.2	length	. 160
		4.5.2.3	param	. 160
4.6	hap_co	ontrol_t Sti	ruct Reference	. 160
	4.6.1	Field Doo	cumentation	. 160
		4.6.1.1	hap_ap_info	. 160
		4.6.1.2	hap_bitvector	. 160
		4.6.1.3	hap_en	. 160
		4.6.1.4	hap_final_index	. 161
		4.6.1.5	hap_index	. 161
		4.6.1.6	hap_ssid	. 161
4.7	LE_BT	_ADDR_T	Γ Struct Reference	. 161
	4.7.1	Field Doo	cumentation	. 161
		4.7.1.1	addr	. 161
		4.7.1.2	type	. 161
4.8	LE_CN	/_CONNE	ECTION_COMPLETE_IND_T Struct Reference	. 162
	4.8.1	Field Doo	cumentation	. 162

xxii CONTENTS

		4.8.1.1	conn_hdl	162
		4.8.1.2	conn_interval	162
		4.8.1.3	conn_latency	162
		4.8.1.4	dev_id	162
		4.8.1.5	peer_addr	163
		4.8.1.6	peer_addr_type	163
		4.8.1.7	role	163
		4.8.1.8	status	163
		4.8.1.9	supervison_timeout	163
4.9	LE_CN	/I_MSG_A	DVERTISE_REPORT_IND_T Struct Reference	163
	4.9.1	Field Doo	cumentation	164
		4.9.1.1	addr	164
		4.9.1.2	addr_type	164
		4.9.1.3	data	164
		4.9.1.4	event_type	164
		4.9.1.5	len	164
		4.9.1.6	rssi	164
4.10	LE_CN	/_MSG_C	ONN_PARA_REQ_T Struct Reference	164
	4.10.1	Field Doo	cumentation	165
		4.10.1.1	conn_hdl	165
		4.10.1.2	itv_max	165
		4.10.1.3	itv_min	165
		4.10.1.4	latency	165
		4.10.1.5	sv_tmo	165
4.11	LE_CN	/I_MSG_C	ONN_UPDATE_COMPLETE_IND_T Struct Reference	165
	4.11.1	Field Doo	cumentation	166
		4.11.1.1	conn_hdl	166
		4.11.1.2	interval	166
		4.11.1.3	latency	166
		4.11.1.4	status	166

CONTENTS xxiii

4.11.1.5 supervision_timeout	66
4.12 LE_CM_MSG_DATA_LEN_CHANGE_IND_T Struct Reference	66
4.12.1 Field Documentation	67
4.12.1.1 conn_hdl	67
4.12.1.2 max_rx_octets	67
4.12.1.3 max_rx_time	67
4.12.1.4 max_tx_octets	67
4.12.1.5 max_tx_time	67
4.13 LE_CM_MSG_DIRECT_ADV_REPORT_IND_T Struct Reference	67
4.13.1 Field Documentation	68
4.13.1.1 direct_addr	68
4.13.1.2 direct_addr_type	68
4.13.1.3 peer_addr	68
4.13.1.4 peer_addr_type	68
4.13.1.5 rssi	68
4.14 LE_CM_MSG_DISCONNECT_COMPLETE_IND_T Struct Reference	68
4.14.1 Field Documentation	69
4.14.1.1 conn_hdl	69
4.14.1.2 reason	69
4.14.1.3 status	69
4.15 LE_CM_MSG_ENCRYPTION_CHANGE_IND_T Struct Reference	69
4.15.1 Field Documentation	69
4.15.1.1 conn_hdl	70
4.15.1.2 devid	70
4.15.1.3 enabled	70
4.15.1.4 status	70
4.16 LE_CM_MSG_ENCRYPTION_REFRESH_IND_T Struct Reference	70
4.16.1 Field Documentation	70
4.16.1.1 conn_hdl	70

xxiv CONTENTS

4.16.1.3 enabled	171
4.16.1.4 status	171
4.17 LE_CM_MSG_INIT_COMPLETE_CFM_T Struct Reference	171
4.17.1 Field Documentation	171
4.17.1.1 status	171
4.18 LE_CM_MSG_LTK_REQ_IND_T Struct Reference	171
4.18.1 Field Documentation	172
4.18.1.1 conn_hdl	172
4.18.1.2 devid	172
4.18.1.3 ediv	172
4.18.1.4 rand	172
4.19 LE_CM_MSG_READ_ADV_TX_POWER_CFM_T Struct Reference	172
4.19.1 Field Documentation	173
4.19.1.1 pwr_level	173
4.19.1.2 status	173
4.20 LE_CM_MSG_READ_BD_ADDR_CFM_T Struct Reference	173
4.20.1 Field Documentation	173
4.20.1.1 bd_addr	173
4.20.1.2 status	173
4.21 LE_CM_MSG_READ_CHANNEL_MAP_CFM_T Struct Reference	174
4.21.1 Field Documentation	174
4.21.1.1 ch_map	174
4.21.1.2 conn_hdl	174
4.21.1.3 status	174
4.22 LE_CM_MSG_READ_PHY_CFM_T Struct Reference	174
4.22.1 Field Documentation	175
4.22.1.1 conn_hdl	175
4.22.1.2 rx_phy	175
4.22.1.3 status	175
4.22.1.4 tx_phy	175

CONTENTS xxv

4.23 LE_CM_MSG_READ_RESOLVING_LIST_SIZE_CFM_T Struct Reference
4.23.1 Field Documentation
4.23.1.1 size
4.23.1.2 status
4.24 LE_CM_MSG_READ_RSSI_CFM_T Struct Reference
4.24.1 Field Documentation
4.24.1.1 conn_hdl
4.24.1.2 rssi
4.24.1.3 status
4.25 LE_CM_MSG_READ_TX_POWER_CFM_T Struct Reference
4.25.1 Field Documentation
4.25.1.1 conn_hdl
4.25.1.2 status
4.25.1.3 tx_power
4.26 LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM_T Struct Reference
4.26.1 Field Documentation
4.26.1.1 size
4.26.1.2 status
4.27 LE_CM_MSG_SET_DATA_LENGTH_CFM_T Struct Reference
4.27.1 Field Documentation
4.27.1.1 conn_hdl
4.27.1.2 status
4.28 LE_CM_MSG_SET_DISCONNECT_CFM_T Struct Reference
4.28.1 Field Documentation
4.28.1.1 handle
4.28.1.2 status
4.29 LE_CM_MSG_SET_PHY_CFM_T Struct Reference
4.29.1 Field Documentation
4.29.1.1 conn_hdl
4.29.1.2 status

xxvi CONTENTS

80	1			 . .)	nce	erer	Refe	uct F	· Strı	EQ_1	_RE	ιΤΕ	'DA	_UP	۱AL_	IGN	G_S	_MSG_	_E_CN	4.30	
80	1			 . .		 											n	atio	nent	cun	Do	Field D	1.30.1		
80	1			 . .		 												_hdl	onn_	CC	1.1	4.30.1			
80	1			 		 												fier	lenti	id	1.2	4.30.1			
80	1			 		 										.	nax	al_r	ıterv	in	1.3	4.30.1			
80	1			 		 											nin	al_r	ıterv	in	1.4	4.30.1			
80	1			 		 										y	enc	_late	ave	sl	1.5	4.30.1			
81	1			 		 							. 		er	tipli	nuľ	ut_r	meo	tir	1.6	4.30.1			
81	1			 		 							e .	erend	Refe	ıct l	Stru	_T \$	TUS	TAT	Q_S	_REQ_	_E_CN	4.31	
81	1			 		 											n	atio	nent	cun	Do	Field D	1.31.1		
81	1			 		 												3. .	tatus	st	1.1	4.31.1			
81	1			 		 								.	ence	fere	Re	ruct	T Str	A_ 1	PAR	NN_PA	_E_CC	4.32	
81	1			 		 											n	atio	nent	cun	Do	Field D	1.32.1		
81	1			 		 												ax .	v_m	itv	1.1	4.32.1			
82	1			 		 							. 					in .	v_m	itv	1.2	4.32.1			
82	1			 		 							. 					су.	ıtenc	la	1.3	4.32.1			
82	1		 	 		 											ut	neo	v_tin	S۱	1.4	4.32.1			
82	1		 	 		 				е	ence	efere	ct Re	Stru	1_T	₹ A N	PAF	G_F	SIN	RTI	VEI	P_ADV	_E_GA	4.33	
82	1			 		 											n	atio	nent	cun	Do	Field D	1.33.1		
82	1		 	 		 										р.	ma	nel_	hanr	cł	1.1	4.33.1			
83	1		 	 		 											су	poli	lter_	fil	1.2	4.33.1			
83	1		 	 		 										.	nax	al_r	ıterv	in	1.3	4.33.1			
83	1		 	 		 											nin	al_r	ıterv	in	1.4	4.33.1			
83	1		 	 		 										/pe	r_ty	add	wn_:	01	1.5	4.33.1			
83	1		 	 		 											lr	add	eer_	pe	1.6	4.33.1			
83	1		 	 		 										ype	lr_t	_add	eer_	pe	1.7	4.33.1			
83	1		 	 		 													/pe	ty	1.8	4.33.1			
83	1		 	 		 							nce	efere	et Ro	truc	TS	·M_	ARA	_P/	NN	P_CON	_E_GA	4.34	
84	1		 	 		 											n	atio	nent	cun	Do	Field D	1.34.1		
84	1		 	 		 										ζ.	nax	al_r	ıterv	in	1.1	4.34.1			
	1 1 1 1 1 1 1 1 1 1 1									e			ct Re	Stru	 (_T	RAM p ype struc	n ut PAF n max min r_ty dr T S	atio ax . in . cy . meo G_F atio nel_ poli ral_r add _add _add _atio	ment v_mi v_mi uteno v_tin uSINo thanr lter_ there eer_ rpe ARA	cum itv la sv RTII cum ch fill in ov pe ty LP7 cum	1.1 1.2 1.3 1.4 VEI Do 1.1 1.2 1.3 1.4 1.5 1.6 1.7 1.8 DNN	Field E 4.32.1 4.32.1 4.32.1 4.32.1 4.32.1 P_ADV Field E 4.33.1 4.33.1 4.33.1 4.33.1 4.33.1 F_CON Field E	LE_GA	4.33	

CONTENTS xxvii

	4.34.1.2 interval_min	34
	4.34.1.3 latency	34
	4.34.1.4 supervision_timeout	34
4.35 LE_GA	P_SCAN_PARAM_T Struct Reference	34
4.35.1	Field Documentation	35
	4.35.1.1 filter_policy	35
	4.35.1.2 interval	35
	4.35.1.3 own_addr_type	35
	4.35.1.4 type	35
	4.35.1.5 window	35
4.36 LE_GA	TT_ATTR_T Struct Reference	35
4.36.1	Field Documentation	36
	4.36.1.1 format	36
	4.36.1.2 handle	36
	4.36.1.3 len	36
	4.36.1.4 maxLen	36
	4.36.1.5 permit	36
	4.36.1.6 pUuid	36
	4.36.1.7 pVal	36
4.37 LE_GA	TT_MSG_ACCESS_READ_IND_T Struct Reference	37
4.37.1	Field Documentation	37
	4.37.1.1 conn_hdl	37
	4.37.1.2 devid	37
	4.37.1.3 handle	37
	4.37.1.4 offset	37
4.38 LE_GA	TT_MSG_ACCESS_WRITE_IND_T Struct Reference	37
4.38.1	Field Documentation	38
	4.38.1.1 conn_hdl	38
	4.38.1.2 devid	38
	4.38.1.3 flag	38

xxviii CONTENTS

4.38.1.4 handle	88
4.38.1.5 len	188
4.38.1.6 offset	189
4.38.1.7 pVal	189
4.39 LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_IND_T Struct Reference	189
4.39.1 Field Documentation	189
4.39.1.1 conn_hdl	189
4.39.1.2 devid	189
4.39.1.3 format	189
4.39.1.4 handle	190
4.39.1.5 uuid	190
4.40 LE_GATT_MSG_CHARACTERISTIC_DECL_INFO_IND_T Struct Reference	190
4.40.1 Field Documentation	190
4.40.1.1 conn_hdl	190
4.40.1.2 devid	190
4.40.1.3 format	191
4.40.1.4 handle	191
4.40.1.5 property	191
4.40.1.6 uuid	191
4.40.1.7 val_hdl	191
4.41 LE_GATT_MSG_CHARACTERISTIC_VAL_IND_T Struct Reference	191
4.41.1 Field Documentation	192
4.41.1.1 att_err	192
4.41.1.2 conn_hdl	192
4.41.1.3 devid	192
4.41.1.4 handle	192
4.41.1.5 len	192
4.41.1.6 offset	192
4.41.1.7 val	192
4.42 LE_GATT_MSG_CONFIRMATION_CFM_T Struct Reference	193

CONTENTS xxix

4.42.1 Field Documentation	93
4.42.1.1 conn_hdl	93
4.42.1.2 devid	93
4.42.1.3 handle	93
4.43 LE_GATT_MSG_EXCHANGE_MTU_CFM_T Struct Reference	93
4.43.1 Field Documentation	94
4.43.1.1 conn_hdl	94
4.43.1.2 current_rx_mtu	94
4.43.1.3 devid	94
4.44 LE_GATT_MSG_EXCHANGE_MTU_IND_T Struct Reference	94
4.44.1 Field Documentation	94
4.44.1.1 client_rx_mtu	94
4.44.1.2 conn_hdl	95
4.44.1.3 devid	95
4.45 LE_GATT_MSG_EXECUTE_WRITE_RELIABLE_CFM_T Struct Reference	95
4.45.1 Field Documentation	95
4.45.1.1 att_err	95
4.45.1.2 conn_hdl	95
4.45.1.3 devid	95
4.45.1.4 err_hdl	96
4.45.1.5 status	96
4.46 LE_GATT_MSG_FIND_ALL_CHAR_DESC_CFM_T Struct Reference	96
4.46.1 Field Documentation	96
4.46.1.1 att_err	96
4.46.1.2 conn_hdl	96
4.46.1.3 devid	96
4.46.1.4 handle	97
4.46.1.5 status	97
4.47 LE_GATT_MSG_FIND_ALL_PRIMARY_SERVICE_CFM_T Struct Reference	97
4.47.1 Field Documentation	97

4.47.1.1 att_err	97
4.47.1.2 conn_hdl	97
4.47.1.3 devid	97
4.47.1.4 handle	98
4.47.1.5 status	98
4.48 LE_GATT_MSG_FIND_CHARACTERISTIC_CFM_T Struct Reference	98
4.48.1 Field Documentation	98
4.48.1.1 att_err	98
4.48.1.2 conn_hdl	98
4.48.1.3 devid	98
4.48.1.4 handle	99
4.48.1.5 status	99
4.49 LE_GATT_MSG_FIND_INCLUDED_SERVICE_CFM_T Struct Reference	99
4.49.1 Field Documentation	99
4.49.1.1 att_err	99
4.49.1.2 conn_hdl	99
4.49.1.3 devid	99
4.49.1.4 handle	00
4.49.1.5 status	00
4.50 LE_GATT_MSG_FIND_PRIMARY_SERVICE_BY_UUID_CFM_T Struct Reference	00
4.50.1 Field Documentation	:00
4.50.1.1 att_err	:00
4.50.1.2 conn_hdl	:00
4.50.1.3 devid	.00
4.50.1.4 handle	01
4.50.1.5 status	01
4.51 LE_GATT_MSG_INCLUDE_SERVICE_INFO_IND_T Struct Reference	.01
4.51.1 Field Documentation	.01
4.51.1.1 conn_hdl	.01
4.51.1.2 devid	.01

CONTENTS xxxi

	4.51.1.3 end_hdl
	4.51.1.4 format
	4.51.1.5 handle
	4.51.1.6 start_hdl
	4.51.1.7 uuid
4.52 LE_G	ATT_MSG_INDICATE_IND_T Struct Reference
4.52.	Field Documentation
	4.52.1.1 conn_hdl
	4.52.1.2 devid
	4.52.1.3 handle
	4.52.1.4 len
	4.52.1.5 val
4.53 LE_G	ATT_MSG_NOTIFY_CFM_T Struct Reference
4.53.	Field Documentation
	4.53.1.1 conn_hdl
	4.53.1.2 devid
	4.53.1.3 handle
	4.53.1.4 status
4.54 LE_G	ATT_MSG_NOTIFY_IND_T Struct Reference
4.54.	Field Documentation
	4.54.1.1 conn_hdl
	4.54.1.2 devid
	4.54.1.3 handle
	4.54.1.4 len
	4.54.1.5 val
4.55 LE_G	ATT_MSG_OPERATION_TIMEOUT_T Struct Reference
4.55.	Field Documentation
	4.55.1.1 att_op
	4.55.1.2 conn_hdl
	4.55.1.3 devid

xxxii CONTENTS

4.56 LE_GAT	_MSG_PREPARE_WRITE_RELIABLE_CFM_T Struct Reference	:06
4.56.1 F	eld Documentation	:06
4	56.1.1 att_err	:06
4	56.1.2 conn_hdl	:06
4	56.1.3 devid	:06
4	56.1.4 handle	207
4	56.1.5 status	207
4.57 LE_GAT	_MSG_READ_CHAR_VAL_BY_UUID_CFM_T Struct Reference	207
4.57.1 F	eld Documentation	:07
4	57.1.1 att_err	:07
4	57.1.2 conn_hdl	<u>2</u> 07
4	57.1.3 devid	<u>2</u> 07
4	57.1.4 handle	208
4	57.1.5 status	208
4.58 LE_GAT	_MSG_READ_CHARACTERISTIC_VALUE_CFM_T Struct Reference	208
4.58.1 F	eld Documentation	208
4	58.1.1 att_err	208
4	58.1.2 conn_hdl	208
4	58.1.3 devid	208
4	58.1.4 handle	209
4	58.1.5 status	209
4.59 LE_GAT	_MSG_READ_LONG_CHAR_VAL_CFM_T Struct Reference	209
4.59.1 F	eld Documentation	209
4	59.1.1 att_err	209
4	59.1.2 conn_hdl	209
4	59.1.3 devid	209
4	59.1.4 handle	210
4	59.1.5 status	210
4.60 LE_GAT	_MSG_READ_MULTIPLE_CHAR_VAL_CFM_T Struct Reference	10
4.60.1 F	eld Documentation	210

CONTENTS xxxiii

		4.60.1.1	att_err	210
		4.60.1.2	conn_hdl	210
		4.60.1.3	devid	211
		4.60.1.4	err_hdl	211
		4.60.1.5	len	211
		4.60.1.6	status	211
		4.60.1.7	val	211
4.61	LE_GA	TT_MSG_	SERVICE_INFO_IND_T Struct Reference	211
	4.61.1	Field Doo	cumentation	212
		4.61.1.1	conn_hdl	212
		4.61.1.2	devid	212
		4.61.1.3	end_hdl	212
		4.61.1.4	format	212
		4.61.1.5	start_hdl	212
		4.61.1.6	uuid	212
4.62	LE_GA	TT_MSG_	SIGNED_WRITE_CFM_T Struct Reference	212
	4.62.1	Field Doo	cumentation	213
		4.62.1.1	conn_hdl	213
		4.62.1.2	devid	213
		4.62.1.3	handle	213
		4.62.1.4	status	213
4.63	LE_GA	TT_MSG_	_WRITE_CHAR_VAL_RELIABLE_CFM_T Struct Reference	213
	4.63.1	Field Doo	cumentation	214
		4.63.1.1	att_err	214
		4.63.1.2	conn_hdl	214
		4.63.1.3	devid	214
		4.63.1.4	handle	214
		4.63.1.5	status	214
4.64	LE_GA	TT_MSG_	_WRITE_CHAR_VALUE_CFM_T Struct Reference	214

4.6	4.1.1 att_err	15
4.6	4.1.2 conn_hdl	15
4.6	4.1.3 devid	15
4.6	4.1.4 handle	15
4.6	4.1.5 status	15
4.65 LE_GATT_	MSG_WRITE_LONG_CHAR_VALUE_CFM_T Struct Reference 2	15
4.65.1 Fie	d Documentation	16
4.6	5.1.1 att_err	16
4.6	5.1.2 conn_hdl	16
4.6	5.1.3 devid	16
4.6	5.1.4 handle	16
4.6	5.1.5 status	16
4.66 LE_GATT_	MSG_WRITE_NO_RSP_CFM_T Struct Reference	16
4.66.1 Fie	d Documentation	17
4.6	6.1.1 conn_hdl	17
4.6	3.1.2 devid	17
4.6	6.1.3 handle	17
4.6	6.1.4 status	17
4.67 LE_GATT_	SERVICE_T Struct Reference	17
4.67.1 Fie	d Documentation	17
4.6	7.1.1 endHdl	18
4.6	7.1.2 pAttr	18
4.6	7.1.3 startHdl	18
4.6	7.1.4 svc_id	18
4.68 LE_SMP_N	ISG_ENCRYPTION_CHANGE_IND_T Struct Reference	18
4.68.1 Fie	d Documentation	18
4.6	3.1.1 conn_hdl	18
4.6	3.1.2 enable	19
4.69 LE_SMP_N	ISG_ENCRYPTION_REFRESH_IND_T Struct Reference	19
4.69.1 Fie	d Documentation	19

CONTENTS XXXV

4.69.1.1 conn_hdl
4.69.1.2 status
4.70 LE_SMP_MSG_OOB_DATA_REQUEST_IND_T Struct Reference
4.70.1 Field Documentation
4.70.1.1 conn_hdl
4.71 LE_SMP_MSG_PAIRING_ACTION_IND_T Struct Reference
4.71.1 Field Documentation
4.71.1.1 action
4.71.1.2 conn_hdl
4.71.1.3 lost_bond
4.71.1.4 sc
4.72 LE_SMP_MSG_PAIRING_COMPLETE_IND_T Struct Reference
4.72.1 Field Documentation
4.72.1.1 authenticated
4.72.1.2 bonded
4.72.1.3 conn_hdl
4.72.1.4 peer_id_addr
4.72.1.5 sc
4.72.1.6 status
4.73 LE_SMP_MSG_PASSKEY_DISPLAY_IND_T Struct Reference
4.73.1 Field Documentation
4.73.1.1 conn_hdl
4.73.1.2 passkey
4.74 LE_SMP_MSG_PASSKEY_INPUT_IND_T Struct Reference
4.74.1 Field Documentation
4.74.1.1 conn_hdl
4.75 LE_SMP_MSG_SC_OOB_DATA_REQUEST_IND_T Struct Reference
4.75.1 Field Documentation
4.75.1.1 conn_hdl
4.76 LE_SMP_MSG_SLAVE_SECURITY_REQUEST_IND_T Struct Reference

xxxvi CONTENTS

	4.76.1	Field Documentation	 	223
		4.76.1.1 bondable	 	224
		4.76.1.2 conn_hdl	 	224
		4.76.1.3 keypress	 	224
		4.76.1.4 mitm	 	224
		4.76.1.5 sc	 	224
4.77	LE_SM	MP_MSG_USER_CONFIRM_IND_T Struct Reference	 	224
	4.77.1	Field Documentation	 	224
		4.77.1.1 confirm_num	 	225
		4.77.1.2 conn_hdl	 	225
4.78	LE_SM	MP_SC_OOB_DATA_T Struct Reference	 	225
	4.78.1	Field Documentation	 	225
		4.78.1.1 confirm	 	225
		4.78.1.2 rand	 	225
4.79	LE_SY	S_MSG_BUF_OVERFLOW_T Struct Reference	 	225
	4.79.1	Field Documentation	 	226
		4.79.1.1 conn_hdl	 	226
4.80	mw_ble	ewifi_cbs_store_t Struct Reference	 	226
	4.80.1	Field Documentation	 	226
		4.80.1.1 manufacture_name	 	226
4.81	mw_wi	ifi_auto_connect_ap_info_t Struct Reference	 	226
	4.81.1	Field Documentation	 	227
		4.81.1.1 ap_channel	 	227
		4.81.1.2 beacon_interval	 	227
		4.81.1.3 bssid	 	227
		4.81.1.4 capabilities	 	227
		4.81.1.5 dtim_prod	 	228
		4.81.1.6 fast_connect	 	228
		4.81.1.7 free_ocpy	 	228
		4.81.1.8 hid_ssid	 	228

CONTENTS xxxvii

	4.81.1.9	hid_ssid_len		 	 	 	228
	4.81.1.1) latest_beacon_rx	c_time	 	 	 	228
	4.81.1.1	passphrase		 	 	 	228
	4.81.1.1	2 psk		 	 	 	228
	4.81.1.1	3 rsn_ie		 	 	 	229
	4.81.1.1	1 rssi		 	 	 	229
	4.81.1.1	5 ssid		 	 	 	229
	4.81.1.1	S ssid_len		 	 	 	229
	4.81.1.1	⁷ supported_rates		 	 	 	229
	4.81.1.1	3 wpa_data		 	 	 	229
	4.81.1.1	9 wpa_ie		 	 	 	229
4.82 m	v_wifi_sta_info	_t Struct Referenc	e	 	 	 	229
4.8	32.1 Field Do	cumentation		 	 	 	230
	4.82.1.1	au8Dot11MACA	ddress	 	 	 	230
	4.82.1.2	u8SkipDtimPerio	ds	 	 	 	230
4.83 M	wFimAutoConi	nectCFG_t Struct F	Reference .	 	 	 	230
4.8	33.1 Field Do	cumentation					000
		Juniontation		 	 	 	230
	4.83.1.1	flag		 	 	 	230
	4.83.1.1 4.83.1.2	flag		 	 	 	230
	4.83.1.1 4.83.1.2 4.83.1.3	flag		 	 	 	230 231 231
	4.83.1.1 4.83.1.2 4.83.1.3 4.83.1.4	flag		 	 	 	230 231 231 231
4.84 rx	4.83.1.1 4.83.1.2 4.83.1.3 4.83.1.4 4.83.1.5	flag		 	 	 	230 231 231 231 231
	4.83.1.1 4.83.1.2 4.83.1.3 4.83.1.4 4.83.1.5 _eapol_data S	flag				 	230 231 231 231 231 231
	4.83.1.1 4.83.1.2 4.83.1.3 4.83.1.4 4.83.1.5 _eapol_data S	flag					230 231 231 231 231 231 231
	4.83.1.1 4.83.1.2 4.83.1.3 4.83.1.4 4.83.1.5 _eapol_data S 34.1 Field Do 4.84.1.1	flag front max_save_num rear targetldx truct Reference cumentation frame_buffer					230 231 231 231 231 231 231
4.8	4.83.1.1 4.83.1.2 4.83.1.3 4.83.1.4 4.83.1.5 _eapol_data S 34.1 Field Do 4.84.1.1 4.84.1.2	flag					230 231 231 231 231 231 231 231 232
4.85 S_	4.83.1.1 4.83.1.2 4.83.1.3 4.83.1.4 4.83.1.5 _eapol_data S 34.1 Field Do 4.84.1.1 4.84.1.2 _WIFI_MLME_	flag	t Reference				230 231 231 231 231 231 231 232 232
4.85 S __	4.83.1.1 4.83.1.2 4.83.1.3 4.83.1.4 4.83.1.5 eapol_data S 34.1 Field Do 4.84.1.1 4.84.1.2 WIFI_MLME_ 35.1 Detailed	flag	t Reference				230 231 231 231 231 231 231 232 232
4.85 S __	4.83.1.1 4.83.1.2 4.83.1.3 4.83.1.4 4.83.1.5 _eapol_data S 34.1 Field Do 4.84.1.1 4.84.1.2 WIFI_MLME_ 35.1 Detailed 35.2 Field Do	flag	t Reference				230 231 231 231 231 231 231 232 232 232

xxxviii CONTENTS

	4.85.2.2	tScanType			 	 	 	 	 	 		232
	4.85.2.3	u32Active	ScanDu	ır	 	 	 	 	 	 		232
	4.85.2.4	u32Passiv	eScanE	Our	 	 	 	 	 	 		233
	4.85.2.5	u8aBssid			 	 	 	 	 	 		233
	4.85.2.6	u8aSsid			 	 	 	 	 	 		233
	4.85.2.7	u8Channe	el		 	 	 	 	 	 		233
	4.85.2.8	u8MaxSca	anApNu	m	 	 	 	 	 	 		233
	4.85.2.9	u8Resenc	Cnt .		 	 	 	 	 	 		233
4.86 scan_i	nfo_t Struc	t Reference	·		 	 	 	 	 	 		233
4.86.1	Field Doo	umentation	١		 	 	 	 	 	 		234
	4.86.1.1	ap_chann	el		 	 	 	 	 	 		234
	4.86.1.2	beacon_ir	ıterval		 	 	 	 	 	 		234
	4.86.1.3	bssid			 	 	 	 	 	 		234
	4.86.1.4	capabilitie	s		 	 	 	 	 	 		234
	4.86.1.5	dtim_prod			 	 	 	 	 	 		235
	4.86.1.6	free_ocpy			 	 	 	 	 	 		235
	4.86.1.7	latest_bea	ıcon_rx_	_time .	 	 	 	 	 	 		235
	4.86.1.8	rsn_ie .			 	 	 	 	 	 		235
	4.86.1.9	rssi			 	 	 	 	 	 		235
	4.86.1.10	ssid			 	 	 	 	 	 		235
	4.86.1.11	ssid_len			 	 	 	 	 	 		235
	4.86.1.12	supported	_rates		 	 	 	 	 	 		235
	4.86.1.13	wpa_data			 	 	 	 	 	 		236
	4.86.1.14	wpa_ie .			 	 	 	 	 	 		236
4.87 scan_r	report_t Str	uct Refere	nce		 	 	 	 	 	 		236
4.87.1	Field Doo	umentation	١		 	 	 	 	 	 		236
	4.87.1.1	pScanInfo			 	 	 	 	 	 		236
	4.87.1.2	uScanApl	Num .		 	 	 	 	 	 		236
4.88 T_RfC	md Struct I	Reference			 	 	 	 	 	 		236
4.88.1	Field Doo	umentation	1		 	 	 	 	 	 		237

CONTENTS xxxix

		4.88.1.1	i.	iΑ	۱rg	с.																			237
		4.88.1.2	8	Sã	a A ı	rgv																			237
		4.88.1.3	ι	u	32	Тур	е																		237
4.89	T_RfDe	efEvt Struc	ct	F	₹ef	ere	nce	9.																	237
	4.89.1	Field Doo	cu	ın	ner	ntat	ion																		237
		4.89.1.1	ι	uí	32	Тур	е																		237
		4.89.1.2	ι	u	8al	Dat	a																		238
		4.89.1.3	ι	u8	8S	tatı	JS																		238
4.90	T_RfEv	rt Struct R	₹ef	fe	erer	nce																			238
	4.90.1	Field Doo	cu	un	ner	ntat	ion	١.																	238
		4.90.1.1	į	i8	BRs	ssi																			238
		4.90.1.2	ķ	pl	Pai	ram	١.																		239
		4.90.1.3	ι	u ⁻	16I	RfN	/lod	le .																	239
		4.90.1.4	ι	u ⁻	16I	RxC	Ont																		239
		4.90.1.5	ι	u ⁻	16	RxC	Orc	Ok	Cı	nt															239
		4.90.1.6	ι	uí	321	Fre	q																		239
		4.90.1.7	ι	uí	321	Mod	de																		239
		4.90.1.8	ι	uí	32I	RfC	ha	nn	el																239
		4.90.1.9	ι	uí	32	Тур	е																		239
		4.90.1.10	0ι	u8	8Fr	req																			240
		4.90.1.11	1 ι	u8	8lp	ocE	nat	ole																	240
		4.90.1.12	2ι	u8	8Le	en																			240
		4.90.1.13	3ι	u8	8P	hy																			240
		4.90.1.14	4ι	u8	8P	kt .																			240
		4.90.1.15	5ι	u8	8R	ese	erve	ed																	240
		4.90.1.16	6ι	u8	8S [.]	tatı	JS																		240
		4.90.1.17	7ι	u8	8U	nic	ast																		240
4.91	wifi_act	tive_scan_	_ti	in	ne	_t S	Stru	ct	Re	efe	re	nc	e												241
		Detailed																							
	4.91.2	Field Doo	cu	un	ner	ntat	tion	١.																	241

xI CONTENTS

	4.91.2.1 max
	4.91.2.2 min
4.92 wifi_a	p_config_t Struct Reference
4.92.1	Detailed Description
4.92.2	Prield Documentation
	4.92.2.1 auth_mode
	4.92.2.2 beacon_interval
	4.92.2.3 channel
	4.92.2.4 encrypt_type
	4.92.2.5 max_connection
	4.92.2.6 password
	4.92.2.7 password_length
	4.92.2.8 ssid
	4.92.2.9 ssid_hidden
	4.92.2.10 ssid_length
4.93 wifi_a	uto_connect_info_t Struct Reference
4.93.1	Detailed Description
4.93.2	Prield Documentation
	4.93.2.1 ap_channel
	4.93.2.2 beacon_interval
	4.93.2.3 bssid
	4.93.2.4 capabilities
	4.93.2.5 dtim_prod
	4.93.2.6 fast_connect
	4.93.2.7 hid_ssid
	4.93.2.8 rssi
	4.93.2.9 ssid
	4.93.2.10 supported_rates
4.94 wifi_cr	md_t Struct Reference
4.94.1	Field Documentation

CONTENTS xli

		4.94.1.1	ar	rg1								 		 	 		 			246
		4.94.1.2	ar	rg2								 		 	 		 			246
		4.94.1.3	cr	md_t	type							 		 	 		 			246
		4.94.1.4	pr	rvDa	ıta							 		 	 		 			246
4.95	wifi_co	nfig_t Unic	on I	Refe	renc	е.						 		 	 		 			246
	4.95.1	Detailed	De	scrip	otion							 		 	 		 			246
	4.95.2	Field Doo	cun	nenta	ation							 		 	 		 			247
		4.95.2.1	aŗ	p_co	onfig							 		 			 			247
		4.95.2.2	st	:a_c	onfig							 		 	 		 			247
4.96	wifi_eve	ent_info_t	Un	ion I	Refe	rend	се					 		 			 			247
	4.96.1	Detailed	De	scrip	otion	•						 		 			 			247
	4.96.2	Field Doo	cun	nenta	ation							 		 			 			247
		4.96.2.1	CC	onne	ected							 		 			 			247
		4.96.2.2	di	scor	nnect	ted						 		 			 			248
		4.96.2.3	go	ot_ip) .							 		 	 		 			248
		4.96.2.4	SC	can_	_done	e .						 		 	 		 			248
4.97	wifi_eve	ent_sta_co	onn	necte	∍d_t \$	Stru	ıct F	Refe	erer	nce		 		 	 		 			248
	4.97.1	Detailed	De	scrip	otion							 		 	 		 			248
	4.97.2	Field Doo	cun	nenta	ation							 		 	 		 			248
		4.97.2.1	aı	uthm	node							 		 	 		 			248
		4.97.2.2	bs	ssid								 		 			 			249
		4.97.2.3	cł	nann	nel .							 		 	 		 			249
		4.97.2.4	SS	sid .								 		 	 		 			249
		4.97.2.5	SS	sid_l	en							 		 	 		 			249
4.98	wifi_eve	ent_sta_di	isco	onne	ected	_t S	Stru	ct R	Refe	ren	се	 		 	 		 			249
	4.98.1	Detailed	De	scrip	otion							 		 	 		 			249
	4.98.2	Field Doo	cun	nenta	ation							 		 			 			249
		4.98.2.1	bs	ssid								 		 			 			250
		4.98.2.2	re	aso	n .							 		 			 			250
		4.98.2.3	SS	sid .								 		 	 		 			250

xlii CONTENTS

4.98.2.4 ssid_len
4.99 wifi_event_sta_got_ip_t Struct Reference
4.99.1 Field Documentation
4.99.1.1 ip_changed
4.100 wifi_event_sta_scan_done_t Struct Reference
4.100.1 Detailed Description
4.100.2 Field Documentation
4.100.2.1 number
4.100.2.2 scan_id
4.100.2.3 status
4.101 wifi_evt_t Struct Reference
4.101.1 Field Documentation
4.101.1.1 evt_type
4.101.1.2 prvData
4.102wifi_fast_scan_threshold_t Struct Reference
4.102.1 Detailed Description
4.102.2 Field Documentation
4.102.2.1 authmode
4.102.2.2 rssi
4.103wifi_init_config_t Struct Reference
4.103.1 Detailed Description
4.103.2 Field Documentation
4.103.2.1 event_handler
4.103.2.2 magic
4.104wifi_scan_config_t Struct Reference
4.104.1 Detailed Description
4.104.2 Field Documentation
4.104.2.1 bssid
4.104.2.2 channel
4.104.2.3 scan_time

CONTENTS xliii

4.104.2.4 scan_type	. 254
4.104.2.5 show_hidden	. 254
4.104.2.6 ssid	. 255
4.105wifi_scan_info_t Struct Reference	. 255
4.105.1 Detailed Description	. 255
4.105.2 Field Documentation	. 255
4.105.2.1 auth_mode	. 255
4.105.2.2 beacon_interval	. 255
4.105.2.3 bssid	. 256
4.105.2.4 capability_info	. 256
4.105.2.5 channel	. 256
4.105.2.6 dtim_period	. 256
4.105.2.7 group_cipher	. 256
4.105.2.8 pairwise_cipher	. 256
4.105.2.9 rssi	. 256
4.105.2.10ssid	. 257
4.105.2.11ssid_length	. 257
4.106wifi_scan_list_t Struct Reference	. 257
4.106.1 Detailed Description	. 257
4.106.2 Field Documentation	. 257
4.106.2.1 ap_record	. 257
4.106.2.2 num	. 257
4.107wifi_scan_time_t Union Reference	. 258
4.107.1 Detailed Description	. 258
4.107.2 Field Documentation	. 258
4.107.2.1 active	. 258
4.107.2.2 passive	. 258
4.108wifi_sta_config_t Struct Reference	. 258
4.108.1 Detailed Description	. 259
4.108.2 Field Documentation	. 259

XIIV CONTENTS

4.108.2.1 bssid	259
4.108.2.2 bssid_present	259
4.108.2.3 password	259
4.108.2.4 password_length	259
4.108.2.5 scan_method	259
4.108.2.6 sort_method	259
4.108.2.7 ssid	260
4.108.2.8 ssid_length	260
4.108.2.9 threshold	260
4.109wifi_wpa_ie_data_t Struct Reference	260
4.109.1 Detailed Description	260
4.109.2 Field Documentation	260
4.109.2.1 capabilities	261
4.109.2.2 group_cipher	261
4.109.2.3 key_mgmt	261
4.109.2.4 mgmt_group_cipher	261
4.109.2.5 num_pmkid	261
4.109.2.6 pairwise_cipher	261
4.109.2.7 pmkid	261
4.109.2.8 proto	261
alass.	200
dex	263

Chapter 1

Module Index

1.1 Modules

Here is a list of all modules:

ALL APIs	. 7
BLE CM APIs	8
BLE GAP APIs	15
BLE GATT APIs	
BLE MSG APIs	71
BLE SMP APIs	83
I APIs	. 91
VIFI Common APIs	97
VIFI STA APIs	100
numeration	145

2 Module Index

Chapter 2

Data Structure Index

2.1 Data Structures

Here are the data structures with brief descriptions:

_wpa_ie_data	151
asso_data	152
auto_conn_info_t	154
auto_connect_cfg_t	157
event_msg_t	
Send information to event by event_msg_t	159
hap_control_t	160
LE_BT_ADDR_T	161
LE_CM_CONNECTION_COMPLETE_IND_T	162
LE_CM_MSG_ADVERTISE_REPORT_IND_T	163
LE_CM_MSG_CONN_PARA_REQ_T	164
LE_CM_MSG_CONN_UPDATE_COMPLETE_IND_T	165
LE_CM_MSG_DATA_LEN_CHANGE_IND_T	166
LE_CM_MSG_DIRECT_ADV_REPORT_IND_T	167
LE_CM_MSG_DISCONNECT_COMPLETE_IND_T	168
LE_CM_MSG_ENCRYPTION_CHANGE_IND_T	169
LE_CM_MSG_ENCRYPTION_REFRESH_IND_T	170
LE_CM_MSG_INIT_COMPLETE_CFM_T	171
	171
	172
	173
LE_CM_MSG_READ_CHANNEL_MAP_CFM_T	174
LE_CM_MSG_READ_PHY_CFM_T	174
LE_CM_MSG_READ_RESOLVING_LIST_SIZE_CFM_T	175
LE_CM_MSG_READ_RSSI_CFM_T	176
LE_CM_MSG_READ_TX_POWER_CFM_T	176
LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM_T	177
LE_CM_MSG_SET_DATA_LENGTH_CFM_T	178
LE_CM_MSG_SET_DISCONNECT_CFM_T	178
LE_CM_MSG_SET_PHY_CFM_T	179
LE_CM_MSG_SIGNAL_UPDATE_REQ_T	180
LE_CM_REQ_STATUS_T	181
LE_CONN_PARA_T	181
	182
LE GAP CONN PARAM T	183

Data Structure Index

LE_GAP_SCAN_PARAM_T
LE_GATT_ATTR_T
LE_GATT_MSG_ACCESS_READ_IND_T
LE_GATT_MSG_ACCESS_WRITE_IND_T 18
LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_IND_T18
LE_GATT_MSG_CHARACTERISTIC_DECL_INFO_IND_T
LE_GATT_MSG_CHARACTERISTIC_VAL_IND_T19
LE_GATT_MSG_CONFIRMATION_CFM_T
LE_GATT_MSG_EXCHANGE_MTU_CFM_T
LE_GATT_MSG_EXCHANGE_MTU_IND_T
LE GATT MSG EXECUTE WRITE RELIABLE CFM T
LE GATT MSG FIND ALL CHAR DESC CFM T
LE_GATT_MSG_FIND_ALL_PRIMARY_SERVICE_CFM_T19
LE_GATT_MSG_FIND_CHARACTERISTIC_CFM_T
LE_GATT_MSG_FIND_INCLUDED_SERVICE_CFM_T
LE_GATT_MSG_FIND_PRIMARY_SERVICE_BY_UUID_CFM_T
LE_GATT_MSG_INCLUDE_SERVICE_INFO_IND_T
LE_GATT_MSG_INDICATE_IND_T
LE_GATT_MSG_NOTIFY_CFM_T
LE_GATT_MSG_NOTIFY_IND_T
LE GATT MSG OPERATION TIMEOUT T
LE_GATT_MSG_PREPARE_WRITE_RELIABLE_CFM_T
LE_GATT_MSG_READ_CHAR_VAL_BY_UUID_CFM_T
LE GATT MSG READ CHARACTERISTIC VALUE CFM T
LE_GATT_MSG_READ_LONG_CHAR_VAL_CFM_T
LE_GATT_MSG_READ_MULTIPLE_CHAR_VAL_CFM_T
LE_GATT_MSG_SERVICE_INFO_IND_T
LE_GATT_MSG_SIGNED_WRITE_CFM_T
LE_GATT_MSG_WRITE_CHAR_VAL_RELIABLE_CFM_T
LE_GATT_MSG_WRITE_CHAR_VALUE_CFM_T
LE_GATT_MSG_WRITE_LONG_CHAR_VALUE_CFM_T
LE_GATT_MSG_WRITE_NO_RSP_CFM_T
LE_GATT_SERVICE_T
LE_SMP_MSG_ENCRYPTION_CHANGE_IND_T
LE_SMP_MSG_ENCRYPTION_REFRESH_IND_T 21
LE_SMP_MSG_OOB_DATA_REQUEST_IND_T 21
LE_SMP_MSG_PAIRING_ACTION_IND_T
LE_SMP_MSG_PAIRING_COMPLETE_IND_T
LE_SMP_MSG_PASSKEY_DISPLAY_IND_T 22
LE_SMP_MSG_PASSKEY_INPUT_IND_T
LE_SMP_MSG_SC_OOB_DATA_REQUEST_IND_T 22
LE_SMP_MSG_SLAVE_SECURITY_REQUEST_IND_T
LE_SMP_MSG_USER_CONFIRM_IND_T
LE_SMP_SC_OOB_DATA_T 22
LE_SYS_MSG_BUF_OVERFLOW_T 22
mw_blewifi_cbs_store_t
mw_wifi_auto_connect_ap_info_t 22
mw_wifi_sta_info_t 22
MwFimAutoConnectCFG_t
rx_eapol_data
S_WIFI_MLME_SCAN_CFG
scan_info_t 23
scan_report_t
T_RfCmd
T_RfDefEvt
wifi_active_scan_time_t
Range of active scan times per channel
- · · · · · · · · · · · · · · · · · · ·

2.1 Data Structures 5

wifi_ap_config_t	
This structure is the Wi-Fi configuration for initialization for Soft-AP mode	241
wifi_auto_connect_info_t	
This structure is the Wi-Fi auto connect for save in the flash (FIM)	. 243
wifi_cmd_t	245
wifi_config_t	
Wi-Fi configuration for initialization	246
wifi_event_info_t	
Wifi_event_info_t	247
wifi_event_sta_connected_t	
Wifi_event_sta_connected_t	248
wifi_event_sta_disconnected_t	
Wifi_event_sta_disconnected_t	. 249
wifi_event_sta_got_ip_t	250
wifi_event_sta_scan_done_t	
Wifi_event_sta_scan_done_t	. 251
wifi_evt_t	251
wifi_fast_scan_threshold_t	
Structure describing parameters for a Wi-Fi fast scan	252
wifi_init_config_t	
WiFi stack configuration parameters	253
wifi_scan_config_t	
Parameters for an SSID scan	253
wifi_scan_info_t	
This structure defines the inforamtion of scanned APs	255
wifi_scan_list_t	
This structure defines the list of scanned APs with their corresponding information	257
wifi_scan_time_t	
Aggregate of active & passive scan time per channel	258
wifi_sta_config_t	
This structure is the Wi-Fi configuration for initialization for STA mode	258
wifi_wpa_ie_data_t	
This structure is the Wi-Fi auto connect with wpa information for save in the flash (FIM)	260

6 Data Structure Index

Chapter 3

Module Documentation

3.1 BLE ALL APIs

BLE ALL APIs.

Modules

- BLE CM APIs
- BLE GAP APIs
- BLE GATT APIs
- BLE MSG APIs
- BLE SMP APIs

Functions

• UINT8 LeSmpGetBondIdFromAddr (LE_BT_ADDR_T *peer_addr)

3.1.1 Detailed Description

BLE ALL APIs.

3.1.2 Function Documentation

3.1.2.1 LeSmpGetBondldFromAddr()

```
UINT8 LeSmpGetBondIdFromAddr ( \label{eq:less_def} \texttt{LE\_BT\_ADDR\_T} \ * \ peer\_addr \ )
```

3.2 BLE CM APIS

Data Structures

- struct LE CM CONNECTION COMPLETE IND T
- struct LE_CM_MSG_ADVERTISE_REPORT_IND_T
- struct LE_CM_MSG_CONN_PARA_REQ_T
- struct LE_CM_MSG_CONN_UPDATE_COMPLETE_IND_T
- struct LE CM MSG DATA LEN CHANGE IND T
- struct LE_CM_MSG_DIRECT_ADV_REPORT_IND_T
- struct LE CM MSG DISCONNECT COMPLETE IND T
- struct LE CM MSG ENCRYPTION CHANGE IND T
- struct LE_CM_MSG_ENCRYPTION_REFRESH_IND_T
- struct LE_CM_MSG_INIT_COMPLETE_CFM_T
- struct LE CM MSG LTK REQ IND T
- struct LE_CM_MSG_READ_ADV_TX_POWER_CFM_T
- struct LE_CM_MSG_READ_BD_ADDR_CFM_T
- struct LE_CM_MSG_READ_CHANNEL_MAP_CFM_T
- struct LE_CM_MSG_READ_PHY_CFM_T
- struct LE CM MSG READ RESOLVING LIST SIZE CFM T
- struct LE_CM_MSG_READ_RSSI_CFM_T
- struct LE_CM_MSG_READ_TX_POWER_CFM_T
- struct LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM_T
- struct LE_CM_MSG_SET_DATA_LENGTH_CFM_T
- struct LE CM MSG SET DISCONNECT CFM T
- struct LE_CM_MSG_SET_PHY_CFM_T
- struct LE_CM_MSG_SIGNAL_UPDATE_REQ_T
- struct LE_CM_REQ_STATUS_T

Typedefs

- typedef LE CM REQ STATUS T LE CM MSG ADD TO RESOLVING LIST CFM T
- typedef LE CM REQ STATUS T LE CM MSG ADD TO WHITE LIST CFM T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_CANCEL_CONNECTION_CFM_T
- typedef LE CM REQ STATUS T LE CM MSG CLEAR RESOLVING LIST CFM T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_CLEAR_WHITE_LIST_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_CREATE_CONNECTION_CFM_T
- typedef LE CM REQ STATUS TLE CM MSG ENTER ADVERTISING CFM T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_ENTER_SCANNING_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_EXIT_ADVERTISING_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_EXIT_SCANNING_CFM_T
- typedef LE_CM_MSG_READ_PHY_CFM_T LE_CM_MSG_PHY_UPDATE_COMPLETE_IND_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_REMOVE_FROM_RESOLVING_LIST_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_ADVERTISING_DATA_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_ADVERTISING_PARAMS_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_CHANNEL_MAP_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_DEFAULT_PHY_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_RANDOM_ADDRESS_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_RPA_TIMEOUT_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_SCAN_PARAMS_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_SCAN_RSP_DATA_CFM_T

3.2 BLE CM APIs 9

Enumerations

- enum {
 - LE_CM_MSG_INIT_COMPLETE_CFM = LE_CM_MSG_BASE, LE_CM_MSG_SET_DISCONNECT_CFM,
 - LE_CM_MSG_DISCONNECT_COMPLETE_IND, LE_CM_MSG_SET_ADVERTISING_DATA_CFM,
 - LE_CM_MSG_SET_SCAN_RSP_DATA_CFM, LE_CM_MSG_SET_ADVERTISING_PARAMS_CFM,
 - LE_CM_MSG_ENTER_ADVERTISING_CFM, LE_CM_MSG_EXIT_ADVERTISING_CFM,
 - ${\tt LE_CM_MSG_SET_SCAN_PARAMS_CFM}, {\tt LE_CM_MSG_ENTER_SCANNING_CFM}, {\tt LE_CM_MSG_EXIT_SCANNING_CFM}, {\tt LE_CM_MSG_EXIT_SCANNING_C$
 - LE CM MSG CREATE CONNECTION CFM,
 - LE_CM_MSG_CANCEL_CONNECTION_CFM, LE_CM_MSG_READ_TX_POWER_CFM, LE_CM_MSG_READ_BD_ADDR_
 - LE CM MSG READ RSSI CFM,
 - LE_CM_MSG_SET_RANDOM_ADDRESS_CFM, LE_CM_MSG_READ_ADV_TX_POWER_CFM, LE_CM_MSG_READ_WH
 - LE CM MSG CLEAR WHITE LIST CFM,
 - LE_CM_MSG_ADD_TO_WHITE_LIST_CFM, LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM,
 - LE_CM_MSG_SET_CHANNEL_MAP_CFM, LE_CM_MSG_READ_CHANNEL_MAP_CFM,
 - LE_CM_MSG_SET_DATA_LENGTH_CFM, LE_CM_MSG_DATA_LEN_CHANGE_IND, LE_CM_MSG_ADD_TO_RESOLVIN
 - LE CM MSG REMOVE FROM RESOLVING LIST CFM.
 - LE CM MSG CLEAR RESOLVING LIST CFM, LE CM MSG READ RESOLVING LIST SIZE CFM,
 - LE CM MSG SET RPA TIMEOUT CFM, LE CM MSG SIGNAL UPDATE REQ,
 - LE_CM_MSG_CONN_UPDATE_COMPLETE_IND, LE_CM_MSG_CONN_PARA_REQ, LE_CM_MSG_ENCRYPTION_CHAN
 - LE CM MSG ENCRYPTION REFRESH IND,
 - LE_CM_MSG_LTK_REQ_IND, LE_CM_MSG_ADVERTISE_REPORT_IND, LE_CM_MSG_DIRECT_ADV_REPORT_IND,
- LE_CM_CONNECTION_COMPLETE_IND,
- LE_CM_MSG_READ_LOCAL_RPA_CFM, LE_CM_MSG_READ_PHY_CFM, LE_CM_MSG_SET_DEFAULT_PHY_CFM,
- LE CM MSG SET PHY CFM,
- LE_CM_MSG_PHY_UPDATE_COMPLETE_IND, LE_CM_MSG_TOP }

BLE connection management message id.

Functions

void LeCmInit (TASK appTask)

BLE Connection Management Module Init.

- 3.2.1 Detailed Description
- 3.2.2 Typedef Documentation

3.2.2.1 LE_CM_MSG_ADD_TO_RESOLVING_LIST_CFM_T

typedef LE_CM_REQ_STATUS_T LE_CM_MSG_ADD_TO_RESOLVING_LIST_CFM_T

3.2.2.2 LE_CM_MSG_ADD_TO_WHITE_LIST_CFM_T

typedef LE_CM_REQ_STATUS_T LE_CM_MSG_ADD_TO_WHITE_LIST_CFM_T

```
3.2.2.3 LE_CM_MSG_CANCEL_CONNECTION_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_CANCEL_CONNECTION_CFM_T
3.2.2.4 LE_CM_MSG_CLEAR_RESOLVING_LIST_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_CLEAR_RESOLVING_LIST_CFM_T
3.2.2.5 LE_CM_MSG_CLEAR_WHITE_LIST_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_CLEAR_WHITE_LIST_CFM_T
3.2.2.6 LE_CM_MSG_CREATE_CONNECTION_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_CREATE_CONNECTION_CFM_T
3.2.2.7 LE_CM_MSG_ENTER_ADVERTISING_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_ENTER_ADVERTISING_CFM_T
3.2.2.8 LE CM MSG ENTER SCANNING CFM T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_ENTER_SCANNING_CFM_T
3.2.2.9 LE_CM_MSG_EXIT_ADVERTISING_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_EXIT_ADVERTISING_CFM_T
3.2.2.10 LE_CM_MSG_EXIT_SCANNING_CFM_T
```

typedef LE_CM_REQ_STATUS_T LE_CM_MSG_EXIT_SCANNING_CFM_T

3.2 BLE CM APIs

```
3.2.2.11 LE_CM_MSG_PHY_UPDATE_COMPLETE_IND_T
typedef LE_CM_MSG_READ_PHY_CFM_T LE_CM_MSG_PHY_UPDATE_COMPLETE_IND_T
3.2.2.12 LE_CM_MSG_REMOVE_FROM_RESOLVING_LIST_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_REMOVE_FROM_RESOLVING_LIST_CFM_T
3.2.2.13 LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM_T
3.2.2.14 LE CM MSG SET ADVERTISING DATA CFM T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_ADVERTISING_DATA_CFM_T
3.2.2.15 LE_CM_MSG_SET_ADVERTISING_PARAMS_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_ADVERTISING_PARAMS_CFM_T
3.2.2.16 LE CM MSG SET CHANNEL MAP CFM T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_CHANNEL_MAP_CFM_T
3.2.2.17 LE_CM_MSG_SET_DEFAULT_PHY_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_DEFAULT_PHY_CFM_T
3.2.2.18 LE_CM_MSG_SET_RANDOM_ADDRESS_CFM_T
```

typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_RANDOM_ADDRESS_CFM_T

3.2.2.19 LE_CM_MSG_SET_RPA_TIMEOUT_CFM_T

typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_RPA_TIMEOUT_CFM_T

3.2.2.20 LE_CM_MSG_SET_SCAN_PARAMS_CFM_T

typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_SCAN_PARAMS_CFM_T

3.2.2.21 LE_CM_MSG_SET_SCAN_RSP_DATA_CFM_T

typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_SCAN_RSP_DATA_CFM_T

3.2.3 Enumeration Type Documentation

3.2.3.1 anonymous enum

anonymous enum

BLE connection management message id.

Enumerator

LE_CM_MSG_INIT_COMPLETE_CFM	initialize complete
LE_CM_MSG_SET_DISCONNECT_CFM	set disconnect confirm
LE_CM_MSG_DISCONNECT_COMPLETE_IND	disconnect complete indication
LE_CM_MSG_SET_ADVERTISING_DATA_CFM	set advertising data confirm
LE_CM_MSG_SET_SCAN_RSP_DATA_CFM	set scan response data confirm
LE_CM_MSG_SET_ADVERTISING_PARAMS_CFM	set advertising parameters confirm
LE_CM_MSG_ENTER_ADVERTISING_CFM	enter advertising confirm
LE_CM_MSG_EXIT_ADVERTISING_CFM	exit advertising confirm
LE_CM_MSG_SET_SCAN_PARAMS_CFM	set scan parameters confirm
LE_CM_MSG_ENTER_SCANNING_CFM	enter scanning confirm
LE_CM_MSG_EXIT_SCANNING_CFM	exit scanning confirm
LE_CM_MSG_CREATE_CONNECTION_CFM	create connection confirm
LE_CM_MSG_CANCEL_CONNECTION_CFM	cancel connection confirm
LE_CM_MSG_READ_TX_POWER_CFM	read tx power confirm
LE_CM_MSG_READ_BD_ADDR_CFM	read device address confirm
LE_CM_MSG_READ_RSSI_CFM	read RSSI confirm
LE_CM_MSG_SET_RANDOM_ADDRESS_CFM	set random address confirm
LE_CM_MSG_READ_ADV_TX_POWER_CFM	read advertising tx power confirm
LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM	read whitelist size confirm

3.2 BLE CM APIs

Enumerator

	T
LE_CM_MSG_CLEAR_WHITE_LIST_CFM	clear whitelist confirm
LE_CM_MSG_ADD_TO_WHITE_LIST_CFM	add to whitelist confirm
LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM	remove from whitelist confirm
LE_CM_MSG_SET_CHANNEL_MAP_CFM	set channel map confirm
LE_CM_MSG_READ_CHANNEL_MAP_CFM	read channel map confirm
LE_CM_MSG_SET_DATA_LENGTH_CFM	set data length confirm
LE_CM_MSG_DATA_LEN_CHANGE_IND	data length change indication
LE_CM_MSG_ADD_TO_RESOLVING_LIST_CFM	add to resolving list confirm
LE_CM_MSG_REMOVE_FROM_RESOLVING_LIST_CFM	remove from resolving list confirm
LE_CM_MSG_CLEAR_RESOLVING_LIST_CFM	clear resolving list confirm
LE_CM_MSG_READ_RESOLVING_LIST_SIZE_CFM	read resolving list size confirm
LE_CM_MSG_SET_RPA_TIMEOUT_CFM	set resolving private address timeout confirm
LE_CM_MSG_SIGNAL_UPDATE_REQ	signal update request
LE_CM_MSG_CONN_UPDATE_COMPLETE_IND	connection update complete indication
LE_CM_MSG_CONN_PARA_REQ	connection parameters request
LE_CM_MSG_ENCRYPTION_CHANGE_IND	encryption change indication
LE_CM_MSG_ENCRYPTION_REFRESH_IND	encryption refresh indication
LE_CM_MSG_LTK_REQ_IND	long term key indication
LE_CM_MSG_ADVERTISE_REPORT_IND	advertising report indication
LE_CM_MSG_DIRECT_ADV_REPORT_IND	direct advertising report indication
LE_CM_CONNECTION_COMPLETE_IND	connection complete indication
LE_CM_MSG_READ_LOCAL_RPA_CFM	read local resolving private address confirm
LE_CM_MSG_READ_PHY_CFM	
LE_CM_MSG_SET_DEFAULT_PHY_CFM	
LE_CM_MSG_SET_PHY_CFM	
LE_CM_MSG_PHY_UPDATE_COMPLETE_IND	
LE_CM_MSG_TOP	top of CM message id

3.2.4 Function Documentation

3.2.4.1 LeCmInit()

BLE Connection Management Module Init.

Parameters

the reference of BLE task.

Returns

None.

3.3 BLE GAP APIs 15

3.3 BLE GAP APIS

Data Structures

- struct LE GAP ADVERTISING PARAM T
- struct LE GAP CONN PARAM T
- struct LE_GAP_SCAN_PARAM_T

Macros

- #define GAP_ADTYPE_128BIT_COMPLETE 0x07
- #define GAP_ADTYPE_128BIT_MORE 0x06
- #define GAP ADTYPE 16BIT COMPLETE 0x03
- #define GAP_ADTYPE_16BIT_MORE 0x02
- #define GAP ADTYPE 32BIT COMPLETE 0x05
- #define GAP_ADTYPE_32BIT_MORE 0x04
- #define GAP ADTYPE 3D INFO DATA 0x3D
- #define GAP_ADTYPE_ADV_INTERVAL 0x1A
- #define GAP_ADTYPE_APPEARANCE 0x19
- #define GAP_ADTYPE_FLAGS 0x01
- #define GAP ADTYPE FLAGS BREDR NOT SUPPORTED 0x04
- #define GAP ADTYPE FLAGS GENERAL 0x02
- #define GAP_ADTYPE_FLAGS_LIMITED 0x01
- #define GAP ADTYPE LE BD ADDR 0x1B
- #define GAP_ADTYPE_LE_ROLE 0x1C
- #define GAP_ADTYPE_LOCAL_NAME_COMPLETE 0x09
- #define GAP_ADTYPE_LOCAL_NAME_SHORT 0x08
- #define GAP_ADTYPE_MANUFACTURER_SPECIFIC 0xFF
- #define GAP_ADTYPE_OOB_CLASS_OF_DEVICE 0x0D
- #define GAP_ADTYPE_OOB_SIMPLE_PAIRING_HASHC 0x0E
- #define GAP_ADTYPE_OOB_SIMPLE_PAIRING_RANDR 0x0F
- #define GAP_ADTYPE_POWER_LEVEL 0x0A
- #define GAP_ADTYPE_PUBLIC_TARGET_ADDR 0x17
- #define GAP ADTYPE RANDOM TARGET ADDR 0x18
- #define GAP_ADTYPE_SERVICE_DATA 0x16
- #define GAP ADTYPE SERVICE DATA 128BIT 0x21
- #define GAP_ADTYPE_SERVICE_DATA_32BIT 0x20
- #define GAP_ADTYPE_SERVICES_LIST_128BIT 0x15
- #define GAP ADTYPE SERVICES LIST 16BIT 0x14
- #define GAP_ADTYPE_SIGNED_DATA 0x13
- #define GAP_ADTYPE_SIMPLE_PAIRING_HASHC_256 0x1D
- #define GAP_ADTYPE_SIMPLE_PAIRING_RANDR_256 0x1E
- #define GAP_ADTYPE_SLAVE_CONN_INTERVAL_RANGE 0x12
- #define GAP ADTYPE SM OOB FLAG 0x11
- #define GAP ADTYPE SM TK 0x10
- #define GAP PUBLIC ADDR 0
- #define GAP_RAND_ADDR_NRPA 2
- #define GAP_RAND_ADDR_RPA 3
- #define GAP_RAND_ADDR_STATIC 1
- #define GAP_SCAN_TYPE_ACTIVE 1
- #define GAP_SCAN_TYPE_PASSIVE 0
- #define GAP_TX_PWR_CURR_VAL 0
- #define GAP_TX_PWR_MAX_VAL 1

- #define GAPBOND_IO_CAP_DISPLAY_ONLY 0x00
- #define GAPBOND_IO_CAP_DISPLAY_YES_NO 0x01
- #define GAPBOND_IO_CAP_KEYBOARD_DISPLAY 0x04
- #define GAPBOND IO CAP KEYBOARD ONLY 0x02
- #define GAPBOND IO CAP NO INPUT NO OUTPUT 0x03
- #define GAPBOND_PAIRING_MODE_INITIATE 0x02
- #define GAPBOND PAIRING MODE NO PAIRING 0x00
- #define GAPBOND PAIRING MODE WAIT FOR REQ 0x01
- #define LE_GAP_ADV_MAX_SIZE 31

Functions

LE ERR STATE LeGapAddToResolvingList (LE BT ADDR T *bt addr, UINT8 *irk)

Add device to resolving-list.

• LE ERR STATE LeGapAddToWhiteList (LE BT ADDR T *bt addr)

Add device to whitelist.

• LE_ERR_STATE LeGapAdvertisingEnable (BOOL start)

Enable or disable advertising function.

• LE_ERR_STATE LeGapCentralConnectReq (LE_BT_ADDR_T *taddr, UINT8 own_addr_type)

Central connect request.

• LE_ERR_STATE LeGapCentralSetDataChannel (UINT8 *ch)

Central set data channel.

LE ERR STATE LeGapClearResolvingList (void)

Clear the resolving-list in the controller.

• LE ERR STATE LeGapClearWhiteList (void)

Clear whitelist in the controller.

LE_ERR_STATE LeGapConnectCancelReq (void)

Cancel connect request.

void LeGapConnParaRequestRsp (UINT16 conn_hdl, BOOL accept)

Connection parameters request response.

• LE_ERR_STATE LeGapConnUpdateRequest (UINT16 conn_hdl, LE_CONN_PARA_T *para)

Connection parameters update request.

• void LeGapConnUpdateResponse (UINT16 conn_hdl, UINT8 identifier, BOOL accept)

Connection parameters update response.

• LE ERR STATE LeGapDisconnectReg (UINT16 conn hdl)

Disconnect the physical connection.

LE_ERR_STATE LeGapGenRandAddr (UINT8 type, BD_ADDR addr)

Called to generation random address.

void LeGapGetBtAddr (void)

Get owner device address.

void LeGapReadAdvChannelTxPower (void)

Read ADV channel txpower.

• LE_ERR_STATE LeGapReadChannelMap (UINT16 conn_hdl)

Read channel map.

- LE_ERR_STATE LeGapReadPhy (UINT16 conn_hdl)
- void LeGapReadResolvingListSize (void)

Read the resolving-list size in the controller.

LE_ERR_STATE LeGapReadRssi (UINT16 conn_hdl)

Read RSSI value from controller.

• LE_ERR_STATE LeGapReadTxPower (UINT16 conn_hdl, UINT8 type)

Read tx power value for the specified connection.

3.3 BLE GAP APIs

void LeGapReadWhiteListSize (void)

Read whitelist size in the controller.

• LE_ERR_STATE LeGapRemoveFromWhiteList (LE_BT_ADDR_T *bt_addr)

Remove device from whitelist.

• LE_ERR_STATE LeGapScanningReq (BOOL start, BOOL filter)

Request scanning start.

• LE_ERR_STATE LeGapSetAdvData (UINT8 len, UINT8 *data)

Called to set ADV data.

• LE_ERR_STATE LeGapSetAdvParameter (LE_GAP_ADVERTISING_PARAM_T *params)

Called to set ADV parameters.

LE_ERR_STATE LeGapSetConnParameter (UINT16 interval_min, UINT16 interval_max, UINT16 slave_
 — latency, UINT16 supervision_timeout)

Called to set connection parameters.

- LE_ERR_STATE LeGapSetDataChannelPduLen (UINT16 conn_hdl, UINT16 tx_octets, UINT16 tx_time) Set data channel PDU length.
- LE ERR STATE LeGapSetDefaultPhy (UINT8 tx, UINT8 rx)
- LE ERR STATE LeGapSetPhy (UINT16 conn hdl, UINT8 tx, UINT8 rx, UINT16 option)
- LE ERR STATE LeGapSetRandAddr (BD ADDR addr)

Called to set random address.

LE ERR STATE LeGapSetRpaTimeout (UINT16 timeout)

Set resolvable private address timeout.

LE_ERR_STATE LeGapSetStaticAddr (BD_ADDR addr)

Called to set static address.

• LE ERR STATE LeSetScanParameter (LE GAP SCAN PARAM T *params)

Called to set scan parameters.

• LE ERR STATE LeSetScanRspData (UINT8 len, UINT8 *data)

Called to set scan response data.

3.3.1 Detailed Description

3.3.2 Macro Definition Documentation

3.3.2.1 GAP_ADTYPE_128BIT_COMPLETE

#define GAP_ADTYPE_128BIT_COMPLETE 0x07

3.3.2.2 GAP_ADTYPE_128BIT_MORE

#define GAP_ADTYPE_128BIT_MORE 0x06

3.3.2.3 GAP_ADTYPE_16BIT_COMPLETE

#define GAP_ADTYPE_16BIT_COMPLETE 0x03

3.3.2.4 GAP_ADTYPE_16BIT_MORE

#define GAP_ADTYPE_16BIT_MORE 0x02

3.3.2.5 GAP_ADTYPE_32BIT_COMPLETE

#define GAP_ADTYPE_32BIT_COMPLETE 0x05

3.3.2.6 GAP_ADTYPE_32BIT_MORE

#define GAP_ADTYPE_32BIT_MORE 0x04

3.3.2.7 GAP_ADTYPE_3D_INFO_DATA

#define GAP_ADTYPE_3D_INFO_DATA 0x3D

3.3.2.8 GAP_ADTYPE_ADV_INTERVAL

#define GAP_ADTYPE_ADV_INTERVAL 0x1A

3.3.2.9 GAP_ADTYPE_APPEARANCE

#define GAP_ADTYPE_APPEARANCE 0x19

3.3.2.10 GAP_ADTYPE_FLAGS

#define GAP_ADTYPE_FLAGS 0x01

3.3 BLE GAP APIs

3.3.2.11 GAP_ADTYPE_FLAGS_BREDR_NOT_SUPPORTED

#define GAP_ADTYPE_FLAGS_BREDR_NOT_SUPPORTED 0x04

3.3.2.12 GAP_ADTYPE_FLAGS_GENERAL

#define GAP_ADTYPE_FLAGS_GENERAL 0x02

3.3.2.13 GAP_ADTYPE_FLAGS_LIMITED

#define GAP_ADTYPE_FLAGS_LIMITED 0x01

3.3.2.14 GAP_ADTYPE_LE_BD_ADDR

#define GAP_ADTYPE_LE_BD_ADDR 0x1B

3.3.2.15 GAP_ADTYPE_LE_ROLE

#define GAP_ADTYPE_LE_ROLE 0x1C

3.3.2.16 GAP_ADTYPE_LOCAL_NAME_COMPLETE

#define GAP_ADTYPE_LOCAL_NAME_COMPLETE 0x09

3.3.2.17 GAP_ADTYPE_LOCAL_NAME_SHORT

#define GAP_ADTYPE_LOCAL_NAME_SHORT 0x08

3.3.2.18 GAP_ADTYPE_MANUFACTURER_SPECIFIC

#define GAP_ADTYPE_MANUFACTURER_SPECIFIC 0xFF

3.3.2.19 GAP_ADTYPE_OOB_CLASS_OF_DEVICE

#define GAP_ADTYPE_OOB_CLASS_OF_DEVICE 0x0D

3.3.2.20 GAP_ADTYPE_OOB_SIMPLE_PAIRING_HASHC

#define GAP_ADTYPE_OOB_SIMPLE_PAIRING_HASHC 0x0E

3.3.2.21 GAP_ADTYPE_OOB_SIMPLE_PAIRING_RANDR

#define GAP_ADTYPE_OOB_SIMPLE_PAIRING_RANDR 0x0F

3.3.2.22 GAP_ADTYPE_POWER_LEVEL

#define GAP_ADTYPE_POWER_LEVEL 0x0A

3.3.2.23 GAP_ADTYPE_PUBLIC_TARGET_ADDR

#define GAP_ADTYPE_PUBLIC_TARGET_ADDR 0x17

3.3.2.24 GAP_ADTYPE_RANDOM_TARGET_ADDR

#define GAP_ADTYPE_RANDOM_TARGET_ADDR 0x18

3.3.2.25 GAP_ADTYPE_SERVICE_DATA

#define GAP_ADTYPE_SERVICE_DATA 0x16

3.3.2.26 GAP_ADTYPE_SERVICE_DATA_128BIT

#define GAP_ADTYPE_SERVICE_DATA_128BIT 0x21

3.3 BLE GAP APIs 21

3.3.2.27 GAP_ADTYPE_SERVICE_DATA_32BIT

#define GAP_ADTYPE_SERVICE_DATA_32BIT 0x20

3.3.2.28 GAP_ADTYPE_SERVICES_LIST_128BIT

#define GAP_ADTYPE_SERVICES_LIST_128BIT 0x15

3.3.2.29 GAP_ADTYPE_SERVICES_LIST_16BIT

#define GAP_ADTYPE_SERVICES_LIST_16BIT 0x14

3.3.2.30 GAP_ADTYPE_SIGNED_DATA

#define GAP_ADTYPE_SIGNED_DATA 0x13

3.3.2.31 GAP_ADTYPE_SIMPLE_PAIRING_HASHC_256

#define GAP_ADTYPE_SIMPLE_PAIRING_HASHC_256 0x1D

3.3.2.32 GAP_ADTYPE_SIMPLE_PAIRING_RANDR_256

#define GAP_ADTYPE_SIMPLE_PAIRING_RANDR_256 0x1E

3.3.2.33 GAP_ADTYPE_SLAVE_CONN_INTERVAL_RANGE

#define GAP_ADTYPE_SLAVE_CONN_INTERVAL_RANGE 0x12

3.3.2.34 GAP_ADTYPE_SM_OOB_FLAG

#define GAP_ADTYPE_SM_OOB_FLAG 0x11

3.3.2.35 GAP_ADTYPE_SM_TK

#define GAP_ADTYPE_SM_TK 0x10

3.3.2.36 GAP_PUBLIC_ADDR

#define GAP_PUBLIC_ADDR 0

3.3.2.37 GAP_RAND_ADDR_NRPA

#define GAP_RAND_ADDR_NRPA 2

3.3.2.38 GAP_RAND_ADDR_RPA

#define GAP_RAND_ADDR_RPA 3

3.3.2.39 GAP_RAND_ADDR_STATIC

#define GAP_RAND_ADDR_STATIC 1

3.3.2.40 GAP_SCAN_TYPE_ACTIVE

#define GAP_SCAN_TYPE_ACTIVE 1

3.3.2.41 GAP_SCAN_TYPE_PASSIVE

#define GAP_SCAN_TYPE_PASSIVE 0

3.3.2.42 GAP_TX_PWR_CURR_VAL

#define GAP_TX_PWR_CURR_VAL 0

3.3 BLE GAP APIs

3.3.2.43 GAP_TX_PWR_MAX_VAL

#define GAP_TX_PWR_MAX_VAL 1

3.3.2.44 GAPBOND_IO_CAP_DISPLAY_ONLY

#define GAPBOND_IO_CAP_DISPLAY_ONLY 0x00

3.3.2.45 GAPBOND_IO_CAP_DISPLAY_YES_NO

#define GAPBOND_IO_CAP_DISPLAY_YES_NO 0x01

3.3.2.46 GAPBOND_IO_CAP_KEYBOARD_DISPLAY

#define GAPBOND_IO_CAP_KEYBOARD_DISPLAY 0x04

3.3.2.47 GAPBOND_IO_CAP_KEYBOARD_ONLY

#define GAPBOND_IO_CAP_KEYBOARD_ONLY 0x02

3.3.2.48 GAPBOND_IO_CAP_NO_INPUT_NO_OUTPUT

 $\verb|#define GAPBOND_IO_CAP_NO_INPUT_NO_OUTPUT 0x03|\\$

3.3.2.49 GAPBOND_PAIRING_MODE_INITIATE

#define GAPBOND_PAIRING_MODE_INITIATE 0x02

3.3.2.50 GAPBOND_PAIRING_MODE_NO_PAIRING

#define GAPBOND_PAIRING_MODE_NO_PAIRING 0×00

3.3.2.51 GAPBOND_PAIRING_MODE_WAIT_FOR_REQ

```
#define GAPBOND_PAIRING_MODE_WAIT_FOR_REQ 0x01
```

3.3.2.52 LE_GAP_ADV_MAX_SIZE

```
#define LE_GAP_ADV_MAX_SIZE 31
```

3.3.3 Function Documentation

3.3.3.1 LeGapAddToResolvingList()

Add device to resolving-list.

Parameters

bt_addr	BT device address.	
irk	IRK, Identity Resolving Key	

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.2 LeGapAddToWhiteList()

```
LE_ERR_STATE LeGapAddToWhiteList ( \label{legapAddToWhiteList} \mbox{LE\_BT\_ADDR\_T} \ * \ bt\_addr \ )
```

Add device to whitelist.

Parameters

ht addr	BT device address.
Di_aaaai	Di acvice addices.

3.3 BLE GAP APIs 25

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.3 LeGapAdvertisingEnable()

```
LE_ERR_STATE LeGapAdvertisingEnable ( {\tt BOOL}\ start\ )
```

Enable or disable advertising function.

Parameters

```
start TRUE is enable, FALSE is disable.
```

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.4 LeGapCentralConnectReq()

Central connect request.

Parameters

taddr	advertisers device address.
own_addr_type	owner address type.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.5 LeGapCentralSetDataChannel()

```
LE_ERR_STATE LeGapCentralSetDataChannel ( {\tt UINT8~*~ch~})
```

Central set data channel.

3.3 BLE GAP APIs 27

Parameters

```
ch data channel.
```

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.6 LeGapClearResolvingList()

```
\label{legapClearResolvingList} \mbox{LE\_ERR\_STATE LeGapClearResolvingList (} \\ \mbox{void )}
```

Clear the resolving-list in the controller.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.7 LeGapClearWhiteList()

Clear whitelist in the controller.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.8 LeGapConnectCancelReq()

Cancel connect request.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.9 LeGapConnParaRequestRsp()

Connection parameters request response.

Parameters

conn_hdl	connection handle.
accept	TRUE is accept, FALSE is not.

Returns

None.

3.3.3.10 LeGapConnUpdateRequest()

```
LE_ERR_STATE LeGapConnUpdateRequest (  \label{legapConn_hdl}  \mbox{UINT16 } conn\_hdl, \\ \mbox{LE_CONN_PARA_T * para )}
```

Connection parameters update request.

Parameters

conn_hdl	connection handle.
para	update connection parameters.

Returns

None.

3.3.3.11 LeGapConnUpdateResponse()

Connection parameters update response.

Parameters

conn_hdl	connection handle.
identifier	TBD
accept	accept request, or not.

Returns

None.

3.3 BLE GAP APIs

3.3.3.12 LeGapDisconnectReq()

Disconnect the physical connection.

Parameters

```
conn_hdl connection handle.
```

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.13 LeGapGenRandAddr()

```
LE_ERR_STATE LeGapGenRandAddr (  \mbox{UINT8 } type, \\ \mbox{BD\_ADDR } addr \mbox{ )}
```

Called to generation random address.

Parameters

type	address type.
addr	address.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.14 LeGapGetBtAddr()

```
void LeGapGetBtAddr (
     void )
```

Get owner device address.

3.3.3.15 LeGapReadAdvChannelTxPower()

```
\begin{tabular}{ll} \beg
```

Read ADV channel txpower.

3.3.3.16 LeGapReadChannelMap()

Read channel map.

Parameters

```
conn_hdl connection handle.
```

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.17 LeGapReadPhy()

```
LE_ERR_STATE LeGapReadPhy ( UINT16 conn_hdl )
```

3.3.3.18 LeGapReadResolvingListSize()

Read the resolving-list size in the controller.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.19 LeGapReadRssi()

Read RSSI value from controller.

3.3 BLE GAP APIs 31

Parameters

```
conn_hdl connection handle.
```

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.20 LeGapReadTxPower()

Read tx power value for the specified connection.

Parameters

conn_hdl	connection handle.
type	current tx power, or maxinum tx power. Don't support.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.21 LeGapReadWhiteListSize()

Read whitelist size in the controller.

3.3.3.22 LeGapRemoveFromWhiteList()

```
LE_ERR_STATE LeGapRemoveFromWhiteList (  \label{legapRemoveFromWhiteList}  \mbox{LE\_BT\_ADDR\_T} * bt\_addr )
```

Remove device from whitelist.

Remove device from resolving-list.

Parameters

```
bt_addr BT device address.
```

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.23 LeGapScanningReq()

```
LE_ERR_STATE LeGapScanningReq (
BOOL start,
BOOL filter )
```

Request scanning start.

Parameters

start	TRUE is start, FALSE is not.
filter	scan policy, refer to LE_HCI_SCAN_FILT_* in ble_hci_if.h

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.24 LeGapSetAdvData()

Called to set ADV data.

Parameters

len ADV data lengtl	
data	ADV data.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3 BLE GAP APIs 33

3.3.3.25 LeGapSetAdvParameter()

Called to set ADV parameters.

Parameters

params advertising params.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.26 LeGapSetConnParameter()

Called to set connection parameters.

Parameters

interval_min	mininum connection interval.
interval_max	maxinum connection interval.
slave_letency	slave letency.
supervision_timeout	supervison timeout.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.27 LeGapSetDataChannelPduLen()

```
LE_ERR_STATE LeGapSetDataChannelPduLen ( UINT16 conn_hdl,
```

```
UINT16 tx_octets,
UINT16 tx_time )
```

Set data channel PDU length.

Parameters

tx_octets	the maximum number of octets in the Payload field that the local device will send to the remote	
	device.	
tx_time	the maximum number of microseconds that the local device will take to transmit a PDU to the	
	remote device.	

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.28 LeGapSetDefaultPhy()

3.3.3.29 LeGapSetPhy()

3.3.3.30 LeGapSetRandAddr()

```
LE_ERR_STATE LeGapSetRandAddr ( {\tt BD\_ADDR} \  \, addr \  \, )
```

Called to set random address.

Parameters

addr	the rendem address which should be set
aaar	the random address which should be set.

3.3 BLE GAP APIs 35

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.31 LeGapSetRpaTimeout()

Set resolvable private address timeout.

Parameters

timeout RPA_Timeout, measured in seconds.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.32 LeGapSetStaticAddr()

```
LE_ERR_STATE LeGapSetStaticAddr ( BD_ADDR \ addr )
```

Called to set static address.

Parameters

addr the static address which should be set.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.33 LeSetScanParameter()

Called to set scan parameters.

Parameters

```
params scan parameters.
```

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.3.3.34 LeSetScanRspData()

Called to set scan response data.

Parameters

len	scan response data length.
data	scan response data.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4 BLE GATT APIS

Data Structures

- struct LE_GATT_ATTR_T
- struct LE GATT MSG ACCESS READ IND T
- struct LE_GATT_MSG_ACCESS_WRITE_IND_T
- · struct LE GATT MSG CHAR DESCRIPTOR INFO IND T
- struct LE GATT MSG CHARACTERISTIC DECL INFO IND T
- struct LE GATT MSG CHARACTERISTIC VAL IND T
- struct LE GATT MSG CONFIRMATION CFM T
- struct LE_GATT_MSG_EXCHANGE_MTU_CFM_T
- struct LE GATT MSG EXCHANGE MTU IND T
- struct LE GATT MSG EXECUTE WRITE RELIABLE CFM T
- struct LE_GATT_MSG_FIND_ALL_CHAR_DESC_CFM_T
- struct LE_GATT_MSG_FIND_ALL_PRIMARY_SERVICE_CFM_T
- struct LE GATT MSG FIND CHARACTERISTIC CFM T
- struct LE_GATT_MSG_FIND_INCLUDED_SERVICE_CFM_T
- struct LE GATT MSG FIND PRIMARY SERVICE BY UUID CFM T
- struct LE_GATT_MSG_INCLUDE_SERVICE_INFO_IND_T
- struct LE_GATT_MSG_INDICATE_IND_T
- struct LE_GATT_MSG_NOTIFY_CFM_T
- struct LE_GATT_MSG_NOTIFY_IND_T
- struct LE_GATT_MSG_OPERATION_TIMEOUT_T
- struct LE GATT MSG PREPARE WRITE RELIABLE CFM T
- struct LE_GATT_MSG_READ_CHAR_VAL_BY_UUID_CFM_T
- struct LE_GATT_MSG_READ_CHARACTERISTIC_VALUE_CFM_T
- struct LE_GATT_MSG_READ_LONG_CHAR_VAL_CFM_T
- struct LE_GATT_MSG_READ_MULTIPLE_CHAR_VAL_CFM_T
- struct LE_GATT_MSG_SERVICE_INFO_IND_T
- struct LE_GATT_MSG_SIGNED_WRITE_CFM_T
- struct LE_GATT_MSG_WRITE_CHAR_VAL_RELIABLE_CFM_T
- struct LE_GATT_MSG_WRITE_CHAR_VALUE_CFM_T
- struct LE_GATT_MSG_WRITE_LONG_CHAR_VALUE_CFM_T
- struct LE_GATT_MSG_WRITE_NO_RSP_CFM_T
- struct LE_GATT_SERVICE_T

Macros

- #define CHAR_AGGREGATE_DESCRIPTOR(len, pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcCharAggregateUuid, LE_GATT_PERMIT_READ, 0, len, (UINT8 *)(pVal)}
- #define CHAR_CLIENT_CONFIG_DESCRIPTOR(permit, pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcClientCharConfigUuid, LE_GATT_PERMIT_READ | permit, 0, 2, (UINT8 *)(pVal)}
- #define CHAR_DECL_UUID16_ATTR_VAL(prop, type) {(prop), 0, 0, UINT16_LO(type), UINT16_HI(type)}
- #define CHAR_EXT_PROP_DESCRIPTOR(pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcCharExtPropUuid, LE_GATT_PERMIT_READ, 0, 2, (UINT8 *)(pVal)}
- #define CHAR_PRESENT_FORMAT_DESCRIPTOR(pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcCharFormatUuid, LE_GATT_PERMIT_READ, 0, 7, (UINT8 *)(pVal)}
- #define CHAR_SERVER_CONFIG_DESCRIPTOR(permit, pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcServerCharConfigUuid, LE_GATT_PERMIT_READ | permit, 0, 2, (UINT8 *)(pVal)}
- #define CHAR_USER_DESC_DESCRIPTOR(permit, maxLen, len, pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcCharUserDescUuid, permit, maxLen, len, (UINT8 *)(pVal)}

 #define CHARACTERISTIC_DECL_UUID128(pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcCharacteristicUuid, LE GATT PERMIT READ, 0, 19, (UINT8 *)(pVal)}

- #define CHARACTERISTIC_DECL_UUID16(pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcCharacteristicUuid, LE_GATT_PERMIT_READ, 0, 5, (UINT8 *)(pVal)}
- #define CHARACTERISTIC_UUID128(pUuid, permit, maxLen, len, pVal) {0, LE_GATT_UUID128, (UINT16 *)pUuid, permit, maxLen, len, (UINT8 *)(pVal)}
- #define CHARACTERISTIC_UUID16(pUuid, permit, maxLen, len, pVal) {0, LE_GATT_UUID16, (UINT16 *)pUuid, permit, maxLen, len, (UINT8 *)(pVal)}
- #define GATT CHAR AGG FORMAT UUID 0x2905
- #define GATT CHAR EXT PROPS UUID 0x2900
- #define GATT CHAR FORMAT UUID 0x2904
- #define GATT_CHAR_USER_DESC_UUID 0x2901
- #define GATT CHARACTERISTIC UUID 0x2803
- #define GATT CLIENT CHAR CFG UUID 0x2902
- #define GATT_EXT_REPORT_REF_UUID 0x2907
- #define GATT INCLUDE UUID 0x2802
- #define GATT_PRIMARY_SERVICE_UUID 0x2800
- #define GATT REPORT REF UUID 0x2908
- #define GATT SECONDARY SERVICE UUID 0x2801
- #define GATT_SERV_CHAR_CFG_UUID 0x2903
- #define GATT VALID RANGE UUID 0x2906
- #define INCLUDE_DECL_UUID128(pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcIncludeUuid, LE_GATT_PERMIT_READ, 0, 4, (UINT8 *)(pVal)}
- #define INCLUDE_DECL_UUID128_ATTR_VAL() {0, 0, 0, 0}
- #define INCLUDE DECL UUID16 ATTR VAL(uuid) {0, 0, 0, 0, UINT16 LO(uuid), UINT16 HI(uuid)}
- #define INCLUDE_DECL_UUINT16(pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcIncludeUuid, LE_GATT_PERMIT_READ, 0, 6, (UINT8 *)(pVal)}
- #define LE_ATT_UUID_SIZE 2
- #define LE GATT CHAR PROP AUTH 0x40
- #define LE GATT CHAR PROP BCAST 0x01

Characteristic Properties Bit.

- #define LE_GATT_CHAR_PROP_EXT_PROP 0x80
- #define LE_GATT_CHAR_PROP_IND 0x20
- #define LE GATT CHAR PROP NTF 0x10
- #define LE GATT CHAR PROP RD 0x02
- #define LE GATT CHAR PROP WR 0x08
- #define LE_GATT_CHAR_PROP_WR_NO_RESP 0x04
- #define LE_GATT_CLIENT_CFG_INDICATION 0x02
- #define LE_GATT_CLIENT_CFG_NOTIFICATION 0x01
- #define LE_GATT_EXT_PROP_RELIABLE_WR 0x0001
- #define LE_GATT_EXT_PROP_WR_AUX 0x0002
- #define LE_GATT_FLAG_PREPARE_WRITE 0x02
- #define LE_GATT_FLAG_WRITE_CMD 0x01
- #define LE_GATT_FLAG_WRITE_REQ 0x00
- #define LE_GATT_PERM_AUTH_READABLE (0x1<<4)
- #define LE GATT PERM AUTH WRITABLE (0x1<<6)
- #define LE GATT PERM NONE (0x00)
- #define LE GATT PERM READ (0x1<<1)
- #define LE GATT PERM RELIABLE WRITE (0x1<<5)
- #define LE_GATT_PERM_WRITE_CMD (0x1<<2)
- #define LE_GATT_PERM_WRITE_REQ (0x1<<3)
- #define LE_GATT_PERMIT_AUTHEN_READ (0x0040)
- #define LE_GATT_PERMIT_AUTHEN_WRITE (0x0080)
- #define LE GATT PERMIT AUTHOR READ (0x0004)
- #define LE_GATT_PERMIT_AUTHOR_WRITE (0x0008)

- #define LE_GATT_PERMIT_ENCRYPT_READ (0x0010)
- #define LE_GATT_PERMIT_ENCRYPT_WRITE (0x0020)
- #define LE_GATT_PERMIT_READ (0x0001)
- #define LE_GATT_PERMIT_READABLE (LE_GATT_PERMIT_READ | LE_GATT_PERMIT_AUTHEN_READ | LE_GATT_PERMIT_AUTHOR_READ | LE_GATT_PERMIT_ENCRYPT_READ | LE_GATT_PERMIT_SC_AUTHEN_READ)
- #define LE_GATT_PERMIT_SC_AUTHEN_READ (0x0100)
- #define LE GATT PERMIT SC AUTHEN WRITE (0x0200)
- #define LE_GATT_PERMIT_WRITABLE (LE_GATT_PERMIT_WRITE | LE_GATT_PERMIT_AUTHEN_WRITE | LE_GATT_PERMIT_AUTHOR_WRITE | LE_GATT_PERMIT_ENCRYPT_WRITE | LE_GATT_PERMIT_SC_AUTHEN_WRITE | LE_GA
- #define LE_GATT_PERMIT_WRITE (0x0002)
- #define PRIMARY_SERVICE_DECL_UUID128(pUuid) {0, LE_GATT_UUID16, (UINT16 *)&gcPrimaryServiceUuid, LE_GATT_PERMIT_READ, 0, 16, (UINT8 *)(pUuid)}
- #define PRIMARY_SERVICE_DECL_UUID16(pUuid) {0, LE_GATT_UUID16, (UINT16 *)&gcPrimaryServiceUuid, LE GATT PERMIT READ, 0, 2, (UINT8 *)(pUuid)}
- #define SECONDARY_SERVICE_DECL_UUID128(pUuid) {0, LE_GATT_UUID16, (UINT16 *)&gcSecondaryServiceUuid, LE_GATT_PERMIT_READ, 0, 16, (UINT8 *)(pUuid)}
- #define SECONDARY_SERVICE_DECL_UUID16(pUuid) {0, LE_GATT_UUID16, (UINT16 *)&gcSecondaryServiceUuid, LE_GATT_PERMIT_READ, 0, 2, (UINT8 *)(pUuid)}

Enumerations

```
enum {
 LE_GATT_MSG_INIT_CFM = LE_GATT_MSG_BASE, LE_GATT_MSG_EXCHANGE_MTU_IND, LE_GATT_MSG_EXCHANG
 LE GATT MSG ACCESS READ IND,
 LE_GATT_MSG_ACCESS_WRITE_IND, LE_GATT_MSG_SERVICE_INFO_IND, LE_GATT_MSG_FIND_ALL_PRIMARY_SE
 LE_GATT_MSG_FIND_PRIMARY_SERVICE_BY_UUID_CFM,
 LE_GATT_MSG_INCLUDE_SERVICE_INFO_IND, LE_GATT_MSG_FIND_INCLUDED_SERVICE_CFM,
 LE GATT MSG CHARACTERISTIC DECL INFO IND, LE GATT MSG FIND CHARACTERISTIC CFM,
 LE GATT MSG CHAR DESCRIPTOR INFO IND,
                                          LE GATT MSG FIND ALL CHAR DESC CFM,
 LE_GATT_MSG_CHARACTERISTIC_VAL_IND, LE_GATT_MSG_READ_CHARACTERISTIC_VALUE_CFM,
 LE_GATT_MSG_READ_CHAR_VAL_BY_UUID_CFM, LE_GATT_MSG_READ_LONG_CHAR_VAL_CFM,
 LE_GATT_MSG_READ_MULTIPLE_CHAR_VAL_CFM, LE_GATT_MSG_WRITE_CHAR_VALUE_CFM,
 LE_GATT_MSG_WRITE_LONG_CHAR_VALUE_CFM, LE_GATT_MSG_WRITE_CHAR_VAL_RELIABLE_CFM,
 LE GATT MSG PREPARE WRITE RELIABLE CFM, LE GATT MSG EXECUTE WRITE RELIABLE CFM,
 LE GATT MSG WRITE NO RSP CFM, LE GATT MSG SIGNED WRITE CFM, LE GATT MSG NOTIFY IND,
 LE GATT MSG NOTIFY CFM,
 LE_GATT_MSG_INDICATE_IND, LE_GATT_MSG_CONFIRMATION_CFM, LE_GATT_MSG_OPERATION_TIMEOUT,
 LE_GATT_MSG_SIGN_RESOLUTION_FAIL,
 LE_GATT_MSG_TOP }
   BLE GATT message id.
```

Functions

- LE_ERR_STATE LeGattAccessReadRsp (UINT16 conn_hdl, UINT16 handle, UINT8 att_err)
 Gatt access read response.
- LE_ERR_STATE LeGattAccessWriteRsp (UINT16 conn_hdl, UINT8 method, UINT16 handle, UINT8 att_err)

 Gatt access write response.
- LE_ERR_STATE LeGattChangeAttrVal (LE_GATT_SERVICE_T *svc, UINT16 attrld, UINT16 len, void *val)

 Change attribute value.
- LE_ERR_STATE LeGattCharValConfirmation (UINT16 conn_hdl)

Prepare write characteristic value response.

• LE_ERR_STATE LeGattCharValIndicate (UINT16 conn_hdl, UINT16 hdl, UINT16 len, UINT8 *pval) Gatt characteristic value indication.

LE_ERR_STATE LeGattCharValNotify (UINT16 conn_hdl, UINT16 hdl, UINT16 len, UINT8 *pval)
 Gatt characteristic value notification.

• LE ERR STATE LeGattExchangeMtuReg (UINT16 conn hdl, UINT16 mtu)

Exchange MTU request.

LE_ERR_STATE LeGattExchangeMtuRsp (UINT16 conn_hdl, UINT16 mtu)

Exchange MTU response.

• LE ERR STATE LeGattExecuteWriteCharValReliable (UINT16 conn hdl, BOOL yesno)

Execute write characteristic value request.

LE_ERR_STATE LeGattFindAllCharacteristic (UINT16 conn_hdl, UINT16 start_hdl, UINT16 end_hdl)
 Find all characteristic.

• LE_ERR_STATE LeGattFindAllCharDescriptor (UINT16 conn_hdl, UINT16 start_hdl, UINT16 end_hdl) Find all characteristic description.

• LE_ERR_STATE LeGattFindAllPrimaryService (UINT16 conn_hdl)

Find all primary service.

• LE_ERR_STATE LeGattFindCharacteristicByUuid (UINT16 conn_hdl, UINT16 start_hdl, UINT16 end_hdl, UINT8 format, UINT16 *uuid)

Find characteristic by UUID.

LE_ERR_STATE LeGattFindIncludedService (UINT16 conn_hdl, UINT16 start_hdl, UINT16 end_hdl)
 Find include service.

• LE_ERR_STATE LeGattFindPrimaryServiceByUuid (UINT16 conn_hdl, UINT8 format, UINT16 *uuid) Find primary service by UUID.

• UINT16 LeGattGetAttrHandle (LE_GATT_SERVICE_T *svc, UINT16 attrld)

Get attribute handle.

• LE_ERR_STATE LeGattGetAttrVal (LE_GATT_SERVICE_T *svc, UINT16 attrld, UINT16 *len, void *val)

Get attribute value.

UINT16 LeGattGetAttrValLen (LE GATT SERVICE T *svc, UINT16 attrld)

Get the length of attribute value.

• UINT16 LeGattGetAttrValMaxLen (LE_GATT_SERVICE_T *svc, UINT16 attrld)

Get the max length of attribute value.

void LeGattInit (TASK appTask)

BLE Gatt module init.

• LE_ERR_STATE LeGattModifyAttrVal (LE_GATT_SERVICE_T *svc, UINT16 attrld, UINT16 offset, UINT16 len, void *val)

Modify attribute value.

• LE_ERR_STATE LeGattPrepareWriteCharValReliable (UINT16 conn_hdl, UINT16 handle, UINT16 offset, UINT16 len, UINT8 *val)

Prepare write characteristic value request.

LE_ERR_STATE LeGattReadCharValByUuid (UINT16 conn_hdl, UINT16 start_hdl, UINT16 end_hdl, UINT8 format, UINT16 *uuid)

Read a characteristic value by UUID.

• LE_ERR_STATE LeGattReadCharValue (UINT16 conn_hdl, UINT16 handle)

Read a characteristic value.

• LE ERR STATE LeGattReadLongCharVal (UINT16 conn hdl, UINT16 handle, UINT16 offset)

Read a long characteristic value.

 $\bullet \ \ \mathsf{LE}_\mathsf{ERR}_\mathsf{STATE} \ \mathsf{LeGattReadMultipleCharVal} \ (\mathsf{UINT16} \ \mathsf{conn_hdl}, \ \mathsf{UINT16} \ \mathsf{count}, \ \mathsf{UINT16} \ \mathsf{*handle})$

• LE_ERR_STATE LeGattRegisterIncludeService (UINT16 inc_hdl, UINT16 start_hdl, UINT16 end_hdl, UI

NT16 uuid)

Called to register an include service.

Read Multiple characteristic values.

LE GATT SERVICE T * LeGattRegisterService (LE GATT ATTR T *attrTable, UINT16 numAttr)

Called to register a service.

• LE_ERR_STATE LeGattSignedWriteNoRsp (UINT16 conn_hdl, UINT16 handle, UINT16 len, UINT8 *val) Signed write without response.

void LeGattStopCurrentProcedure (UINT16 conn hdl)

Stop current procedure.

- LE_ERR_STATE LeGattWriteCharVal (UINT16 conn_hdl, UINT16 handle, UINT16 len, UINT8 *val)

 Write characteristic value.
- LE_ERR_STATE LeGattWriteCharValReliable (UINT16 conn_hdl, UINT16 handle, UINT16 offset, UINT16 len, UINT8 *val)

Write characteristic value reliable.

• LE_ERR_STATE LeGattWriteLongCharVal (UINT16 conn_hdl, UINT16 handle, UINT16 offset, UINT16 len, UINT8 *val)

Write long characteristic value.

• LE_ERR_STATE LeGattWriteNoRsp (UINT16 conn_hdl, UINT16 handle, UINT16 len, UINT8 *val) Write without response.

Variables

- · const UINT16 gcCharacteristicUuid
- · const UINT16 gcCharAggregateUuid
- · const UINT16 gcCharExtPropUuid
- const UINT16 gcCharFormatUuid
- const UINT16 gcCharUserDescUuid
- const UINT16 gcClientCharConfigUuid
- · const UINT16 gcExtReportRefUuid
- · const UINT16 gcIncludeUuid
- const UINT16 gcPrimaryServiceUuid
- const UINT16 gcReportRefUuid
- · const UINT16 gcSecondaryServiceUuid
- const UINT16 gcServerCharConfigUuid
- · const UINT16 gcValidRangeUuid

3.4.1 Detailed Description

3.4.2 Macro Definition Documentation

3.4.2.1 CHAR AGGREGATE DESCRIPTOR

3.4.2.2 CHAR_CLIENT_CONFIG_DESCRIPTOR

3.4.2.3 CHAR_DECL_UUID16_ATTR_VAL

3.4.2.4 CHAR_EXT_PROP_DESCRIPTOR

3.4.2.5 CHAR_PRESENT_FORMAT_DESCRIPTOR

3.4.2.6 CHAR_SERVER_CONFIG_DESCRIPTOR

3.4.2.7 CHAR_USER_DESC_DESCRIPTOR

3.4.2.8 CHARACTERISTIC_DECL_UUID128

3.4.2.9 CHARACTERISTIC DECL_UUID16

3.4.2.10 CHARACTERISTIC_UUID128

```
#define CHARACTERISTIC_UUID128( pUuid, \\ permit, \\ maxLen, \\ len, \\ pVal ) \ \{0, \ LE\_GATT\_UUID128, \ (UINT16 *) pUuid, \ permit, \ maxLen, \ len, \ (UINT8 *) (p \leftrightarrow Val) \}
```

3.4.2.11 CHARACTERISTIC UUID16

3.4.2.12 GATT_CHAR_AGG_FORMAT_UUID

```
#define GATT_CHAR_AGG_FORMAT_UUID 0x2905
```

3.4.2.13 GATT_CHAR_EXT_PROPS_UUID

```
#define GATT_CHAR_EXT_PROPS_UUID 0x2900
```

3.4.2.14 GATT_CHAR_FORMAT_UUID

#define GATT_CHAR_FORMAT_UUID 0x2904

3.4.2.15 GATT_CHAR_USER_DESC_UUID

#define GATT_CHAR_USER_DESC_UUID 0x2901

3.4.2.16 GATT_CHARACTERISTIC_UUID

#define GATT_CHARACTERISTIC_UUID 0x2803

3.4.2.17 GATT_CLIENT_CHAR_CFG_UUID

#define GATT_CLIENT_CHAR_CFG_UUID 0x2902

3.4.2.18 GATT_EXT_REPORT_REF_UUID

#define GATT_EXT_REPORT_REF_UUID 0x2907

3.4.2.19 GATT_INCLUDE_UUID

#define GATT_INCLUDE_UUID 0x2802

3.4.2.20 GATT_PRIMARY_SERVICE_UUID

#define GATT_PRIMARY_SERVICE_UUID 0x2800

3.4.2.21 GATT_REPORT_REF_UUID

#define GATT_REPORT_REF_UUID 0x2908

3.4.2.22 GATT_SECONDARY_SERVICE_UUID

```
#define GATT_SECONDARY_SERVICE_UUID 0x2801
```

3.4.2.23 GATT_SERV_CHAR_CFG_UUID

```
#define GATT_SERV_CHAR_CFG_UUID 0x2903
```

3.4.2.24 GATT_VALID_RANGE_UUID

```
#define GATT_VALID_RANGE_UUID 0x2906
```

3.4.2.25 INCLUDE DECL_UUID128

3.4.2.26 INCLUDE_DECL_UUID128_ATTR_VAL

```
#define INCLUDE_DECL_UUID128_ATTR_VAL() {0, 0, 0, 0}
```

3.4.2.27 INCLUDE_DECL_UUID16_ATTR_VAL

3.4.2.28 INCLUDE_DECL_UUINT16

3.4.2.29 LE_ATT_UUID_SIZE

#define LE_ATT_UUID_SIZE 2

3.4.2.30 LE_GATT_CHAR_PROP_AUTH

#define LE_GATT_CHAR_PROP_AUTH 0x40

3.4.2.31 LE_GATT_CHAR_PROP_BCAST

#define LE_GATT_CHAR_PROP_BCAST 0x01

Characteristic Properties Bit.

3.4.2.32 LE_GATT_CHAR_PROP_EXT_PROP

#define LE_GATT_CHAR_PROP_EXT_PROP 0x80

3.4.2.33 LE_GATT_CHAR_PROP_IND

#define LE_GATT_CHAR_PROP_IND 0x20

3.4.2.34 LE_GATT_CHAR_PROP_NTF

#define LE_GATT_CHAR_PROP_NTF 0x10

3.4.2.35 LE_GATT_CHAR_PROP_RD

#define LE_GATT_CHAR_PROP_RD 0x02

3.4.2.36 LE_GATT_CHAR_PROP_WR

#define LE_GATT_CHAR_PROP_WR 0x08

3.4.2.37 LE_GATT_CHAR_PROP_WR_NO_RESP

#define LE_GATT_CHAR_PROP_WR_NO_RESP 0x04

3.4.2.38 LE_GATT_CLIENT_CFG_INDICATION

#define LE_GATT_CLIENT_CFG_INDICATION 0x02

3.4.2.39 LE_GATT_CLIENT_CFG_NOTIFICATION

#define LE_GATT_CLIENT_CFG_NOTIFICATION 0x01

3.4.2.40 LE_GATT_EXT_PROP_RELIABLE_WR

#define LE_GATT_EXT_PROP_RELIABLE_WR 0x0001

3.4.2.41 LE_GATT_EXT_PROP_WR_AUX

#define LE_GATT_EXT_PROP_WR_AUX 0x0002

3.4.2.42 LE_GATT_FLAG_PREPARE_WRITE

#define LE_GATT_FLAG_PREPARE_WRITE 0x02

3.4.2.43 LE_GATT_FLAG_WRITE_CMD

 $\#define LE_GATT_FLAG_WRITE_CMD 0x01$

3.4.2.44 LE_GATT_FLAG_WRITE_REQ

#define LE_GATT_FLAG_WRITE_REQ 0x00

3.4.2.45 LE_GATT_PERM_AUTH_READABLE

#define LE_GATT_PERM_AUTH_READABLE (0x1 << 4)

3.4.2.46 LE_GATT_PERM_AUTH_WRITABLE

#define LE_GATT_PERM_AUTH_WRITABLE (0x1<<6)</pre>

3.4.2.47 LE_GATT_PERM_NONE

#define LE_GATT_PERM_NONE (0x00)

3.4.2.48 LE_GATT_PERM_READ

#define LE_GATT_PERM_READ (0x1<<1)</pre>

3.4.2.49 LE_GATT_PERM_RELIABLE_WRITE

#define LE_GATT_PERM_RELIABLE_WRITE (0x1 << 5)

3.4.2.50 LE_GATT_PERM_WRITE_CMD

#define LE_GATT_PERM_WRITE_CMD (0x1 << 2)

3.4.2.51 LE_GATT_PERM_WRITE_REQ

 $\texttt{\#define LE_GATT_PERM_WRITE_REQ (0x1}{<<3})$

3.4.2.52 LE_GATT_PERMIT_AUTHEN_READ

#define LE_GATT_PERMIT_AUTHEN_READ (0x0040)

3.4.2.53 LE_GATT_PERMIT_AUTHEN_WRITE

#define LE_GATT_PERMIT_AUTHEN_WRITE (0x0080)

3.4.2.54 LE_GATT_PERMIT_AUTHOR_READ

#define LE_GATT_PERMIT_AUTHOR_READ (0x0004)

3.4.2.55 LE_GATT_PERMIT_AUTHOR_WRITE

#define LE_GATT_PERMIT_AUTHOR_WRITE (0x0008)

3.4.2.56 LE_GATT_PERMIT_ENCRYPT_READ

#define LE_GATT_PERMIT_ENCRYPT_READ (0x0010)

3.4.2.57 LE_GATT_PERMIT_ENCRYPT_WRITE

#define LE_GATT_PERMIT_ENCRYPT_WRITE (0x0020)

3.4.2.58 LE_GATT_PERMIT_READ

#define LE_GATT_PERMIT_READ (0x0001)

3.4.2.59 LE_GATT_PERMIT_READABLE

#define LE_GATT_PERMIT_READABLE (LE_GATT_PERMIT_READ | LE_GATT_PERMIT_AUTHEN_READ | LE_GATT_PERMIT_AUTHOR_READ | LE_GATT_PERMIT_ENCRYPT_READ | LE_GATT_PERMIT_SC_AUTHEN_READ)

3.4.2.60 LE_GATT_PERMIT_SC_AUTHEN_READ

```
#define LE_GATT_PERMIT_SC_AUTHEN_READ (0x0100)
```

3.4.2.61 LE_GATT_PERMIT_SC_AUTHEN_WRITE

```
#define LE_GATT_PERMIT_SC_AUTHEN_WRITE (0x0200)
```

3.4.2.62 LE_GATT_PERMIT_WRITABLE

```
#define LE_GATT_PERMIT_WRITABLE (LE_GATT_PERMIT_WRITE | LE_GATT_PERMIT_AUTHEN_WRITE | LE_GATT_PERMIT_AUTHOR_WRITE | LE_GATT_PERMIT_ENCRYPT_WRITE | LE_GATT_PERMIT_SC_AUTHEN_WRITE)
```

3.4.2.63 LE_GATT_PERMIT_WRITE

```
#define LE_GATT_PERMIT_WRITE (0x0002)
```

3.4.2.64 PRIMARY_SERVICE_DECL_UUID128

3.4.2.65 PRIMARY_SERVICE_DECL_UUID16

3.4.2.66 SECONDARY_SERVICE_DECL_UUID128

3.4.2.67 SECONDARY_SERVICE_DECL_UUID16

3.4.3 Enumeration Type Documentation

3.4.3.1 anonymous enum

anonymous enum

BLE GATT message id.

Enumerator

LE_GATT_MSG_INIT_CFM	initialize confirm message
LE_GATT_MSG_EXCHANGE_MTU_IND	exchange MTU indication
LE_GATT_MSG_EXCHANGE_MTU_CFM	exchange MTU confirm
LE_GATT_MSG_ACCESS_READ_IND	access read indication
LE_GATT_MSG_ACCESS_WRITE_IND	access write indication
LE_GATT_MSG_SERVICE_INFO_IND	service infomation indication
LE_GATT_MSG_FIND_ALL_PRIMARY_SERVICE↔	find all primary service confirm
_CFM	
LE_GATT_MSG_FIND_PRIMARY_SERVICE_BY	find primary service by UUID fonfirm
_UUID_CFM	
LE_GATT_MSG_INCLUDE_SERVICE_INFO_IND	include service infomation
LE_GATT_MSG_FIND_INCLUDED_SERVICE_CFM	find include service confirm
LE_GATT_MSG_CHARACTERISTIC_DECL_INF	characteristic declaration info indication
O_IND	final above stavistic as ofive
LE_GATT_MSG_FIND_CHARACTERISTIC_CFM	find characteristic confirm
LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_IND	characteristic descriptor info indication
LE_GATT_MSG_FIND_ALL_CHAR_DESC_CFM	find all characteristic descriptors confirm
LE_GATT_MSG_CHARACTERISTIC_VAL_IND	characteristic value, indication message
LE_GATT_MSG_READ_CHARACTERISTIC_VAL↔ UE_CFM	read characteristic value, confirm message
LE_GATT_MSG_READ_CHAR_VAL_BY_UUID_C↔	read characteristic value by UUID confirm message
FM	
LE_GATT_MSG_READ_LONG_CHAR_VAL_CFM	read long characteristic value confirm mesage
LE_GATT_MSG_READ_MULTIPLE_CHAR_VAL_←	read multiple characteristic value confirm
CFM	
LE_GATT_MSG_WRITE_CHAR_VALUE_CFM	write characteristic value confirm
LE_GATT_MSG_WRITE_LONG_CHAR_VALUE_← CFM	write long characteristic value confirm
LE_GATT_MSG_WRITE_CHAR_VAL_RELIABLE↔	write characteristic value reliable confirm
_CFM	
LE_GATT_MSG_PREPARE_WRITE_RELIABLE_	prepare write reliable confirm
CFM	

Enumerator

LE_GATT_MSG_EXECUTE_WRITE_RELIABLE_←	execute write reliable confirm
CFM	
LE_GATT_MSG_WRITE_NO_RSP_CFM	write no response confirm
LE_GATT_MSG_SIGNED_WRITE_CFM	signed write confirm
LE_GATT_MSG_NOTIFY_IND	notify indication
LE_GATT_MSG_NOTIFY_CFM	notify confirm
LE_GATT_MSG_INDICATE_IND	indicate indication
LE_GATT_MSG_CONFIRMATION_CFM	confirmation confirm
LE_GATT_MSG_OPERATION_TIMEOUT	operation timeout
LE_GATT_MSG_SIGN_RESOLUTION_FAIL	sign resolution fail
LE_GATT_MSG_TOP	top of GATT message id

3.4.4 Function Documentation

3.4.4.1 LeGattAccessReadRsp()

Gatt access read response.

Parameters

conn_hdl	connection handle.	
handle	attribute handle.	
att_err	0 is OK, others refer to LE_ATT_ERR_* in ble_att_if.h.	

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.2 LeGattAccessWriteRsp()

Gatt access write response.

Parameters

conn_hdl	connection handle.	
method	refer to LE_GATT_FLAG_* in ble_gatt_if.h	
handle	attribute handle.	
att_err	0 is OK, others refer to LE_ATT_ERR_* in ble_att_if.h.	

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.3 LeGattChangeAttrVal()

```
LE_ERR_STATE LeGattChangeAttrVal (

LE_GATT_SERVICE_T * svc,

UINT16 attrId,

UINT16 len,

void * val )
```

Change attribute value.

Parameters

	svc	service.
	attr⇔	attribute index of service.
	ld	
in	len	attribute value length.
in	val	attribute value.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.4 LeGattCharValConfirmation()

```
LE_ERR_STATE LeGattCharValConfirmation ( {\tt UINT16} \ \ conn\_hdl \ )
```

Prepare write characteristic value response.

Parameters

conn_hdl	connection handle.
----------	--------------------

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.5 LeGattCharValIndicate()

Gatt characteristic value indication.

Parameters

conn_hdl	connection handle.
hdl	characteristic value handle.
len	value length.
pval	value.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.6 LeGattCharValNotify()

Gatt characteristic value notification.

Parameters

conn_hdl	connection handle.
hdl	characteristic value handle.
len	value length.
pval	value.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.7 LeGattExchangeMtuReq()

Exchange MTU request.

Parameters

conn_hdl	connection handle.
mtu	MTU.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.8 LeGattExchangeMtuRsp()

Exchange MTU response.

Parameters

conn_hdl	connection handle.
mtu	MTU.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.9 LeGattExecuteWriteCharValReliable()

Execute write characteristic value request.

Parameters

conn_hdl	connection handle.
yesno	execute write or not.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.10 LeGattFindAllCharacteristic()

Find all characteristic.

Parameters

conn_hdl	connection handle.
start_hdl	start handle.
end_hdl	end handle.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.11 LeGattFindAllCharDescriptor()

Find all characteristic description.

Parameters

conn_hdl	connection handle.
start_hdl	start handle.
end_hdl	end handle.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.12 LeGattFindAllPrimaryService()

```
LE_ERR_STATE LeGattFindAllPrimaryService ( {\tt UINT16} \ \ conn\_hdl \ )
```

Find all primary service.

Parameters

conn_hdl	connection handle.
----------	--------------------

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.13 LeGattFindCharacteristicByUuid()

Find characteristic by UUID.

Parameters

conn_hdl	connection handle.
start_hdl	start handle.
end_hdl	end handle.
format	UUID type.
uuid	UUID.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.14 LeGattFindIncludedService()

Find include service.

Parameters

conn_hdl	connection handle.
start_hdl	start handle.
end_hdl	end handle.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.15 LeGattFindPrimaryServiceByUuid()

Find primary service by UUID.

Parameters

conn_hdl	connection handle.
format	UUID type.
uuid	UUID.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.16 LeGattGetAttrHandle()

Get attribute handle.

Parameters

svc	service.
attr⇔	attribute index of service.
ld	

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.17 LeGattGetAttrVal()

```
LE_ERR_STATE LeGattGetAttrVal (

LE_GATT_SERVICE_T * svc,

UINT16 attrId,

UINT16 * len,

void * val )
```

Get attribute value.

Parameters

	svc	service.
	attr⇔ Id	attribute index of service.
out	len	attribute value length.
out	val	attribute value.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.18 LeGattGetAttrValLen()

Get the length of attribute value.

Parameters

SVC	service.
attr⊷	attribute index of service.
ld	

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.19 LeGattGetAttrValMaxLen()

Get the max length of attribute value.

Parameters

SVC	service.
attr⇔	attribute index of service.
ld	

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.20 LeGattInit()

BLE Gatt module init.

Parameters

appTask the reference of BLE task.

Returns

None.

3.4.4.21 LeGattModifyAttrVal()

Modify attribute value.

Parameters

SVC	servie.
attrld	attribute index of service.
offset	modify offset.
len	modify length.
val	modify value.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.22 LeGattPrepareWriteCharValReliable()

Prepare write characteristic value request.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.
offset	offset written.
len	length written.
val	value.

3.4 BLE GATT APIs 63

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.23 LeGattReadCharValByUuid()

Read a characteristic value by UUID.

Parameters

conn_hdl	connection handle.
start_hdl	start handle.
end_hdl	end handle.
format	UUID type.
uuid	UUID.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.24 LeGattReadCharValue()

Read a characteristic value.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.25 LeGattReadLongCharVal()

Read a long characteristic value.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.
offset	characteristic value offset.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.26 LeGattReadMultipleCharVal()

Read Multiple characteristic values.

Parameters

conn_hdl	connection handle.
count	handle count.
handle	handle table.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.27 LeGattRegisterIncludeService()

```
LE_ERR_STATE LeGattRegisterIncludeService ( UINT16 inc_hdl,
```

3.4 BLE GATT APIS 65

```
UINT16 start_hdl,
UINT16 end_hdl,
UINT16 uuid )
```

Called to register an include service.

Parameters

inc_hdl	include service handle.
start_hdl	start handle.
end_hdl	end handle.
uuid	include service UUID.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.28 LeGattRegisterService()

Called to register a service.

Parameters

attrTable	service attribute table.
numAttr	the attribute number of service.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.29 LeGattSignedWriteNoRsp()

Signed write without response.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.
len	length of the data to be written.
val	the value to be written.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.30 LeGattStopCurrentProcedure()

Stop current procedure.

Parameters

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.31 LeGattWriteCharVal()

Write characteristic value.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.
len	length of the data to be written.
val	the value to be written.

3.4 BLE GATT APIs 67

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.32 LeGattWriteCharValReliable()

Write characteristic value reliable.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.
offset	offset written.
len	length written.
val	value.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.33 LeGattWriteLongCharVal()

Write long characteristic value.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.
offset	value position offset.
len	length of the data to be written.
val	the value to be written.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.4.34 LeGattWriteNoRsp()

Write without response.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.
len	length of the data to be written.
val	the value to be written.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

3.4.5 Variable Documentation

3.4.5.1 gcCharacteristicUuid

```
const UINT16 gcCharacteristicUuid
```

3.4.5.2 gcCharAggregateUuid

const UINT16 gcCharAggregateUuid

3.4 BLE GATT APIs 69

3.4.5.3 gcCharExtPropUuid

const UINT16 gcCharExtPropUuid

3.4.5.4 gcCharFormatUuid

const UINT16 gcCharFormatUuid

3.4.5.5 gcCharUserDescUuid

const UINT16 gcCharUserDescUuid

3.4.5.6 gcClientCharConfigUuid

const UINT16 gcClientCharConfigUuid

3.4.5.7 gcExtReportRefUuid

const UINT16 gcExtReportRefUuid

3.4.5.8 gclncludeUuid

const UINT16 gcIncludeUuid

3.4.5.9 gcPrimaryServiceUuid

const UINT16 gcPrimaryServiceUuid

3.4.5.10 gcReportRefUuid

const UINT16 gcReportRefUuid

3.4.5.11 gcSecondaryServiceUuid

const UINT16 gcSecondaryServiceUuid

3.4.5.12 gcServerCharConfigUuid

const UINT16 gcServerCharConfigUuid

3.4.5.13 gcValidRangeUuid

const UINT16 gcValidRangeUuid

3.5 BLE MSG APIs 71

3.5 BLE MSG APIs

Data Structures

struct LE_SYS_MSG_BUF_OVERFLOW_T

Macros

- #define LE ATT MSG BASE 0x1400
- #define LE_CM_MSG_BASE 0x1100
- #define LE_GATT_MSG_BASE 0x1500
- #define LE_HCI_MSG_BASE 0x1000
- #define LE_L2CAP_MSG_BASE 0x1200
- #define LE_SMP_MSG_BASE 0x1300
- #define LE_SYS_MSG_BASE 0x8000
- #define MESSAGE_ALLOCATE(M, S) PanicUnlessMalloc(sizeof(M##_T) + S)
- #define MESSAGE BULID(M) M## T *msg = PanicUnlessMalloc(sizeof(M## T))
- #define MESSAGE_DATA_BULID(M, S) M##_T *msg = PanicUnlessMalloc(sizeof(M##_T) + S)
- #define MESSAGE_OFFSET(M) ((UINT8 *)msg + sizeof(M##_T))
- #define T_HOUR(h) ((UINT32)((h) * (UINT32)1000 * (UINT32)60) * (UINT32)60)
- #define T_MIN(m) ((UINT32)((m) * (UINT32)1000 * (UINT32)60))
- #define T SEC(s) ((UINT32)((s) * (UINT32)1000))

Typedefs

- typedef MsgData MESSAGE
- typedef UINT16 MESSAGEID
- typedef void const * MsgData
- typedef const UINT8 * MsgLock
- typedef MsgLock MSGLOCK
- typedef UINT16 MSGSUBID
- typedef UINT32 MSGTIMER
- typedef TASKPACK * Task
- · typedef Task TASK
- typedef void(* TASKHANDLER) (Task, UINT16, MsgData)
- typedef void ** TASKPACK

Enumerations

enum { LE_SYS_MSG_BUF_OVERFLOW = (LE_SYS_MSG_BASE + 1), LE_SYS_MSG_TOP }
 BLE system message id.

Functions

• UINT16 LeCancelAllMessage (TASK task, MESSAGEID id)

Cancel all message in queue.

• UINT16 LeCancelAllSubMessage (TASK task, MESSAGEID id, MSGSUBID subId)

Cancel all sub message in queue.

BOOL LeCancelFirstMessage (TASK task, MESSAGEID id)

Cancel the first message in queue.

BOOL LeCancelFirstSubMessage (TASK task, MESSAGEID id, MSGSUBID subId)

Cancel the first sub message in queue.

UINT16 LeGetSubMsgld (UINT16 *s)

Get sub message id.

• BOOL LeHostCreateTask (TASK task, TASKHANDLER hdl)

Create BLE task.

void LeHostMessageLoop (void)

message loop run.

void LeSendMessage (TASK task, MESSAGEID msgld, MESSAGE msg)

Send message to BLE task.

void LeSendMessageAfter (TASK task, MESSAGEID msgld, MESSAGE msg, UINT32 delay)

Delay, then send message to BLE task.

void LeSendMessageUnlock (TASK task, MESSAGEID id, MESSAGE msg, MSGLOCK lock)

Send message until lock is 0.

• void LeSendSubMessage (TASK task, MESSAGEID msgld, MSGSUBID subId, MESSAGE msg)

Send sub message.

void LeSendSubMessageAfter (TASK task, MESSAGEID msgld, MSGSUBID subId, MESSAGE msg, UIN

T32 delay)

Delay, then send sub message.

 void LeSendSubMessageUnlock (TASK task, MESSAGEID id, MSGSUBID subId, MESSAGE msg, MSGLOCK lock)

Send sub message until lock is 0.

3.5.1 Detailed Description

3.5.2 Macro Definition Documentation

3.5.2.1 LE_ATT_MSG_BASE

#define LE_ATT_MSG_BASE 0x1400

3.5.2.2 LE_CM_MSG_BASE

#define LE_CM_MSG_BASE 0x1100

3.5 BLE MSG APIs 73

3.5.2.3 LE_GATT_MSG_BASE

```
#define LE_GATT_MSG_BASE 0x1500
```

3.5.2.4 LE_HCI_MSG_BASE

```
#define LE_HCI_MSG_BASE 0x1000
```

3.5.2.5 LE_L2CAP_MSG_BASE

```
#define LE_L2CAP_MSG_BASE 0x1200
```

3.5.2.6 LE_SMP_MSG_BASE

```
#define LE_SMP_MSG_BASE 0x1300
```

3.5.2.7 LE_SYS_MSG_BASE

```
#define LE_SYS_MSG_BASE 0x8000
```

3.5.2.8 MESSAGE_ALLOCATE

3.5.2.9 MESSAGE_BULID

3.5.2.10 MESSAGE_DATA_BULID

3.5.2.11 MESSAGE_OFFSET

3.5.2.12 T_HOUR

3.5.2.13 T_MIN

```
#define T_MIN(  m \ ) \ ((UINT32) \ ((m) \ * \ (UINT32) \ 1000 \ * \ (UINT32) \ 60))
```

3.5.2.14 T_SEC

3.5.3 Typedef Documentation

3.5.3.1 MESSAGE

typedef MsgData MESSAGE

3.5 BLE MSG APIs 75

3.5.3.2 MESSAGEID

typedef UINT16 MESSAGEID

3.5.3.3 MsgData

typedef void const* MsgData

3.5.3.4 MsgLock

typedef const UINT8* MsgLock

3.5.3.5 MSGLOCK

typedef MsgLock MSGLOCK

3.5.3.6 MSGSUBID

typedef UINT16 MSGSUBID

3.5.3.7 MSGTIMER

typedef UINT32 MSGTIMER

3.5.3.8 Task

typedef TASKPACK* Task

3.5.3.9 TASK

typedef Task TASK

3.5.3.10 TASKHANDLER

```
typedef void(* TASKHANDLER) (Task, UINT16, MsgData)
```

3.5.3.11 TASKPACK

```
typedef void** TASKPACK
```

3.5.4 Enumeration Type Documentation

3.5.4.1 anonymous enum

anonymous enum

BLE system message id.

Enumerator

LE_SYS_MSG_BUF_OVERFLOW	message buffer overflow
LE_SYS_MSG_TOP	top of system message id

3.5.5 Function Documentation

3.5.5.1 LeCancelAllMessage()

```
UINT16 LeCancelAllMessage ( {\it TASK}~task, \\ {\it MESSAGEID}~id~)
```

Cancel all message in queue.

Parameters

task	task.
id	message id.

3.5 BLE MSG APIs 77

Returns

0 is ok, others is error.

3.5.5.2 LeCancelAllSubMessage()

Cancel all sub message in queue.

Parameters

task	the task of recvice message.
id	message id.
sub⊷	sub message id.
ld	

Returns

0 is ok, others is error.

3.5.5.3 LeCancelFirstMessage()

```
BOOL LeCancelFirstMessage ( {\tt TASK}\ task, {\tt MESSAGEID}\ id\ )
```

Cancel the first message in queue.

Parameters

task	task.
id	message id.

Returns

True is ok, false is error.

3.5.5.4 LeCancelFirstSubMessage()

```
BOOL LeCancelFirstSubMessage (

TASK task,

MESSAGEID id,

MSGSUBID subId )
```

Cancel the first sub message in queue.

Parameters

task	the task of recvice message.
id	message id.
sub⇔	sub message id.
ld	

Returns

True is ok, false is error.

3.5.5.5 LeGetSubMsgld()

Get sub message id.

Parameters

sub	message id.
sub	message id.

Returns

0 is ok, others is error.

3.5.5.6 LeHostCreateTask()

```
BOOL LeHostCreateTask (
TASK task,
TASKHANDLER hdl )
```

Create BLE task.

3.5 BLE MSG APIs 79

Parameters

task	the reference of BLE task.
hdl	callback handle of BLE task.

Returns

TRUE is success, FALSE is failed.

3.5.5.7 LeHostMessageLoop()

message loop run.

Returns

None.

3.5.5.8 LeSendMessage()

Send message to BLE task.

Parameters

task	reference of BLE task.
msg←	message ID.
ld	
msg	message.

Returns

None.

3.5.5.9 LeSendMessageAfter()

```
void LeSendMessageAfter ( {\tt TASK}\ task,
```

```
MESSAGEID msgId,
MESSAGE msg,
UINT32 delay)
```

Delay, then send message to BLE task.

Parameters

task	reference of BLE task.
msg⇔	message ID.
ld	
msg	message.
delay	delay time, ms.

Returns

None.

3.5.5.10 LeSendMessageUnlock()

Send message until lock is 0.

Parameters

task	the task of recvice message.
id	message id.
msg	message.
lock	lock number.

Returns

None.

3.5.5.11 LeSendSubMessage()

Send sub message.

3.5 BLE MSG APIs 81

Parameters

task	the task of recvice message.
msg← Id	message id.
subId	sub message id.
msg	message.

Returns

None.

3.5.5.12 LeSendSubMessageAfter()

Delay, then send sub message.

Parameters

task	the task of recvice message.
msg⇔	message id.
ld	
subId	sub message id.
msg	message.
delay	delay time.

Returns

None.

3.5.5.13 LeSendSubMessageUnlock()

```
void LeSendSubMessageUnlock (
    TASK task,
    MESSAGEID id,
    MSGSUBID subId,
    MESSAGE msg,
    MSGLOCK lock )
```

Send sub message until lock is 0.

Parameters

task	the task of recvice message.
id	message id.
sub⊷ Id	sub message id.
msg	message.
lock	lock number.

Returns

None.

3.6 BLE SMP APIs

3.6 BLE SMP APIs

Data Structures

- struct LE_SMP_MSG_ENCRYPTION_CHANGE_IND_T
- struct LE_SMP_MSG_ENCRYPTION_REFRESH_IND_T
- struct LE SMP MSG OOB DATA REQUEST IND T
- struct LE_SMP_MSG_PAIRING_ACTION_IND_T
- struct LE_SMP_MSG_PAIRING_COMPLETE_IND_T
- struct LE SMP MSG PASSKEY DISPLAY IND T
- struct LE_SMP_MSG_PASSKEY_INPUT_IND_T
- struct LE_SMP_MSG_SC_OOB_DATA_REQUEST_IND_T
- struct LE_SMP_MSG_SLAVE_SECURITY_REQUEST_IND_T
- struct LE_SMP_MSG_USER_CONFIRM_IND_T
- struct LE_SMP_SC_OOB_DATA_T

Macros

- #define LE MAX BOND COUNT 8
- #define LE_SM_IO_CAP_DISP_ONLY 0x00
- #define LE_SM_IO_CAP_DISP_YES_NO 0x01
- #define LE_SM_IO_CAP_KEYBOARD_DISP 0x04
- #define LE_SM_IO_CAP_KEYBOARD_ONLY 0x02
- #define LE SM IO CAP NO IO 0x03
- #define LE_SM_PAIR_MITM_NO 0x00
- #define LE_SM_PAIR_MITM_YES 0x01
- #define LE SM PAIR OOB NO 0x00
- #define LE_SM_PAIR_OOB_YES 0x01
- #define LE SM PAIR SC NO 0x00
- #define LE_SM_PAIR_SC_YES 0x01

Enumerations

```
    enum {
        LE_SMP_MSG_SLAVE_SECURITY_REQUEST_IND = LE_SMP_MSG_BASE, LE_SMP_MSG_PAIRING_ACTION_IND,
        LE_SMP_MSG_PASSKEY_DISPLAY_IND, LE_SMP_MSG_PASSKEY_INPUT_IND,
        LE_SMP_MSG_OOB_DATA_REQUEST_IND, LE_SMP_MSG_SC_OOB_DATA_REQUEST_IND, LE_SMP_MSG_USER_CC_LE_SMP_MSG_ENCRYPTION_CHANGE_IND,
        LE_SMP_MSG_ENCRYPTION_REFRESH_IND, LE_SMP_MSG_PAIRING_COMPLETE_IND, LE_SMP_LONG_TERM_KEY_LE_SMP_KEYS_IND,
        LE_SMP_MSG_TOP }
```

BLE SMP message id.

enum {
 LE_SMP_PAIR_JUST_WORK, LE_SMP_PAIR_OOB, LE_SMP_PAIR_PASSKEY_INPUT, LE_SMP_PAIR_DISPLAY,
 LE_SMP_PAIR_NUM_COMPARE }

Functions

void LeSmpInit (TASK appTask)

BLE SMP Module Init.

• void LeSmpOobAuthDataRsp (UINT16 conn_hdl, UINT8 *data, UINT16 len)

SMP OOB authenticate data response.

• UINT16 LeSmpOobPresent (UINT16 conn_hdl, BOOL oob_present)

SMP OOB present.

void LeSmpPasskeyInput (UINT16 conn_hdl, UINT32 passkey)

Input passkey.

• UINT16 LeSmpScOobComputeConfirmVal (UINT8 *rand, UINT8 *confirm)

SMP secure connection OOB compute confirm value.

- void LeSmpScOobDataRsp (UINT16 conn_hdl, UINT8 *our_rand, LE_SMP_SC_OOB_DATA_T *peer)

 OOB data response.
- UINT16 LeSmpSecurityReq (UINT16 conn_hdl)

BLE SMP security request.

UINT16 LeSmpSecurityRsp (UINT16 conn_hdl, BOOL accept)

BLE SMP security request.

• UINT16 LeSmpSetDefaultConfig (UINT8 iocap, BOOL mitm, BOOL sc, BOOL bond)

Set default configure for pairing.

• UINT16 LeSmpUserConfirmRsp (UINT16 conn_hdl, BOOL accept)

User confirm response.

3.6.1 Detailed Description

3.6.2 Macro Definition Documentation

```
3.6.2.1 LE_MAX_BOND_COUNT
```

```
#define LE_MAX_BOND_COUNT 8
```

3.6.2.2 LE_SM_IO_CAP_DISP_ONLY

```
\texttt{\#define LE\_SM\_IO\_CAP\_DISP\_ONLY 0x00}
```

display only

3.6.2.3 LE_SM_IO_CAP_DISP_YES_NO

```
#define LE_SM_IO_CAP_DISP_YES_NO 0x01
```

display + yes or no

3.6 BLE SMP APIs 85

3.6.2.4 LE_SM_IO_CAP_KEYBOARD_DISP

#define LE_SM_IO_CAP_KEYBOARD_DISP 0x04

display + keyboard

3.6.2.5 LE_SM_IO_CAP_KEYBOARD_ONLY

#define LE_SM_IO_CAP_KEYBOARD_ONLY 0x02

keyboard only

3.6.2.6 LE_SM_IO_CAP_NO_IO

#define LE_SM_IO_CAP_NO_IO 0x03

no input and output

3.6.2.7 LE_SM_PAIR_MITM_NO

#define LE_SM_PAIR_MITM_NO 0x00

3.6.2.8 LE_SM_PAIR_MITM_YES

#define LE_SM_PAIR_MITM_YES 0x01

3.6.2.9 LE_SM_PAIR_OOB_NO

#define LE_SM_PAIR_OOB_NO 0x00

3.6.2.10 LE_SM_PAIR_OOB_YES

#define LE_SM_PAIR_OOB_YES 0x01

3.6.2.11 LE_SM_PAIR_SC_NO

#define LE_SM_PAIR_SC_NO 0x00

3.6.2.12 LE_SM_PAIR_SC_YES

#define LE_SM_PAIR_SC_YES 0x01

3.6.3 Enumeration Type Documentation

3.6.3.1 anonymous enum

anonymous enum

BLE SMP message id.

Enumerator

LE_SMP_MSG_SLAVE_SECURITY_REQUEST_IND	slave security request
LE_SMP_MSG_PAIRING_ACTION_IND	pairing action indication
LE_SMP_MSG_PASSKEY_DISPLAY_IND	passkey display indication
LE_SMP_MSG_PASSKEY_INPUT_IND	passkey input indication
LE_SMP_MSG_OOB_DATA_REQUEST_IND	OOB date request indication
LE_SMP_MSG_SC_OOB_DATA_REQUEST_IND	SC OOB data request indication
LE_SMP_MSG_USER_CONFIRM_IND	user confirm indication
LE_SMP_MSG_ENCRYPTION_CHANGE_IND	encryption change indication
LE_SMP_MSG_ENCRYPTION_REFRESH_IND	encryption refresh indication
LE_SMP_MSG_PAIRING_COMPLETE_IND	pairing complete indication
LE_SMP_LONG_TERM_KEY_REQ	long term key request
LE_SMP_KEYS_IND	keys indication
LE_SMP_MSG_TOP	top of SMP message id

3.6.3.2 anonymous enum

anonymous enum

Enumerator

LE_SMP_PAIR_JUST_WORK	just work
LE_SMP_PAIR_OOB	out of band
LE_SMP_PAIR_PASSKEY_INPUT	passkey entry
LE_SMP_PAIR_DISPLAY display	
LE_SMP_PAIR_NUM_COMPARE	number compare

3.6 BLE SMP APIs 87

3.6.4 Function Documentation

3.6.4.1 LeSmpInit()

BLE SMP Module Init.

Parameters

appTask	the reference of BLE task.
---------	----------------------------

Returns

None.

3.6.4.2 LeSmpOobAuthDataRsp()

SMP OOB authenticate data response.

Parameters

conn_hdl	connection handle.
data	response data.
len	data length.

Returns

None.

3.6.4.3 LeSmpOobPresent()

SMP OOB present.

Parameters

conn_hdl	connection handle.
oob_present	present or not.

Returns

0 is Ok, others refer to SMP_ERR_* in ble_err.h.

3.6.4.4 LeSmpPasskeyInput()

Input passkey.

Parameters

conn_hdl	connection handle.
passkey	passkey.

Returns

None.

3.6.4.5 LeSmpScOobComputeConfirmVal()

SMP secure connection OOB compute confirm value.

Parameters

rand	random data.	
confirm	confirm data.	

Returns

0 is Ok, others refer to SMP_ERR_* in ble_err.h.

3.6 BLE SMP APIs

3.6.4.6 LeSmpScOobDataRsp()

OOB data response.

Parameters

conn_hdl	connection handld.
our_rand	our random data.
peer	peer OOB data.

Returns

None.

3.6.4.7 LeSmpSecurityReq()

BLE SMP security request.

Parameters

```
conn_hdl connection handle.
```

Returns

0 is Ok, others refer to SMP_ERR_* in ble_err.h.

3.6.4.8 LeSmpSecurityRsp()

BLE SMP security request.

Parameters

conn_hdl	connection handle.
accept	TRUE is accept, FALSE is not.

Returns

0 is Ok, others refer to SMP_ERR_* in ble_err.h.

3.6.4.9 LeSmpSetDefaultConfig()

Set default configure for pairing.

Parameters

iocap	IO capability.	
mitm	TRUE is MITM protected, FALSE is not.	
sc	sc TRUE is request BLE secure connection pairing, FALSE is not	
bond	TRUE: bonding, FALSE: no bonding.	

Returns

0 is Ok, others refer to SMP_ERR_* in ble_err.h.

3.6.4.10 LeSmpUserConfirmRsp()

User confirm response.

Parameters

conn_hdl	connection handle.
accept	yes or no.

Returns

0 is Ok, others refer to SMP_ERR_* in ble_err.h.

3.7 WIFI APIs 91

3.7 WIFI APIs

WIFI APIs.

Modules

- · WIFI Common APIs
- WIFI STA APIs
- Enumeration

Data Structures

• struct wifi_active_scan_time_t

Range of active scan times per channel.

· struct wifi_ap_config_t

This structure is the Wi-Fi configuration for initialization for Soft-AP mode.

· struct wifi_auto_connect_info_t

This structure is the Wi-Fi auto connect for save in the flash (FIM).

· union wifi_config_t

Wi-Fi configuration for initialization.

· struct wifi_fast_scan_threshold_t

Structure describing parameters for a Wi-Fi fast scan.

· struct wifi_init_config_t

WiFi stack configuration parameters.

struct wifi_scan_config_t

Parameters for an SSID scan.

· struct wifi_scan_info_t

This structure defines the inforamtion of scanned APs.

struct wifi_scan_list_t

This structure defines the list of scanned APs with their corresponding information.

· union wifi scan time t

Aggregate of active & passive scan time per channel.

struct wifi_sta_config_t

This structure is the Wi-Fi configuration for initialization for STA mode.

· struct wifi_wpa_ie_data_t

This structure is the Wi-Fi auto connect with wpa information for save in the flash (FIM).

Macros

#define WIFI_BEACON_INTERVAL_LENGTH (2)

Beacon interval length in a frame header.

• #define WIFI CAPABILITY INFO LENGTH (2)

Length of capability information in a frame header.

#define WIFI_LENGTH_802_11 (24)

Length of 802.11 MAC header.

#define WIFI LENGTH PASSPHRASE (64)

The maximum length of passphrase used in WPA-PSK and WPA2-PSK encryption types.

#define WIFI_MAC_ADDRESS_LENGTH (6)

MAC address length.

• #define WIFI_MAC_NUM_OF_CHANNELS (14)

maximum number of WIFI channels

#define WIFI_MAX_LENGTH_OF_SSID (32+1)

The maximum length of SSID.

• #define WIFI_MAX_SCAN_AP_NUM (16)

maximum number of ap list items which can stored

• #define WIFI_MAX_SUPPORTED_RATES (8)

maximum number of supported data rate

Typedefs

- · typedef wifi scan info t wifi ap record t
- typedef int(* wifi_event_notify_cb_t) (void *data)

Enumerations

• enum wifi_auto_connet_mode_e { WIFI_AUTO_CONNECT_DISABLE, WIFI_AUTO_CONNECT_ENABLE } WiFi auto connect mode parameters.

Functions

- int wifi_event_process_handler (wifi_event_t event, uint8_t *payload, uint32_t length)

 Default event handler for system events.
- void wifi_install_default_event_handlers (void)

instaall default event handler for wifi event (internal use)

• int wifi_register_event_handler (wifi_event_t idx, wifi_event_handler_t handler)

register wifi event handelrt (internal use)

3.7.1 Detailed Description

WIFI APIs.

3.7.2 Macro Definition Documentation

3.7.2.1 WIFI_BEACON_INTERVAL_LENGTH

#define WIFI_BEACON_INTERVAL_LENGTH (2)

Beacon interval length in a frame header.

3.7 WIFI APIs 93

3.7.2.2 WIFI_CAPABILITY_INFO_LENGTH

```
#define WIFI_CAPABILITY_INFO_LENGTH (2)
```

Length of capability information in a frame header.

3.7.2.3 WIFI_LENGTH_802_11

```
#define WIFI_LENGTH_802_11 (24)
```

Length of 802.11 MAC header.

3.7.2.4 WIFI_LENGTH_PASSPHRASE

```
#define WIFI_LENGTH_PASSPHRASE (64)
```

The maximum length of passphrase used in WPA-PSK and WPA2-PSK encryption types.

3.7.2.5 WIFI_MAC_ADDRESS_LENGTH

```
#define WIFI_MAC_ADDRESS_LENGTH (6)
```

MAC address length.

3.7.2.6 WIFI_MAC_NUM_OF_CHANNELS

```
#define WIFI_MAC_NUM_OF_CHANNELS (14)
```

maximum number of WIFI channels

3.7.2.7 WIFI_MAX_LENGTH_OF_SSID

```
#define WIFI_MAX_LENGTH_OF_SSID (32+1)
```

The maximum length of SSID.

3.7.2.8 WIFI_MAX_SCAN_AP_NUM

```
#define WIFI_MAX_SCAN_AP_NUM (16)
```

maximum number of ap list items which can stored

3.7.2.9 WIFI_MAX_SUPPORTED_RATES

```
#define WIFI_MAX_SUPPORTED_RATES (8)
```

maximum number of supported data rate

3.7.3 Typedef Documentation

3.7.3.1 wifi_ap_record_t

```
typedef wifi_scan_info_t wifi_ap_record_t
```

3.7.3.2 wifi_event_notify_cb_t

```
typedef int(* wifi_event_notify_cb_t) (void *data)
```

3.7.4 Enumeration Type Documentation

3.7.4.1 wifi_auto_connet_mode_e

```
enum wifi_auto_connet_mode_e
```

WiFi auto connect mode parameters.

Enumerator

WIFI_AUTO_CONNECT_DISABLE	
WIFI_AUTO_CONNECT_ENABLE	

3.7 WIFI APIs 95

3.7.5 Function Documentation

3.7.5.1 wifi_event_process_handler()

Default event handler for system events.

This function performs default handling of system events. When using event_loop APIs, it is called automatically before invoking the user-provided callback function.

Applications which implement a custom event loop must call this function as part of event processing.

Parameters

in	event	event type Set the event type,Options are
		WIFI_EVENT_INIT_COMPLETE
		WIFI_EVENT_SCAN_COMPLETE
		WIFI_EVENT_STA_START
		WIFI_EVENT_STA_STOP
		WIFI_EVENT_STA_CONNECTED
		WIFI_EVENT_STA_DISCONNECTED
		WIFI_EVENT_STA_CONNECTION_FAILED
		WIFI_EVENT_STA_GOT_IP
in	payload	Data block that transmitted to event
in	length	The length of data block

Returns

0 : success other : failed

3.7.5.2 wifi_install_default_event_handlers()

```
void wifi_install_default_event_handlers ( \mbox{void} \quad \mbox{)}
```

instaall default event handler for wifi event (internal use)

3.7.5.3 wifi_register_event_handler()

register wifi event handelrt (internal use)

Parameters

	in	idx	one of the enums of
			bt_scan_mode_t
ĺ	in	handler	the Wi-Fi event handler

Returns

0 : success other : failed

3.8 WIFI Common APIs 97

3.8 WIFI Common APIs

Data Structures

```
struct event_msg_t
```

Send information to event by event_msg_t.

union wifi_event_info_t

```
wifi_event_info_t
```

struct wifi_event_sta_connected_t

wifi_event_sta_connected_t

· struct wifi_event_sta_disconnected_t

wifi event sta disconnected t

- struct wifi_event_sta_got_ip_t
- struct wifi_event_sta_scan_done_t

wifi_event_sta_scan_done_t

Typedefs

• typedef int(* wifi_event_cb_t) (wifi_event_id_t event, void *data, uint16_t length)

Application specified event callback function.

Functions

• int wifi_event_loop_init (wifi_event_cb_t cb)

Event Loop Initialization Create the event handler and call back funtion.

int wifi_event_loop_send (event_msg_t *msg)

Send an event to event task.

void wifi_event_loop_set_cb (wifi_event_cb_t cb, void *ctx)

Set application specified event callback function.

int wifi_event_process_handler (wifi_event_t event, uint8_t *payload, uint32_t length)

Default event handler for system events.

3.8.1 Detailed Description

3.8.2 Typedef Documentation

```
3.8.2.1 wifi_event_cb_t
```

```
typedef int(* wifi_event_cb_t) (wifi_event_id_t event, void *data, uint16_t length)
```

Application specified event callback function.

3.8.3 Function Documentation

3.8.3.1 wifi_event_loop_init()

Event Loop Initialization Create the event handler and call back funtion.

Parameters

cb : application specified event callback

Returns

0 : success other : failed

3.8.3.2 wifi_event_loop_send()

Send an event to event task.

Attention

1. Other task/modules, such as the TCPIP module, can call this API to send an event to event task

Parameters

```
event_msg_t * msg: Send information to event by msg
```

Returns

0 : success other : failed

3.8.3.3 wifi_event_loop_set_cb()

Set application specified event callback function.

Attention

1. If cb is NULL, means application does not need to handle If cb is not NULL, it will be called when an event is received and after the default event callback is completed

3.8 WIFI Common APIs 99

Parameters

wifi_event_←	cb : callback
cb_t	
void	*ctx : reserved for user

3.8.3.4 wifi_event_process_handler()

Default event handler for system events.

This function performs default handling of system events.

Applications which implement a custom event loop must call this function as part of event processing.

Parameters

in	event	event type Set the event type,Options are
		WIFI_EVENT_INIT_COMPLETE
		WIFI_EVENT_SCAN_COMPLETE
		WIFI_EVENT_STA_START
		WIFI_EVENT_STA_STOP
		WIFI_EVENT_STA_CONNECTED
		WIFI_EVENT_STA_DISCONNECTED
		WIFI_EVENT_STA_CONNECTION_FAILED
		WIFI_EVENT_STA_GOT_IP
in	payload	Data block transmitted to event
in	length	The length of the data block

Returns

0 : success other : failed

3.9 WIFI STA APIS

Macros

• #define WIFI_READY_TIME 2000

Typedefs

```
typedef int(* wifi_auto_connect_clear_ap_info_fp_t) (uint8_t index)
```

- typedef int(* wifi_auto_connect_get_ap_info_fp_t) (uint8_t index, wifi_auto_connect_info_t *info)
- typedef int(* wifi_auto_connect_get_ap_num_fp_t) (uint8_t *num)
- typedef int(* wifi_auto_connect_get_mode_fp_t) (uint8_t *mode)
- typedef int(* wifi_auto_connect_get_saved_ap_num_fp_t) (uint8_t *num)
- typedef int(* wifi_auto_connect_init_fp_t) (void)
- typedef int(* wifi_auto_connect_reset_fp_t) (void)
- typedef int(* wifi_auto_connect_set_ap_num_fp_t) (uint8_t num)
- typedef int(* wifi_auto_connect_set_mode_fp_t) (uint8_t mode)
- typedef int(* wifi auto connect start fp t) (void)
- typedef int(* wifi_auto_connect_update_ch_fp_t) (uint8_t ac_index, uint8_t channel)
- typedef int(* wifi_config_get_bandwidth_fp_t) (wifi_mode_t interface, wifi_bandwidth_t *bandwidth)
- typedef int(* wifi_config_get_bssid_fp_t) (uint8_t *bssid)
- typedef int(* wifi_config_get_channel_fp_t) (wifi_mode_t interface, uint8_t *channel)
- typedef int(* wifi_config_get_dtim_interval_fp_t) (uint8_t *interval)
- typedef int(* wifi_config_get_listen_interval_fp_t) (uint8_t *interval)
- typedef int(* wifi_config_get_mac_address_fp_t) (wifi_mode_t interface, uint8_t *address)
- typedef int(* wifi config get mac tx data rate fp t) (wifi mac data rate t *data rate)
- typedef int(* wifi_config_get_opmode_fp_t) (uint8_t *mode)
- typedef int(* wifi_config_get_skip_dtim_fp_t) (uint8_t *value)
- typedef int(* wifi_config_get_ssid_fp_t) (uint8_t *ssid, uint8_t *ssid_length)
- typedef int(* wifi config get sta mac address from flash fp t) (uint8 t *bssid)
- typedef int(* wifi_config_set_bandwidth_fp_t) (wifi_mode_t interface, wifi_bandwidth_t bandwidth)
- typedef int(* wifi_config_set_bssid_fp_t) (uint8_t *bssid)
- typedef int(* wifi_config_set_channel_fp_t) (wifi_mode_t interface, uint8_t channel)
- typedef int(* wifi_config_set_dtim_interval_fp_t) (uint8_t interval)
- typedef int(* wifi_config_set_listen_interval_fp_t) (uint8_t interval)
- typedef int(* wifi_config_set_mac_address_fp_t) (wifi_mode_t interface, uint8_t *address)
- typedef int(* wifi config set mac tx data rate fp t) (wifi mac data rate t data rate)
- typedef int(* wifi config set opmode fp t) (uint8 t mode)
- typedef int(* wifi_config_set_skip_dtim_fp_t) (uint8_t value, bool save_flash)
- typedef int(* wifi_config_set_ssid_fp_t) (wifi_mode_t interface, uint8_t *ssid, uint8_t ssid_length)
- typedef int(* wifi_connection_connect_fp_t) (wifi_config_t *config)
- typedef int(* wifi_connection_connect_from_ac_index_fp_t) (uint8_t index)
- typedef int(* wifi connection connect from ac list fp t) (wifi config t *config)
- typedef int(* wifi_connection_disconnect_ap_fp_t) (void)
- typedef int(* wifi_connection_disconnect_sta_fp_t) (uint8_t *address)
- typedef int(* wifi_connection_get_rssi_fp_t) (int8_t *rssi)
- typedef int(* wifi_connection_register_event_handler_fp_t) (wifi_event_t event, wifi_event_handler_t handler)
- typedef int(* wifi_connection_scan_start_fp_t) (uint8_t *ssid, uint8_t ssid_length, uint8_t *bssid, uint8_←
 t scan mode, uint8 t scan option)
- typedef int(* wifi_connection_unregister_event_handler_fp_t) (wifi_event_t event, wifi_event_handler_t handler)
- typedef int(* wifi_convert_auth_mode_fp_t) (scan_info_t *pinfo, int privacy)
- typedef int(* wifi_deinit_fp_t) (void)

 typedef int32_t(* wifi_event_handler_t) (wifi_event_t event, uint8_t *payload, uint32_t length) This defines the Wi-Fi event handler. Call wifi connection register event handler() to register a handler, then the Wi-Fi driver generates an event and sends it to the handler. typedef int(* wifi_fast_connect_get_mode_fp_t) (uint8_t ap_index, uint8_t *mode) typedef int(* wifi fast connect set mode fp t) (uint8 t ap index, uint8 t mode) typedef int(* wifi_fast_connect_start_fp_t) (uint8_t ap_index) typedef int(* wifi_get_config_fp_t) (wifi_mode_t interface, wifi_config_t *conf) typedef void(* wifi_init_complete_cb_t) (void *ctx) Initialization of complete callback function. typedef int(* wifi init fp t) (const wifi init config t *config, wifi init complete cb t init cb) typedef int32 t wifi result t typedef int(* wifi scan get ap list fp t) (wifi scan list t *scan list) typedef int(* wifi_scan_get_ap_num_fp_t) (uint16_t *number) typedef int(* wifi_scan_get_ap_records_fp_t) (uint16_t *number, wifi_scan_info_t *ap_records) typedef int(* wifi_scan_start_fp_t) (const wifi_scan_config_t *config, bool block) typedef int(* wifi_scan_stop_fp_t) (void) typedef int(* wifi_set_config_fp_t) (wifi_mode_t interface, wifi_config_t *conf) typedef int(* wifi_sta_get_ap_info_fp_t) (wifi_ap_record_t *ap_info) typedef int(* wifi_start_fp_t) (void) typedef int(* wifi_stop_fp_t) (void) **Functions** int wifi auto connect clear ap info (uint8 t index) Clear the AP information which index in the. int wifi_auto_connect_get_ap_info (uint8_t index, wifi_auto_connect_info_t *info) Get the AP information. int wifi auto connect get ap num (uint8 t *num) Get the maximum number of AP information. int wifi_auto_connect_get_mode (uint8_t *mode) Get the auto connect mode. int wifi_auto_connect_get_saved_ap_num (uint8_t *num) Get the current number of AP save in flash. int wifi_auto_connect_init (void) Initialize function of auto connect. int wifi_auto_connect_reset (void) Reset all of auto/fast connect configuration. int wifi_auto_connect_set_ap_num (uint8_t num) Set the maximum number of AP information. int wifi auto connect set mode (uint8 t mode) Set the auto connect mode. int wifi_auto_connect_start (void) Start auto connect mechanism. int wifi_auto_connect_update_ch (uint8_t ac_index, uint8_t channel) Update the channel which AP index in auto connect list. int wifi config get bandwidth (wifi mode t interface, wifi bandwidth t *bandwidth) Get the bandwidth of OPL1000 specified interface. int wifi config get bssid (uint8 t *bssid)

get bssid after scan

int wifi config get channel (wifi mode t interface, uint8 t *channel)

Get the primary/secondary channel of OPL1000.

int wifi_config_get_dtim_interval (uint8_t *interval)
 int wifi_config_get_listen_interval (uint8_t *interval)

Get mac of specified interface.

• int wifi_config_get_mac_address (wifi_mode_t interface, uint8_t *address)

```
    int wifi config get mac tx data rate (wifi mac data rate t *data rate)

      Get the Mac tx data rate in current wifi setting of OPL1000.

    int wifi config get opmode (uint8 t *mode)

    int wifi_config_get_skip_dtim (uint8_t *value)

      Get the Skip DTIM value in current wifi setting of OPL1000.
int wifi_config_get_ssid (uint8_t *ssid, uint8_t *ssid_length)
      Get ssid value of AP.

    int wifi_config_get_sta_mac_address_from_flash (uint8_t *bssid)

      Get mac address of station from flash.
• int wifi_config_set_bandwidth (wifi_mode_t interface, wifi_bandwidth_t bandwidth)
      Set the bandwidth of OPL1000 specified interface.
int wifi_config_set_bssid (uint8_t *bssid)
      config OPL1000 Wi-Fi bssid.
• int wifi_config_set_channel (wifi_mode_t interface, uint8_t channel)
      Set primary/secondary channel of OPL1000.

    int wifi config set dtim interval (uint8 t interval)

    int wifi_config_set_listen_interval (uint8_t interval)

int wifi_config_set_mac_address (wifi_mode_t interface, uint8_t *address)
      Set MAC address of OPL1000 Wi-Fi station or the soft-AP interface.

    int wifi_config_set_mac_tx_data_rate (wifi_mac_data_rate_t data_rate)

      Set the Mac tx data rate setting of OPL1000.
• int wifi config set opmode (uint8 t mode)

    int wifi config set skip dtim (uint8 t value, bool save flash)

      Set the Skip DTIM value of OPL1000.

    int wifi_config_set_ssid (wifi_mode_t interface, uint8_t *ssid, uint8_t ssid_length)

      Set the ssid value of the current device.

    int wifi_connection_connect (wifi_config_t *config)

      Connect OPL1000 Wi-Fi station to certain AP.

    int wifi_connection_connect_from_ac_index (uint8_t index)

      Connect OPL1000 Wi-Fi station to certain AP by auto connect index.

    int wifi connection connect from ac list (wifi config t *config)

      Connect OPL1000 Wi-Fi station to certain AP in auto connect list.

    int wifi_connection_disconnect_ap (void)

      Disconnect the link between OPL1000 and connected AP.

    int wifi_connection_disconnect_sta (uint8_t *address)

      Disconnect the link between the current device and the station.
• int wifi_connection_get_rssi (int8_t *rssi)
      get signal strength of AP
• int wifi_connection_register_event_handler (wifi_event_t event, wifi_event_handler_t handler)
      register wifi call back handler

    int wifi connection scan start (uint8 t *ssid, uint8 t ssid length, uint8 t *bssid, uint8 t scan mode, uint8 ←

  t scan option)
• int wifi connection unregister event handler (wifi event t event, wifi event handler t handler)
      unregister wifi call back handler

    int wifi_convert_auth_mode (scan_info_t *pinfo, int privacy)

• int wifi deinit (void)
      De-init Wi-Fi Initialization and Configuration functions.
                                                                                                   Generated by Doxygen
```

int wifi_fast_connect_get_mode (uint8_t ap_index, uint8_t *mode)

Get the fast connect mode.

int wifi_fast_connect_set_mode (uint8_t ap_index, uint8_t mode)

Set the fast connect mode.

int wifi_fast_connect_start (uint8_t ap_index)

Start fast connect mechanism.

int wifi_get_config (wifi_mode_t interface, wifi_config_t *conf)

Get configuration of specified interface.

• int wifi_init (const wifi_init_config_t *config, wifi_init_complete_cb_t init_cb)

Init Wi-Fi Initializes the wifi according to the specified parameters in the config.

int wifi_scan_get_ap_list (wifi_scan_list_t *scan_list)

Get list of APs that found in last scan operation.

int wifi_scan_get_ap_num (uint16_t *number)

Get the number of scanned APs.

• int wifi_scan_get_ap_records (uint16_t *number, wifi_scan_info_t *ap_records)

Get AP list found in last scan operation.

• int wifi_scan_start (const wifi_scan_config_t *config, bool block)

Scan all available APs. After invoke the wifi set config() and wifi start(), then call wifi scan start() to scan APs.

int wifi scan stop (void)

Stop scanning process.

int wifi_set_config (wifi_mode_t interface, wifi_config_t *conf)

Set configuration of OPL1000 STA.

int wifi_sta_get_ap_info (wifi_ap_record_t *ap_info)

Get information of AP which OPL1000 station is associated with.

• int wifi_start (void)

Start Wi-Fi working.

int wifi_stop (void)

Stop wifi working.

Variables

- wifi_auto_connect_clear_ap_info_fp_t wifi_auto_connect_clear_ap_info_api
- · wifi auto connect get ap info fp t wifi auto connect get ap info api
- wifi_auto_connect_get_ap_num_fp_t wifi_auto_connect_get_ap_num_api
- wifi_auto_connect_get_mode_fp_t wifi_auto_connect_get_mode_api
- wifi_auto_connect_get_saved_ap_num_fp_t wifi_auto_connect_get_saved_ap_num_api
- · wifi auto connect init fp t wifi auto connect init api
- wifi_auto_connect_reset_fp_t wifi_auto_connect_reset_api
- wifi_auto_connect_set_ap_num_fp_t wifi_auto_connect_set_ap_num_api
- · wifi auto connect set mode fp t wifi auto connect set mode api
- wifi_auto_connect_start_fp_t wifi_auto_connect_start_api
- wifi_auto_connect_update_ch_fp_t wifi_auto_connect_update_ch_api
- · wifi config get bandwidth fp t wifi config get bandwidth api
- wifi_config_get_bssid_fp_t wifi_config_get_bssid_api
- wifi_config_get_channel_fp_t wifi_config_get_channel_api
- wifi_config_get_dtim_interval_fp_t wifi_config_get_dtim_interval_api
- wifi_config_get_listen_interval_fp_t wifi_config_get_listen_interval_api
- wifi_config_get_mac_address_fp_t wifi_config_get_mac_address_api
- wifi_config_get_mac_tx_data_rate_fp_t wifi_config_get_mac_tx_data_rate_api
- wifi_config_get_opmode_fp_t wifi_config_get_opmode_api
- wifi_config_get_skip_dtim_fp_t wifi_config_get_skip_dtim_api

- wifi_config_get_ssid_fp_t wifi_config_get_ssid_api
- · wifi config get sta mac address from flash fp t wifi config get sta mac address from flash api
- wifi_config_set_bandwidth_fp_t wifi_config_set_bandwidth_api
- · wifi config set bssid fp t wifi config set bssid api
- · wifi config set channel fp t wifi config set channel api
- wifi_config_set_dtim_interval_fp_t wifi_config_set_dtim_interval_api
- wifi_config_set_listen_interval_fp_t wifi_config_set_listen_interval_api
- wifi_config_set_mac_address_fp_t wifi_config_set_mac_address_api
- wifi_config_set_mac_tx_data_rate_fp_t wifi_config_set_mac_tx_data_rate_api
- wifi_config_set_opmode_fp_t wifi_config_set_opmode_api
- · wifi config set skip dtim fp t wifi config set skip dtim api
- · wifi config set ssid fp t wifi config set ssid api
- wifi_connection_connect_api
- wifi_connection_connect_from_ac_index_fp_t wifi_connection_connect_from_ac_index_api
- wifi_connection_connect_from_ac_list_fp_t wifi_connection_connect_from_ac_list_api
- wifi_connection_disconnect_ap_fp_t wifi_connection_disconnect_ap_api
- wifi_connection_disconnect_sta_fp_t wifi_connection_disconnect_sta_api
- · wifi connection get rssi fp t wifi connection get rssi api
- wifi_connection_register_event_handler_fp_t wifi_connection_register_event_handler_api
- wifi_connection_scan_start_fp_t wifi_connection_scan_start_api
- · wifi connection unregister event handler fp t wifi connection unregister event handler api
- wifi_convert_auth_mode_fp_t wifi_convert_auth_mode_api
- wifi_deinit_fp_t wifi_deinit_api
- wifi_fast_connect_get_mode_fp_t wifi_fast_connect_get_mode_api
- · wifi fast connect set mode fp t wifi fast connect set mode api
- wifi_fast_connect_start_fp_t wifi_fast_connect_start_api
- · wifi get config fp t wifi get config api
- wifi_init_fp_t wifi_init_api
- wifi_scan_get_ap_list_fp_t wifi_scan_get_ap_list_api
- wifi_scan_get_ap_num_fp_t wifi_scan_get_ap_num_api
- · wifi scan get ap records fp t wifi scan get ap records api
- wifi_scan_start_fp_t wifi_scan_start_api
- wifi_scan_stop_fp_t wifi_scan_stop_api
- wifi_set_config_fp_t wifi_set_config_api
- wifi_sta_get_ap_info_fp_t wifi_sta_get_ap_info_api
- · wifi start fp t wifi start api
- · wifi stop fp t wifi stop api

3.9.1 Detailed Description

3.9.2 Macro Definition Documentation

3.9.2.1 WIFI_READY_TIME

#define WIFI_READY_TIME 2000

3.9.3 Typedef Documentation

```
3.9.3.1 wifi_auto_connect_clear_ap_info_fp_t
typedef int(* wifi_auto_connect_clear_ap_info_fp_t) (uint8_t index)
3.9.3.2 wifi_auto_connect_get_ap_info_fp_t
typedef int(* wifi_auto_connect_get_ap_info_fp_t) (uint8_t index, wifi_auto_connect_info_t
*info)
3.9.3.3 wifi_auto_connect_get_ap_num_fp_t
typedef int(* wifi_auto_connect_get_ap_num_fp_t) (uint8_t *num)
3.9.3.4 wifi_auto_connect_get_mode_fp_t
typedef int(* wifi_auto_connect_get_mode_fp_t) (uint8_t *mode)
3.9.3.5 wifi_auto_connect_get_saved_ap_num_fp_t
typedef int(* wifi_auto_connect_get_saved_ap_num_fp_t) (uint8_t *num)
3.9.3.6 wifi_auto_connect_init_fp_t
typedef int(* wifi_auto_connect_init_fp_t) (void)
3.9.3.7 wifi_auto_connect_reset_fp_t
typedef int(* wifi_auto_connect_reset_fp_t) (void)
```

```
3.9.3.8 wifi_auto_connect_set_ap_num_fp_t
typedef int(* wifi_auto_connect_set_ap_num_fp_t) (uint8_t num)
3.9.3.9 wifi_auto_connect_set_mode_fp_t
typedef int(* wifi_auto_connect_set_mode_fp_t) (uint8_t mode)
3.9.3.10 wifi_auto_connect_start_fp_t
typedef int(* wifi_auto_connect_start_fp_t) (void)
3.9.3.11 wifi_auto_connect_update_ch_fp_t
typedef int(* wifi_auto_connect_update_ch_fp_t) (uint8_t ac_index, uint8_t channel)
3.9.3.12 wifi_config_get_bandwidth_fp_t
typedef int(* wifi_config_get_bandwidth_fp_t) (wifi_mode_t interface, wifi_bandwidth_t *bandwidth)
3.9.3.13 wifi config get bssid fp t
typedef int(* wifi_config_get_bssid_fp_t) (uint8_t *bssid)
3.9.3.14 wifi_config_get_channel_fp_t
typedef int(* wifi_config_get_channel_fp_t) (wifi_mode_t interface, uint8_t *channel)
3.9.3.15 wifi_config_get_dtim_interval_fp_t
typedef int(* wifi_config_get_dtim_interval_fp_t) (uint8_t *interval)
```

```
3.9.3.16 wifi_config_get_listen_interval_fp_t
typedef int(* wifi_config_get_listen_interval_fp_t) (uint8_t *interval)
3.9.3.17 wifi_config_get_mac_address_fp_t
typedef int(* wifi_config_get_mac_address_fp_t) (wifi_mode_t interface, uint8_t *address)
3.9.3.18 wifi_config_get_mac_tx_data_rate_fp_t
{\tt typedef\ int(*\ wifi\_config\_get\_mac\_tx\_data\_rate\_fp\_t)\ (wifi\_mac\_data\_rate\_t\ *data\_rate)}
3.9.3.19 wifi_config_get_opmode_fp_t
typedef int(* wifi_config_get_opmode_fp_t) (uint8_t *mode)
3.9.3.20 wifi_config_get_skip_dtim_fp_t
{\tt typedef\ int} \ (*\ wifi\_config\_get\_skip\_dtim\_fp\_t) \ \ (uint8\_t\ *value)
3.9.3.21 wifi config get ssid fp t
typedef int(* wifi_config_get_ssid_fp_t) (uint8_t *ssid, uint8_t *ssid_length)
3.9.3.22 wifi_config_get_sta_mac_address_from_flash_fp_t
typedef int(* wifi_config_get_sta_mac_address_from_flash_fp_t) (uint8_t *bssid)
3.9.3.23 wifi_config_set_bandwidth_fp_t
typedef int(* wifi_config_set_bandwidth_fp_t) (wifi_mode_t interface, wifi_bandwidth_t bandwidth)
```

```
3.9.3.24 wifi_config_set_bssid_fp_t
typedef int(* wifi_config_set_bssid_fp_t) (uint8_t *bssid)
3.9.3.25 wifi_config_set_channel_fp_t
typedef int(* wifi_config_set_channel_fp_t) (wifi_mode_t interface, uint8_t channel)
3.9.3.26 wifi_config_set_dtim_interval_fp_t
typedef int(* wifi_config_set_dtim_interval_fp_t) (uint8_t interval)
3.9.3.27 wifi_config_set_listen_interval_fp_t
typedef int(* wifi_config_set_listen_interval_fp_t) (uint8_t interval)
3.9.3.28 \quad wifi\_config\_set\_mac\_address\_fp\_t
{\tt typedef\ int(*\ wifi\_config\_set\_mac\_address\_fp\_t)\ (wifi\_mode\_t\ interface,\ uint8\_t\ *address)}
3.9.3.29 wifi config set mac tx data rate fp t
typedef int(* wifi_config_set_mac_tx_data_rate_fp_t) (wifi_mac_data_rate_t data_rate)
3.9.3.30 wifi_config_set_opmode_fp_t
typedef int(* wifi_config_set_opmode_fp_t) (uint8_t mode)
3.9.3.31 wifi_config_set_skip_dtim_fp_t
typedef int(* wifi_config_set_skip_dtim_fp_t) (uint8_t value, bool save_flash)
```

```
3.9.3.32 wifi_config_set_ssid_fp_t
length)
3.9.3.33 wifi_connection_connect_fp_t
typedef int(* wifi_connection_connect_fp_t) (wifi_config_t *config)
3.9.3.34 wifi_connection_connect_from_ac_index_fp_t
typedef int(* wifi_connection_connect_from_ac_index_fp_t) (uint8_t index)
3.9.3.35 wifi_connection_connect_from_ac_list_fp_t
typedef int(* wifi_connection_connect_from_ac_list_fp_t) (wifi_config_t *config)
3.9.3.36 wifi_connection_disconnect_ap_fp_t
typedef int(* wifi_connection_disconnect_ap_fp_t) (void)
3.9.3.37 wifi_connection_disconnect_sta_fp_t
{\tt typedef\ int} \ (*\ wifi\_connection\_disconnect\_sta\_fp\_t) \ \ (uint8\_t\ *address)
3.9.3.38 wifi_connection_get_rssi_fp_t
typedef int(* wifi_connection_get_rssi_fp_t) (int8_t *rssi)
```

3.9.3.39 wifi_connection_register_event_handler_fp_t

typedef int(* wifi_connection_register_event_handler_fp_t) (wifi_event_t event, wifi_event_handler_t
handler)

3.9.3.40 wifi_connection_scan_start_fp_t

typedef int (* wifi_connection_scan_start_fp_t) (uint8_t *ssid, uint8_t ssid_length, uint8_ \leftrightarrow t *bssid, uint8_t scan_mode, uint8_t scan_option)

3.9.3.41 wifi_connection_unregister_event_handler_fp_t

typedef int(* wifi_connection_unregister_event_handler_fp_t) (wifi_event_t event, wifi_event_handler_t
handler)

3.9.3.42 wifi_convert_auth_mode_fp_t

typedef int(* wifi_convert_auth_mode_fp_t) (scan_info_t *pinfo, int privacy)

3.9.3.43 wifi_deinit_fp_t

typedef int(* wifi_deinit_fp_t) (void)

3.9.3.44 wifi_event_handler_t

```
typedef int32_t(* wifi_event_handler_t) (wifi_event_t event, uint8_t *payload, uint32_t length)
```

This defines the Wi-Fi event handler. Call wifi_connection_register_event_handler() to register a handler, then the Wi-Fi driver generates an event and sends it to the handler.

in	event	is an optional event to register. For more details, please refer to wifi_event_t.
in	payload	is the payload for the event. When the event is WIFI_EVENT_IOT_CONNECTED in AP mode, payload is the connected STA's MAC address. When the event is WIFI_EVENT_IOT_CONNECTED in STA mode, payload is the connected AP's BSSID.
in	length	is the length of a packet.

Returns

The return value is reserved and it is ignored.

```
3.9.3.45 wifi_fast_connect_get_mode_fp_t
typedef int(* wifi_fast_connect_get_mode_fp_t) (uint8_t ap_index, uint8_t *mode)
3.9.3.46 wifi_fast_connect_set_mode_fp_t
typedef int(* wifi_fast_connect_set_mode_fp_t) (uint8_t ap_index, uint8_t mode)
3.9.3.47 wifi_fast_connect_start_fp_t
typedef int(* wifi_fast_connect_start_fp_t) (uint8_t ap_index)
3.9.3.48 wifi_get_config_fp_t
typedef int(* wifi_get_config_fp_t) (wifi_mode_t interface, wifi_config_t *conf)
3.9.3.49 wifi_init_complete_cb_t
typedef void(* wifi_init_complete_cb_t) (void *ctx)
Initialization of complete callback function.
Invoked when Wi-Fi initialization is complete.
Parameters
```

is context pointer that provided to wifi_init(). It will be passed back to the callback.

```
3.9.3.50 wifi_init_fp_t
typedef int(* wifi_init_fp_t) (const wifi_init_config_t *config, wifi_init_complete_cb_t init↔
3.9.3.51 wifi_result_t
typedef int32_t wifi_result_t
3.9.3.52 wifi_scan_get_ap_list_fp_t
typedef int(* wifi_scan_get_ap_list_fp_t) (wifi_scan_list_t *scan_list)
3.9.3.53 wifi_scan_get_ap_num_fp_t
typedef int(* wifi_scan_get_ap_num_fp_t) (uint16_t *number)
3.9.3.54 wifi_scan_get_ap_records_fp_t
typedef int(* wifi_scan_get_ap_records_fp_t) (uint16_t *number, wifi_scan_info_t *ap_records)
3.9.3.55 wifi_scan_start_fp_t
typedef int(* wifi_scan_start_fp_t) (const wifi_scan_config_t *config, bool block)
3.9.3.56 wifi_scan_stop_fp_t
typedef int(* wifi_scan_stop_fp_t) (void)
```

```
3.9.3.57 wifi_set_config_fp_t

typedef int(* wifi_set_config_fp_t) (wifi_mode_t interface, wifi_config_t *conf)

3.9.3.58 wifi_sta_get_ap_info_fp_t

typedef int(* wifi_sta_get_ap_info_fp_t) (wifi_ap_record_t *ap_info)

3.9.3.59 wifi_start_fp_t

typedef int(* wifi_start_fp_t) (void)

3.9.3.60 wifi_stop_fp_t

typedef int(* wifi_stop_fp_t) (void)
```

3.9.4 Function Documentation

3.9.4.1 wifi_auto_connect_clear_ap_info()

Clear the AP information which index in the.

Attention

1. API returns false if try to clear AP information which something error

in	index	The index of AP position
		• Range is 0 to 2

Returns

0 : success other : failed

3.9.4.2 wifi_auto_connect_get_ap_info()

Get the AP information.

Attention

1. API returns false if try to get AP information which something error

Parameters

in	index	The index of AP position
		• Range is 0 to 2
out	mode	Get the AP information

Returns

0 : success other : failed

3.9.4.3 wifi_auto_connect_get_ap_num()

Get the maximum number of AP information.

Attention

1. API returns false if try to get maximum auto connect numbers which something error

	out	num	Get the maximum number of AP information	
--	-----	-----	--	--

Returns

0 : success other : failed

3.9.4.4 wifi_auto_connect_get_mode()

Get the auto connect mode.

Attention

1. API returns false if try to get auto connect mode which something error

Parameters

out mode Get the auto connect

Returns

0 : success other : failed

3.9.4.5 wifi_auto_connect_get_saved_ap_num()

Get the current number of AP save in flash.

Attention

1. API returns false if try to get current auto connect numbers which something error

Parameters

	out	num	The current number of AP information will be saved in flash.
--	-----	-----	--

Returns

0 : success other : failed

3.9.4.6 wifi_auto_connect_init()

Initialize function of auto connect.

Attention

1. API returns false if try to initial auto connect which something error

Returns

0 : success other : failed

3.9.4.7 wifi_auto_connect_reset()

Reset all of auto/fast connect configuration.

Attention

1. API returns false if try to reset auto connect configuration which something error

Returns

0 : success other : failed

3.9.4.8 wifi_auto_connect_set_ap_num()

Set the maximum number of AP information.

Attention

1. API returns false if try to set maximum auto connect numbers which something error

Parameters

in	num	The maximum number of AP information will be saved in flash.	
		Range is 1 to 3	

Returns

0 : success other : failed

3.9.4.9 wifi_auto_connect_set_mode()

Set the auto connect mode.

Attention

1. API returns false if try to set auto connect mode which something error

Parameters

in	mode	Configure the current wifi working mode, The options are
		WIFI_AUTO_CONNECT_ENABLE
		WIFI_AUTO_CONNECT_DISABLE

Returns

0 : success other : failed

3.9.4.10 wifi_auto_connect_start()

Start auto connect mechanism.

Attention

1. API returns false if try to start auto connect function which something error

Returns

0 : success other : failed

3.9.4.11 wifi_auto_connect_update_ch()

Update the channel which AP index in auto connect list.

Attention

1. API returns false if update channel which something error

Parameters

in	index	The index of AP position
		• Range is 0 to 2
in	channel	The channel of AP's used.
		• Range is 1 to 14

Returns

0 : success other : failed

3.9.4.12 wifi_config_get_bandwidth()

Get the bandwidth of OPL1000 specified interface.

Attention

1. API returns false if try to get an interface which is not enable

Parameters

in	interface	Configure the current wifi working mode, The options are
		WIFI_MODE_STA
		WIFI_MODE_AP (currently not support)
out	bandwidth	Get the bandwidth value of the current wifi module working through the pointer

Returns

0 : success other : failed

3.9.4.13 wifi_config_get_bssid()

get bssid after scan

Parameters

out <i>bssid</i>	the string of bssid
------------------	---------------------

Returns

0 : success other : failed

3.9.4.14 wifi_config_get_channel()

Get the primary/secondary channel of OPL1000.

Attention

1. API returns false if try to get an interface which is not enabled

Parameters

in	interface	Configure the current wifi working mode, The options are
		WIFI_MODE_STA
		WIFI_MODE_AP (currently not support)
out	channel	Get Current module wifi work channel number

Returns

0 : success other : failed

3.9.4.15 wifi_config_get_dtim_interval()

3.9.4.16 wifi_config_get_listen_interval()

3.9.4.17 wifi_config_get_mac_address()

Get mac of specified interface.

in	interface	Configure the current wifi working mode, The options are
		WIFI_MODE_STA
		WIFI_MODE_AP (currently not support)
out	address	Get the MAC address of the device through this interface, The address is similar to this
		structure: xx:xx:xx:xx:xx

Returns

0 : success other : failed

3.9.4.18 wifi_config_get_mac_tx_data_rate()

Get the Mac tx data rate in current wifi setting of OPL1000.

Parameters

out	data_rate	Get the Mac tx data rate
		WIFI_MAC_DATA_RATE_ARA
		WIFI_MAC_DATA_RATE_1M
		WIFI_MAC_DATA_RATE_2M
		• WIFI_MAC_DATA_RATE_5_5M
		WIFI_MAC_DATA_RATE_11M

Returns

0 : success other : failed

3.9.4.19 wifi_config_get_opmode()

3.9.4.20 wifi_config_get_skip_dtim()

Get the Skip DTIM value in current wifi setting of OPL1000.

	out	value	Get the Skip DTIM value in current wifi setting
--	-----	-------	---

Returns

0 : success other : failed

3.9.4.21 wifi_config_get_ssid()

```
int wifi_config_get_ssid (
          uint8_t * ssid,
          uint8_t * ssid_length )
```

Get ssid value of AP.

Parameters

out	ssid	Get ssid by pointer
out	ssid_length	Get the length of the ssid character

Returns

0 : success other : failed

3.9.4.22 wifi_config_get_sta_mac_address_from_flash()

Get mac address of station from flash.

Parameters

out	address	Get the MAC address of station from flash, The address is similar to this structure:
		XX:XX:XX:XX:XX

Returns

0 : success other : failed

3.9.4.23 wifi_config_set_bandwidth()

Set the bandwidth of OPL1000 specified interface.

Parameters

	in	interface	Configure the current wifi working mode, The options are
			WIFI_MODE_STA
			WIFI_MODE_AP (currently not support)
Ī	in	bandwidth	Set the working bandwidth of wifi

Returns

0 : success other : failed

3.9.4.24 wifi_config_set_bssid()

config OPL1000 Wi-Fi bssid.

Parameters

in	bssid	the string of bssid

Returns

0 : success other : failed

3.9.4.25 wifi_config_set_channel()

Set primary/secondary channel of OPL1000.

Attention

- 1. This is a special API for sniffer
- 2. This API should be called after wifi_start()

Parameters

in	interface	Configure the current wifi working mode, The options are
		WIFI_MODE_STA
		WIFI_MODE_AP (currently not support)
in	channel	Set current Wi-Fi work channel number

Returns

0 : success other : failed

3.9.4.26 wifi_config_set_dtim_interval()

3.9.4.27 wifi_config_set_listen_interval()

3.9.4.28 wifi_config_set_mac_address()

Set MAC address of OPL1000 Wi-Fi station or the soft-AP interface.

Attention

- 1. This API can only be called when the interface is disabled
- 2. OPL1000 soft-AP and station have different MAC addresses, do not set them to be the same.

	in	interface	Configure the current wifi working mode, The options are
			WIFI_MODE_STA
			WIFI_MODE_AP (currently not support)
ŀ	in	address	set MAC address

Returns

0 : success other : failed

```
3.9.4.29 wifi_config_set_mac_tx_data_rate()
```

Set the Mac tx data rate setting of OPL1000.

Parameters

in	data_rate	Set the Mac tx data rate
		• WIFI_MAC_DATA_RATE_ARA
		WIFI_MAC_DATA_RATE_1M
		• WIFI_MAC_DATA_RATE_2M
		• WIFI_MAC_DATA_RATE_5_5M
		WIFI_MAC_DATA_RATE_11M
	I	

Returns

0 : success other : failed

3.9.4.30 wifi_config_set_opmode()

3.9.4.31 wifi_config_set_skip_dtim()

Set the Skip DTIM value of OPL1000.

Parameters

in	value	Set the Skip DTIM value	
in	save_flash	Enable/Disable to write in flash.	
		0 : Not write in flash. (Only effect in runtime)	
		1 : Write in flash and effect the value.	

Attention

- 1. This API will set the skip DTIM value to share memory and stored in flash, please use wifi_config_get_skip_dtim() to check it.
- 2. The setting will be effect after next connect. We recommend re-connect AP after setting to make sure the value is correct with negotiate between AP.

Returns

0 : success other : failed

3.9.4.32 wifi_config_set_ssid()

Set the ssid value of the current device.

Parameters

in	interface	Configure the current wifi working mode, The options are	
		WIFI_MODE_STA	
		WIFI_MODE_AP (currently not support)	
in	ssid	Set the value of ssid	
in	ssid_length	The length of ssid parameter	

Returns

0 : success other : failed

3.9.4.33 wifi_connection_connect()

Connect OPL1000 Wi-Fi station to certain AP.

Attention

- 1. This API only impact WIFI_MODE_STA or WIFI_MODE_AP mode
- 2. If OPL1000 is connected to an AP, call wifi_disconnect to disconnect.

Parameters

	in	config	Establish connection parameters
--	----	--------	---------------------------------

Returns

0 : success other : failed

3.9.4.34 wifi_connection_connect_from_ac_index()

Connect OPL1000 Wi-Fi station to certain AP by auto connect index.

Attention

- 1. This API only impact WIFI_MODE_STA or WIFI_MODE_AP mode
- 2. If OPL1000 is connected to an AP, call wifi_disconnect to disconnect.
- 3. Then index should be 0 to begin.

Parameters

	in	index	The index of AP in auto connect list
--	----	-------	--------------------------------------

Returns

0 : success

1 : The index of AP is null

other: failed

3.9.4.35 wifi_connection_connect_from_ac_list()

Connect OPL1000 Wi-Fi station to certain AP in auto connect list.

Attention

- 1. This API only impact WIFI_MODE_STA or WIFI_MODE_AP mode
- 2. If OPL1000 is connected to an AP, call wifi_disconnect to disconnect.

Parameters

in	config	Establish connection parameters
----	--------	---------------------------------

Returns

0 : success
1 : Not found in list other : failed

3.9.4.36 wifi_connection_disconnect_ap()

Disconnect the link between OPL1000 and connected AP.

Returns

0 : success other : failed

3.9.4.37 wifi_connection_disconnect_sta()

Disconnect the link between the current device and the station.

in	address	station address

Returns

0 : success other : failed

3.9.4.38 wifi_connection_get_rssi()

get signal strength of AP

Attention

1. If the scan is successful, this API returns signal strength value, otherwise it will get wrong result

Parameters

```
out rssi rssi value
```

Returns

0 : success other : failed

3.9.4.39 wifi_connection_register_event_handler()

register wifi call back handler

Parameters

in	event	The type of the registered event. Options are	
		WIFI_EVENT_INIT_COMPLETE	
		WIFI_EVENT_SCAN_COMPLETE	
		WIFI_EVENT_STA_START	
		WIFI_EVENT_STA_STOP	
		WIFI_EVENT_STA_CONNECTED	
		WIFI_EVENT_STA_DISCONNECTED	
		WIFI_EVENT_STA_CONNECTION_FAILED	
		WIFI_EVENT_STA_GOT_IP	
in	handler	registered event handler	

Returns

0 : success other : failed

3.9.4.40 wifi_connection_scan_start()

3.9.4.41 wifi_connection_unregister_event_handler()

unregister wifi call back handler

in	event	The type of the unregistered event. Options please refer to	
		wifi_connection_register_event_handler()	
in	handler	unregistered event handler	

Returns

0 : success other : failed

3.9.4.42 wifi_convert_auth_mode()

3.9.4.43 wifi_deinit()

```
int wifi_deinit (
     void )
```

De-init Wi-Fi Initialization and Configuration functions.

Attention

1. This API should be called if want to remove Wi-Fi driver from the system

Returns

0 : success other : failed

3.9.4.44 wifi_fast_connect_get_mode()

Get the fast connect mode.

Attention

1. API returns false if try to get fast connect mode which something error

Parameters

in	index	The index of AP position
		• Range is 0 to 2
out	mode	Get the fast connect mode

Returns

0 : success other : failed

3.9.4.45 wifi_fast_connect_set_mode()

Set the fast connect mode.

Attention

1. API returns false if try to set fast connect mode which something error

Parameters

in	index	The index of AP position
		• Range is 0 to 2
in	mode	The fast connect mode

Returns

0 : success other : failed

3.9.4.46 wifi_fast_connect_start()

Start fast connect mechanism.

Attention

1. API returns false if try to start fast connect function which something error

Parameters

in	index	The index of AP position
		• Range is 0 to 2

Returns

0 : success other : failed

3.9.4.47 wifi_get_config()

Get configuration of specified interface.

Parameters

in	interface	Configure wifi working mode,The options are	
		WIFI_MODE_STA	
		WIFI_MODE_AP (currently not support)	
out	conf	return wifi's current operating parameters	

Returns

0 : success other : failed

3.9.4.48 wifi_init()

Init Wi-Fi Initializes the wifi according to the specified parameters in the config.

Attention

1. This API must be called before other Wi-Fi APIs are invoked

Parameters

iı	1 <i>co</i>	onfig	pointer to Wi-Fi init configuration structure; can point to a temporary variable.
iı	ı ini	it_cb	pointer to Wi-Fi init complete configuration structure; can point to a temporary variable.

Returns

0 : success other : failed

3.9.4.49 wifi_scan_get_ap_list()

Get list of APs that found in last scan operation.

Attention

This API only be called when scan is completed, otherwise it may get wrong value.

Parameters

out	scan_list	store APs' informaton that found in last scan operation
-----	-----------	---

Returns

0 : success other : failed

3.9.4.50 wifi_scan_get_ap_num()

Get the number of scanned APs.

out	number	store number of APs found in last scan operation
-----	--------	--

3.9 WIFI STA APIs

Attention

This API only be called when scan is completed, otherwise it may get wrong value.

Returns

the scan result of AP number

3.9.4.51 wifi_scan_get_ap_records()

Get AP list found in last scan operation.

Parameters

out	number	As input param, it stores max AP number that ap_records can hold. As output param, it
		receives the actual AP number that this API returns.
out	ap_records	wifi_scan_info_t array stores the found APs

Returns

0 : success other : failed

3.9.4.52 wifi_scan_start()

Scan all available APs. After invoke the wifi_set_config() and wifi_start(), then call wifi_scan_start() to scan APs.

Parameters

in	config	Configure parameters for scan operation
in	block	if block is true, this API blocks the caller until scan operation is done, otherwise it returns
		immediately

Returns

0 : success other : failed

3.9.4.53 wifi_scan_stop()

Stop scanning process.

Attention

This API shall be called after wifi_scan_start()

Returns

0 : success other : failed

3.9.4.54 wifi_set_config()

Set configuration of OPL1000 STA.

Attention

- 1. This API is called only when specified interface is enabled, otherwise API calling will be failed
- 2. For station configuration, bssid_set shall be set to 0; set to 1 menas user want to check MAC address of certain AP.
- 3. OPL1000 is limited to working on one channel.

Parameters

in	interface	Configure wifi working mode,The options are
		WIFI_MODE_STA
		WIFI_MODE_AP (currently not support)
in	conf	structure of configuration paremeters

Returns

0 : success other : failed

3.9 WIFI STA APIs

3.9.4.55 wifi_sta_get_ap_info()

Get information of AP which OPL1000 station is associated with.

Parameters

```
out | ap_info | get AP information from list
```

Returns

0 : success other : failed

3.9.4.56 wifi_start()

```
int wifi_start (
     void )
```

Start Wi-Fi working.

• If mode is WIFI_MODE_STA, it creates station control block and starts station

Returns

0 : success other : failed

3.9.4.57 wifi_stop()

```
int wifi_stop (
     void )
```

Stop wifi working.

• If mode is WIFI_MODE_STA, it stops station and releases station control block

Returns

0 : success other : failed

3.9.5 Variable Documentation

```
3.9.5.1 wifi_auto_connect_clear_ap_info_api
wifi_auto_connect_clear_ap_info_fp_t wifi_auto_connect_clear_ap_info_api
3.9.5.2 wifi_auto_connect_get_ap_info_api
wifi\_auto\_connect\_get\_ap\_info\_fp\_t \ wifi\_auto\_connect\_get\_ap\_info\_api
3.9.5.3 wifi_auto_connect_get_ap_num_api
wifi_auto_connect_get_ap_num_fp_t wifi_auto_connect_get_ap_num_api
3.9.5.4 wifi_auto_connect_get_mode_api
wifi_auto_connect_get_mode_fp_t wifi_auto_connect_get_mode_api
3.9.5.5 wifi_auto_connect_get_saved_ap_num_api
wifi_auto_connect_get_saved_ap_num_fp_t wifi_auto_connect_get_saved_ap_num_api
3.9.5.6 wifi_auto_connect_init_api
wifi_auto_connect_init_fp_t wifi_auto_connect_init_api
3.9.5.7 wifi_auto_connect_reset_api
wifi_auto_connect_reset_fp_t wifi_auto_connect_reset_api
```

3.9 WIFI STA APIs 139

```
3.9.5.8 wifi_auto_connect_set_ap_num_api
wifi_auto_connect_set_ap_num_fp_t wifi_auto_connect_set_ap_num_api
3.9.5.9 wifi_auto_connect_set_mode_api
wifi\_auto\_connect\_set\_mode\_fp\_t \ wifi\_auto\_connect\_set\_mode\_api
3.9.5.10 wifi_auto_connect_start_api
wifi\_auto\_connect\_start\_fp\_t \ wifi\_auto\_connect\_start\_api
3.9.5.11 wifi_auto_connect_update_ch_api
wifi_auto_connect_update_ch_fp_t wifi_auto_connect_update_ch_api
3.9.5.12 wifi_config_get_bandwidth_api
wifi\_config\_get\_bandwidth\_fp\_t \ wifi\_config\_get\_bandwidth\_api
3.9.5.13 wifi config get bssid api
wifi_config_get_bssid_fp_t wifi_config_get_bssid_api
3.9.5.14 wifi_config_get_channel_api
wifi\_config\_get\_channel\_fp\_t \ wifi\_config\_get\_channel\_api
3.9.5.15 wifi_config_get_dtim_interval_api
wifi_config_get_dtim_interval_fp_t wifi_config_get_dtim_interval_api
```

```
3.9.5.16 wifi_config_get_listen_interval_api
wifi_config_get_listen_interval_fp_t wifi_config_get_listen_interval_api
3.9.5.17 wifi_config_get_mac_address_api
wifi\_config\_get\_mac\_address\_fp\_t \ wifi\_config\_get\_mac\_address\_api
3.9.5.18 wifi_config_get_mac_tx_data_rate_api
wifi_config_get_mac_tx_data_rate_fp_t wifi_config_get_mac_tx_data_rate_api
3.9.5.19 wifi_config_get_opmode_api
wifi_config_get_opmode_fp_t wifi_config_get_opmode_api
3.9.5.20 wifi_config_get_skip_dtim_api
wifi_config_get_skip_dtim_fp_t wifi_config_get_skip_dtim_api
3.9.5.21 wifi config get ssid api
wifi_config_get_ssid_fp_t wifi_config_get_ssid_api
3.9.5.22 wifi_config_get_sta_mac_address_from_flash_api
wifi\_config\_get\_sta\_mac\_address\_from\_flash\_fp\_t \ wifi\_config\_get\_sta\_mac\_address\_from\_flash\_api
3.9.5.23 wifi_config_set_bandwidth_api
wifi_config_set_bandwidth_fp_t wifi_config_set_bandwidth_api
```

3.9 WIFI STA APIS

```
3.9.5.24 wifi_config_set_bssid_api
wifi_config_set_bssid_fp_t wifi_config_set_bssid_api
3.9.5.25 wifi_config_set_channel_api
wifi\_config\_set\_channel\_fp\_t \ wifi\_config\_set\_channel\_api
3.9.5.26 wifi_config_set_dtim_interval_api
wifi\_config\_set\_dtim\_interval\_fp\_t \ wifi\_config\_set\_dtim\_interval\_api
3.9.5.27 wifi_config_set_listen_interval_api
wifi_config_set_listen_interval_fp_t wifi_config_set_listen_interval_api
3.9.5.28 wifi_config_set_mac_address_api
wifi\_config\_set\_mac\_address\_fp\_t \ wifi\_config\_set\_mac\_address\_api
3.9.5.29 wifi config set mac tx data rate api
wifi_config_set_mac_tx_data_rate_fp_t wifi_config_set_mac_tx_data_rate_api
3.9.5.30 wifi_config_set_opmode_api
{\tt wifi\_config\_set\_opmode\_fp\_t\ wifi\_config\_set\_opmode\_api}
3.9.5.31 wifi_config_set_skip_dtim_api
wifi_config_set_skip_dtim_fp_t wifi_config_set_skip_dtim_api
```

```
3.9.5.32 wifi_config_set_ssid_api
wifi_config_set_ssid_fp_t wifi_config_set_ssid_api
3.9.5.33 wifi_connection_connect_api
{\tt wifi\_connect\_fp\_t\ wifi\_connect\_api}
3.9.5.34 wifi_connection_connect_from_ac_index_api
wifi_connection_connect_from_ac_index_fp_t wifi_connection_connect_from_ac_index_api
3.9.5.35 wifi_connection_connect_from_ac_list_api
wifi_connection_connect_from_ac_list_fp_t wifi_connection_connect_from_ac_list_api
3.9.5.36 wifi_connection_disconnect_ap_api
wifi\_connection\_disconnect\_ap\_fp\_t \ wifi\_connection\_disconnect\_ap\_api
3.9.5.37 wifi_connection_disconnect_sta_api
wifi_connection_disconnect_sta_fp_t wifi_connection_disconnect_sta_api
3.9.5.38 wifi_connection_get_rssi_api
{\tt wifi\_connection\_get\_rssi\_fp\_t\ wifi\_connection\_get\_rssi\_api}
3.9.5.39 wifi_connection_register_event_handler_api
wifi_connection_register_event_handler_fp_t wifi_connection_register_event_handler_api
```

3.9 WIFI STA APIS 143

```
3.9.5.40 wifi_connection_scan_start_api
wifi_connection_scan_start_fp_t wifi_connection_scan_start_api
3.9.5.41 wifi_connection_unregister_event_handler_api
wifi_connection_unregister_event_handler_fp_t wifi_connection_unregister_event_handler_api
3.9.5.42 wifi_convert_auth_mode_api
wifi\_convert\_auth\_mode\_fp\_t \ wifi\_convert\_auth\_mode\_api
3.9.5.43 wifi_deinit_api
wifi_deinit_fp_t wifi_deinit_api
3.9.5.44 wifi_fast_connect_get_mode_api
wifi_fast_connect_get_mode_fp_t wifi_fast_connect_get_mode_api
3.9.5.45 wifi fast connect set mode api
wifi_fast_connect_set_mode_fp_t wifi_fast_connect_set_mode_api
3.9.5.46 wifi_fast_connect_start_api
wifi\_fast\_connect\_start\_fp\_t \ wifi\_fast\_connect\_start\_api
3.9.5.47 wifi_get_config_api
wifi_get_config_fp_t wifi_get_config_api
```

```
3.9.5.48 wifi_init_api
wifi_init_fp_t wifi_init_api
3.9.5.49 wifi_scan_get_ap_list_api
wifi_scan_get_ap_list_fp_t wifi_scan_get_ap_list_api
3.9.5.50 wifi_scan_get_ap_num_api
wifi_scan_get_ap_num_fp_t wifi_scan_get_ap_num_api
3.9.5.51 wifi_scan_get_ap_records_api
wifi_scan_get_ap_records_fp_t wifi_scan_get_ap_records_api
3.9.5.52 wifi_scan_start_api
wifi_scan_start_fp_t wifi_scan_start_api
3.9.5.53 wifi_scan_stop_api
wifi_scan_stop_fp_t wifi_scan_stop_api
3.9.5.54 wifi_set_config_api
wifi_set_config_fp_t wifi_set_config_api
3.9.5.55 wifi_sta_get_ap_info_api
wifi_sta_get_ap_info_fp_t wifi_sta_get_ap_info_api
3.9.5.56 wifi_start_api
wifi_start_fp_t wifi_start_api
3.9.5.57 wifi_stop_api
wifi_stop_fp_t wifi_stop_api
```

3.10 Enumeration 145

3.10 Enumeration

Enumerations

```
enum wifi_auth_mode_t {
  WIFI AUTH OPEN = 0, WIFI AUTH WEP, WIFI AUTH WPA PSK, WIFI AUTH WPA2 PSK,
  WIFI AUTH WPA WPA2_PSK, WIFI_AUTH_WPA2_ENTERPRISE }
        This enumeration defines the wireless authentication mode to indicate the Wi-Fi device authentication attribute.
enum wifi_bandwidth_t { WIFI_BW_HT20 = 1, WIFI_BW_HT40 }
enum wifi_cipher_type_t {
  WIFI_CIPHER_TYPE_NONE = 0, WIFI_CIPHER_TYPE_WEP40, WIFI_CIPHER_TYPE_WEP104,
  WIFI CIPHER TYPE TKIP,
  WIFI CIPHER TYPE CCMP, WIFI CIPHER TYPE TKIP CCMP, WIFI CIPHER TYPE UNKNOWN }
        This enumeration defines wireless security cipher suits.
enum wifi event t {
  WIFI_EVENT_NONE = -1, WIFI_EVENT_INIT_COMPLETE = 0, WIFI_EVENT_SCAN_COMPLETE,
  WIFI_EVENT_STA_START,
  WIFI_EVENT_STA_STOP, WIFI_EVENT_STA_CONNECTED, WIFI_EVENT_STA_DISCONNECTED,
  WIFI EVENT STA CONNECTION FAILED,
  WIFI EVENT STA GOT IP, WIFI EVENT MAX }
        This enumeration defines the supported events generated by the Wi-Fi driver. The event will be sent to the upper
       layer handler registered in wifi_register_event_handler().

    enum wifi mac data rate t {

  WIFI MAC DATA RATE ARA = 0, WIFI MAC DATA RATE 1M, WIFI MAC DATA RATE 2M,
  WIFI MAC DATA RATE 5 5M.
  WIFI_MAC_DATA_RATE_11M }
        This enumeration defines wifi mac tx data rates..

    enum wifi mode t { WIFI MODE NULL = 0, WIFI MODE STA, WIFI MODE AP, WIFI MODE MAX }

    enum wifi reason code t {

  WIFI_REASON_CODE_SUCCESS, WIFI_REASON_CODE_FIND_AP_FAIL, WIFI_REASON_CODE_PREV_AUTH_INVALID
  WIFI REASON CODE DEAUTH LEAVING BSS,
  WIFI REASON CODE DISASSOC INACTIVITY, WIFI REASON CODE DISASSOC AP OVERLOAD,
  WIFI REASON CODE CLASS 2 ERR, WIFI REASON CODE CLASS 3 ERR,
  WIFI_REASON_CODE_DISASSOC_LEAVING_BSS, WIFI_REASON_CODE_ASSOC_BEFORE_AUTH,
  WIFI REASON CODE DISASSOC PWR CAP UNACCEPTABLE, WIFI REASON CODE DISASSOC SUP CHS UNACCEPTABLE DISASSOC SUP CHS UNACCEPT
  WIFI REASON CODE INVALID INFO ELEM = 13, WIFI REASON CODE MIC FAILURE, WIFI REASON CODE 4 WAY
  WIFI REASON CODE GROUP KEY UPDATE TIMEOUT,
  WIFI REASON CODE DIFFERENT INFO ELEM, WIFI REASON CODE GROUP CIPHER INVALID VALID,
  WIFI REASON CODE PAIRWISE CIPHER INVALID, WIFI REASON CODE AKMP INVALID,
  WIFI REASON CODE UNSUPPORTED RSNE VERSION, WIFI REASON CODE INVALID RSNE CAPABILITIES,
  WIFI REASON CODE IEEE 802 1X AUTH FAILED, WIFI REASON CODE CIPHER REJECTED,
  WIFI REASON CODE AUTO CONNECT FAILED = 200, WIFI REASON CODE CONNECT NOT FOUND,
  WIFI REASON CODE CONNECT TIMEOUT }
        This enumeration defines the reason code of the WIFI_EVENT_STA_CONNECTION_FAILED event in wifi_event_t.
       Find the details for the reason code below.
enum wifi_scan_method_t { WIFI_FAST_SCAN = 0, WIFI_ALL_CHANNEL_SCAN }
• enum wifi_scan_type_t { WIFI_SCAN_TYPE_ACTIVE = 0, WIFI_SCAN_TYPE_PASSIVE, WIFI_SCAN_TYPE_MIX
  }
        This enumeration defines the wireless STA scan type.

    enum wifi sort method t { WIFI CONNECT AP BY SIGNAL = 0, WIFI CONNECT AP BY SECURITY }
```

3.10.1 Detailed Description

3.10.2 Enumeration Type Documentation

3.10.2.1 wifi_auth_mode_t

enum wifi_auth_mode_t

This enumeration defines the wireless authentication mode to indicate the Wi-Fi device authentication attribute.

Enumerator

WIFI_AUTH_OPEN	authenticate mode : open
WIFI_AUTH_WEP	authenticate mode : WEP
WIFI_AUTH_WPA_PSK	authenticate mode : WPA_PSK
WIFI_AUTH_WPA2_PSK	authenticate mode : WPA2_PSK
WIFI_AUTH_WPA_WPA2_PSK	authenticate mode : WPA_WPA2_PSK
WIFI_AUTH_WPA2_ENTERPRISE	authenticate mode : WPA2_ENTERPRISE

3.10.2.2 wifi_bandwidth_t

enum wifi_bandwidth_t

Enumerator

WIFI_BW_HT20	Bandwidth is HT20
WIFI_BW_HT40	Bandwidth is HT40

3.10.2.3 wifi_cipher_type_t

enum wifi_cipher_type_t

This enumeration defines wireless security cipher suits.

WIFI_CIPHER_TYPE_NONE	0, the cipher type is none
WIFI_CIPHER_TYPE_WEP40	1, the cipher type is WEP40
WIFI_CIPHER_TYPE_WEP104	2, the cipher type is WEP104
WIFI_CIPHER_TYPE_TKIP	3, the cipher type is TKIP
WIFI_CIPHER_TYPE_CCMP	4, the cipher type is CCMP
WIFI_CIPHER_TYPE_TKIP_CCMP	5, the cipher type is TKIP and CCMP
WIFI_CIPHER_TYPE_UNKNOWN	6, the cipher type is unknown

3.10 Enumeration 147

3.10.2.4 wifi_event_t

```
enum wifi_event_t
```

This enumeration defines the supported events generated by the Wi-Fi driver. The event will be sent to the upper layer handler registered in wifi_register_event_handler().

Enumerator

WIFI_EVENT_NONE	Reserved
WIFI_EVENT_INIT_COMPLETE	Wi-Fi initialization complete event.
WIFI_EVENT_SCAN_COMPLETE	Scan completed event
WIFI_EVENT_STA_START	station start
WIFI_EVENT_STA_STOP	station stop
WIFI_EVENT_STA_CONNECTED	station connected to AP event
WIFI_EVENT_STA_DISCONNECTED	station disconnected from AP
WIFI_EVENT_STA_CONNECTION_FAILED	Connection has failed. For the reason code, please refer to
	wifi_reason_code_t.
WIFI_EVENT_STA_GOT_IP	station got IP from connected AP
WIFI_EVENT_MAX	

3.10.2.5 wifi_mac_data_rate_t

enum wifi_mac_data_rate_t

This enumeration defines wifi mac tx data rates..

Enumerator

	WIFI_MAC_DATA_RATE_ARA	Auto Rate Adaptation
	WIFI_MAC_DATA_RATE_1M	Fix Mac Tx data rate in 1 Mbps
	WIFI_MAC_DATA_RATE_2M	Fix Mac Tx data rate in 2 Mbps
	WIFI_MAC_DATA_RATE_5_5M	Fix Mac Tx data rate in 5.5 Mbps
Ì	WIFI_MAC_DATA_RATE_11M	Fix Mac Tx data rate in 11 Mbps

3.10.2.6 wifi_mode_t

enum wifi_mode_t

WIFI_MODE_NULL	null mode
WIFI_MODE_STA	Wi-Fi station mode
WIFI_MODE_AP	Wi-Fi soft-AP mode
WIFI_MODE_MAX	

3.10.2.7 wifi_reason_code_t

enum wifi_reason_code_t

This enumeration defines the reason code of the WIFI_EVENT_STA_CONNECTION_FAILED event in wifi_event_t. Find the details for the reason code below.

0 Peneryod
0 Reserved.
1 (Internal) No AP found.
2 Previous authentication is no longer valid.
3 Deauthenticated because sending STA is leaving (or has left) IBSS or ES.
4 Disassociated due to inactivity.
5 Disassociated because AP is unable to handle all currently associated STAs.
6 Class 2 frame received from nonauthenticated STA.
7 Class 3 frame received from nonauthenticated STA.
8 Disassociated because sending STA is leaving (or has left) BSS.
9 STA requesting (re)association is not authenticated with responding STA.
10 Disassociated because the information in the Power Capability element is unacceptable.
11 Disassociated because the information in the Supported Channels element is unacceptable.
13 Invalid information element.
14 Message integrity code (MIC) failure.
15 4-Way Handshake time out.
16 Group Key Handshake time out.
17 Information element in 4-Way Handshake different from (Re)Association Request/Probe Response/Beacon frame.
18 Invalid group cipher.
19 Invalid pairwise cipher.
20 Invalid AKMP.
21 Unsupported RSN information element version.
22 Invalid RSN information element capabilities.
23 IEEE 802.1X authentication failed.
24 Cipher suite rejected because of the security policy.
200 Auto connect failed.
201 The target AP is not found.
202 Connect to AP timeout.

3.10 Enumeration 149

3.10.2.8 wifi_scan_method_t

enum wifi_scan_method_t

Enumerator

WIFI_FAST_SCAN	Do fast scan, scan will end after find SSID match AP
WIFI_ALL_CHANNEL_SCAN	All channel scan, scan will end after scan all the channel

3.10.2.9 wifi_scan_type_t

enum wifi_scan_type_t

This enumeration defines the wireless STA scan type.

Enumerator

WIFI_SCAN_TYPE_ACTIVE	Actively scan a network by sending 802.11 probe(s)
WIFI_SCAN_TYPE_PASSIVE	Passively scan a network by listening for beacons from APs
WIFI_SCAN_TYPE_MIX	Active + Passive scan

3.10.2.10 wifi_sort_method_t

enum wifi_sort_method_t

WIFI_CONNECT_AP_BY_SIGNAL	Sort match AP in scan list by RSSI
WIFI_CONNECT_AP_BY_SECURITY	Sort match AP in scan list by security mode

Chapter 4

Data Structure Documentation

4.1 _wpa_ie_data Struct Reference

```
#include <controller_wifi_com.h>
```

Data Fields

- · int capabilities
- int group_cipher
- int key_mgmt
- int mgmt_group_cipher
- size_t num_pmkid
- int pairwise_cipher
- const u8 * pmkid
- int proto

4.1.1 Field Documentation

4.1.1.1 capabilities

int capabilities

4.1.1.2 group_cipher

int group_cipher

4.1.1.3 key_mgmt int key_mgmt 4.1.1.4 mgmt_group_cipher int mgmt_group_cipher 4.1.1.5 num_pmkid size_t num_pmkid 4.1.1.6 pairwise_cipher int pairwise_cipher 4.1.1.7 pmkid const u8* pmkid 4.1.1.8 proto

4.2 asso_data Struct Reference

int proto

#include <controller_wifi_com.h>

- unsigned int eap_workaround
- int eapol_flags
- int group_cipher
- int key_mgmt
- int leap
- int mgmt_group_cipher
- int non_leap
- int pairwise_cipher
- char * passphrase
- int proto
- u8 psk [32]
- int psk_set

4.2.1 Field Documentation

4.2.1.1 eap_workaround

unsigned int eap_workaround

4.2.1.2 eapol_flags

int eapol_flags

4.2.1.3 group_cipher

int group_cipher

4.2.1.4 key_mgmt

int key_mgmt

4.2.1.5 leap

int leap

4.2.1.6 mgmt_group_cipher int mgmt_group_cipher 4.2.1.7 non_leap int non_leap 4.2.1.8 pairwise_cipher int pairwise_cipher 4.2.1.9 passphrase char* passphrase 4.2.1.10 proto int proto 4.2.1.11 psk u8 psk[32] 4.2.1.12 psk_set

4.3 auto_conn_info_t Struct Reference

int psk_set

#include <controller_wifi_com.h>

- u8 ap_channel
- u16 beacon_interval
- u8 bssid [MAC_ADDR_LEN]
- u16 capabilities
- u8 dtim_prod
- u8 fast_connect
- bool free_ocpy
- s8 hid_ssid [IEEE80211_MAX_SSID_LEN+1]
- u8 hid_ssid_len
- u64 latest_beacon_rx_time
- s8 passphrase [MAX_LEN_OF_PASSPHRASE]
- u8 psk [32]
- u8 rsn_ie [256]
- s8 rssi
- s8 ssid [IEEE80211_MAX_SSID_LEN+1]
- u8 ssid_len
- u8 supported_rates [IEEE80211_MAX_SUPPORTED_RATES]
- wpa_ie_data_t wpa_data
- u8 wpa_ie [257]

4.3.1 Field Documentation

4.3.1.1 ap_channel

u8 ap_channel

4.3.1.2 beacon_interval

ul6 beacon_interval

4.3.1.3 bssid

u8 bssid[MAC_ADDR_LEN]

4.3.1.4 capabilities

u16 capabilities

4.3.1.5 dtim_prod u8 dtim_prod 4.3.1.6 fast_connect u8 fast_connect 4.3.1.7 free_ocpy bool free_ocpy 4.3.1.8 hid_ssid s8 hid_ssid[IEEE80211_MAX_SSID_LEN+1] 4.3.1.9 hid_ssid_len u8 hid_ssid_len 4.3.1.10 latest_beacon_rx_time u64 latest_beacon_rx_time 4.3.1.11 passphrase s8 passphrase[MAX_LEN_OF_PASSPHRASE]

4.3.1.12 psk

u8 psk[32]

```
4.3.1.13 rsn_ie
u8 rsn_ie[256]
4.3.1.14 rssi
s8 rssi
4.3.1.15 ssid
s8 ssid[IEEE80211_MAX_SSID_LEN+1]
4.3.1.16 ssid_len
u8 ssid_len
4.3.1.17 supported_rates
u8 supported_rates[IEEE80211_MAX_SUPPORTED_RATES]
4.3.1.18 wpa_data
wpa_ie_data_t wpa_data
4.3.1.19 wpa_ie
u8 wpa_ie[257]
4.4 auto_connect_cfg_t Struct Reference
```

Generated by Doxygen

#include <controller_wifi_com.h>

- bool flag
- s8 front
- u8 max_save_num
- auto_conn_info_t * pFCInfo
- s8 rear
- u8 retryCount
- u8 targetldx
- u32 uFCApNum

4.4.1 Field Documentation

4.4.1.1 flag

bool flag

4.4.1.2 front

s8 front

4.4.1.3 max_save_num

u8 max_save_num

4.4.1.4 pFCInfo

auto_conn_info_t* pFCInfo

4.4.1.5 rear

s8 rear

4.4.1.6 retryCount

u8 retryCount

4.4.1.7 targetIdx

u8 targetIdx

4.4.1.8 uFCApNum

u32 uFCApNum

4.5 event_msg_t Struct Reference

Send information to event by event_msg_t.

```
#include <event_loop.h>
```

Data Fields

- uint32_t event
- uint32_t length
- uint8_t * param

4.5.1 Detailed Description

Send information to event by event_msg_t.

4.5.2 Field Documentation

4.5.2.1 event

uint32_t event

event type

4.5.2.2 length

uint32_t length

Packet length

4.5.2.3 param

uint8_t* param

event parament

4.6 hap_control_t Struct Reference

```
#include <controller_wifi_com.h>
```

Data Fields

- auto_conn_info_t * hap_ap_info
- u16 hap_bitvector
- u8 hap_en
- u8 hap_final_index
- u8 hap_index
- char hap_ssid [IEEE80211_MAX_SSID_LEN+1]

4.6.1 Field Documentation

4.6.1.1 hap_ap_info

auto_conn_info_t* hap_ap_info

4.6.1.2 hap_bitvector

u16 hap_bitvector

4.6.1.3 hap_en

u8 hap_en

4.6.1.4 hap_final_index

u8 hap_final_index

4.6.1.5 hap_index

u8 hap_index

4.6.1.6 hap_ssid

char hap_ssid[IEEE80211_MAX_SSID_LEN+1]

4.7 LE_BT_ADDR_T Struct Reference

#include <ble.h>

Data Fields

- BD_ADDR addr
- UINT8 type

4.7.1 Field Documentation

4.7.1.1 addr

BD_ADDR addr

address

4.7.1.2 type

UINT8 type

address type

Generated by Doxygen

4.8 LE_CM_CONNECTION_COMPLETE_IND_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 conn_interval
- UINT16 conn_latency
- UINT16 dev_id
- BD_ADDR peer_addr
- UINT8 peer_addr_type
- UINT8 role
- UINT16 status
- UINT16 supervison_timeout

4.8.1 Field Documentation

4.8.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.8.1.2 conn_interval

UINT16 conn_interval

connection interval

4.8.1.3 conn_latency

UINT16 conn_latency

connection latency

4.8.1.4 dev_id

UINT16 dev_id

device ID

```
4.8.1.5 peer_addr
BD_ADDR peer_addr
perr address
4.8.1.6 peer_addr_type
UINT8 peer_addr_type
peer address type
4.8.1.7 role
UINT8 role
master or slave
4.8.1.8 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
4.8.1.9 supervison_timeout
UINT16 supervison_timeout
supervision timeout
```

4.9 LE_CM_MSG_ADVERTISE_REPORT_IND_T Struct Reference

```
#include <ble_cm_if.h>
```

Data Fields

- BD_ADDR addr
- UINT8 addr_type
- UINT8 data [1]
- UINT8 event_type
- UINT8 len
- INT8 rssi

4.9.1 Field Documentation

4.9.1.1 addr BD_ADDR addr address 4.9.1.2 addr_type UINT8 addr_type address type 4.9.1.3 data UINT8 data[1] 4.9.1.4 event_type UINT8 event_type 4.9.1.5 len UINT8 len 4.9.1.6 rssi INT8 rssi **RSSI**

4.10 LE_CM_MSG_CONN_PARA_REQ_T Struct Reference

- UINT16 conn_hdl
- UINT16 itv_max
- UINT16 itv_min
- UINT16 latency
- UINT32 sv_tmo

4.10.1 Field Documentation

4.10.1.1 conn_hdl UINT16 conn_hdl connection handle 4.10.1.2 itv_max UINT16 itv_max maxinum connection interval 4.10.1.3 itv_min UINT16 itv_min mininum connection interval

4.10.1.4 latency

UINT16 latency

slave latency

4.10.1.5 sv_tmo

UINT32 sv_tmo

supervision timeout

4.11 LE_CM_MSG_CONN_UPDATE_COMPLETE_IND_T Struct Reference

- UINT16 conn_hdl
- UINT16 interval
- UINT16 latency
- UINT16 status
- UINT32 supervision_timeout

4.11.1 Field Documentation

```
4.11.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.11.1.2 interval

UINT16 interval

connection interval

4.11.1.3 latency
```

4.11.1.4 status

slave letency

UINT16 latency

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.11.1.5 supervision_timeout

UINT32 supervision_timeout

supervision timeout

4.12 LE_CM_MSG_DATA_LEN_CHANGE_IND_T Struct Reference

- UINT16 conn_hdl
- UINT16 max_rx_octets
- UINT16 max_rx_time
- UINT16 max tx octets
- UINT16 max_tx_time

4.12.1 Field Documentation

4.12.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.12.1.2 max_rx_octets

UINT16 max_rx_octets

connMaxRxOctets

4.12.1.3 max_rx_time

UINT16 max_rx_time

connMaxRxTime

4.12.1.4 max_tx_octets

UINT16 max_tx_octets

connMaxTxOctets

4.12.1.5 max_tx_time

UINT16 max_tx_time

connMaxTxTime

4.13 LE_CM_MSG_DIRECT_ADV_REPORT_IND_T Struct Reference

- BD_ADDR direct_addr
- UINT8 direct_addr_type
- BD_ADDR peer_addr
- UINT8 peer_addr_type
- INT8 rssi

4.13.1 Field Documentation

```
4.13.1.1 direct_addr

BD_ADDR direct_addr

direct address

4.13.1.2 direct_addr_type

UINT8 direct_addr_type

direct address type

4.13.1.3 peer_addr

BD_ADDR peer_addr

peer address
```

4.13.1.4 peer_addr_type

UINT8 peer_addr_type

peer address type

4.13.1.5 rssi

INT8 rssi

RSSI

4.14 LE_CM_MSG_DISCONNECT_COMPLETE_IND_T Struct Reference

- UINT16 conn_hdl
- UINT8 reason
- UINT16 status

4.14.1 Field Documentation

4.14.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.14.1.2 reason

UINT8 reason

disconnect reason

4.14.1.3 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.15 LE_CM_MSG_ENCRYPTION_CHANGE_IND_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT16 conn hdl
- UINT16 devid
- UINT8 enabled
- UINT16 status

4.15.1 Field Documentation

4.15.1.1 conn_hdl UINT16 conn_hdl

connection handle

4.15.1.2 devid

UINT16 devid

device ID

4.15.1.3 enabled

UINT8 enabled

4.15.1.4 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.16 LE_CM_MSG_ENCRYPTION_REFRESH_IND_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 devid
- BOOL enabled
- UINT16 status

4.16.1 Field Documentation

4.16.1.1 conn_hdl

UINT16 conn_hdl

connection handle

The second secon
4.16.1.2 devid
UINT16 devid
device ID
4.16.1.3 enabled
BOOL enabled
enable or disable
4.16.1.4 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
4.17 LE_CM_MSG_INIT_COMPLETE_CFM_T Struct Reference
<pre>#include <ble_cm_if.h></ble_cm_if.h></pre>
Data Fields
UINT16 status
4.17.1 Field Documentation
4.17.1.1 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
4.18 LE_CM_MSG_LTK_REQ_IND_T Struct Reference

Generated by Doxygen

#include <ble_cm_if.h>

- UINT16 conn_hdl
- UINT16 devid
- UINT16 ediv
- UINT8 rand [8]

4.18.1 Field Documentation

4.18.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.18.1.2 devid

UINT16 devid

device ID

4.18.1.3 ediv

UINT16 ediv

4.18.1.4 rand

UINT8 rand[8]

4.19 LE_CM_MSG_READ_ADV_TX_POWER_CFM_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- INT8 pwr_level
- UINT16 status

4.19.1 Field Documentation

4.19.1.1 pwr_level

INT8 pwr_level

power level

4.19.1.2 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.20 LE_CM_MSG_READ_BD_ADDR_CFM_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- BD_ADDR bd_addr
- UINT16 status

4.20.1 Field Documentation

4.20.1.1 bd_addr

BD_ADDR bd_addr

4.20.1.2 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.21 LE_CM_MSG_READ_CHANNEL_MAP_CFM_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT8 ch map [5]
- UINT16 conn_hdl
- UINT16 status

4.21.1 Field Documentation

```
4.21.1.1 ch_map
```

UINT8 ch_map[5]

channel map

4.21.1.2 conn_hdl

UINT16 conn_hdl

connection handle

4.21.1.3 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.22 LE_CM_MSG_READ_PHY_CFM_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT16 conn hdl
- UINT8 rx_phy
- UINT16 status
- UINT8 tx_phy

4.22.1 Field Documentation

4.22.1.1 conn_hdl UINT16 conn_hdl

UINT8 rx_phy

4.22.1.2 rx_phy

4.22.1.3 status

UINT16 status

4.22.1.4 tx_phy

UINT8 tx_phy

4.23 LE_CM_MSG_READ_RESOLVING_LIST_SIZE_CFM_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT8 size
- UINT16 status

4.23.1 Field Documentation

4.23.1.1 size

UINT8 size

resolving list size

4.23.1.2 status UINT16 status refer to LE_ERR_STATE in ble_err.h

4.24 LE_CM_MSG_READ_RSSI_CFM_T Struct Reference

```
#include <ble_cm_if.h>
```

Data Fields

- UINT16 conn_hdl
- INT8 rssi
- UINT16 status

4.24.1 Field Documentation

```
4.24.1.1 conn_hdl
```

UINT16 conn_hdl

connection handle

4.24.1.2 rssi

INT8 rssi

RSSI

4.24.1.3 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.25 LE_CM_MSG_READ_TX_POWER_CFM_T Struct Reference

#include <ble_cm_if.h>

- UINT16 conn_hdl
- UINT16 status
- INT8 tx_power

4.25.1 Field Documentation

4.25.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.25.1.2 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.25.1.3 tx_power

INT8 tx_power

tx power

4.26 LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT8 size
- UINT16 status

4.26.1 Field Documentation

```
4.26.1.1 size

UINT8 size

white list size

4.26.1.2 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.27 LE_CM_MSG_SET_DATA_LENGTH_CFM_T Struct Reference

#include <ble_cm_if.h>
```

- UINT16 conn_hdl
- UINT16 status

4.27.1.1 conn_hdl

4.27.1 Field Documentation

```
UINT16 conn_hdl

connection handle

4.27.1.2 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h
```

4.28 LE_CM_MSG_SET_DISCONNECT_CFM_T Struct Reference

#include <ble_cm_if.h>

- UINT16 handle
- UINT16 status

4.28.1 Field Documentation

4.28.1.1 handle

UINT16 handle

connection handle

4.28.1.2 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.29 LE_CM_MSG_SET_PHY_CFM_T Struct Reference

```
#include <ble_cm_if.h>
```

Data Fields

- UINT16 conn_hdl
- UINT16 status

4.29.1 Field Documentation

4.29.1.1 conn_hdl

UINT16 conn_hdl

4.29.1.2 status

UINT16 status

4.30 LE_CM_MSG_SIGNAL_UPDATE_REQ_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 identifier
- UINT16 interval_max
- UINT16 interval_min
- UINT16 slave_latency
- UINT32 timeout_multiplier

4.30.1 Field Documentation

4.30.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.30.1.2 identifier

UINT16 identifier

4.30.1.3 interval_max

UINT16 interval_max

maxinum connection interval

4.30.1.4 interval_min

UINT16 interval_min

mininum connection interval

4.30.1.5 slave_latency

UINT16 slave_latency

slave latency

4.30.1.6 timeout_multiplier

UINT32 timeout_multiplier

4.31 LE_CM_REQ_STATUS_T Struct Reference

#include <ble_cm_if.h>

Data Fields

• UINT16 status

4.31.1 Field Documentation

4.31.1.1 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.32 LE_CONN_PARA_T Struct Reference

#include <ble.h>

Data Fields

- UINT16 itv_max
- UINT16 itv_min
- UINT16 latency
- UINT16 sv_timeout

4.32.1 Field Documentation

4.32.1.1 itv_max

UINT16 itv_max

maxinum connection interval

4.32.1.2 itv_min

UINT16 itv_min

mininum connection interval

4.32.1.3 latency

UINT16 latency

slave latency

4.32.1.4 sv_timeout

UINT16 sv_timeout

supervision timeout

4.33 LE_GAP_ADVERTISING_PARAM_T Struct Reference

#include <ble_gap_if.h>

Data Fields

- UINT8 channel_map
- UINT8 filter_policy
- UINT16 interval_max
- UINT16 interval_min
- UINT8 own_addr_type
- BD_ADDR peer_addr
- UINT8 peer_addr_type
- UINT8 type

4.33.1 Field Documentation

4.33.1.1 channel_map

UINT8 channel_map

advertising channel map

```
4.33.1.2 filter_policy
UINT8 filter_policy
advertising filter policy
4.33.1.3 interval_max
UINT16 interval_max
maxinum advertising interval
4.33.1.4 interval_min
UINT16 interval_min
mininum advertising interval
4.33.1.5 own_addr_type
UINT8 own_addr_type
owner address type
4.33.1.6 peer_addr
BD_ADDR peer_addr
peer address
4.33.1.7 peer_addr_type
UINT8 peer_addr_type
peer address type
4.33.1.8 type
UINT8 type
advertising type
```

4.34 LE_GAP_CONN_PARAM_T Struct Reference

#include <ble_gap_if.h>

- UINT16 interval_max
- UINT16 interval_min
- UINT16 latency
- UINT16 supervision_timeout

4.34.1 Field Documentation

4.34.1.1 interval_max

UINT16 interval_max

maxinum connection interval

4.34.1.2 interval_min

UINT16 interval_min

mininum connection interval

4.34.1.3 latency

UINT16 latency

slave latency

4.34.1.4 supervision_timeout

UINT16 supervision_timeout

supervision timeout for the LE Link

4.35 LE_GAP_SCAN_PARAM_T Struct Reference

#include <ble_gap_if.h>

Data Fields

- UINT8 filter_policy
- UINT16 interval
- UINT8 own_addr_type
- UINT8 type
- UINT16 window

4.35.1 Field Documentation

4.35.1.1 filter_policy

UINT8 filter_policy

scan filter policy

4.35.1.2 interval

UINT16 interval

scan interval

4.35.1.3 own_addr_type

UINT8 own_addr_type

owner address type

4.35.1.4 type

UINT8 type

4.35.1.5 window

scan type

UINT16 window

scan window

4.36 LE_GATT_ATTR_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT8 format
- UINT16 handle
- UINT16 len
- UINT16 maxLen
- UINT16 permit
- UINT16 *const pUuid
- UINT8 *const pVal

4.36.1 Field Documentation

4.36.1.1 format
UINT8 format
UUID type
4.36.1.2 handle
UINT16 handle
handle
4.36.1.3 len
UINT16 len
value length
4.36.1.4 maxLen
UINT16 maxLen
maxinum value length
4.36.1.5 permit
UINT16 permit
permit
4.36.1.6 pUuid
UINT16* const pUuid
UUID
4.36.1.7 pVal
UINT8* const pVal
value

4.37 LE_GATT_MSG_ACCESS_READ_IND_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 devid
- UINT16 handle
- UINT16 offset

4.37.1 Field Documentation

4.37.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.37.1.2 devid

UINT16 devid

device index

4.37.1.3 handle

UINT16 handle

attribute handle

4.37.1.4 offset

UINT16 offset

attribute handle value

4.38 LE_GATT_MSG_ACCESS_WRITE_IND_T Struct Reference

#include <ble_gatt_if.h>

- UINT16 conn_hdl
- UINT16 devid
- UINT8 flag
- UINT16 handle
- UINT16 len
- UINT16 offset
- UINT8 * pVal

4.38.1 Field Documentation

```
4.38.1.1 conn_hdl
```

UINT16 conn_hdl

connection handle

4.38.1.2 devid

UINT16 devid

device ID

4.38.1.3 flag

UINT8 flag

refer to LE_GATT_FLAG_* in ble_gatt_if.h

4.38.1.4 handle

UINT16 handle

attribute handle

4.38.1.5 len

UINT16 len

length written

4.38.1.6 offset	
UINT16 offset	
attribute handle value	
4.38.1.7 pVal	
UINT8* pVal	
value written	
4.39 LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_IND_T Struct Reference	
<pre>#include <ble_gatt_if.h></ble_gatt_if.h></pre>	
Data Fields	
 UINT16 conn_hdl UINT16 devid UINT8 format UINT16 handle UINT16 uuid [8] 	
4.39.1 Field Documentation	
4.39.1.1 conn_hdl	
UINT16 conn_hdl	
connection handle	
4.39.1.2 devid	
UINT16 devid	
device ID	
4.39.1.3 format	
UINT8 format	
UUID type	

UINT16 devid

device ID

4.39.1.4 handle
UINT16 handle
characteristic descriptor handle
4.39.1.5 uuid
UINT16 uuid[8]
UUID
4.40 LE_GATT_MSG_CHARACTERISTIC_DECL_INFO_IND_T Struct Reference
<pre>#include <ble_gatt_if.h></ble_gatt_if.h></pre>
Data Fields
UINT16 conn_hdlUINT16 devid
UINT8 formatUINT16 handle
UINT8 propertyUINT16 uuid [8]
• UINT16 val_hdl
4.40.1 Field Documentation
4.40.4.4
4.40.1.1 conn_hdl
UINT16 conn_hdl
connection handle
4.40.1.2 devid

Generated by Doxygen

4.40.1.3 format UINT8 format **UUID** type 4.40.1.4 handle UINT16 handle characteristic declaration handle 4.40.1.5 property UINT8 property property 4.40.1.6 uuid UINT16 uuid[8] UUID 4.40.1.7 val_hdl UINT16 val_hdl characteristic value handle 4.41 LE_GATT_MSG_CHARACTERISTIC_VAL_IND_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT8 att_err
- UINT16 conn_hdl
- UINT16 devid
- UINT16 handle
- UINT16 len
- UINT16 offset
- UINT8 * val

value

4.41.1 Field Documentation

```
4.41.1.1 att_err
UINT8 att_err
0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h
4.41.1.2 conn_hdl
UINT16 conn_hdl
connection handle
4.41.1.3 devid
UINT16 devid
device ID
4.41.1.4 handle
UINT16 handle
characteristic value handle
4.41.1.5 len
UINT16 len
value length
4.41.1.6 offset
UINT16 offset
value position offset
4.41.1.7 val
UINT8* val
```

4.42 LE_GATT_MSG_CONFIRMATION_CFM_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 devid
- UINT16 handle

4.42.1 Field Documentation

4.42.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.42.1.2 devid

UINT16 devid

device ID

4.42.1.3 handle

UINT16 handle

attribute handle

4.43 LE_GATT_MSG_EXCHANGE_MTU_CFM_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 current_rx_mtu
- UINT16 devid

4.43.1 Field Documentation

4.43.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.43.1.2 current_rx_mtu

UINT16 current_rx_mtu

current receive MTU

4.43.1.3 devid

UINT16 devid

device ID

4.44 LE_GATT_MSG_EXCHANGE_MTU_IND_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 client_rx_mtu
- UINT16 conn_hdl
- UINT16 devid

4.44.1 Field Documentation

4.44.1.1 client_rx_mtu

UINT16 client_rx_mtu

client receive MTU

```
4.44.1.2 conn_hdl
UINT16 conn_hdl
connection handle
4.44.1.3 devid
UINT16 devid
device ID
       LE_GATT_MSG_EXECUTE_WRITE_RELIABLE_CFM_T Struct Reference
4.45
#include <ble_gatt_if.h>
Data Fields
   • UINT8 att err
   • UINT16 conn hdl

    UINT16 devid

    UINT16 err_hdl

   • UINT16 status
4.45.1 Field Documentation
4.45.1.1 att_err
UINT8 att_err
0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h
4.45.1.2 conn_hdl
UINT16 conn_hdl
connection handle
4.45.1.3 devid
UINT16 devid
```

4.45.1.4 err_hdl UINT16 err_hdl TBD 4.45.1.5 status UINT16 status refer to LE_ERR_STATE in ble_err.h

4.46 LE_GATT_MSG_FIND_ALL_CHAR_DESC_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

device ID

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

4.46.1 Field Documentation

```
4.46.1.1 att_err

UINT8 att_err

O is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

4.46.1.2 conn_hdl

UINT16 conn_hdl

connection handle

4.46.1.3 devid
```

4.46.1.4 handle UINT16 handle characteristic descriptor handle 4.46.1.5 status UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.47 LE_GATT_MSG_FIND_ALL_PRIMARY_SERVICE_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

4.47.1 Field Documentation

```
4.47.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

4.47.1.2 conn_hdl

UINT16 conn_hdl

connection handle

4.47.1.3 devid
```

4.47.1.4 handle

UINT16 handle

4.47.1.5 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.48 LE_GATT_MSG_FIND_CHARACTERISTIC_CFM_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

4.48.1 Field Documentation

4.48.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

4.48.1.2 conn_hdl

UINT16 conn_hdl

connection handle

4.48.1.3 devid

UINT16 devid

4.48.1.4 handle UINT16 handle characteristic descriptor handle 4.48.1.5 status UINT16 status

4.49 LE_GATT_MSG_FIND_INCLUDED_SERVICE_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

refer to LE_ERR_STATE in ble_err.h

Data Fields

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

4.49.1 Field Documentation

```
4.49.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

4.49.1.2 conn_hdl

UINT16 conn_hdl

connection handle

4.49.1.3 devid
```

4.49.1.4 handle UINT16 handle include service start handle 4.49.1.5 status UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.50 LE_GATT_MSG_FIND_PRIMARY_SERVICE_BY_UUID_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

device ID

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

4.50.1 Field Documentation

```
4.50.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

4.50.1.2 conn_hdl

UINT16 conn_hdl

connection handle

4.50.1.3 devid
```

4.50.1.4 handle UINT16 handle service start handle 4.50.1.5 status UINT16 status refer to LE_ERR_STATE in ble_err.h

4.51 LE_GATT_MSG_INCLUDE_SERVICE_INFO_IND_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

- UINT16 conn hdl
- UINT16 devid
- UINT16 end_hdl
- UINT8 format
- UINT16 handle
- UINT16 start_hdl
- UINT16 uuid [8]

4.51.1 Field Documentation

4.51.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.51.1.2 devid

UINT16 devid

4.51.1.3 end_hdl

UINT16 end_hdl

end handle

4.51.1.4 format

UINT8 format

UUID type

4.51.1.5 handle

UINT16 handle

include servie handle

4.51.1.6 start_hdl

UINT16 start_hdl

start handle

4.51.1.7 uuid

UINT16 uuid[8]

UUID

4.52 LE_GATT_MSG_INDICATE_IND_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

- UINT16 conn_hdl
- UINT16 devid
- UINT16 handle
- UINT16 len
- UINT8 * val

4.52.1 Field Documentation

4.52.1.1 conn_hdl
UINT16 conn_hdl
connection handle
4.52.1.2 devid
UINT16 devid
device ID
4.52.1.3 handle
UINT16 handle
attribute handle
4.52.1.4 len
UINT16 len
value length
4.52.1.5 val
UINT8* val
value
4.53 LE_GATT_MSG_NOTIFY_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

- UINT16 conn_hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

4.53.1 Field Documentation

4.53.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.53.1.2 devid

UINT16 devid

device ID

4.53.1.3 handle

UINT16 handle

attribute handle

4.53.1.4 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.54 LE_GATT_MSG_NOTIFY_IND_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 len
- UINT8 * val

4.54.1 Field Documentation

4.54.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.54.1.2 devid
UINT16 devid
device ID
4.54.1.3 handle
UINT16 handle
attribute handle
4.54.1.4 len
UINT16 len
value length
4.54.1.5 val
UINT8* val
value
4.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference
4.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference
<pre>4.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h></ble_gatt_if.h></pre>
<pre>4.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields</ble_gatt_if.h></pre>
<pre>4.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields</ble_gatt_if.h></pre>
<pre>4.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields</ble_gatt_if.h></pre>
4.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields • UINT8 att_op • UINT16 conn_hdl • UINT16 devid 4.55.1 Field Documentation</ble_gatt_if.h>

4.56.1.3 devid

UINT16 devid

```
4.55.1.2 conn_hdl
UINT16 conn_hdl
connection handle
4.55.1.3 devid
UINT16 devid
device ID
      LE_GATT_MSG_PREPARE_WRITE_RELIABLE_CFM_T Struct Reference
4.56
#include <ble_gatt_if.h>
Data Fields
   • UINT8 att err
   • UINT16 conn hdl
   • UINT16 devid
   • UINT16 handle
   • UINT16 status
4.56.1 Field Documentation
4.56.1.1 att_err
UINT8 att_err
0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h
4.56.1.2 conn_hdl
UINT16 conn_hdl
connection handle
```

4.56.1.4 handle UINT16 handle attribute handle 4.56.1.5 status UINT16 status refer to LE_ERR_STATE in ble_err.h

4.57 LE_GATT_MSG_READ_CHAR_VAL_BY_UUID_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

4.57.1 Field Documentation

```
4.57.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

4.57.1.2 conn_hdl

UINT16 conn_hdl

connection handle

4.57.1.3 devid
```

device ID

4.57.1.4 handle UINT16 handle characteristic value handle 4.57.1.5 status UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.58 LE_GATT_MSG_READ_CHARACTERISTIC_VALUE_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

device ID

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

4.58.1 Field Documentation

```
4.58.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

4.58.1.2 conn_hdl

UINT16 conn_hdl

connection handle

4.58.1.3 devid
```

4.58.1.4 handle UINT16 handle characteristic value handle 4.58.1.5 status UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.59 LE_GATT_MSG_READ_LONG_CHAR_VAL_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

4.59.1 Field Documentation

```
4.59.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

4.59.1.2 conn_hdl

UINT16 conn_hdl

connection handle

4.59.1.3 devid
```

device ID

4.59.1.4 handle

UINT16 handle

characteristic value handle

4.59.1.5 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.60 LE_GATT_MSG_READ_MULTIPLE_CHAR_VAL_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 err_hdl
- UINT16 len
- UINT16 status
- UINT8 * val

4.60.1 Field Documentation

4.60.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

4.60.1.2 conn_hdl

UINT16 conn_hdl

connection handle

```
4.60.1.3 devid
UINT16 devid
device ID
4.60.1.4 err_hdl
UINT16 err_hdl
TBD
4.60.1.5 len
UINT16 len
value length
4.60.1.6 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
4.60.1.7 val
UINT8* val
value
       LE_GATT_MSG_SERVICE_INFO_IND_T Struct Reference
4.61
```

```
#include <ble_gatt_if.h>
```

Data Fields

- UINT16 conn_hdl
- UINT16 devid
- UINT16 end_hdl
- UINT8 format
- UINT16 start_hdl
- UINT16 uuid [8]

4.61.1 Field Documentation

4.61.1.1 conn_hdl UINT16 conn_hdl connection handle 4.61.1.2 devid UINT16 devid device ID 4.61.1.3 end_hdl UINT16 end_hdl end handle 4.61.1.4 format UINT8 format **UUID** type 4.61.1.5 start_hdl UINT16 start_hdl start handle 4.61.1.6 uuid UINT16 uuid[8] UUID

4.62 LE_GATT_MSG_SIGNED_WRITE_CFM_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

4.62.1 Field Documentation

4.62.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.62.1.2 devid

UINT16 devid

device ID

4.62.1.3 handle

UINT16 handle

attribute handle

4.62.1.4 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.63 LE_GATT_MSG_WRITE_CHAR_VAL_RELIABLE_CFM_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT8 att_err
- UINT16 conn_hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

4.63.1 Field Documentation

```
4.63.1.1 att_err
UINT8 att_err
0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h
4.63.1.2 conn_hdl
UINT16 conn_hdl
connection handle
4.63.1.3 devid
UINT16 devid
device ID
4.63.1.4 handle
UINT16 handle
characteristic value handle
4.63.1.5 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
      LE_GATT_MSG_WRITE_CHAR_VALUE_CFM_T Struct Reference
4.64
```

Data Fields

- UINT8 att_err
- UINT16 conn hdl

#include <ble_gatt_if.h>

- UINT16 devid
- UINT16 handle
- UINT16 status

4.64.1 Field Documentation

```
4.64.1.1 att_err
UINT8 att_err
0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h
4.64.1.2 conn_hdl
UINT16 conn_hdl
connection handle
4.64.1.3 devid
UINT16 devid
device ID
4.64.1.4 handle
UINT16 handle
attribute handle
4.64.1.5 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
```

4.65 LE_GATT_MSG_WRITE_LONG_CHAR_VALUE_CFM_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT8 att_err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

4.65.1 Field Documentation

```
4.65.1.1 att_err
UINT8 att_err
0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h
4.65.1.2 conn_hdl
UINT16 conn_hdl
connection handle
4.65.1.3 devid
UINT16 devid
device ID
4.65.1.4 handle
UINT16 handle
characteristic value handle
4.65.1.5 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
```

4.66 LE_GATT_MSG_WRITE_NO_RSP_CFM_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

4.66.1 Field Documentation

4.66.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.66.1.2 devid

UINT16 devid

device ID

4.66.1.3 handle

UINT16 handle

attribute handle

4.66.1.4 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.67 LE_GATT_SERVICE_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 endHdl
- LE_GATT_ATTR_T * pAttr
- UINT16 startHdl
- UINT16 svc_id

4.67.1 Field Documentation

```
4.67.1.1 endHdl
UINT16 endHdl
end handle
4.67.1.2 pAttr
LE_GATT_ATTR_T* pAttr
pointer attribute table
4.67.1.3 startHdl
UINT16 startHdl
start handle
4.67.1.4 svc_id
UINT16 svc_id
service ID
      LE_SMP_MSG_ENCRYPTION_CHANGE_IND_T Struct Reference
#include <ble_smp_if.h>
Data Fields
   • UINT16 conn_hdl
   • BOOL enable
4.68.1 Field Documentation
```

4.68.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.68.1.2 enable

BOOL enable

enable or disable

4.69 LE_SMP_MSG_ENCRYPTION_REFRESH_IND_T Struct Reference

#include <ble_smp_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 status

4.69.1 Field Documentation

4.69.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.69.1.2 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.70 LE_SMP_MSG_OOB_DATA_REQUEST_IND_T Struct Reference

#include <ble_smp_if.h>

Data Fields

• UINT16 conn hdl

4.70.1 Field Documentation

4.70.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.71 LE_SMP_MSG_PAIRING_ACTION_IND_T Struct Reference

```
#include <ble_smp_if.h>
```

Data Fields

- UINT8 action
- UINT16 conn_hdl
- BOOL lost_bond
- UINT8 sc

4.71.1 Field Documentation

```
4.71.1.1 action
```

UINT8 action

refer to LE_SM_IO_CAP_* in ble_smp_if.h

4.71.1.2 conn_hdl

UINT16 conn_hdl

connection handle

4.71.1.3 lost_bond

BOOL lost_bond

remote lost bond

4.71.1.4 sc

UINT8 sc

secure connection

4.72 LE_SMP_MSG_PAIRING_COMPLETE_IND_T Struct Reference

#include <ble_smp_if.h>

Data Fields

- UINT8 authenticated
- UINT8 bonded
- UINT16 conn_hdl
- LE_BT_ADDR_T peer_id_addr
- UINT8 sc
- UINT16 status

4.72.1 Field Documentation

4.72.1.1 authenticated

UINT8 authenticated

authenticated

4.72.1.2 bonded

UINT8 bonded

bonded

4.72.1.3 conn_hdl

UINT16 conn_hdl

connection handle

4.72.1.4 peer_id_addr

LE_BT_ADDR_T peer_id_addr

peer device address

4.72.1.5 sc

UINT8 sc

secure connection

4.72.1.6 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

4.73 LE_SMP_MSG_PASSKEY_DISPLAY_IND_T Struct Reference

#include <ble_smp_if.h>

Data Fields

- UINT16 conn_hdl
- UINT32 passkey

4.73.1 Field Documentation

4.73.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.73.1.2 passkey

UINT32 passkey

passkey

4.74 LE_SMP_MSG_PASSKEY_INPUT_IND_T Struct Reference

#include <ble_smp_if.h>

Data Fields

• UINT16 conn hdl

4.74.1 Field Documentation

4.74.1.1 conn_hdl

UINT16 conn_hdl
connection handle

4.75 LE_SMP_MSG_SC_OOB_DATA_REQUEST_IND_T Struct Reference

#include <ble_smp_if.h>

Data Fields

• UINT16 conn_hdl

4.75.1 Field Documentation

4.75.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.76 LE_SMP_MSG_SLAVE_SECURITY_REQUEST_IND_T Struct Reference

#include <ble_smp_if.h>

Data Fields

- UINT8 bondable
- UINT16 conn_hdl
- UINT8 keypress
- UINT8 mitm
- UINT8 sc

4.76.1 Field Documentation

4.76.1.1 bondable UINT8 bondable bonding 4.76.1.2 conn_hdl UINT16 conn_hdl connection handle 4.76.1.3 keypress

4.76.1.4 mitm

keypress status

UINT8 mitm

MITM

4.76.1.5 sc

UINT8 sc

secure connection

4.77 LE_SMP_MSG_USER_CONFIRM_IND_T Struct Reference

```
#include <ble_smp_if.h>
```

Data Fields

- UINT32 confirm_num
- UINT16 conn_hdl

4.77.1 Field Documentation

4.77.1.1 confirm_num UINT32 confirm_num confirm number 4.77.1.2 conn_hdl UINT16 conn_hdl connection handle 4.78 LE_SMP_SC_OOB_DATA_T Struct Reference #include <ble_smp_if.h> **Data Fields** • UINT8 confirm [16] • UINT8 rand [16] 4.78.1 Field Documentation 4.78.1.1 confirm UINT8 confirm[16] confirm data 4.78.1.2 rand UINT8 rand[16]

4.79 LE_SYS_MSG_BUF_OVERFLOW_T Struct Reference

#include <ble_msg.h>

random data

Data Fields

• UINT16 conn_hdl

4.79.1 Field Documentation

4.79.1.1 conn_hdl

UINT16 conn_hdl

connection handle

4.80 mw_blewifi_cbs_store_t Struct Reference

#include <controller_wifi_com.h>

Data Fields

• uint8_t manufacture_name [STA_INFO_MAX_MANUF_NAME_SIZE]

4.80.1 Field Documentation

4.80.1.1 manufacture_name

uint8_t manufacture_name[STA_INFO_MAX_MANUF_NAME_SIZE]

4.81 mw_wifi_auto_connect_ap_info_t Struct Reference

#include <controller_wifi_com.h>

Data Fields

- u8 ap_channel
- u16 beacon_interval
- u8 bssid [MAC_ADDR_LEN]
- u16 capabilities
- u8 dtim_prod
- u8 fast_connect
- bool free_ocpy
- s8 hid_ssid [IEEE80211_MAX_SSID_LEN+1]
- u8 hid_ssid_len
- u64 latest_beacon_rx_time
- s8 passphrase [64]
- u8 psk [32]
- u8 rsn_ie [256]
- s8 rssi
- s8 ssid [IEEE80211_MAX_SSID_LEN+1]
- u8 ssid_len
- u8 supported_rates [IEEE80211_MAX_SUPPORTED_RATES]
- wpa_ie_data_t wpa_data
- u8 wpa_ie [257]

4.81.1 Field Documentation

4.81.1.1 ap_channel

u8 ap_channel

4.81.1.2 beacon_interval

ul6 beacon_interval

4.81.1.3 bssid

u8 bssid[MAC_ADDR_LEN]

4.81.1.4 capabilities

u16 capabilities

4.81.1.5 dtim_prod

u8 dtim_prod

4.81.1.6 fast_connect

u8 fast_connect

4.81.1.7 free_ocpy

bool free_ocpy

4.81.1.8 hid_ssid

s8 hid_ssid[IEEE80211_MAX_SSID_LEN+1]

4.81.1.9 hid_ssid_len

u8 hid_ssid_len

4.81.1.10 latest_beacon_rx_time

u64 latest_beacon_rx_time

4.81.1.11 passphrase

s8 passphrase[64]

4.81.1.12 psk

u8 psk[32]

```
4.81.1.13 rsn_ie
u8 rsn_ie[256]
4.81.1.14 rssi
s8 rssi
4.81.1.15 ssid
s8 ssid[IEEE80211_MAX_SSID_LEN+1]
4.81.1.16 ssid_len
u8 ssid_len
4.81.1.17 supported_rates
u8 supported_rates[IEEE80211_MAX_SUPPORTED_RATES]
4.81.1.18 wpa_data
wpa_ie_data_t wpa_data
4.81.1.19 wpa_ie
u8 wpa_ie[257]
       mw_wifi_sta_info_t Struct Reference
4.82
```

#include <controller_wifi_com.h>

Data Fields

- uint8_t au8Dot11MACAddress [MAC_ADDR_LEN]
- uint8_t u8SkipDtimPeriods

4.82.1 Field Documentation

4.82.1.1 au8Dot11MACAddress

uint8_t au8Dot11MACAddress[MAC_ADDR_LEN]

4.82.1.2 u8SkipDtimPeriods

uint8_t u8SkipDtimPeriods

4.83 MwFimAutoConnectCFG_t Struct Reference

#include <controller_wifi_com.h>

Data Fields

- bool flag
- s8 front
- u8 max_save_num
- s8 rear
- u8 targetldx

4.83.1 Field Documentation

4.83.1.1 flag

bool flag

4.83.1.2 fronts8 front

4.83.1.3 max_save_num

u8 max_save_num

4.83.1.4 rear

s8 rear

4.83.1.5 targetIdx

u8 targetIdx

4.84 rx_eapol_data Struct Reference

#include <controller_wifi_com.h>

Data Fields

- u8 frame_buffer [384]
- unsigned int frame_length

4.84.1 Field Documentation

4.84.1.1 frame_buffer

u8 frame_buffer[384]

4.84.1.2 frame_length

unsigned int frame_length

4.85 S_WIFI_MLME_SCAN_CFG Struct Reference

#include <controller_wifi_com.h>

Data Fields

- scan_report_t * ptScanReport
- E_WIFI_MLME_SCAN_TYPE tScanType
- uint32_t u32ActiveScanDur
- uint32_t u32PassiveScanDur
- uint8_t u8aBssid [MAC_ADDR_LEN]
- uint8_t u8aSsid [IEEE80211_MAX_SSID_LEN+1]
- uint8_t u8Channel
- uint8_t u8MaxScanApNum
- uint8_t u8ResendCnt

4.85.1 Detailed Description

The parameter of MLME_CMD_SCAN

4.85.2 Field Documentation

4.85.2.1 ptScanReport

scan_report_t* ptScanReport

The scan report which filled by MSQ, report to APS

4.85.2.2 tScanType

E_WIFI_MLME_SCAN_TYPE tScanType

scan type. active, passive, or mix mode

4.85.2.3 u32ActiveScanDur

uint32_t u32ActiveScanDur

Scan duration per scan counter in channel. units: millisecond

4.85.2.4 u32PassiveScanDur

uint32_t u32PassiveScanDur

Scan duration per channel. units: millisecond

4.85.2.5 u8aBssid

uint8_t u8aBssid[MAC_ADDR_LEN]

Not supported yet. MAC address of AP

4.85.2.6 u8aSsid

uint8_t u8aSsid[IEEE80211_MAX_SSID_LEN+1]

Not supported yet. SSID of AP

4.85.2.7 u8Channel

uint8_t u8Channel

Only specific channel or scan all channels

4.85.2.8 u8MaxScanApNum

uint8_t u8MaxScanApNum

Max scan AP number. When scanned AP number over this value, MSQ will drop the AP with smallest RSSI value

4.85.2.9 u8ResendCnt

uint8_t u8ResendCnt

Send probe req counter per channel when active scan. After send probe req, it will wait active scan time, and then send next probe req. The total time will be increased by a factor of this value

4.86 scan_info_t Struct Reference

#include <controller_wifi_com.h>

Data Fields

- uint8_t ap_channel
- uint16_t beacon_interval
- uint8_t bssid [MAC_ADDR_LEN]
- uint16_t capabilities
- uint8_t dtim_prod
- unsigned char free_ocpy
- uint64_t latest_beacon_rx_time
- u8 rsn_ie [256]
- int8_t rssi
- char ssid [IEEE80211_MAX_SSID_LEN+1]
- uint8_t ssid_len
- uint8_t supported_rates [IEEE80211_MAX_SUPPORTED_RATES]
- wpa_ie_data_t wpa_data
- u8 wpa_ie [257]

4.86.1 Field Documentation

4.86.1.1 ap_channel

uint8_t ap_channel

4.86.1.2 beacon_interval

uint16_t beacon_interval

4.86.1.3 bssid

uint8_t bssid[MAC_ADDR_LEN]

4.86.1.4 capabilities

uint16_t capabilities

4.86.1.5 dtim_prod uint8_t dtim_prod 4.86.1.6 free_ocpy unsigned char free_ocpy 4.86.1.7 latest_beacon_rx_time uint64_t latest_beacon_rx_time 4.86.1.8 rsn_ie u8 rsn_ie[256] 4.86.1.9 rssi int8_t rssi 4.86.1.10 ssid char ssid[IEEE80211_MAX_SSID_LEN+1] 4.86.1.11 ssid_len uint8_t ssid_len

4.86.1.12 supported_rates

uint8_t supported_rates[IEEE80211_MAX_SUPPORTED_RATES]

4.86.1.13 wpa_data

```
wpa_ie_data_t wpa_data
```

4.86.1.14 wpa_ie

u8 wpa_ie[257]

4.87 scan_report_t Struct Reference

```
#include <controller_wifi_com.h>
```

Data Fields

- scan_info_t * pScanInfo
- u32 uScanApNum

4.87.1 Field Documentation

4.87.1.1 pScanInfo

```
scan_info_t* pScanInfo
```

4.87.1.2 uScanApNum

u32 uScanApNum

4.88 T_RfCmd Struct Reference

```
#include <controller_wifi.h>
```

Data Fields

- int iArgc
- $char * saArgv [RF_CMD_PARAM_NUM]$
- uint32_t u32Type

4.88.1 Field Documentation

4.88.1.1 iArgc

int iArgc

4.88.1.2 saArgv

char* saArgv[RF_CMD_PARAM_NUM]

4.88.1.3 u32Type

uint32_t u32Type

4.89 T_RfDefEvt Struct Reference

#include <controller_wifi.h>

Data Fields

- uint32_t u32Type
- uint8_t u8aData [59]
- uint8_t u8Status

4.89.1 Field Documentation

4.89.1.1 u32Type

uint32_t u32Type

4.89.1.2 u8aData

uint8_t u8aData[59]

4.89.1.3 u8Status

uint8_t u8Status

4.90 T_RfEvt Struct Reference

```
#include <controller_wifi.h>
```

Data Fields

- int8_t i8Rssi
- void * pParam
- uint16_t u16RfMode
- uint16_t u16RxCnt
- uint16_t u16RxCrcOkCnt
- uint32_t u32Freq
- uint32_t u32Mode
- uint32_t u32RfChannel
- uint32_t u32Type
- uint8_t u8Freq
- uint8_t u8lpcEnable
- uint8_t u8Len
- uint8_t u8Phy
- uint8_t u8Pkt
- uint8_t u8Reserved
- uint8_t u8Status
- uint8_t u8Unicast

4.90.1 Field Documentation

4.90.1.1 i8Rssi

int8_t i8Rssi

4.90.1.2 pParam

void* pParam

4.90.1.3 u16RfMode

uint16_t u16RfMode

4.90.1.4 u16RxCnt

uint16_t u16RxCnt

4.90.1.5 u16RxCrcOkCnt

uint16_t u16RxCrcOkCnt

4.90.1.6 u32Freq

uint32_t u32Freq

4.90.1.7 u32Mode

uint32_t u32Mode

4.90.1.8 u32RfChannel

uint32_t u32RfChannel

4.90.1.9 u32Type

uint32_t u32Type

4.90.1.17 u8Unicast

uint8_t u8Unicast

240 **Data Structure Documentation** 4.90.1.10 u8Freq uint8_t u8Freq 4.90.1.11 u8lpcEnable uint8_t u8IpcEnable 4.90.1.12 u8Len uint8_t u8Len 4.90.1.13 u8Phy uint8_t u8Phy 4.90.1.14 u8Pkt uint8_t u8Pkt 4.90.1.15 u8Reserved uint8_t u8Reserved 4.90.1.16 u8Status uint8_t u8Status

Generated by Doxygen

4.91 wifi_active_scan_time_t Struct Reference

Range of active scan times per channel.

```
#include <wifi_types.h>
```

Data Fields

- · uint32_t max
- uint32 t min

4.91.1 Detailed Description

Range of active scan times per channel.

4.91.2 Field Documentation

4.91.2.1 max

```
uint32_t max
```

maximum active scan time per channel, units: millisecond, maximum values 1500ms may cause station to disconnect from AP and are not recommended.

4.91.2.2 min

```
uint32_t min
```

minimum active scan time per channel, units: millisecond

4.92 wifi_ap_config_t Struct Reference

This structure is the Wi-Fi configuration for initialization for Soft-AP mode.

```
#include <wifi_types.h>
```

Data Fields

- wifi_auth_mode_t auth_mode
- uint16_t beacon_interval
- uint8_t channel
- wifi_cipher_type_t encrypt_type
- uint8_t max_connection
- uint8_t password [WIFI_LENGTH_PASSPHRASE]
- uint8 t password length
- uint8_t ssid [WIFI_MAX_LENGTH_OF_SSID]
- uint8_t ssid_hidden
- uint8_t ssid_length

4.92.1 Detailed Description

This structure is the Wi-Fi configuration for initialization for Soft-AP mode.

4.92.2 Field Documentation

```
4.92.2.1 auth_mode
```

```
wifi_auth_mode_t auth_mode
```

The authentication mode.

4.92.2.2 beacon_interval

```
uint16_t beacon_interval
```

Beacon interval, $100 \sim 60000$ ms, default 100 ms

4.92.2.3 channel

uint8_t channel

The channel of Soft-AP.

4.92.2.4 encrypt_type

```
wifi_cipher_type_t encrypt_type
```

The encryption mode.

```
4.92.2.5 max_connection
uint8_t max_connection
Max number of stations allowed to connect in, default 4, max 4
4.92.2.6 password
uint8_t password[WIFI_LENGTH_PASSPHRASE]
The password of the Soft-AP.
4.92.2.7 password_length
uint8_t password_length
The length of the password.
4.92.2.8 ssid
uint8_t ssid[WIFI_MAX_LENGTH_OF_SSID]
The SSID of the Soft-AP.
4.92.2.9 ssid_hidden
uint8_t ssid_hidden
Broadcast SSID or not, default 0, broadcast the SSID
4.92.2.10 ssid_length
```

4.93 wifi_auto_connect_info_t Struct Reference

This structure is the Wi-Fi auto connect for save in the flash (FIM).

```
#include <wifi_types.h>
```

uint8_t ssid_length

The length of the SSID.

Data Fields

- uint8_t ap_channel
- uint16_t beacon_interval
- uint8_t bssid [WIFI_MAC_ADDRESS_LENGTH]
- uint16_t capabilities
- uint8_t dtim_prod
- uint8_t fast_connect
- char hid_ssid [WIFI_MAX_LENGTH_OF_SSID]
- int8_t rssi
- char ssid [WIFI_MAX_LENGTH_OF_SSID]
- uint8_t supported_rates [WIFI_MAX_SUPPORTED_RATES]

4.93.1 Detailed Description

This structure is the Wi-Fi auto connect for save in the flash (FIM).

4.93.2 Field Documentation

4.93.2.1 ap_channel

uint8_t ap_channel

4.93.2.2 beacon_interval

uint16_t beacon_interval

4.93.2.3 bssid

uint8_t bssid[WIFI_MAC_ADDRESS_LENGTH]

4.93.2.4 capabilities

uint16_t capabilities

4.93.2.5 dtim_prod

uint8_t dtim_prod

4.93.2.6 fast_connect

uint8_t fast_connect

4.93.2.7 hid_ssid

char hid_ssid[WIFI_MAX_LENGTH_OF_SSID]

4.93.2.8 rssi

int8_t rssi

4.93.2.9 ssid

char ssid[WIFI_MAX_LENGTH_OF_SSID]

4.93.2.10 supported_rates

uint8_t supported_rates[WIFI_MAX_SUPPORTED_RATES]

4.94 wifi_cmd_t Struct Reference

#include <controller_wifi.h>

Data Fields

- u32 arg1:8
- u32 arg2:16
- u32 cmd_type:8
- void * prvData

4.94.1 Field Documentation

4.94.1.1 arg1

u32 arg1

4.94.1.2 arg2

u32 arg2

4.94.1.3 cmd_type

u32 cmd_type

4.94.1.4 prvData

void* prvData

4.95 wifi_config_t Union Reference

Wi-Fi configuration for initialization.

#include <wifi_types.h>

Data Fields

- wifi_ap_config_t ap_config
- wifi_sta_config_t sta_config

4.95.1 Detailed Description

Wi-Fi configuration for initialization.

4.95.2 Field Documentation

```
4.95.2.1 ap_config
```

wifi_ap_config_t ap_config

The configurations for the AP. It should be set when the wifi_mode_t is WIFI_MODE_AP .

4.95.2.2 sta_config

```
wifi_sta_config_t sta_config
```

The configurations for the STA. It should be set when the wifi_mode_t is WIFI_MODE_STA.

4.96 wifi_event_info_t Union Reference

```
wifi_event_info_t
```

```
#include <wifi_event.h>
```

Data Fields

- wifi_event_sta_connected_t connected
- wifi_event_sta_disconnected_t disconnected
- wifi_event_sta_got_ip_t got_ip
- wifi_event_sta_scan_done_t scan_done

4.96.1 Detailed Description

```
wifi_event_info_t
```

4.96.2 Field Documentation

4.96.2.1 connected

```
wifi_event_sta_connected_t connected
```

station connected to AP

wifi_auth_mode_t authmode

```
4.96.2.2 disconnected
wifi_event_sta_disconnected_t disconnected
station disconnected to AP
4.96.2.3 got_ip
wifi_event_sta_got_ip_t got_ip
station got IP, first time got IP or when IP is changed
4.96.2.4 scan_done
wifi_event_sta_scan_done_t scan_done
station scan (APs) done
       wifi_event_sta_connected_t Struct Reference
4.97
wifi_event_sta_connected_t
#include <wifi_event.h>
Data Fields
   wifi_auth_mode_t authmode
   • uint8_t bssid [6]
   • uint8_t channel
   • uint8_t ssid [32]
   • uint8_t ssid_len
4.97.1 Detailed Description
wifi_event_sta_connected_t
4.97.2 Field Documentation
4.97.2.1 authmode
```

```
4.97.2.2 bssid
uint8_t bssid[6]
BSSID of connected AP
4.97.2.3 channel
uint8_t channel
channel of connected AP
4.97.2.4 ssid
uint8_t ssid[32]
SSID of connected AP
4.97.2.5 ssid len
uint8_t ssid_len
SSID length of connected AP
       wifi_event_sta_disconnected_t Struct Reference
4.98
wifi_event_sta_disconnected_t
#include <wifi_event.h>
Data Fields
   • uint8_t bssid [6]
   • uint8_t reason
   • uint8_t ssid [32]
```

• uint8_t ssid_len

4.98.1 Detailed Description

wifi_event_sta_disconnected_t

4.98.2 Field Documentation

4.98.2.1 bssid

uint8_t bssid[6]

BSSID of disconnected AP

4.98.2.2 reason

uint8_t reason

reason of disconnection

4.98.2.3 ssid

uint8_t ssid[32]

SSID of disconnected AP

4.98.2.4 ssid_len

uint8_t ssid_len

SSID length of disconnected AP

4.99 wifi_event_sta_got_ip_t Struct Reference

```
#include <wifi_event.h>
```

Data Fields

• bool ip_changed

4.99.1 Field Documentation

4.99.1.1 ip_changed

bool ip_changed

4.100 wifi_event_sta_scan_done_t Struct Reference

```
wifi_event_sta_scan_done_t
#include <wifi_event.h>
Data Fields
   • uint8_t number
   • uint8_t scan_id
   • uint32_t status
4.100.1 Detailed Description
wifi_event_sta_scan_done_t
4.100.2 Field Documentation
4.100.2.1 number
uint8_t number
4.100.2.2 scan_id
uint8_t scan_id
4.100.2.3 status
uint32_t status
status of scanning APs
4.101
       wifi_evt_t Struct Reference
```

#include <controller_wifi.h>

Data Fields

- uint32_t evt_type
- void * prvData

4.101.1 Field Documentation

4.101.1.1 evt_type

uint32_t evt_type

4.101.1.2 prvData

void* prvData

4.102 wifi_fast_scan_threshold_t Struct Reference

Structure describing parameters for a Wi-Fi fast scan.

```
#include <wifi_types.h>
```

Data Fields

- wifi_auth_mode_t authmode
- int8_t rssi

4.102.1 Detailed Description

Structure describing parameters for a Wi-Fi fast scan.

4.102.2 Field Documentation

4.102.2.1 authmode

wifi_auth_mode_t authmode

The weakest authmode to accept in the fast scan mode

4.102.2.2 rssi

int8_t rssi

The minimum rssi to accept in the fast scan mode

4.103 wifi_init_config_t Struct Reference

WiFi stack configuration parameters.

```
#include <wifi_types.h>
```

Data Fields

- wifi_event_notify_cb_t event_handler
- int magic

4.103.1 Detailed Description

WiFi stack configuration parameters.

4.103.2 Field Documentation

```
4.103.2.1 event_handler
```

```
wifi_event_notify_cb_t event_handler
```

WiFi event handler

4.103.2.2 magic

int magic

WiFi init magic number, it should be the last field

4.104 wifi_scan_config_t Struct Reference

Parameters for an SSID scan.

```
#include <wifi_types.h>
```

Data Fields

- uint8_t * bssid
- uint8_t channel
- wifi_scan_time_t scan_time
- wifi_scan_type_t scan_type
- bool show_hidden
- uint8_t * ssid

4.104.1 Detailed Description

Parameters for an SSID scan.

4.104.2 Field Documentation

```
4.104.2.1 bssid
```

uint8_t* bssid

MAC address of AP, point to array[WIFI_MAC_ADDRESS_LENGTH]

4.104.2.2 channel

uint8_t channel

channel, scan the specific channel

4.104.2.3 scan_time

wifi_scan_time_t scan_time

scan time per channel

4.104.2.4 scan_type

wifi_scan_type_t scan_type

scan type, active or passive

4.104.2.5 show_hidden

bool show_hidden

enable to scan AP whose SSID is hidden

```
4.104.2.6 ssid
```

uint8_t* ssid

SSID of AP

4.105 wifi_scan_info_t Struct Reference

This structure defines the inforamtion of scanned APs.

```
#include <wifi_types.h>
```

Data Fields

- wifi_auth_mode_t auth_mode
- uint16_t beacon_interval
- uint8_t bssid [WIFI_MAC_ADDRESS_LENGTH]
- uint16_t capability_info
- uint8_t channel
- uint8_t dtim_period
- wifi_cipher_type_t group_cipher
- wifi_cipher_type_t pairwise_cipher
- int rssi
- uint8_t ssid [WIFI_MAX_LENGTH_OF_SSID]
- uint8_t ssid_length

4.105.1 Detailed Description

This structure defines the inforamtion of scanned APs.

4.105.2 Field Documentation

```
4.105.2.1 auth_mode
```

```
wifi_auth_mode_t auth_mode
```

Please refer to the definition of wifi_auth_mode_t.

4.105.2.2 beacon_interval

uint16_t beacon_interval

Indicates the beacon interval.

```
4.105.2.3 bssid
```

```
uint8_t bssid[WIFI_MAC_ADDRESS_LENGTH]
```

AP's MAC address.

4.105.2.4 capability_info

```
uint16_t capability_info
```

The Capability Information field contains a number of subfields that are used to indicate requested or advertised optional capabilities.

4.105.2.5 channel

uint8_t channel

The channel used.

4.105.2.6 dtim_period

```
uint8_t dtim_period
```

The DTIM Period indicates the number of beacon intervals between successive DTIMs. If all TIMs are DTIMs, the DTIM Period field has the value 1.

4.105.2.7 group_cipher

```
wifi_cipher_type_t group_cipher
```

group cipher of AP

4.105.2.8 pairwise_cipher

```
wifi_cipher_type_t pairwise_cipher
```

pairwise cipher of AP, Please refer to the definition of #wifi_encrypt_type_t.

4.105.2.9 rssi

int rssi

Records the RSSI value when probe response is received.

```
4.105.2.10 ssid
```

```
uint8_t ssid[WIFI_MAX_LENGTH_OF_SSID]
```

Stores the predefined SSID.

4.105.2.11 ssid_length

```
uint8_t ssid_length
```

Length of the SSID.

4.106 wifi_scan_list_t Struct Reference

This structure defines the list of scanned APs with their corresponding information.

```
#include <wifi_types.h>
```

Data Fields

- wifi_scan_info_t ap_record [WIFI_MAX_SCAN_AP_NUM]
- int num

4.106.1 Detailed Description

This structure defines the list of scanned APs with their corresponding information.

4.106.2 Field Documentation

```
4.106.2.1 ap_record
```

```
wifi_scan_info_t ap_record[WIFI_MAX_SCAN_AP_NUM]
```

The information about an AP obtained through the scan result is stored

4.106.2.2 num

int num

number of AP in the list

4.107 wifi_scan_time_t Union Reference

Aggregate of active & passive scan time per channel.

```
#include <wifi_types.h>
```

Data Fields

- wifi_active_scan_time_t active
- · uint32_t passive

4.107.1 Detailed Description

Aggregate of active & passive scan time per channel.

4.107.2 Field Documentation

4.107.2.1 active

```
wifi_active_scan_time_t active
```

active scan time per channel, units: millisecond.

4.107.2.2 passive

```
uint32_t passive
```

maximum active scan time per channel, units: millisecond, maximum values 1500ms may cause station to disconnect from AP and are not recommended.

4.108 wifi_sta_config_t Struct Reference

This structure is the Wi-Fi configuration for initialization for STA mode.

```
#include <wifi_types.h>
```

Data Fields

- uint8_t bssid [WIFI_MAC_ADDRESS_LENGTH]
- uint8_t bssid_present
- uint8_t password [WIFI_LENGTH_PASSPHRASE]
- uint8_t password_length
- · wifi scan method t scan method
- wifi_sort_method_t sort_method
- uint8_t ssid [WIFI_MAX_LENGTH_OF_SSID]
- uint8_t ssid_length
- wifi_fast_scan_threshold_t threshold

4.108.1 Detailed Description

This structure is the Wi-Fi configuration for initialization for STA mode.

4.108.2 Field Documentation

```
4.108.2.1 bssid
```

```
uint8_t bssid[WIFI_MAC_ADDRESS_LENGTH]
```

The MAC address of the target AP.

```
4.108.2.2 bssid_present
```

```
uint8_t bssid_present
```

The BSSID is present if it is set to 1. Otherwise, it is set to 0.

4.108.2.3 password

```
uint8_t password[WIFI_LENGTH_PASSPHRASE]
```

The password of the target AP.

4.108.2.4 password_length

```
uint8_t password_length
```

The length of the password. If the length is 64, the password is regarded as PMK.

4.108.2.5 scan_method

```
{\tt wifi\_scan\_method\_t\ scan\_method}
```

do all channel scan or fast scan

4.108.2.6 sort_method

```
wifi_sort_method_t sort_method
```

sort the connect AP in the list by rssi or security mode

```
4.108.2.7 ssid
```

```
uint8_t ssid[WIFI_MAX_LENGTH_OF_SSID]
```

The SSID of the target AP.

4.108.2.8 ssid_length

uint8_t ssid_length

The length of the SSID.

4.108.2.9 threshold

```
wifi_fast_scan_threshold_t threshold
```

When scan_method is set to WIFI_FAST_SCAN, only APs which have an auth mode that is more secure than the selected auth mode and a signal stronger than the minimum RSSI will be used.

4.109 wifi_wpa_ie_data_t Struct Reference

This structure is the Wi-Fi auto connect with wpa information for save in the flash (FIM).

```
#include <wifi_types.h>
```

Data Fields

- · int capabilities
- int group_cipher
- int key_mgmt
- int mgmt group cipher
- · uint32_t num_pmkid
- int pairwise_cipher
- const uint8_t * pmkid
- int proto

4.109.1 Detailed Description

This structure is the Wi-Fi auto connect with wpa information for save in the flash (FIM).

4.109.2 Field Documentation

4.109.2.1 capabilities int capabilities 4.109.2.2 group_cipher int group_cipher 4.109.2.3 key_mgmt int key_mgmt 4.109.2.4 mgmt_group_cipher int mgmt_group_cipher 4.109.2.5 num_pmkid uint32_t num_pmkid 4.109.2.6 pairwise_cipher int pairwise_cipher 4.109.2.7 pmkid const uint8_t* pmkid

Generated by Doxygen

4.109.2.8 proto

int proto

Index

_wpa_ie_data, 151	LE_GATT_MSG_EXECUTE_WRITE_RELIABL↔
capabilities, 151	E_CFM_T, 195
group_cipher, 151	${\sf LE_GATT_MSG_FIND_ALL_CHAR_DESC_CF} \leftarrow$
key_mgmt, 151	M_T, 196
mgmt_group_cipher, 152	LE_GATT_MSG_FIND_ALL_PRIMARY_SERVI←
num_pmkid, 152	CE_CFM_T, 197
pairwise_cipher, 152	LE_GATT_MSG_FIND_CHARACTERISTIC_CF
pmkid, 152	M_T, 198
proto, 152	LE_GATT_MSG_FIND_INCLUDED_SERVICE_
	CFM T, 199
action	LE_GATT_MSG_FIND_PRIMARY_SERVICE_B
LE_SMP_MSG_PAIRING_ACTION_IND_T, 220	Y UUID CFM T, 200
active	LE_GATT_MSG_PREPARE_WRITE_RELIABL
wifi_scan_time_t, 258	E_CFM_T, 206
addr	LE_GATT_MSG_READ_CHAR_VAL_BY_UUID←
LE_BT_ADDR_T, 161	_CFM_T, 207
${\sf LE_CM_MSG_ADVERTISE_REPORT_IND_} {\leftarrow}$	LE_GATT_MSG_READ_CHARACTERISTIC_V
T, 164	ALUE_CFM_T, 208
addr_type	LE_GATT_MSG_READ_LONG_CHAR_VAL_C
${\sf LE_CM_MSG_ADVERTISE_REPORT_IND_} {\leftarrow}$	FM T, 209
T, 164	LE_GATT_MSG_READ_MULTIPLE_CHAR_VA←
ap_channel	L_CFM_T, 210
auto_conn_info_t, 155	LE_GATT_MSG_WRITE_CHAR_VAL_RELIAB↔
mw_wifi_auto_connect_ap_info_t, 227	LE CFM T, 214
scan_info_t, 234	LE_GATT_MSG_WRITE_CHAR_VALUE_CFM↔
wifi_auto_connect_info_t, 244	T, 215
ap_config	LE_GATT_MSG_WRITE_LONG_CHAR_VALU↔
wifi_config_t, 247	E_CFM_T, 216
ap_record	att_op
wifi_scan_list_t, 257	LE_GATT_MSG_OPERATION_TIMEOUT_T, 205
arg1	au8Dot11MACAddress
wifi_cmd_t, 246	
arg2	mw_wifi_sta_info_t, 230
wifi_cmd_t, 246	auth_mode
asso_data, 152	wifi_ap_config_t, 242
eap_workaround, 153	wifi_scan_info_t, 255
eapol_flags, 153	authenticated
group_cipher, 153	LE_SMP_MSG_PAIRING_COMPLETE_IND_T,
key_mgmt, 153	221
leap, 153	authmode
mgmt_group_cipher, 153	wifi_event_sta_connected_t, 248
non_leap, 154	wifi_fast_scan_threshold_t, 252
pairwise_cipher, 154	auto_conn_info_t, 154
passphrase, 154	ap_channel, 155
proto, 154	beacon_interval, 155
psk, 154	bssid, 155
psk_set, 154	capabilities, 155
att_err	dtim_prod, 155
LE_GATT_MSG_CHARACTERISTIC_VAL_IND↔	fast_connect, 156
_T, 192	free_ocpy, 156

hid_ssid, 156	BLE GAP APIs, 15
hid_ssid_len, 156	GAP_ADTYPE_128BIT_COMPLETE, 17
latest_beacon_rx_time, 156	GAP_ADTYPE_128BIT_MORE, 17
passphrase, 156	GAP_ADTYPE_16BIT_COMPLETE, 17
psk, 156	GAP_ADTYPE_16BIT_MORE, 18
rsn_ie, 156	GAP_ADTYPE_32BIT_COMPLETE, 18
rssi, 157	GAP_ADTYPE_32BIT_MORE, 18
ssid, 157	GAP_ADTYPE_3D_INFO_DATA, 18
ssid_len, 157	GAP_ADTYPE_ADV_INTERVAL, 18
supported_rates, 157	GAP_ADTYPE_APPEARANCE, 18
wpa_data, 157	GAP_ADTYPE_FLAGS_BREDR_NOT_SUPPO↔
wpa_ie, 157	RTED, 18
auto_connect_cfg_t, 157	GAP_ADTYPE_FLAGS_GENERAL, 19
flag, 158	GAP_ADTYPE_FLAGS_LIMITED, 19
front, 158	GAP_ADTYPE_FLAGS, 18
max_save_num, 158	GAP_ADTYPE_LE_BD_ADDR, 19
pFCInfo, 158	GAP_ADTYPE_LE_ROLE, 19
rear, 158	GAP_ADTYPE_LOCAL_NAME_COMPLETE, 19
retryCount, 158	GAP_ADTYPE_LOCAL_NAME_SHORT, 19
targetldx, 159	GAP_ADTYPE_MANUFACTURER_SPECIFIC, 19
uFCApNum, 159	GAP_ADTYPE_OOB_CLASS_OF_DEVICE, 19
BLE ALL APIs, 7	GAP_ADTYPE_OOB_SIMPLE_PAIRING_HAS↔
LeSmpGetBondIdFromAddr, 7	HC, 20
BLE CM APIs, 8	GAP_ADTYPE_OOB_SIMPLE_PAIRING_RAN↔
LE_CM_MSG_ADD_TO_RESOLVING_LIST_C	DR, 20
FM_T, 9	GAP_ADTYPE_POWER_LEVEL, 20
LE_CM_MSG_ADD_TO_WHITE_LIST_CFM_T	GAP_ADTYPE_PUBLIC_TARGET_ADDR, 20
LE_CM_MSG_CANCEL_CONNECTION_CFM_	CAD ADTVOE DANIDOM TADCET ADDD 00
a	GAP_ADTYPE_SERVICE_DATA_128BIT, 20
LE_CM_MSG_CLEAR_RESOLVING_LIST_CF	GAP_ADTYPE_SERVICE_DATA_32BIT, 20
M_T, 10	GAP_ADTYPE_SERVICE_DATA, 20
LE_CM_MSG_CLEAR_WHITE_LIST_CFM_T,	GAP_ADTYPE_SERVICES_LIST_128BIT, 21
LE_CM_MSG_CREATE_CONNECTION_CFM_	
10	GAP_ADTYPE_SIGNED_DATA, 21
LE_CM_MSG_ENTER_ADVERTISING_CFM_1	GAP_ADTYPE_SIMPLE_PAIRING_HASHC_256,
10	21
LE CM MSG ENTER SCANNING CFM T, 1	GAP_ADTYPE_SIMPLE_PAIRING_RANDR_256,
LE CM MSG EXIT ADVERTISING CFM T, 1	
LE CM MSG EXIT SCANNING CFM T, 10	GAP_ADTYPE_SLAVE_CONN_INTERVAL_RA↔
LE_CM_MSG_PHY_UPDATE_COMPLETE_IN	∠ NGE, 21
D_T, 10	GAP_ADTYPE_SM_OOB_FLAG, 21
LE_CM_MSG_REMOVE_FROM_RESOLVING	GAP_ADTYPE_SM_TK, 21
LIST_CFM_T, 11	GAP_PUBLIC_ADDR, 22
LE_CM_MSG_REMOVE_FROM_WHITE_LIST	GAP_RAND_ADDR_NRPA, 22 GAP_RAND_ADDR_NRPA, 22
_CFM_T, 11	GAP_RAND_ADDR_RPA, 22
LE CM MSG SET ADVERTISING DATA CF	GAP_RAND_ADDR_STATIC, 22
M_T, 11	GAP_SCAN_TYPE_ACTIVE, 22
LE_CM_MSG_SET_ADVERTISING_PARAMS	GAP_SCAN_TYPE_PASSIVE, 22
CFM_T, 11	GAP_TX_PWR_CURR_VAL, 22
LE_CM_MSG_SET_CHANNEL_MAP_CFM_T,	11 GAP TX PWR MAX VAL, 22
LE_CM_MSG_SET_DEFAULT_PHY_CFM_T,	
LE_CM_MSG_SET_RANDOM_ADDRESS_CF	
M_T, 11	GAPBOND IO CAP KEYBOARD DISPLAY, 23
LE_CM_MSG_SET_RPA_TIMEOUT_CFM_T,	
LE_CM_MSG_SET_SCAN_PARAMS_CFM_T,	
LE_CM_MSG_SET_SCAN_RSP_DATA_CFM_	
12	GAPBOND_PAIRING_MODE_INITIATE, 23
LeCmInit, 13	GAPBOND_PAIRING_MODE_NO_PAIRING, 23
•	

	GAPBOND_PAIRING_MODE_WAIT_FOR_REQ,	GATT_REPORT_REF_UUID, 44
	23	GATT_SECONDARY_SERVICE_UUID, 44
	LE_GAP_ADV_MAX_SIZE, 24	GATT_SERV_CHAR_CFG_UUID, 45
	LeGapAddToResolvingList, 24	GATT_VALID_RANGE_UUID, 45
	LeGapAddToWhiteList, 24	gcCharAggregateUuid, 68
	LeGapAdvertisingEnable, 25	gcCharExtPropUuid, 68
	LeGapCentralConnectReq, 25	gcCharFormatUuid, 69
	LeGapCentralSetDataChannel, 25	gcCharUserDescUuid, 69
	LeGapClearResolvingList, 27	gcCharacteristicUuid, 68
	LeGapClearWhiteList, 27	gcClientCharConfigUuid, 69
	LeGapConnParaRequestRsp, 27	gcExtReportRefUuid, 69
	LeGapConnUpdateRequest, 28	gcIncludeUuid, 69
	LeGapConnUpdateResponse, 28	gcPrimaryServiceUuid, 69
	LeGapConnectCancelReq, 27	gcReportRefUuid, 69
	LeGapDisconnectReq, 29	gcSecondaryServiceUuid, 69
	LeGapGenRandAddr, 29	gcServerCharConfigUuid, 70
	LeGapGetBtAddr, 29	gcValidRangeUuid, 70
	LeGapReadAdvChannelTxPower, 29	INCLUDE DECL UUID128, 45
	LeGapReadChannelMap, 30	INCLUDE_DECL_UUID128_ATTR_VAL, 45
	LeGapReadPhy, 30	INCLUDE_DECL_UUID16_ATTR_VAL, 45
	LeGapReadResolvingListSize, 30	INCLUDE DECL UUINT16, 45
	LeGapReadRssi, 30	LE_ATT_UUID_SIZE, 45
	LeGapReadTxPower, 31	LE_GATT_CHAR_PROP_AUTH, 46
	LeGapReadWhiteListSize, 31	LE GATT CHAR PROP BCAST, 46
	LeGapRemoveFromWhiteList, 31	LE_GATT_CHAR_PROP_EXT_PROP, 46
	LeGapScanningReq, 32	LE_GATT_CHAR_PROP_IND, 46
	LeGapSetAdvData, 32	LE_GATT_CHAR_PROP_NTF, 46
	LeGapSetAdvParameter, 33	LE_GATT_CHAR_PROP_RD, 46
	LeGapSetConnParameter, 33	LE_GATT_CHAR_PROP_WR_NO_RESP, 47
	LeGapSetDataChannelPduLen, 33	LE_GATT_CHAR_PROP_WR, 46
	LeGapSetDefaultPhy, 34	LE_GATT_CLIENT_CFG_INDICATION, 47
	LeGapSetPhy, 34	LE_GATT_CLIENT_CFG_NOTIFICATION, 47
	LeGapSetRandAddr, 34	LE_GATT_EXT_PROP_RELIABLE_WR, 47
	LeGapSetRpaTimeout, 35	LE_GATT_EXT_PROP_WR_AUX, 47
	LeGapSetStaticAddr, 35	LE_GATT_FLAG_PREPARE_WRITE, 47
	LeSetScanParameter, 35	LE_GATT_FLAG_WRITE_CMD, 47
	LeSetScanRspData, 36	LE GATT FLAG WRITE REQ, 47
RI F	GATT APIs, 37	LE_GATT_PERM_AUTH_READABLE, 48
DLL	CHAR_AGGREGATE_DESCRIPTOR, 41	LE GATT PERM AUTH WRITABLE, 48
	CHAR CLIENT CONFIG DESCRIPTOR, 41	LE GATT PERM NONE, 48
	CHAR DECL UUID16 ATTR VAL, 42	LE_GATT_PERM_READ, 48
	CHAR_EXT_PROP_DESCRIPTOR, 42	LE_GATT_PERM_RELIABLE_WRITE, 48
	CHAR_PRESENT_FORMAT_DESCRIPTOR, 42	LE GATT PERM WRITE CMD, 48
	CHAR SERVER CONFIG DESCRIPTOR, 42	LE_GATT_PERM_WRITE_REQ, 48
	CHAR_USER_DESC_DESCRIPTOR, 42	LE_GATT_PERMIT_AUTHEN_READ, 48
	CHARACTERISTIC_DECL_UUID128, 42	LE_GATT_PERMIT_AUTHEN_WRITE, 49
	CHARACTERISTIC_DECL_UUID16, 43	LE_GATT_PERMIT_AUTHOR_READ, 49
	CHARACTERISTIC_UUID128, 43	LE_GATT_FERMIT_AUTHOR_WRITE, 49
	CHARACTERISTIC_UUID16, 43	LE_GATT_PERMIT_ENCRYPT_READ, 49
	GATT_CHAR_AGG_FORMAT_UUID, 43	LE GATT PERMIT ENCRYPT WRITE, 49
	GATT_CHAR_EXT_PROPS_UUID, 43	LE GATT PERMIT READABLE, 49
	GATT_CHAR_FORMAT_UUID, 43	LE_GATT_PERMIT_READABLE, 49 LE_GATT_PERMIT_READ, 49
	GATT_CHAR_FORMAT_00ID, 43 GATT_CHAR_USER_DESC_UUID, 44	LE_GATT_PERMIT_READ, 49 LE_GATT_PERMIT_SC_AUTHEN_READ, 49
	GATT_CHARACTERISTIC_UUID, 44	LE_GATT_PERMIT_SC_AUTHEN_WRITE, 50
	GATT_CLIENT_CHAR_CFG_UUID, 44	LE_GATT_PERMIT_WRITABLE, 50
	GATT_EXT_REPORT_REF_UUID, 44	LE_GATT_PERMIT_WRITE, 50
	GATT_INCLUDE_UUID, 44	LeGattAccessReadRsp, 52
	GATT_PRIMARY_SERVICE_UUID, 44	LeGattAccessWriteRsp, 52

LeGattChangeAttrVal, 53	MESSAGE_BULID, 73
LeGattCharValConfirmation, 53	MESSAGE_DATA_BULID, 73
LeGattCharValIndicate, 54	MESSAGE_OFFSET, 74
LeGattCharValNotify, 54	MESSAGEID, 74
LeGattExchangeMtuReq, 55	MESSAGE, 74
LeGattExchangeMtuRsp, 55	MSGLOCK, 75
LeGattExecuteWriteCharValReliable, 55	MSGSUBID, 75
LeGattFindAllCharDescriptor, 56	MSGTIMER, 75
•	
LeGattFindAllCharacteristic, 56	MsgData, 75
LeGattFindAllPrimaryService, 57	MsgLock, 75
LeGattFindCharacteristicByUuid, 57	T_HOUR, 74
LeGattFindIncludedService, 58	T_MIN, 74
LeGattFindPrimaryServiceByUuid, 58	T_SEC, 74
LeGattGetAttrHandle, 58	TASKHANDLER, 75
LeGattGetAttrVal, 59	TASKPACK, 76
LeGattGetAttrValLen, 59	TASK, 75
LeGattGetAttrValMaxLen, 61	Task, 75
LeGattInit, 61	BLE SMP APIs, 83
LeGattModifyAttrVal, 62	LE_MAX_BOND_COUNT, 84
LeGattPrepareWriteCharValReliable, 62	LE SM IO CAP DISP ONLY, 84
LeGattReadCharValByUuid, 63	LE_SM_IO_CAP_DISP_YES_NO, 84
LeGattReadCharValue, 63	LE_SM_IO_CAP_KEYBOARD_DISP, 84
LeGattReadLongCharVal, 64	LE SM IO CAP KEYBOARD ONLY, 85
LeGattReadMultipleCharVal, 64	LE_SM_IO_CAP_NO_IO, 85
LeGattRegisterIncludeService, 64	LE_SM_PAIR_MITM_NO, 85
LeGattRegisterService, 65	LE_SM_PAIR_MITM_YES, 85
LeGattSignedWriteNoRsp, 65	LE_SM_PAIR_OOB_NO, 85
LeGattStopCurrentProcedure, 66	LE_SM_PAIR_OOB_YES, 85
LeGattWriteCharVal, 66	LE_SM_PAIR_SC_NO, 85
LeGattWriteCharValReliable, 67	LE_SM_PAIR_SC_YES, 85
LeGattWriteLongCharVal, 67	LeSmpInit, 87
LeGattWriteNoRsp, 68	LeSmpOobAuthDataRsp, 87
PRIMARY_SERVICE_DECL_UUID128, 50	LeSmpOobPresent, 87
PRIMARY SERVICE DECL UUID16, 50	LeSmpPasskeyInput, 88
SECONDARY_SERVICE_DECL_UUID128, 50	LeSmpScOobComputeConfirmVal, 88
SECONDARY_SERVICE_DECL_UUID16, 50	LeSmpScOobDataRsp, 88
BLE MSG APIs, 71	LeSmpSecurityReq, 89
LE ATT MSG BASE, 72	LeSmpSecurityRsp, 89
LE_CM_MSG_BASE, 72	LeSmpSetDefaultConfig, 90
LE_GATT_MSG_BASE, 72	
	LeSmpUserConfirmRsp, 90
LE_HCI_MSG_BASE, 73	bd_addr
LE_L2CAP_MSG_BASE, 73	LE_CM_MSG_READ_BD_ADDR_CFM_T, 173
LE_SMP_MSG_BASE, 73	beacon_interval
LE_SYS_MSG_BASE, 73	auto_conn_info_t, 155
LeCancelAllMessage, 76	mw_wifi_auto_connect_ap_info_t, 227
LeCancelAllSubMessage, 77	scan_info_t, 234
LeCancelFirstMessage, 77	wifi_ap_config_t, 242
LeCancelFirstSubMessage, 77	wifi_auto_connect_info_t, 244
LeGetSubMsgld, 78	wifi_scan_info_t, 255
LeHostCreateTask, 78	bondable
LeHostMessageLoop, 79	LE_SMP_MSG_SLAVE_SECURITY_REQUES←
LeSendMessage, 79	T_IND_T, 223
LeSendMessageAfter, 79	bonded
LeSendMessageUnlock, 80	LE_SMP_MSG_PAIRING_COMPLETE_IND_T,
LeSendSubMessage, 80	221
5 ·	
LeSendSubMessageAfter, 81	bssid
LeSendSubMessageUnlock, 81	auto_conn_info_t, 155
MESSAGE_ALLOCATE, 73	mw_wifi_auto_connect_ap_info_t, 227

scan_info_t, 234	conn_hdl
wifi_auto_connect_info_t, 244	LE_CM_CONNECTION_COMPLETE_IND_T, 162
wifi_event_sta_connected_t, 248	LE_CM_MSG_CONN_PARA_REQ_T, 165
wifi_event_sta_disconnected_t, 249	LE_CM_MSG_CONN_UPDATE_COMPLETE_I←
wifi_scan_config_t, 254	ND T, 166
wifi scan info t, 255	LE_CM_MSG_DATA_LEN_CHANGE_IND_T, 167
wifi_sta_config_t, 259	LE_CM_MSG_DISCONNECT_COMPLETE_IN↔
bssid_present	D T, 169
wifi_sta_config_t, 259	LE_CM_MSG_ENCRYPTION_CHANGE_IND_T,
<u></u>	169
CHAR_AGGREGATE_DESCRIPTOR	LE_CM_MSG_ENCRYPTION_REFRESH_IND_T,
BLE GATT APIs, 41	170
CHAR_CLIENT_CONFIG_DESCRIPTOR	LE_CM_MSG_LTK_REQ_IND_T, 172
BLE GATT APIs, 41	LE_CM_MSG_READ_CHANNEL_MAP_CFM_T,
CHAR_DECL_UUID16_ATTR_VAL	174
BLE GATT APIs, 42	
CHAR_EXT_PROP_DESCRIPTOR	LE_CM_MSG_READ_PHY_CFM_T, 175
BLE GATT APIs, 42	LE_CM_MSG_READ_RSSI_CFM_T, 176
CHAR_PRESENT_FORMAT_DESCRIPTOR	LE_CM_MSG_READ_TX_POWER_CFM_T, 177
BLE GATT APIs, 42	LE_CM_MSG_SET_DATA_LENGTH_CFM_T,
CHAR_SERVER_CONFIG_DESCRIPTOR	178
BLE GATT APIs, 42	LE_CM_MSG_SET_PHY_CFM_T, 179
CHAR_USER_DESC_DESCRIPTOR	LE_CM_MSG_SIGNAL_UPDATE_REQ_T, 180
BLE GATT APIs, 42	LE_GATT_MSG_ACCESS_READ_IND_T, 187
CHARACTERISTIC_DECL_UUID128	LE_GATT_MSG_ACCESS_WRITE_IND_T, 188
BLE GATT APIs, 42	${\sf LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_} {\leftarrow}$
CHARACTERISTIC_DECL_UUID16	IND_T, 189
BLE GATT APIs, 43	LE_GATT_MSG_CHARACTERISTIC_DECL_IN↔
CHARACTERISTIC_UUID128	FO_IND_T, 190
BLE GATT APIs, 43	LE_GATT_MSG_CHARACTERISTIC_VAL_IND↔
CHARACTERISTIC_UUID16	_T, 192
BLE GATT APIs, 43	LE_GATT_MSG_CONFIRMATION_CFM_T, 193
capabilities	LE_GATT_MSG_EXCHANGE_MTU_CFM_T, 194
_wpa_ie_data, 151	LE_GATT_MSG_EXCHANGE_MTU_IND_T, 194
auto_conn_info_t, 155	LE_GATT_MSG_EXECUTE_WRITE_RELIABL↔
mw_wifi_auto_connect_ap_info_t, 227	E_CFM_T, 195
scan_info_t, 234	LE_GATT_MSG_FIND_ALL_CHAR_DESC_CF↔
wifi_auto_connect_info_t, 244	M_T, 196
wifi_wpa_ie_data_t, 260	LE GATT MSG FIND ALL PRIMARY SERVI↔
capability_info	CE_CFM_T, 197
wifi_scan_info_t, 256	LE_GATT_MSG_FIND_CHARACTERISTIC_CF↔
ch_map	M T, 198
LE_CM_MSG_READ_CHANNEL_MAP_CFM_T,	LE_GATT_MSG_FIND_INCLUDED_SERVICE_↔
174	CFM_T, 199
channel	LE_GATT_MSG_FIND_PRIMARY_SERVICE_B↔
wifi_ap_config_t, 242	Y_UUID_CFM_T, 200
wifi_event_sta_connected_t, 249	LE_GATT_MSG_INCLUDE_SERVICE_INFO_I↔
wifi_scan_config_t, 254	ND_T, 201
wifi_scan_info_t, 256	LE GATT MSG INDICATE IND T, 202
channel_map	LE_GATT_MSG_NOTIFY_CFM_T, 203
	LE_GATT_MSG_NOTIFY_IND_T, 204
LE_GAP_ADVERTISING_PARAM_T, 182	LE_GATT_MSG_OPERATION_TIMEOUT_T, 205
client_rx_mtu	
LE_GATT_MSG_EXCHANGE_MTU_IND_T, 194	LE_GATT_MSG_PREPARE_WRITE_RELIABL↔
cmd_type	E_CFM_T, 206
wifi_cmd_t, 246	LE_GATT_MSG_READ_CHAR_VAL_BY_UUID↔
confirm	_CFM_T, 207
LE_SMP_SC_OOB_DATA_T, 225	LE_GATT_MSG_READ_CHARACTERISTIC_V ALUE CEM T 200
confirm_num	ALUE_CFM_T, 208
LE_SMP_MSG_USER_CONFIRM_IND_T, 224	LE_GATT_MSG_READ_LONG_CHAR_VAL_C↔

FM_T, 209	LE_GATT_MSG_EXCHANGE_MTU_IND_T, 195
LE_GATT_MSG_READ_MULTIPLE_CHAR_VA↔	LE_GATT_MSG_EXECUTE_WRITE_RELIABL←
L_CFM_T, 210	E_CFM_T, 195
LE_GATT_MSG_SERVICE_INFO_IND_T, 212	LE_GATT_MSG_FIND_ALL_CHAR_DESC_CF↔
LE_GATT_MSG_SIGNED_WRITE_CFM_T, 213	M_T, 196
LE_GATT_MSG_WRITE_CHAR_VAL_RELIAB↔ LE_CFM_T, 214	LE_GATT_MSG_FIND_ALL_PRIMARY_SERVI↔ CE_CFM_T, 197
LE_GATT_MSG_WRITE_CHAR_VALUE_CFM↔	LE_GATT_MSG_FIND_CHARACTERISTIC_CF←
_T, 215	M_T, 198
LE_GATT_MSG_WRITE_LONG_CHAR_VALU↔	LE_GATT_MSG_FIND_INCLUDED_SERVICE_
E_CFM_T, 216	CFM_T, 199
LE_GATT_MSG_WRITE_NO_RSP_CFM_T, 217	LE_GATT_MSG_FIND_PRIMARY_SERVICE_B←
LE_SMP_MSG_ENCRYPTION_CHANGE_IND↔	Y_UUID_CFM_T, 200
_T, 218	LE_GATT_MSG_INCLUDE_SERVICE_INFO_I
LE_SMP_MSG_ENCRYPTION_REFRESH_IND↔	ND_T, 201
_T, 219	LE_GATT_MSG_INDICATE_IND_T, 203
LE_SMP_MSG_OOB_DATA_REQUEST_IND_T,	LE_GATT_MSG_NOTIFY_CFM_T, 204
219	LE_GATT_MSG_NOTIFY_IND_T, 204
LE_SMP_MSG_PAIRING_ACTION_IND_T, 220	LE_GATT_MSG_OPERATION_TIMEOUT_T, 206
LE_SMP_MSG_PAIRING_COMPLETE_IND_T,	${\sf LE_GATT_MSG_PREPARE_WRITe_RELIABL} {\leftarrow}$
221	E_CFM_T, 206
LE_SMP_MSG_PASSKEY_DISPLAY_IND_T, 222	LE_GATT_MSG_READ_CHAR_VAL_BY_UUID
LE_SMP_MSG_PASSKEY_INPUT_IND_T, 222	_CFM_T, 207
LE_SMP_MSG_SC_OOB_DATA_REQUEST_I↔	${\sf LE_GATT_MSG_READ_CHARACTERISTIC_V} {\leftarrow}$
ND_T, 223	ALUE_CFM_T, 208
LE_SMP_MSG_SLAVE_SECURITY_REQUES↔	$LE_GATT_MSG_READ_LONG_CHAR_VAL_C {\hookleftarrow}$
T_IND_T, 224	FM_T, 209
LE_SMP_MSG_USER_CONFIRM_IND_T, 225	LE_GATT_MSG_READ_MULTIPLE_CHAR_VA↔
LE_SYS_MSG_BUF_OVERFLOW_T, 226	L_CFM_T, 210
conn_interval	LE_GATT_MSG_SERVICE_INFO_IND_T, 212
LE_CM_CONNECTION_COMPLETE_IND_T, 162	LE_GATT_MSG_SIGNED_WRITE_CFM_T, 213
conn_latency	LE_GATT_MSG_WRITE_CHAR_VAL_RELIAB↔
LE_CM_CONNECTION_COMPLETE_IND_T, 162	LE_CFM_T, 214
connected	${\sf LE_GATT_MSG_WRITe_CHAR_VALUE_CFM} {\leftarrow}$
wifi_event_info_t, 247	_T, 215
current_rx_mtu	${\sf LE_GATT_MSG_WRITe_LONG_CHAR_VALU} {\leftarrow}$
LE_GATT_MSG_EXCHANGE_MTU_CFM_T, 194	E_CFM_T, 216
	LE_GATT_MSG_WRITE_NO_RSP_CFM_T, 217
data	direct_addr
LE_CM_MSG_ADVERTISE_REPORT_IND_←	LE_CM_MSG_DIRECT_ADV_REPORT_IND_T,
T, 164	168
dev_id	direct_addr_type
LE_CM_CONNECTION_COMPLETE_IND_T, 162	LE_CM_MSG_DIRECT_ADV_REPORT_IND_T,
devid	168
LE_CM_MSG_ENCRYPTION_CHANGE_IND_T,	disconnected
170	wifi_event_info_t, 247
LE_CM_MSG_ENCRYPTION_REFRESH_IND_T,	dtim_period
170	wifi_scan_info_t, 256
LE_CM_MSG_LTK_REQ_IND_T, 172	dtim_prod
LE_GATT_MSG_ACCESS_READ_IND_T, 187	auto_conn_info_t, 155
LE_GATT_MSG_ACCESS_WRITE_IND_T, 188	mw_wifi_auto_connect_ap_info_t, 227
LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_	scan_info_t, 234
IND_T, 189	wifi_auto_connect_info_t, 244
LE_GATT_MSG_CHARACTERISTIC_DECL_IN↔	
FO_IND_T, 190	eap_workaround
LE_GATT_MSG_CHARACTERISTIC_VAL_IND↔	asso_data, 153
_T, 192	eapol_flags
LE_GATT_MSG_CONFIRMATION_CFM_T, 193	asso_data, 153
LE_GATT_MSG_EXCHANGE_MTU_CFM_T, 194	ediv

LE_CM_MSG_LTK_REQ_IND_T, 172	LE_GATT_ATTR_T, 186
enable	LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_←
LE_SMP_MSG_ENCRYPTION_CHANGE_IND↔ _T, 218	IND_T, 189 LE_GATT_MSG_CHARACTERISTIC_DECL_IN↔
_1, 210 enabled	FO_IND_T, 190
LE_CM_MSG_ENCRYPTION_CHANGE_IND_T,	$LE_GATT_MSG_INCLUDE_SERVICE_INFO_I {\leftarrow}$
170 LE_CM_MSG_ENCRYPTION_REFRESH_IND_T,	ND_T, 202 LE_GATT_MSG_SERVICE_INFO_IND_T, 212
171	frame buffer
encrypt_type	rx_eapol_data, 231
wifi_ap_config_t, 242	frame length
end_hdl	rx_eapol_data, 231
LE_GATT_MSG_INCLUDE_SERVICE_INFO_I↔	free_ocpy
ND_T, 201	auto_conn_info_t, 156
LE_GATT_MSG_SERVICE_INFO_IND_T, 212	mw_wifi_auto_connect_ap_info_t, 228
endHdl	scan_info_t, 235
LE_GATT_SERVICE_T, 217	front
Enumeration, 145	auto_connect_cfg_t, 158
wifi_auth_mode_t, 145	MwFimAutoConnectCFG_t, 230
wifi_bandwidth_t, 146	OAD ADTIVES ASSET COMPLETE
wifi_cipher_type_t, 146	GAP_ADTYPE_128BIT_COMPLETE
wifi_event_t, 146	BLE GAP APIs, 17 GAP ADTYPE 128BIT MORE
wifi_mac_data_rate_t, 147	BLE GAP APIs, 17
wifi_mode_t, 147	GAP_ADTYPE_16BIT_COMPLETE
wifi_reason_code_t, 148	BLE GAP APIs, 17
wifi_scan_method_t, 149	GAP_ADTYPE_16BIT_MORE
wifi_scan_type_t, 149	BLE GAP APIs, 18
wifi_sort_method_t, 149	GAP_ADTYPE_32BIT_COMPLETE
err_hdl	BLE GAP APIs, 18
LE_GATT_MSG_EXECUTE_WRITE_RELIABL↔	GAP_ADTYPE_32BIT_MORE
E_CFM_T, 195	BLE GAP APIs, 18
LE_GATT_MSG_READ_MULTIPLE_CHAR_VA↔ L CFM T, 211	GAP ADTYPE 3D INFO DATA
event	BLE GAP APIs, 18
event_msg_t, 159	GAP_ADTYPE_ADV_INTERVAL
event_handler	BLE GAP APIs, 18
wifi init config t, 253	GAP_ADTYPE_APPEARANCE
event_msg_t, 159	BLE GAP APIs, 18
event, 159	GAP_ADTYPE_FLAGS_BREDR_NOT_SUPPORTED
length, 159	BLE GAP APIs, 18
param, 160	GAP_ADTYPE_FLAGS_GENERAL
event_type	BLE GAP APIs, 19
LE_CM_MSG_ADVERTISE_REPORT_IND_←	GAP_ADTYPE_FLAGS_LIMITED
T, 164	BLE GAP APIs, 19
evt_type	GAP_ADTYPE_FLAGS
wifi_evt_t, 252	BLE GAP APIs, 18
	GAP_ADTYPE_LE_BD_ADDR
fast_connect	BLE GAP APIs, 19
auto_conn_info_t, 156	GAP_ADTYPE_LE_ROLE
mw_wifi_auto_connect_ap_info_t, 228	BLE GAP APIs, 19
wifi_auto_connect_info_t, 245	GAP_ADTYPE_LOCAL_NAME_COMPLETE
filter_policy	BLE GAP APIS, 19
LE_GAP_ADVERTISING_PARAM_T, 182	GAP_ADTYPE_LOCAL_NAME_SHORT BLE GAP APIs, 19
LE_GAP_SCAN_PARAM_T, 185 flag	GAP_ADTYPE_MANUFACTURER_SPECIFIC
auto_connect_cfg_t, 158	BLE GAP APIs, 19
LE_GATT_MSG_ACCESS_WRITE_IND_T, 188	GAP_ADTYPE_OOB_CLASS_OF_DEVICE
MwFimAutoConnectCFG t, 230	BLE GAP APIs, 19
format	GAP_ADTYPE_OOB_SIMPLE_PAIRING_HASHC

BLE GAP APIs, 20	BLE GAP APIs, 23
GAP_ADTYPE_OOB_SIMPLE_PAIRING_RANDR	GAPBOND_PAIRING_MODE_NO_PAIRING
BLE GAP APIs, 20	BLE GAP APIs, 23
GAP_ADTYPE_POWER_LEVEL	GAPBOND_PAIRING_MODE_WAIT_FOR_REQ
BLE GAP APIs, 20	BLE GAP APIs, 23
GAP_ADTYPE_PUBLIC_TARGET_ADDR	GATT_CHAR_AGG_FORMAT_UUID
BLE GAP APIs, 20	BLE GATT APIs, 43
GAP_ADTYPE_RANDOM_TARGET_ADDR	GATT_CHAR_EXT_PROPS_UUID
BLE GAP APIs, 20	BLE GATT APIs, 43
GAP_ADTYPE_SERVICE_DATA_128BIT	GATT_CHAR_FORMAT_UUID
BLE GAP APIs, 20	BLE GATT APIs, 43
GAP_ADTYPE_SERVICE_DATA_32BIT	GATT_CHAR_USER_DESC_UUID
BLE GAP APIs, 20	BLE GATT APIs, 44
GAP ADTYPE SERVICE DATA	GATT_CHARACTERISTIC_UUID
BLE GAP APIs, 20	BLE GATT APIs, 44
GAP ADTYPE SERVICES LIST 128BIT	GATT_CLIENT_CHAR_CFG_UUID
BLE GAP APIs, 21	BLE GATT APIs, 44
GAP ADTYPE SERVICES LIST 16BIT	GATT_EXT_REPORT_REF_UUID
BLE GAP APIs, 21	BLE GATT APIs, 44
GAP_ADTYPE_SIGNED_DATA	GATT_INCLUDE_UUID
BLE GAP APIs, 21	BLE GATT APIs, 44
GAP_ADTYPE_SIMPLE_PAIRING_HASHC_256	GATT PRIMARY SERVICE UUID
BLE GAP APIs, 21	BLE GATT APIs, 44
GAP_ADTYPE_SIMPLE_PAIRING_RANDR_256	GATT_REPORT_REF_UUID
BLE GAP APIs, 21	BLE GATT APIs, 44
GAP_ADTYPE_SLAVE_CONN_INTERVAL_RANGE	GATT_SECONDARY_SERVICE_UUID
BLE GAP APIs, 21	BLE GATT APIs, 44
GAP_ADTYPE_SM_OOB_FLAG	GATT_SERV_CHAR_CFG_UUID
BLE GAP APIs, 21	BLE GATT APIs, 45
GAP_ADTYPE_SM_TK	GATT_VALID_RANGE_UUID
BLE GAP APIs, 21	BLE GATT APIs, 45
GAP_PUBLIC_ADDR	gcCharAggregateUuid
BLE GAP APIs, 22	BLE GATT APIs, 68
GAP RAND ADDR NRPA	gcCharExtPropUuid
BLE GAP APIs, 22	BLE GATT APIs, 68
GAP_RAND_ADDR_RPA	gcCharFormatUuid
BLE GAP APIs, 22	
GAP_RAND_ADDR_STATIC	BLE GATT APIs, 69
BLE GAP APIs, 22	gcCharUserDescUuid BLE GATT APIs, 69
GAP_SCAN_TYPE_ACTIVE	
BLE GAP APIs, 22	gcCharacteristicUuid
GAP_SCAN_TYPE_PASSIVE	BLE GATT APIs, 68 gcClientCharConfigUuid
BLE GAP APIs, 22	BLE GATT APIs, 69
GAP_TX_PWR_CURR_VAL	gcExtReportRefUuid
BLE GAP APIs, 22	BLE GATT APIs, 69
GAP_TX_PWR_MAX_VAL	gcIncludeUuid
BLE GAP APIS, 22	BLE GATT APIs, 69
GAPBOND_IO_CAP_DISPLAY_ONLY	gcPrimaryServiceUuid
BLE GAP APIs, 23	BLE GATT APIs, 69
GAPBOND_IO_CAP_DISPLAY_YES_NO	gcReportRefUuid
BLE GAP APIS, 23	BLE GATT APIs, 69
GAPBOND_IO_CAP_KEYBOARD_DISPLAY	gcSecondaryServiceUuid
BLE GAP APIs, 23	BLE GATT APIs, 69
GAPBOND_IO_CAP_KEYBOARD_ONLY	gcServerCharConfigUuid
BLE GAP APIS, 23	BLE GATT APIs, 70
GAPBOND_IO_CAP_NO_INPUT_NO_OUTPUT	gcValidRangeUuid
BLE GAP APIS, 23	BLE GATT APIs, 70
GAPBOND_PAIRING_MODE_INITIATE	got_ip

wifi_event_info_t, 248	hap_index, 161
group_cipher	hap_ssid, 161
_wpa_ie_data, 151	hap_en
asso_data, 153	hap_control_t, 160
wifi_scan_info_t, 256	hap_final_index
wifi_wpa_ie_data_t, 261	hap_control_t, 160
handla	hap_index
handle	hap_control_t, 161
LE_CM_MSG_SET_DISCONNECT_CFM_T, 179	hap_ssid
LE_GATT_ATTR_T, 186 LE_GATT_MSG_ACCESS_READ_IND_T, 187	hap_control_t, 161
	hid_ssid
LE_GATT_MSG_ACCESS_WRITE_IND_T, 188 LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_←	auto_conn_info_t, 156
IND_T, 189	mw_wifi_auto_connect_ap_info_t, 228
LE_GATT_MSG_CHARACTERISTIC_DECL_IN↔	wifi_auto_connect_info_t, 245
FO_IND_T, 191	hid_ssid_len
LE_GATT_MSG_CHARACTERISTIC_VAL_IND↔	auto_conn_info_t, 156
_T, 192	mw_wifi_auto_connect_ap_info_t, 228
LE GATT MSG CONFIRMATION CFM T, 193	
LE GATT MSG FIND ALL CHAR DESC CF↔	i8Rssi
M T, 196	T_RfEvt, 238
LE_GATT_MSG_FIND_ALL_PRIMARY_SERVI↔	iArgc
CE_CFM_T, 197	T_RfCmd, 237
LE_GATT_MSG_FIND_CHARACTERISTIC_CF↔	INCLUDE_DECL_UUID128
M_T, 198	BLE GATT APIs, 45
LE_GATT_MSG_FIND_INCLUDED_SERVICE_←	INCLUDE_DECL_UUID128_ATTR_VAL
CFM_T, 199	BLE GATT APIs, 45
LE_GATT_MSG_FIND_PRIMARY_SERVICE_B↔	INCLUDE_DECL_UUID16_ATTR_VAL
Y_UUID_CFM_T, 200	BLE GATT APIs, 45
LE_GATT_MSG_INCLUDE_SERVICE_INFO_I↔	INCLUDE_DECL_UUINT16
ND_T, 202	BLE GATT APIs, 45
LE_GATT_MSG_INDICATE_IND_T, 203	identifier
LE_GATT_MSG_NOTIFY_CFM_T, 204	LE_CM_MSG_SIGNAL_UPDATE_REQ_T, 180
LE_GATT_MSG_NOTIFY_IND_T, 205	interval
LE_GATT_MSG_PREPARE_WRITE_RELIABL←	LE_CM_MSG_CONN_UPDATE_COMPLETE_I
E_CFM_T, 206	ND_T, 166
LE_GATT_MSG_READ_CHAR_VAL_BY_UUID↔	LE_GAP_SCAN_PARAM_T, 185
_CFM_T, 207	interval_max
${\sf LE_GATT_MSG_READ_CHARACTERISTIC_V} {\leftarrow}$	LE_CM_MSG_SIGNAL_UPDATE_REQ_T, 180
ALUE_CFM_T, 208	LE_GAP_ADVERTISING_PARAM_T, 183
$LE_GATT_MSG_READ_LONG_CHAR_VAL_C {\leftarrow}$	LE_GAP_CONN_PARAM_T, 184
FM_T, 209	interval_min
LE_GATT_MSG_SIGNED_WRITE_CFM_T, 213	LE_CM_MSG_SIGNAL_UPDATE_REQ_T, 180
LE_GATT_MSG_WRITE_CHAR_VAL_RELIAB↔	LE_GAP_ADVERTISING_PARAM_T, 183
LE_CFM_T, 214	LE_GAP_CONN_PARAM_T, 184
LE_GATT_MSG_WRITE_CHAR_VALUE_CFM←	ip_changed
_T, 215	wifi_event_sta_got_ip_t, 250
LE_GATT_MSG_WRITE_LONG_CHAR_VALU↔	itv_max
E_CFM_T, 216	LE_CM_MSG_CONN_PARA_REQ_T, 165
LE_GATT_MSG_WRITE_NO_RSP_CFM_T, 217	LE_CONN_PARA_T, 181
hap_ap_info	itv_min LE_CM_MSG_CONN_PARA_REQ_T, 165
hap_control_t, 160	LE_CONN_PARA_T, 181
hap_bitvector	LL_OOMIN_I AIM_I, 101
hap_control_t, 160	key_mgmt
hap_control_t, 160 hap_ap_info, 160	_wpa_ie_data, 151
hap_bitvector, 160	asso_data, 153
hap_en, 160	wifi_wpa_ie_data_t, 261
hap_final_index, 160	keypress

LE_SMP_MSG_SLAVE_SECURITY_REQUES↔ T_IND_T, 224	max_tx_time, 167 LE_CM_MSG_DIRECT_ADV_REPORT_IND_T, 167
1_1110_1, 224	direct_addr, 168
LE_ATT_MSG_BASE	
BLE MSG APIs, 72	direct_addr_type, 168
LE_ATT_UUID_SIZE	peer_addr, 168
BLE GATT APIs, 45	peer_addr_type, 168
LE_BT_ADDR_T, 161	rssi, 168
addr, 161	LE_CM_MSG_DISCONNECT_COMPLETE_IND_T,
type, 161	168
LE_CM_CONNECTION_COMPLETE_IND_T, 162	conn_hdl, 169
conn hdl, 162	reason, 169
conn_interval, 162	status, 169
	LE_CM_MSG_ENCRYPTION_CHANGE_IND_T, 169
conn_latency, 162	conn_hdl, 169
dev_id, 162	devid, 170
peer_addr, 162	enabled, 170
peer_addr_type, 163	status, 170
role, 163	LE_CM_MSG_ENCRYPTION_REFRESH_IND_T, 170
status, 163	conn_hdl, 170
supervison_timeout, 163	devid, 170
LE_CM_MSG_ADD_TO_RESOLVING_LIST_CFM_T	enabled, 171
BLE CM APIs, 9	status, 171
LE_CM_MSG_ADD_TO_WHITE_LIST_CFM_T	LE_CM_MSG_ENTER_ADVERTISING_CFM_T
BLE CM APIs, 9	BLE CM APIs, 10
LE_CM_MSG_ADVERTISE_REPORT_IND_T, 163	LE_CM_MSG_ENTER_SCANNING_CFM_T
addr, 164	BLE CM APIs, 10
addr_type, 164	LE_CM_MSG_EXIT_ADVERTISING_CFM_T
data, 164	BLE CM APIs, 10
event_type, 164	LE_CM_MSG_EXIT_SCANNING_CFM_T
len, 164	BLE CM APIs, 10
rssi, 164	
LE_CM_MSG_BASE	LE_CM_MSG_INIT_COMPLETE_CFM_T, 171
BLE MSG APIs, 72	status, 171
LE_CM_MSG_CANCEL_CONNECTION_CFM_T	LE_CM_MSG_LTK_REQ_IND_T, 171
BLE CM APIs, 9	conn_hdl, 172
LE_CM_MSG_CLEAR_RESOLVING_LIST_CFM_T	devid, 172
BLE CM APIs, 10	ediv, 172
LE_CM_MSG_CLEAR_WHITE_LIST_CFM_T	rand, 172
BLE CM APIs, 10	LE_CM_MSG_PHY_UPDATE_COMPLETE_IND_T
LE_CM_MSG_CONN_PARA_REQ_T, 164	BLE CM APIs, 10
conn_hdl, 165	LE_CM_MSG_READ_ADV_TX_POWER_CFM_T, 172
itv_max, 165	pwr_level, 173
itv_min, 165	status, 173
latency, 165	LE_CM_MSG_READ_BD_ADDR_CFM_T, 173
sv_tmo, 165	bd_addr, 173
LE_CM_MSG_CONN_UPDATE_COMPLETE_IND_T,	status, 173
165	LE_CM_MSG_READ_CHANNEL_MAP_CFM_T, 174
conn_hdl, 166	ch_map, 174
interval, 166	conn_hdl, 174
latency, 166	status, 174
status, 166	LE_CM_MSG_READ_PHY_CFM_T, 174
supervision_timeout, 166	conn_hdl, 175
LE_CM_MSG_CREATE_CONNECTION_CFM_T	rx_phy, 175
BLE CM APIs, 10	status, 175
LE_CM_MSG_DATA_LEN_CHANGE_IND_T, 166	tx_phy, 175
conn_hdl, 167	LE_CM_MSG_READ_RESOLVING_LIST_SIZE_CF
max_rx_octets, 167	M_T, 175
max_rx_time, 167	size, 175
max_tx_octets, 167	status, 175
ax_tx_00.010, 107	Status, 170

LE_CM_MSG_READ_RSSI_CFM_T, 176	LE_GAP_ADV_MAX_SIZE
conn_hdl, 176	BLE GAP APIs, 24
rssi, 176	LE_GAP_ADVERTISING_PARAM_T, 182
status, 176	channel_map, 182
LE_CM_MSG_READ_TX_POWER_CFM_T, 176	filter_policy, 182
conn_hdl, 177	interval_max, 183
status, 177	interval_min, 183
tx_power, 177	own_addr_type, 183
LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM_T,	peer_addr, 183
177	peer_addr_type, 183
size, 177	type, 183
status, 178	LE_GAP_CONN_PARAM_T, 183
LE_CM_MSG_REMOVE_FROM_RESOLVING_LIST←	interval_max, 184
_CFM_T	interval_min, 184
BLE CM APIs, 11	latency, 184
LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM←	supervision_timeout, 184
т	LE_GAP_SCAN_PARAM_T, 184
BLE CM APIs, 11	filter policy, 185
LE_CM_MSG_SET_ADVERTISING_DATA_CFM_T	interval, 185
BLE CM APIs, 11	own_addr_type, 185
LE_CM_MSG_SET_ADVERTISING_PARAMS_CFM↔	type, 185
T	window, 185
BLE CM APIs, 11	LE_GATT_ATTR_T, 185
LE_CM_MSG_SET_CHANNEL_MAP_CFM_T	format, 186
BLE CM APIs, 11	handle, 186
LE_CM_MSG_SET_DATA_LENGTH_CFM_T, 178	len, 186
conn_hdl, 178	maxLen, 186
status, 178	pUuid, 186
LE_CM_MSG_SET_DEFAULT_PHY_CFM_T	pVal, 186
BLE CM APIs, 11	permit, 186
LE_CM_MSG_SET_DISCONNECT_CFM_T, 178	•
handle, 179	LE_GATT_CHAR_PROP_AUTH BLE GATT APIs, 46
	LE GATT CHAR PROP BCAST
status, 179 LE_CM_MSG_SET_PHY_CFM_T, 179	BLE GATT APIs, 46
conn_hdl, 179	•
	LE_GATT_CHAR_PROP_EXT_PROP BLE GATT APIs, 46
status, 179	
LE_CM_MSG_SET_RANDOM_ADDRESS_CFM_T	LE_GATT_CHAR_PROP_IND
BLE CM APIS, 11	BLE GATT APIS, 46
LE_CM_MSG_SET_RPA_TIMEOUT_CFM_T	LE_GATT_CHAR_PROP_NTF
BLE CM APIS, 11	BLE GATT APIS, 46
LE_CM_MSG_SET_SCAN_PARAMS_CFM_T	LE_GATT_CHAR_PROP_RD
BLE CM APIs, 12	BLE GATT APIS, 46
LE_CM_MSG_SET_SCAN_RSP_DATA_CFM_T	LE_GATT_CHAR_PROP_WR_NO_RESP
BLE CM APIs, 12	BLE GATT APIs, 47
LE_CM_MSG_SIGNAL_UPDATE_REQ_T, 180	LE_GATT_CHAR_PROP_WR
conn_hdl, 180	BLE GATT APIs, 46
identifier, 180	LE_GATT_CLIENT_CFG_INDICATION
interval_max, 180	BLE GATT APIs, 47
interval_min, 180	LE_GATT_CLIENT_CFG_NOTIFICATION
slave_latency, 180	BLE GATT APIs, 47
timeout_multiplier, 180	LE_GATT_EXT_PROP_RELIABLE_WR
LE_CM_REQ_STATUS_T, 181	BLE GATT APIs, 47
status, 181	LE_GATT_EXT_PROP_WR_AUX
LE_CONN_PARA_T, 181	BLE GATT APIs, 47
itv_max, 181	LE_GATT_FLAG_PREPARE_WRITE
itv_min, 181	BLE GATT APIs, 47
latency, 182	LE_GATT_FLAG_WRITE_CMD
sv_timeout, 182	BLE GATT APIs, 47

LE_GATT_FLAG_WRITE_REQ	err_hdl, 195
BLE GATT APIs, 47	status, 196
LE_GATT_MSG_ACCESS_READ_IND_T, 187	LE_GATT_MSG_FIND_ALL_CHAR_DESC_CFM_T,
conn_hdl, 187	196
devid, 187	att_err, 196
handle, 187	conn_hdl, 196
offset, 187	devid, 196
LE_GATT_MSG_ACCESS_WRITE_IND_T, 187	handle, 196
conn_hdl, 188	status, 197
devid, 188	${\sf LE_GATT_MSG_FIND_ALL_PRIMARY_SERVICE_} \leftarrow$
flag, 188	CFM_T, 197
handle, 188	att_err, 197
len, 188	conn_hdl, 197
offset, 188	devid, 197
pVal, 189	handle, 197
LE_GATT_MSG_BASE	status, 198
BLE MSG APIs, 72	LE_GATT_MSG_FIND_CHARACTERISTIC_CFM_T,
LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_IND_T,	198
189	att_err, 198
conn_hdl, 189	conn_hdl, 198
devid, 189	devid, 198
format, 189	handle, 198
handle, 189	status, 199
uuid, 190	LE_GATT_MSG_FIND_INCLUDED_SERVICE_CFM↔
LE_GATT_MSG_CHARACTERISTIC_DECL_INFO_I↔	_T, 199
ND_T, 190	att_err, 199
conn_hdl, 190	conn_hdl, 199
devid, 190	devid, 199
format, 190	handle, 199
handle, 191	status, 200
property, 191	${\sf LE_GATT_MSG_FIND_PRIMARY_SERVICE_BY_U} \leftarrow$
uuid, 191	UID_CFM_T, 200
val_hdl, 191	att_err, 200
LE_GATT_MSG_CHARACTERISTIC_VAL_IND_T, 191	conn_hdl, 200
att_err, 192	devid, 200
conn_hdl, 192	handle, 200
devid, 192	status, 201
handle, 192	LE_GATT_MSG_INCLUDE_SERVICE_INFO_IND_T,
len, 192	201
offset, 192	conn_hdl, 201
val, 192	devid, 201
LE_GATT_MSG_CONFIRMATION_CFM_T, 193	end_hdl, 201
conn_hdl, 193	format, 202
devid, 193	handle, 202
handle, 193	start_hdl, 202
LE_GATT_MSG_EXCHANGE_MTU_CFM_T, 193	uuid, 202
conn_hdl, 194	LE_GATT_MSG_INDICATE_IND_T, 202
current_rx_mtu, 194	conn_hdl, 202
devid, 194	devid, 203
LE_GATT_MSG_EXCHANGE_MTU_IND_T, 194	handle, 203
client_rx_mtu, 194	len, 203
conn_hdl, 194	val, 203
devid, 195	LE_GATT_MSG_NOTIFY_CFM_T, 203
${\sf LE_GATT_MSG_EXECUTE_WRITe_RELIABLE_CF} \leftarrow$	conn_hdl, 203
M_T, 195	devid, 204
att_err, 195	handle, 204
conn_hdl, 195	status, 204
devid, 195	LE_GATT_MSG_NOTIFY_IND_T, 204

I II 004	LE CATT MOO WRITE OHAR VAL REHARIE O
conn_hdl, 204	LE_GATT_MSG_WRITE_CHAR_VAL_RELIABLE_C↔
devid, 204	FM_T, 213
handle, 205	att_err, 214
len, 205	conn_hdl, 214
val, 205	devid, 214
LE_GATT_MSG_OPERATION_TIMEOUT_T, 205	handle, 214
att_op, 205	status, 214
conn_hdl, 205	LE_GATT_MSG_WRITE_CHAR_VALUE_CFM_T, 214
devid, 206	att err, 215
LE GATT MSG PREPARE WRITE RELIABLE CF↔	conn_hdl, 215
M T, 206	devid, 215
att_err, 206	handle, 215
	status, 215
conn_hdl, 206	
devid, 206	LE_GATT_MSG_WRITE_LONG_CHAR_VALUE_CF↔
handle, 206	M_T, 215
status, 207	att_err, 216
LE_GATT_MSG_READ_CHAR_VAL_BY_UUID_CF↔	conn_hdl, 216
M_T, 207	devid, 216
att_err, 207	handle, 216
conn_hdl, 207	status, 216
devid, 207	LE_GATT_MSG_WRITE_NO_RSP_CFM_T, 216
handle, 207	conn_hdl, 217
status, 208	devid, 217
LE_GATT_MSG_READ_CHARACTERISTIC_VALU	handle, 217
E CFM T, 208	status, 217
att_err, 208	LE_GATT_PERM_AUTH_READABLE
conn_hdl, 208	BLE GATT APIs, 48
	LE_GATT_PERM_AUTH_WRITABLE
devid, 208	
handle, 208	BLE GATT APIS, 48
status, 209	LE_GATT_PERM_NONE
LE_GATT_MSG_READ_LONG_CHAR_VAL_CFM_T,	BLE GATT APIs, 48
209	LE_GATT_PERM_READ
att_err, 209	BLE GATT APIs, 48
conn_hdl, 209	LE_GATT_PERM_RELIABLE_WRITE
devid, 209	BLE GATT APIs, 48
handle, 209	LE_GATT_PERM_WRITE_CMD
status, 210	BLE GATT APIs, 48
LE_GATT_MSG_READ_MULTIPLE_CHAR_VAL_C←	LE_GATT_PERM_WRITE_REQ
FM_T, 210	BLE GATT APIs, 48
att_err, 210	LE_GATT_PERMIT_AUTHEN_READ
conn_hdl, 210	BLE GATT APIs, 48
devid, 210	LE_GATT_PERMIT_AUTHEN_WRITE
err_hdl, 211	BLE GATT APIs, 49
len, 211	LE_GATT_PERMIT_AUTHOR_READ
status, 211	BLE GATT APIS, 49
val, 211	LE_GATT_PERMIT_AUTHOR_WRITE
LE_GATT_MSG_SERVICE_INFO_IND_T, 211	BLE GATT APIs, 49
conn_hdl, 212	LE_GATT_PERMIT_ENCRYPT_READ
devid, 212	BLE GATT APIs, 49
end_hdl, 212	LE_GATT_PERMIT_ENCRYPT_WRITE
format, 212	BLE GATT APIs, 49
start_hdl, 212	LE_GATT_PERMIT_READABLE
uuid, 212	BLE GATT APIs, 49
LE_GATT_MSG_SIGNED_WRITE_CFM_T, 212	LE_GATT_PERMIT_READ
conn_hdl, 213	BLE GATT APIs, 49
devid, 213	LE_GATT_PERMIT_SC_AUTHEN_READ
handle, 213	BLE GATT APIs, 49
status, 213	LE_GATT_PERMIT_SC_AUTHEN_WRITE
31a1u3, <u>210</u>	FF_QVII THMII 20 VOIHEN MUHE

BLE GATT APIs, 50	peer_id_addr, 221
LE_GATT_PERMIT_WRITABLE	sc, 221
BLE GATT APIs, 50	status, 221
LE_GATT_PERMIT_WRITE	LE_SMP_MSG_PASSKEY_DISPLAY_IND_T, 222
BLE GATT APIs, 50	conn_hdl, 222
LE_GATT_SERVICE_T, 217	passkey, 222
endHdl, 217	LE_SMP_MSG_PASSKEY_INPUT_IND_T, 222
pAttr, 218	conn_hdl, 222
startHdl, 218	LE_SMP_MSG_SC_OOB_DATA_REQUEST_IND_T,
svc_id, 218	223
LE_HCI_MSG_BASE	conn_hdl, 223
BLE MSG APIs, 73	LE_SMP_MSG_SLAVE_SECURITY_REQUEST_IN⊷
LE_L2CAP_MSG_BASE	D T, 223
BLE MSG APIs, 73	bondable, 223
LE_MAX_BOND_COUNT	conn_hdl, 224
BLE SMP APIs, 84	keypress, 224
LE_SM_IO_CAP_DISP_ONLY	mitm, 224
BLE SMP APIs, 84	sc, 224
LE_SM_IO_CAP_DISP_YES_NO	LE_SMP_MSG_USER_CONFIRM_IND_T, 224
BLE SMP APIs, 84	confirm_num, 224
LE_SM_IO_CAP_KEYBOARD_DISP	conn hdl, 225
BLE SMP APIs, 84	LE_SMP_SC_OOB_DATA_T, 225
LE_SM_IO_CAP_KEYBOARD_ONLY	confirm, 225
BLE SMP APIs, 85	rand, 225
LE_SM_IO_CAP_NO_IO	LE_SYS_MSG_BASE
BLE SMP APIs, 85	BLE MSG APIs, 73
LE_SM_PAIR_MITM_NO	LE_SYS_MSG_BUF_OVERFLOW_T, 225
BLE SMP APIs, 85	conn_hdl, 226
LE_SM_PAIR_MITM_YES	latency
BLE SMP APIs, 85	LE_CM_MSG_CONN_PARA_REQ_T, 165
LE_SM_PAIR_OOB_NO	LE_CM_MSG_CONN_UPDATE_COMPLETE_I↔
BLE SMP APIs, 85	ND_T, 166
LE_SM_PAIR_OOB_YES	LE_CONN_PARA_T, 182
BLE SMP APIs, 85	LE GAP CONN PARAM T, 184
LE_SM_PAIR_SC_NO	latest_beacon_rx_time
BLE SMP APIs, 85	auto_conn_info_t, 156
LE_SM_PAIR_SC_YES	mw_wifi_auto_connect_ap_info_t, 228
BLE SMP APIs, 85	scan_info_t, 235
LE_SMP_MSG_BASE	LeCancelAllMessage
BLE MSG APIs, 73	BLE MSG APIs, 76
LE_SMP_MSG_ENCRYPTION_CHANGE_IND_T, 218	LeCancelAllSubMessage
conn_hdl, 218	BLE MSG APIs, 77
enable, 218	LeCancelFirstMessage
LE_SMP_MSG_ENCRYPTION_REFRESH_IND_T,	BLE MSG APIs, 77
219	LeCancelFirstSubMessage
conn_hdl, 219	BLE MSG APIs, 77
status, 219	LeCmInit
LE_SMP_MSG_OOB_DATA_REQUEST_IND_T, 219	BLE CM APIs, 13
conn_hdl, 219	LeGapAddToResolvingList
LE_SMP_MSG_PAIRING_ACTION_IND_T, 220	BLE GAP APIs, 24
action, 220	LeGapAddToWhiteList
conn_hdl, 220	BLE GAP APIs, 24
lost_bond, 220	LeGapAdvertisingEnable
sc, 220	BLE GAP APIs, 25
LE_SMP_MSG_PAIRING_COMPLETE_IND_T, 221	LeGapCentralConnectReq
authenticated, 221	BLE GAP APIs, 25
bonded, 221	LeGapCentralSetDataChannel
conn_hdl, 221	BLE GAP APIs, 25
-	

LeGapClearResolvingList	LeGattChangeAttrVal
BLE GAP APIs, 27	BLE GATT APIs, 53
LeGapClearWhiteList	LeGattCharValConfirmation
BLE GAP APIs, 27	BLE GATT APIs, 53
LeGapConnParaRequestRsp	LeGattCharValIndicate
BLE GAP APIs, 27	BLE GATT APIs, 54
LeGapConnUpdateRequest	LeGattCharValNotify
BLE GAP APIs, 28	BLE GATT APIs, 54
LeGapConnUpdateResponse	LeGattExchangeMtuReq
BLE GAP APIs, 28	BLE GATT APIs, 55
LeGapConnectCancelReg	LeGattExchangeMtuRsp
BLE GAP APIs, 27	BLE GATT APIs, 55
LeGapDisconnectReq	LeGattExecuteWriteCharValReliable
BLE GAP APIs, 29	BLE GATT APIs, 55
LeGapGenRandAddr	LeGattFindAllCharDescriptor
BLE GAP APIs, 29	BLE GATT APIs, 56
LeGapGetBtAddr	LeGattFindAllCharacteristic
BLE GAP APIs, 29	BLE GATT APIs, 56
LeGapReadAdvChannelTxPower	LeGattFindAllPrimaryService
•	
BLE GAP APIs, 29	BLE GATT APIs, 57
LeGapReadChannelMap	LeGattFindCharacteristicByUuid
BLE GAP APIs, 30	BLE GATT APIs, 57
LeGapReadPhy	LeGattFindIncludedService
BLE GAP APIs, 30	BLE GATT APIs, 58
LeGapReadResolvingListSize	LeGattFindPrimaryServiceByUuid
BLE GAP APIs, 30	BLE GATT APIs, 58
LeGapReadRssi	LeGattGetAttrHandle
BLE GAP APIs, 30	BLE GATT APIs, 58
LeGapReadTxPower	LeGattGetAttrVal
BLE GAP APIs, 31	BLE GATT APIs, 59
LeGapReadWhiteListSize	LeGattGetAttrValLen
BLE GAP APIs, 31	BLE GATT APIs, 59
LeGapRemoveFromWhiteList	LeGattGetAttrValMaxLen
BLE GAP APIs, 31	BLE GATT APIs, 61
LeGapScanningReq	LeGattInit
BLE GAP APIs, 32	BLE GATT APIs, 61
LeGapSetAdvData	LeGattModifyAttrVal
BLE GAP APIs, 32	BLE GATT APIs, 62
LeGapSetAdvParameter	LeGattPrepareWriteCharValReliable
BLE GAP APIs, 33	BLE GATT APIs, 62
LeGapSetConnParameter	LeGattReadCharValByUuid
BLE GAP APIs, 33	BLE GATT APIs, 63
LeGapSetDataChannelPduLen	LeGattReadCharValue
BLE GAP APIs, 33	BLE GATT APIs, 63
LeGapSetDefaultPhy	LeGattReadLongCharVal
BLE GAP APIs, 34	BLE GATT APIs, 64
LeGapSetPhy	LeGattReadMultipleCharVal
BLE GAP APIs, 34	BLE GATT APIs, 64
LeGapSetRandAddr	LeGattRegisterIncludeService
BLE GAP APIs, 34	BLE GATT APIs, 64
LeGapSetRpaTimeout	LeGattRegisterService
BLE GAP APIs, 35	BLE GATT APIs, 65
LeGapSetStaticAddr	LeGattSignedWriteNoRsp
BLE GAP APIs, 35	BLE GATT APIs, 65
LeGattAccessReadRsp	LeGattStopCurrentProcedure
BLE GATT APIs, 52	BLE GATT APIs, 66
LeGattAccessWriteRsp	LeGattWriteCharVal
•	
BLE GATT APIs, 52	BLE GATT APIs, 66

LeGattWriteCharValRe		${\sf LE_GATT_MSG_CHARACTERISTIC_VAL_IND} {\leftarrow}$
BLE GATT APIs,	67	_T, 192
LeGattWriteLongChar\	√al	LE_GATT_MSG_INDICATE_IND_T, 203
BLE GATT APIs,	67	LE_GATT_MSG_NOTIFY_IND_T, 205
LeGattWriteNoRsp		LE_GATT_MSG_READ_MULTIPLE_CHAR_VA
BLE GATT APIs,	68	L_CFM_T, 211
LeGetSubMsgld		length
BLE MSG APIs, 7	78	event_msg_t, 159
LeHostCreateTask		lost_bond
BLE MSG APIs, 7	7 8	LE_SMP_MSG_PAIRING_ACTION_IND_T, 220
LeHostMessageLoop		MESSAGE ALLOCATE
BLE MSG APIs, 7	' 9	BLE MSG APIs, 73
LeSendMessage		MESSAGE BULID
BLE MSG APIs, 7	' 9	BLE MSG APIs, 73
LeSendMessageAfter		MESSAGE_DATA_BULID
BLE MSG APIs, 7	79	BLE MSG APIs, 73
LeSendMessageUnloc		MESSAGE_OFFSET
BLE MSG APIs, 8		BLE MSG APIs, 74
LeSendSubMessage		MESSAGEID
BLE MSG APIs, 8	30	BLE MSG APIs, 74
LeSendSubMessageA		MESSAGE
BLE MSG APIs, 8		BLE MSG APIs, 74
LeSendSubMessageU		MSGLOCK
BLE MSG APIs, 8		BLE MSG APIs, 75
LeSetScanParameter		MSGSUBID
BLE GAP APIs, 3	F	BLE MSG APIs, 75
	3	MSGTIMER
LeSetScanRspData	6	BLE MSG APIs, 75
BLE GAP APIs, 3		magic
LeSmpGetBondIdFrom	iAddr	wifi_init_config_t, 253
BLE ALL APIs, 7		manufacture_name
LeSmpInit	-	mw_blewifi_cbs_store_t, 226
BLE SMP APIs, 8		max
LeSmpOobAuthDataR	•	wifi_active_scan_time_t, 241
BLE SMP APIs, 8	17	max_connection
LeSmpOobPresent		wifi_ap_config_t, 242
BLE SMP APIs, 8	7	max_rx_octets
LeSmpPasskeyInput		LE CM MSG DATA LEN CHANGE IND T, 167
BLE SMP APIs, 8		max_rx_time
LeSmpScOobCompute		LE_CM_MSG_DATA_LEN_CHANGE_IND_T, 167
BLE SMP APIs, 8		max save num
LeSmpScOobDataRsp		auto_connect_cfg_t, 158
BLE SMP APIs, 8	8	MwFimAutoConnectCFG_t, 231
LeSmpSecurityReq		max_tx_octets
BLE SMP APIs, 8	9	LE_CM_MSG_DATA_LEN_CHANGE_IND_T, 167
LeSmpSecurityRsp		max tx time
BLE SMP APIs, 8	9	LE_CM_MSG_DATA_LEN_CHANGE_IND_T, 167
LeSmpSetDefaultConf	ig	maxLen
BLE SMP APIs, 9	0	LE_GATT_ATTR_T, 186
LeSmpUserConfirmRs	р	mgmt_group_cipher
BLE SMP APIs, 9	0	_wpa_ie_data, 152
leap		asso_data, 153
asso_data, 153		wifi_wpa_ie_data_t, 261
len		min
LE_CM_MSG_AD	OVERTISE_REPORT_IND_←	wifi_active_scan_time_t, 241
T, 164	-	mitm
LE_GATT_ATTR	_T, 186	LE_SMP_MSG_SLAVE_SECURITY_REQUES↔
	ACCESS_WRITE_IND_T, 188	T_IND_T, 224

MsgData	pParam
BLE MSG APIs, 75	T_RfEvt, 238
MsgLock	PRIMARY_SERVICE_DECL_UUID128
BLE MSG APIs, 75	BLE GATT APIs, 50
mw_blewifi_cbs_store_t, 226	PRIMARY_SERVICE_DECL_UUID16
manufacture_name, 226	BLE GATT APIs, 50
mw_wifi_auto_connect_ap_info_t, 226	pScanInfo
ap_channel, 227	scan_report_t, 236
beacon_interval, 227	pUuid
bssid, 227	LE_GATT_ATTR_T, 186
capabilities, 227	pVal
dtim_prod, 227	LE GATT ATTR T, 186
fast_connect, 228	LE_GATT_MSG_ACCESS_WRITE_IND_T, 189
free_ocpy, 228	pairwise_cipher
hid_ssid, 228	_wpa_ie_data, 152
hid_ssid_len, 228	asso_data, 154
latest_beacon_rx_time, 228	
passphrase, 228	wifi_scan_info_t, 256
psk, 228	wifi_wpa_ie_data_t, 261
rsn_ie, 228	param
rssi, 229	event_msg_t, 160
	passive
ssid, 229	wifi_scan_time_t, 258
ssid_len, 229	passkey
supported_rates, 229	LE_SMP_MSG_PASSKEY_DISPLAY_IND_T, 222
wpa_data, 229	passphrase
wpa_ie, 229	asso_data, 154
mw_wifi_sta_info_t, 229	auto_conn_info_t, 156
au8Dot11MACAddress, 230	mw_wifi_auto_connect_ap_info_t, 228
u8SkipDtimPeriods, 230	password
MwFimAutoConnectCFG_t, 230	wifi_ap_config_t, 243
flag, 230	wifi_sta_config_t, 259
front, 230	password_length
max_save_num, 231	wifi_ap_config_t, 243
rear, 231	wifi sta config t, 259
targetldx, 231	peer_addr
	LE CM CONNECTION COMPLETE IND T, 162
non_leap	LE_CM_MSG_DIRECT_ADV_REPORT_IND_T,
asso_data, 154	168
num	LE_GAP_ADVERTISING_PARAM_T, 183
wifi_scan_list_t, 257	
num_pmkid	peer_addr_type
_wpa_ie_data, 152	LE_CM_CONNECTION_COMPLETE_IND_T, 163
wifi_wpa_ie_data_t, 261	LE_CM_MSG_DIRECT_ADV_REPORT_IND_T,
number	168
wifi_event_sta_scan_done_t, 251	LE_GAP_ADVERTISING_PARAM_T, 183
	peer_id_addr
offset	LE_SMP_MSG_PAIRING_COMPLETE_IND_T,
LE_GATT_MSG_ACCESS_READ_IND_T, 187	221
LE_GATT_MSG_ACCESS_WRITE_IND_T, 188	permit
LE_GATT_MSG_CHARACTERISTIC_VAL_IND↔	LE_GATT_ATTR_T, 186
T, 192	pmkid
own_addr_type	_wpa_ie_data, 152
LE_GAP_ADVERTISING_PARAM_T, 183	wifi_wpa_ie_data_t, 261
LE_GAP_SCAN_PARAM_T, 185	property
	LE_GATT_MSG_CHARACTERISTIC_DECL_IN←
pAttr	FO_IND_T, 191
LE_GATT_SERVICE_T, 218	proto
pFCInfo	_wpa_ie_data, 152
auto_connect_cfg_t, 158	asso_data, 154
<u>-</u>	

wifi_wpa_ie_data_t, 261	u8ResendCnt, 233
prvData	u8aBssid, 233
wifi_cmd_t, 246	u8aSsid, 233
wifi_evt_t, 252	SECONDARY_SERVICE_DECL_UUID128
psk	BLE GATT APIs, 50
asso_data, 154	SECONDARY_SERVICE_DECL_UUID16
auto_conn_info_t, 156 mw_wifi_auto_connect_ap_info_t, 228	BLE GATT APIs, 50
psk_set	saArgv
asso_data, 154	T_RfCmd, 237
ptScanReport	LE_SMP_MSG_PAIRING_ACTION_IND_T, 220
S_WIFI_MLME_SCAN_CFG, 232	LE SMP MSG PAIRING COMPLETE IND T,
pwr_level	221
LE_CM_MSG_READ_ADV_TX_POWER_CFM↔	LE_SMP_MSG_SLAVE_SECURITY_REQUES↔
_T, 173	T_IND_T, 224
	scan_done
rand	wifi_event_info_t, 248
LE_CM_MSG_LTK_REQ_IND_T, 172	scan_id
LE_SMP_SC_OOB_DATA_T, 225	wifi_event_sta_scan_done_t, 251
rear	scan_info_t, 233
auto_connect_cfg_t, 158 MwFimAutoConnectCFG_t, 231	ap_channel, 234
reason	beacon_interval, 234
LE_CM_MSG_DISCONNECT_COMPLETE_IN←	bssid, 234
D_T, 169	capabilities, 234
wifi_event_sta_disconnected_t, 250	dtim_prod, 234
retryCount	free_ocpy, 235
auto_connect_cfg_t, 158	latest_beacon_rx_time, 235
role	rsn_ie, 235 rssi, 235
LE_CM_CONNECTION_COMPLETE_IND_T, 163	ssid, 235
rsn_ie	ssid_len, 235
auto_conn_info_t, 156	supported_rates, 235
mw_wifi_auto_connect_ap_info_t, 228	wpa_data, 235
scan_info_t, 235	wpa ie, 236
rssi	scan_method
auto_conn_info_t, 157 LE_CM_MSG_ADVERTISE_REPORT_IND_↔	wifi_sta_config_t, 259
T, 164	scan_report_t, 236
LE_CM_MSG_DIRECT_ADV_REPORT_IND_T,	pScanInfo, 236
168	uScanApNum, 236
LE CM MSG READ RSSI CFM T, 176	scan_time
mw_wifi_auto_connect_ap_info_t, 229	wifi_scan_config_t, 254
scan_info_t, 235	scan_type
wifi_auto_connect_info_t, 245	wifi_scan_config_t, 254
wifi_fast_scan_threshold_t, 252	show_hidden
wifi_scan_info_t, 256	wifi_scan_config_t, 254
rx_eapol_data, 231	size LE CM MSG READ RESOLVING LIST SIZE↔
frame_buffer, 231	_CFM_T, 175
frame_length, 231	_SIM_I, 770 LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM↔
rx_phy LE CM MSC BEAD BHY CEM T 175	T, 177
LE_CM_MSG_READ_PHY_CFM_T, 175	slave_latency
S_WIFI_MLME_SCAN_CFG, 232	LE_CM_MSG_SIGNAL_UPDATE_REQ_T, 180
ptScanReport, 232	sort_method
tScanType, 232	wifi_sta_config_t, 259
u32ActiveScanDur, 232	ssid
u32PassiveScanDur, 232	auto_conn_info_t, 157
u8Channel, 233	mw_wifi_auto_connect_ap_info_t, 229
u8MaxScanApNum, 233	scan_info_t, 235

wifi_ap_config_t, 243	${\sf LE_GATT_MSG_FIND_ALL_CHAR_DESC_CF} {\leftarrow}$
wifi_auto_connect_info_t, 245	M_T, 197
wifi_event_sta_connected_t, 249	LE_GATT_MSG_FIND_ALL_PRIMARY_SERVI↔
wifi_event_sta_disconnected_t, 250	CE_CFM_T, 198
wifi_scan_config_t, 254	${\sf LE_GATT_MSG_FIND_CHARACTERISTIC_CF} {\leftarrow}$
wifi_scan_info_t, 256	M_T, 199
wifi_sta_config_t, 259	${\sf LE_GATT_MSG_FIND_INCLUDED_SERVICE_} {\leftarrow}$
ssid_hidden	CFM_T, 200
 wifi_ap_config_t, 243	${\sf LE_GATT_MSG_FIND_PRIMARY_SERVICE_B} {\leftarrow}$
ssid_len	Y_UUID_CFM_T, 201
auto_conn_info_t, 157	LE_GATT_MSG_NOTIFY_CFM_T, 204
mw_wifi_auto_connect_ap_info_t, 229	LE_GATT_MSG_PREPARE_WRITE_RELIABL←
scan_info_t, 235	E_CFM_T, 207
wifi_event_sta_connected_t, 249	LE_GATT_MSG_READ_CHAR_VAL_BY_UUID↔
wifi_event_sta_disconnected_t, 250	_CFM_T, 208
ssid_length	LE_GATT_MSG_READ_CHARACTERISTIC_V↔
	ALUE_CFM_T, 209
wifi_ap_config_t, 243	${\sf LE_GATT_MSG_READ_LONG_CHAR_VAL_C} \leftarrow$
wifi_scan_info_t, 257	FM_T, 210
wifi_sta_config_t, 260	LE_GATT_MSG_READ_MULTIPLE_CHAR_VA↔
sta_config	L_CFM_T, 211
wifi_config_t, 247	LE_GATT_MSG_SIGNED_WRITE_CFM_T, 213
start_hdl	LE_GATT_MSG_WRITE_CHAR_VAL_RELIAB↔
LE_GATT_MSG_INCLUDE_SERVICE_INFO_I	LE_CFM_T, 214
ND_T, 202	LE_GATT_MSG_WRITE_CHAR_VALUE_CFM↔
LE_GATT_MSG_SERVICE_INFO_IND_T, 212	_T, 215
startHdl	LE_GATT_MSG_WRITE_LONG_CHAR_VALU↔
LE_GATT_SERVICE_T, 218	E_CFM_T, 216
status	LE_GATT_MSG_WRITE_NO_RSP_CFM_T, 217
LE_CM_CONNECTION_COMPLETE_IND_T, 163	LE_SMP_MSG_ENCRYPTION_REFRESH_IND↔
LE_CM_MSG_CONN_UPDATE_COMPLETE_I↔	_T, 219
ND_T, 166	LE_SMP_MSG_PAIRING_COMPLETE_IND_T,
LE_CM_MSG_DISCONNECT_COMPLETE_IN↔	221
D_T, 169	wifi_event_sta_scan_done_t, 251
LE_CM_MSG_ENCRYPTION_CHANGE_IND_T,	supervision_timeout
170	LE_CM_MSG_CONN_UPDATE_COMPLETE_I↔
LE_CM_MSG_ENCRYPTION_REFRESH_IND_T,	ND_T, 166
171	LE_GAP_CONN_PARAM_T, 184
LE_CM_MSG_INIT_COMPLETE_CFM_T, 171	supervison_timeout
LE_CM_MSG_READ_ADV_TX_POWER_CFM↔	LE_CM_CONNECTION_COMPLETE_IND_T, 163
_T, 173	supported_rates
LE_CM_MSG_READ_BD_ADDR_CFM_T, 173	auto_conn_info_t, 157
LE_CM_MSG_READ_CHANNEL_MAP_CFM_T,	mw_wifi_auto_connect_ap_info_t, 229
174	scan_info_t, 235
LE_CM_MSG_READ_PHY_CFM_T, 175	wifi_auto_connect_info_t, 245
LE_CM_MSG_READ_RESOLVING_LIST_SIZE←	sv_timeout
_CFM_T, 175	LE_CONN_PARA_T, 182
LE_CM_MSG_READ_RSSI_CFM_T, 176	sv_tmo
LE_CM_MSG_READ_TX_POWER_CFM_T, 177	LE_CM_MSG_CONN_PARA_REQ_T, 165
LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM↔	svc_id
	LE_GATT_SERVICE_T, 218
LE_CM_MSG_SET_DATA_LENGTH_CFM_T,	T HOUR
178	BLE MSG APIs, 74
LE_CM_MSG_SET_DISCONNECT_CFM_T, 179	T MIN
LE_CM_MSG_SET_PHY_CFM_T, 179	BLE MSG APIs, 74
LE_CM_REQ_STATUS_T, 181	T_RfCmd, 236
LE_GATT_MSG_EXECUTE_WRITE_RELIABL↔	iArgc, 237
E_CFM_T, 196	saArgv, 237
, , , , , , , , , , , , , , , , , , ,	· · · · · · · · · · ·

u32Type, 237	u32Freq
T_RfDefEvt, 237	T_RfEvt, 239
u32Type, 237	u32Mode
u8Status, 238	T_RfEvt, 239
u8aData, 237	u32PassiveScanDur
T RfEvt, 238	S_WIFI_MLME_SCAN_CFG, 232
i8Rssi, 238	u32RfChannel
pParam, 238	T_RfEvt, 239
u16RfMode, 239	u32Type
u16RxCnt, 239	T_RfCmd, 237
u16RxCrcOkCnt, 239	T RfDefEvt, 237
u32Freq, 239	T RfEvt, 239
u32Mode, 239	u8Channel
u32RfChannel, 239	S_WIFI_MLME_SCAN_CFG, 233
u32Type, 239	u8Freq
u8Freq, 239	T_RfEvt, 239
u8lpcEnable, 240	u8lpcEnable
u8Len, 240	T_RfEvt, 240
u8Phy, 240	u8Len
u8Pkt, 240	T RfEvt, 240
u8Reserved, 240	u8MaxScanApNum
u8Status, 240	S WIFI MLME SCAN CFG, 233
u8Unicast, 240	u8Phy
T_SEC	T_RfEvt, 240
BLE MSG APIs, 74	u8Pkt
TASKHANDLER	T_RfEvt, 240
BLE MSG APIs, 75	u8ResendCnt
TASKPACK	S_WIFI_MLME_SCAN_CFG, 233
BLE MSG APIs, 76	u8Reserved
TASK	T_RfEvt, 240
BLE MSG APIs, 75	u8SkipDtimPeriods
tScanType	mw_wifi_sta_info_t, 230
S_WIFI_MLME_SCAN_CFG, 232	u8Status
targetldx	T_RfDefEvt, 238
auto_connect_cfg_t, 159	T_RfEvt, 240
MwFimAutoConnectCFG_t, 231	u8Unicast
Task	T_RfEvt, 240
BLE MSG APIs, 75	u8aBssid
threshold	S_WIFI_MLME_SCAN_CFG, 233
wifi_sta_config_t, 260	u8aData
timeout_multiplier	T_RfDefEvt, 237
LE_CM_MSG_SIGNAL_UPDATE_REQ_T, 180	u8aSsid
tx_phy	S_WIFI_MLME_SCAN_CFG, 233
LE_CM_MSG_READ_PHY_CFM_T, 175	uFCApNum
tx_power	auto_connect_cfg_t, 159
LE_CM_MSG_READ_TX_POWER_CFM_T, 177	uScanApNum
type	scan_report_t, 236
LE_BT_ADDR_T, 161	uuid
LE_GAP_ADVERTISING_PARAM_T, 183	LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_
LE_GAP_SCAN_PARAM_T, 185	IND_T, 190
u1CD4Mada	LE_GATT_MSG_CHARACTERISTIC_DECL_IN←
u16RfMode	FO_IND_T, 191
T_RfEvt, 239	LE_GATT_MSG_INCLUDE_SERVICE_INFO_I
u16RxCnt	ND_T, 202
T_RfEvt, 239	LE_GATT_MSG_SERVICE_INFO_IND_T, 212
u16RxCrcOkCnt	vol
T_RfEvt, 239	VAL LE CATT MCC CHARACTERISTIC VALUED.
u32ActiveScanDur	LE_GATT_MSG_CHARACTERISTIC_VAL_IND
S_WIFI_MLME_SCAN_CFG, 232	_T, 192

LE_GATT_MSG_INDICATE_IND_T, 203	wifi_auto_connect_start, 117
LE_GATT_MSG_NOTIFY_IND_T, 205	wifi_auto_connect_start_api, 139
LE_GATT_MSG_READ_MULTIPLE_CHAR_VA↔	wifi_auto_connect_start_fp_t, 106
L_CFM_T, 211	wifi_auto_connect_update_ch, 118
val_hdl	wifi_auto_connect_update_ch_api, 139
LE_GATT_MSG_CHARACTERISTIC_DECL_IN←	wifi_auto_connect_update_ch_fp_t, 106
FO_IND_T, 191	wifi_config_get_bandwidth, 118
	wifi_config_get_bandwidth_api, 139
WIFI APIs, 91	wifi_config_get_bandwidth_fp_t, 106
WIFI_BEACON_INTERVAL_LENGTH, 92	wifi config get bssid, 119
WIFI_CAPABILITY_INFO_LENGTH, 92	wifi_config_get_bssid_api, 139
WIFI_LENGTH_802_11, 93	wifi_config_get_bssid_fp_t, 106
WIFI_LENGTH_PASSPHRASE, 93	wifi_config_get_channel, 119
WIFI_MAC_ADDRESS_LENGTH, 93	wifi_config_get_channel_api, 139
WIFI_MAC_NUM_OF_CHANNELS, 93	wifi_config_get_channel_fp_t, 106
WIFI_MAX_LENGTH_OF_SSID, 93	wifi_config_get_dtim_interval, 120
WIFI_MAX_SCAN_AP_NUM, 93	wifi_config_get_dtim_interval_api, 139
WIFI_MAX_SUPPORTED_RATES, 94	wifi_config_get_dtim_interval_fp_t, 106
wifi_ap_record_t, 94	wifi_config_get_listen_interval, 120
wifi_auto_connet_mode_e, 94	wifi config get listen interval api, 139
wifi_event_notify_cb_t, 94	wifi_config_get_listen_interval_fp_t, 106
wifi_event_process_handler, 95	wifi_config_get_mac_address, 120
wifi_install_default_event_handlers, 95	wifi config get mac address api, 140
wifi_register_event_handler, 95	wifi_config_get_mac_address_fp_t, 107
WIFI Common APIs, 97	wifi_config_get_mac_tx_data_rate, 121
wifi_event_cb_t, 97	wifi_config_get_mac_tx_data_rate_api, 140
wifi_event_loop_init, 97	wifi_config_get_mac_tx_data_rate_fp_t, 107
wifi_event_loop_send, 98	wifi_config_get_opmode, 121
wifi_event_loop_set_cb, 98	wifi_config_get_opmode_api, 140
wifi_event_process_handler, 99	wifi_config_get_opmode_fp_t, 107
WIFI STA APIS, 100	wifi_config_get_skip_dtim, 121
WIFI_READY_TIME, 104	wifi_config_get_skip_dtim_api, 140
wifi_auto_connect_clear_ap_info, 113	wifi_config_get_skip_dtim_fp_t, 107
wifi_auto_connect_clear_ap_info_api, 138	wifi config get ssid, 122
wifi_auto_connect_clear_ap_info_fp_t, 104	wifi_config_get_ssid_api, 140
wifi_auto_connect_get_ap_info, 114	wifi_config_get_ssid_fp_t, 107
wifi_auto_connect_get_ap_info_api, 138	wifi_config_get_sta_mac_address_from_flash, 122
wifi_auto_connect_get_ap_info_fp_t, 105	wifi_config_get_sta_mac_address_from_flash_api,
wifi_auto_connect_get_ap_num, 114	140
wifi_auto_connect_get_ap_num_api, 138	wifi_config_get_sta_mac_address_from_flash_
wifi_auto_connect_get_ap_num_fp_t, 105	fp_t, 107
wifi_auto_connect_get_mode, 115 wifi_auto_connect_get_mode_api, 138	wifi_config_set_bandwidth, 122
wiii_auto_connect_get_mode_api, 136 wifi_auto_connect_get_mode_fp_t, 105	wifi_config_set_bandwidth_api, 140
wifi_auto_connect_get_nlode_ip_t, 103 wifi_auto_connect_get_saved_ap_num, 115	wifi_config_set_bandwidth_fp_t, 107
wifi_auto_connect_get_saved_ap_num_api, 138	wifi config set bssid, 123
wiii_auto_connect_get_saved_ap_num_fp_t, 105	wifi_config_set_bssid_api, 140
wii_auto_connect_init, 115	wifi config set bssid fp t, 107
wifi_auto_connect_init, 113	wifi_config_set_channel, 123
wifi_auto_connect_init_fp_t, 105	wifi_config_set_channel_api, 141
wifi_auto_connect_reset, 116	wifi_config_set_channel_fp_t, 108
wifi_auto_connect_reset_api, 138	wifi_config_set_dtim_interval, 124
wifi_auto_connect_reset_api, 136 wifi_auto_connect_reset_fp_t, 105	wifi_config_set_dtim_interval_api, 141
· _ · _	wifi_config_set_dtim_interval_fp_t, 108
wifi_auto_connect_set_ap_num, 116	wifi_config_set_listen_interval, 124
wifi_auto_connect_set_ap_num_api, 138 wifi_auto_connect_set_ap_num_fp_t, 105	wifi_config_set_listen_interval_api, 141
wiii_auto_connect_set_ap_num_ip_t, 105 wifi_auto_connect_set_mode, 117	wifi_config_set_listen_interval_fp_t, 108
	wifi_config_set_mac_address, 124
wifi_auto_connect_set_mode_api, 139	
wifi_auto_connect_set_mode_fp_t, 106	wifi_config_set_mac_address_api, 141

''' '' I I I I I I I I I I I I I I I I	'C' 1 C' 100
wifi_config_set_mac_address_fp_t, 108	wifi_get_config, 133
wifi_config_set_mac_tx_data_rate, 125	wifi_get_config_api, 143
wifi_config_set_mac_tx_data_rate_api, 141	wifi_get_config_fp_t, 111
wifi_config_set_mac_tx_data_rate_fp_t, 108	wifi_init, 133
wifi_config_set_opmode, 125	wifi_init_api, 143
wifi_config_set_opmode_api, 141	wifi_init_complete_cb_t, 111
wifi_config_set_opmode_fp_t, 108	wifi_init_fp_t, 111
wifi_config_set_skip_dtim, 125	wifi_result_t, 112
wifi_config_set_skip_dtim_api, 141	wifi_scan_get_ap_list, 134
wifi_config_set_skip_dtim_fp_t, 108	wifi_scan_get_ap_list_api, 144
wifi_config_set_ssid, 126	wifi_scan_get_ap_list_fp_t, 112
wifi_config_set_ssid_api, 141	wifi_scan_get_ap_num, 134
wifi_config_set_ssid_fp_t, 108	wifi_scan_get_ap_num_api, 144
wifi_connection_connect, 126	wifi_scan_get_ap_num_fp_t, 112
wifi_connection_connect_api, 142	wifi_scan_get_ap_records, 135
wifi_connection_connect_fp_t, 109	wifi_scan_get_ap_records_api, 144
wifi connection connect from ac index, 127	wifi_scan_get_ap_records_fp_t, 112
wifi_connection_connect_from_ac_index_api, 142	wifi_scan_start, 135
wifi_connection_connect_from_ac_index_fp_t, 109	wifi_scan_start_api, 144
wifi_connection_connect_from_ac_list, 127	wifi_scan_start_fp_t, 112
wifi_connection_connect_from_ac_list_api, 142	wifi_scan_stop, 135
wifi_connection_connect_from_ac_list_fp_t, 109	wifi_scan_stop_api, 144
wifi_connection_disconnect_ap, 128	wifi_scan_stop_fp_t, 112
wifi_connection_disconnect_ap_api, 142	wifi_set_config, 136
wifi_connection_disconnect_ap_fp_t, 109	wifi_set_config_api, 144
wifi_connection_disconnect_sta, 128	wifi_set_config_fp_t, 112
wifi_connection_disconnect_sta_api, 142	wifi_sta_get_ap_info, 136
wifi_connection_disconnect_sta_fp_t, 109	wifi_sta_get_ap_info_api, 144
wifi_connection_disconnect_sta_ip_t, 109 wifi_connection_get_rssi, 129	wifi_sta_get_ap_info_fp_t, 113
	wii_sta_get_ap_iiio_ip_t, 113 wifi_start, 137
wifi_connection_get_rssi_api, 142	
wifi_connection_get_rssi_fp_t, 109	wifi_start_api, 144
wifi_connection_register_event_handler, 129	wifi_start_fp_t, 113
wifi_connection_register_event_handler_api, 142	wifi_stop, 137
wifi_connection_register_event_handler_fp_t, 109	wifi_stop_api, 144
wifi_connection_scan_start, 130	wifi_stop_fp_t, 113
wifi_connection_scan_start_api, 142	WIFI_BEACON_INTERVAL_LENGTH
wifi_connection_scan_start_fp_t, 110	WIFI APIs, 92
wifi_connection_unregister_event_handler, 130	WIFI_CAPABILITY_INFO_LENGTH
wifi_connection_unregister_event_handler_api,	WIFI APIs, 92
143	WIFI_LENGTH_802_11
wifi_connection_unregister_event_handler_fp_t,	WIFI APIs, 93
110	WIFI_LENGTH_PASSPHRASE
wifi_convert_auth_mode, 131	WIFI APIs, 93
wifi_convert_auth_mode_api, 143	WIFI_MAC_ADDRESS_LENGTH
wifi_convert_auth_mode_fp_t, 110	WIFI APIs, 93
wifi_deinit, 131	WIFI_MAC_NUM_OF_CHANNELS
wifi_deinit_api, 143	WIFI APIs, 93
wifi_deinit_fp_t, 110	WIFI_MAX_LENGTH_OF_SSID
wifi_event_handler_t, 110	WIFI APIs, 93
wifi_fast_connect_get_mode, 131	WIFI_MAX_SCAN_AP_NUM
wifi_fast_connect_get_mode_api, 143	WIFI APIs, 93
wifi_fast_connect_get_mode_fp_t, 111	WIFI_MAX_SUPPORTED_RATES
wifi_fast_connect_set_mode, 132	WIFI APIs, 94
wifi_fast_connect_set_mode_api, 143	WIFI_READY_TIME
wifi_fast_connect_set_mode_fp_t, 111	WIFI STA APIs, 104
wifi_fast_connect_start, 132	wifi_active_scan_time_t, 241
wifi_fast_connect_start_api, 143	max, 241
wifi_fast_connect_start_fp_t, 111	min, 241

:		tr tutat
WIII_	ap_config_t, 241	wifi_auto_connect_init_api
	auth_mode, 242	WIFI STA APIs, 138
	beacon_interval, 242	wifi_auto_connect_init_fp_t
	channel, 242	WIFI STA APIs, 105
	encrypt_type, 242	wifi_auto_connect_reset
	max_connection, 242	WIFI STA APIs, 116
	password, 243	wifi_auto_connect_reset_api
	password_length, 243	WIFI STA APIs, 138
	ssid, 243	wifi_auto_connect_reset_fp_t
	ssid_hidden, 243	WIFI STA APIs, 105
	ssid_length, 243	wifi_auto_connect_set_ap_num
wifi_	_ap_record_t	WIFI STA APIs, 116
	WIFI APIs, 94	wifi_auto_connect_set_ap_num_api
wifi_	auth_mode_t	WIFI STA APIs, 138
	Enumeration, 145	wifi_auto_connect_set_ap_num_fp_t
wifi_	auto_connect_clear_ap_info	WIFI STA APIs, 105
	WIFI STA APIs, 113	wifi_auto_connect_set_mode
wifi_	auto_connect_clear_ap_info_api	WIFI STA APIs, 117
	WIFI STA APIs, 138	wifi_auto_connect_set_mode_api
wifi_	auto_connect_clear_ap_info_fp_t	WIFI STA APIs, 139
	WIFI STA APIs, 104	wifi auto connect set mode fp t
wifi	auto connect get ap info	WIFI STA APIs, 106
	WIFI STA APIs, 114	wifi_auto_connect_start
wifi_	auto_connect_get_ap_info_api	WIFI STA APIs, 117
	WIFI STA APIs, 138	wifi_auto_connect_start_api
wifi_	auto_connect_get_ap_info_fp_t	WIFI STA APIs, 139
	WIFI STA APIs, 105	wifi_auto_connect_start_fp_t
wifi_	auto_connect_get_ap_num	WIFI STA APIs, 106
	WIFI STA APIs, 114	wifi_auto_connect_update_ch
wifi_	auto_connect_get_ap_num_api	WIFI STA APIs, 118
	WIFI STA APIs, 138	wifi_auto_connect_update_ch_api
wifi_	auto_connect_get_ap_num_fp_t	WIFI STA APIs, 139
	WIFI STA APIs, 105	wifi_auto_connect_update_ch_fp_t
wifi_	auto_connect_get_mode	WIFI STA APIs, 106
	WIFI STA APIs, 115	wifi_auto_connet_mode_e
wifi_	auto_connect_get_mode_api	WIFI APIs, 94
	WIFI STA APIs, 138	wifi bandwidth t
wifi_	auto_connect_get_mode_fp_t	Enumeration, 146
	WIFI STA APIs, 105	wifi_cipher_type_t
wifi	auto_connect_get_saved_ap_num	Enumeration, 146
	WIFI STA APIs, 115	wifi cmd t, 245
wifi	auto_connect_get_saved_ap_num_api	arg1, 246
	WIFI STA APIs, 138	arg2, 246
wifi	auto connect get saved ap num fp t	cmd type, 246
_	WIFI STA APIs, 105	prvData, 246
wifi	auto_connect_info_t, 243	wifi_config_get_bandwidth
_	ap channel, 244	WIFI STA APIs, 118
	beacon_interval, 244	wifi_config_get_bandwidth_api
	bssid, 244	WIFI STA APIs, 139
	capabilities, 244	wifi_config_get_bandwidth_fp_t
	dtim_prod, 244	WIFI STA APIs, 106
	fast connect, 245	wifi_config_get_bssid
	hid_ssid, 245	WIFI STA APIs, 119
	rssi, 245	wifi_config_get_bssid_api
	ssid, 245	WIFI STA APIs, 139
	supported_rates, 245	wifi_config_get_bssid_fp_t
wifi	auto_connect_init	WIFI STA APIs, 106
	WIFI STA APIs, 115	wifi_config_get_channel

WIFI STA APIs, 107
wifi_config_set_bssid WIFI STA APIs, 123
wifi_config_set_bssid_api
WIFI STA APIs, 140
wifi config set bssid fp t
WIFI STA APIs, 107
wifi_config_set_channel
WIFI STA APIs, 123
wifi_config_set_channel_api
WIFI STA APIs, 141
wifi_config_set_channel_fp_t
WIFI STA APIs, 108
wifi_config_set_dtim_interval
WIFI STA APIs, 124
wifi_config_set_dtim_interval_api
WIFI STA APIs, 141
wifi_config_set_dtim_interval_fp_t WIFI STA APIs, 108
wifi_config_set_listen_interval
WIFI STA APIs, 124
wifi_config_set_listen_interval_api
WIFI STA APIs, 141
wifi_config_set_listen_interval_fp_t
WIFI STA APIs, 108
wifi_config_set_mac_address
WIFI STA APIs, 124
wifi_config_set_mac_address_api
WIFI STA APIs, 141
wifi_config_set_mac_address_fp_t
WIFI STA APIs, 108
wifi_config_set_mac_tx_data_rate
WIFI STA APIs, 125
wifi_config_set_mac_tx_data_rate_api
WIFI STA APIs, 141 wifi_config_set_mac_tx_data_rate_fp_t
WIII_comig_set_mac_tx_data_rate_ip_t WIFI STA APIs, 108
wifi_config_set_opmode
WIFI STA APIs, 125
wifi_config_set_opmode_api
WIFI STA APIs, 141
wifi_config_set_opmode_fp_t
WIFI STA APIs, 108
wifi_config_set_skip_dtim
WIFI STA APIs, 125
wifi_config_set_skip_dtim_api
WIFI STA APIs, 141
wifi_config_set_skip_dtim_fp_t
WIFI STA APIs, 108
wifi_config_set_ssid
WIFI STA APIs, 126 wifi_config_set_ssid_api
WIFI STA APIs, 141
wifi_config_set_ssid_fp_t
WIFI STA APIs, 108
wifi_config_t, 246
ap_config, 247
sta_config, 247

wifi_connection_connect WIFI STA APIs, 126	wifi_convert_auth_mode_fp_t WIFI STA APIs, 110
wifi_connection_connect_api	wifi_deinit
WIFI STA APIs, 142	WIFI STA APIs, 131
wifi_connection_connect_fp_t	wifi_deinit_api
WIFI STA APIs, 109	WIFI STA APIs, 143
wifi_connection_connect_from_ac_index	wifi_deinit_fp_t
WIFI STA APIs, 127	WIFI STA APIs, 110
wifi_connection_connect_from_ac_index_api	wifi_event_cb_t
WIFI STA APIs, 142	WIFI Common APIs, 97
wifi_connection_connect_from_ac_index_fp_t	wifi_event_handler_t
WIFI STA APIs, 109	WIFI STA APIs, 110
wifi_connection_connect_from_ac_list	wifi_event_info_t, 247
WIFI STA APIs, 127	connected, 247
wifi_connection_connect_from_ac_list_api	disconnected, 247
WIFI STA APIs, 142	got_ip, 248
wifi_connection_connect_from_ac_list_fp_t	scan_done, 248
WIFI STA APIs, 109	wifi_event_loop_init
wifi_connection_disconnect_ap	WIFI Common APIs, 97
WIFI STA APIs, 128	wifi_event_loop_send
wifi_connection_disconnect_ap_api	WIFI Common APIs, 98
WIFI STA APIs, 142	wifi_event_loop_set_cb
wifi_connection_disconnect_ap_fp_t	WIFI Common APIs, 98
WIFI STA APIs, 109	wifi_event_notify_cb_t
wifi_connection_disconnect_sta	WIFI APIs, 94
WIFI STA APIs, 128	wifi_event_process_handler
wifi_connection_disconnect_sta_api	WIFI APIs, 95
WIFI STA APIs, 142	WIFI Common APIs, 99
wifi_connection_disconnect_sta_fp_t	wifi_event_sta_connected_t, 248
WIFI STA APIs, 109	authmode, 248
wifi_connection_get_rssi	bssid, 248
WIFI STA APIs, 129	channel, 249
wifi_connection_get_rssi_api	ssid, 249
WIFI STA APIs, 142	ssid_len, 249
wifi_connection_get_rssi_fp_t	wifi_event_sta_disconnected_t, 249
WIFI STA APIs, 109	bssid, 249
wifi_connection_register_event_handler	reason, 250
WIFI STA APIs, 129	ssid, 250
wifi_connection_register_event_handler_api	ssid_len, 250
WIFI STA APIs, 142	wifi_event_sta_got_ip_t, 250
wifi_connection_register_event_handler_fp_t	ip_changed, 250
WIFI STA APIs, 109	wifi_event_sta_scan_done_t, 251
wifi_connection_scan_start	number, 251
WIFI STA APIs, 130	scan_id, 251
wifi_connection_scan_start_api	status, 251
WIFI STA APIs, 142	wifi_event_t
wifi_connection_scan_start_fp_t	Enumeration, 146
WIFI STA APIs, 110	wifi_evt_t, 251
wifi_connection_unregister_event_handler	evt_type, 252
WIFI STA APIs, 130	prvData, 252
wifi_connection_unregister_event_handler_api	wifi_fast_connect_get_mode
WIFI STA APIs, 143	WIFI STA APIs, 131
wifi_connection_unregister_event_handler_fp_t	wifi_fast_connect_get_mode_api
WIFI STA APIs, 110	WIFI STA APIs, 143
wifi_convert_auth_mode	wifi_fast_connect_get_mode_fp_t
WIFI STA APIs, 131	WIFI STA APIs, 111
wifi_convert_auth_mode_api	wifi_fast_connect_set_mode
WIFI STA APIs. 143	WIFI STA APIs. 132

wifi_fast_connect_set_mode_api	WIFI STA APIs, 144
WIFI STA APIs, 143	wifi_scan_get_ap_num_fp_t
wifi_fast_connect_set_mode_fp_t	WIFI STA APIs, 112
WIFI STA APIs, 111 wifi fast connect start	wifi_scan_get_ap_records WIFI STA APIs, 135
WIFI STA APIs, 132	wifi_scan_get_ap_records_api
wifi_fast_connect_start_api	WIFI STA APIs, 144
WIFI STA APIs, 143	wifi_scan_get_ap_records_fp_t
wifi_fast_connect_start_fp_t	WIFI STA APIs, 112
WIFI STA APIs, 111	wifi_scan_info_t, 255
wifi_fast_scan_threshold_t, 252	auth mode, 255
authmode, 252	beacon_interval, 255
rssi, 252	bssid, 255
wifi_get_config	capability_info, 256
WIFI STA APIs, 133	channel, 256
wifi_get_config_api	dtim_period, 256
WIFI STA APIs, 143	group_cipher, 256
wifi_get_config_fp_t	pairwise_cipher, 256
WIFI STA APIs, 111	rssi, 256
wifi_init	ssid, 256
WIFI STA APIs, 133	ssid_length, 257
wifi_init_api	wifi_scan_list_t, 257
WIFI STA APIs, 143	ap_record, 257
wifi_init_complete_cb_t WIFI STA APIs, 111	num, 257 wifi_scan_method_t
wifi_init_config_t, 253	Enumeration, 149
event handler, 253	wifi_scan_start
magic, 253	WIFI STA APIs, 135
wifi init fp t	wifi scan start api
wifi_init_fp_t WIFI STA APIs, 111	wifi_scan_start_api WIFI STA APIs, 144
· -	·
WIFI STA APIs, 111	WIFI STA APIs, 144
WIFI STA APIs, 111 wifi_install_default_event_handlers	WIFI STA APIs, 144 wifi_scan_start_fp_t
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112 wifi_scan_config_t, 253	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t Enumeration, 149
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112 wifi_scan_config_t, 253 bssid, 254	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t Enumeration, 149 wifi_set_config
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112 wifi_scan_config_t, 253	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t Enumeration, 149
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112 wifi_scan_config_t, 253 bssid, 254 channel, 254	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t Enumeration, 149 wifi_set_config WIFI STA APIs, 136
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112 wifi_scan_config_t, 253 bssid, 254 channel, 254 scan_time, 254	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t Enumeration, 149 wifi_set_config WIFI STA APIs, 136 wifi_set_config_api
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112 wifi_scan_config_t, 253 bssid, 254 channel, 254 scan_time, 254 scan_type, 254	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t Enumeration, 149 wifi_set_config WIFI STA APIs, 136 wifi_set_config_api WIFI STA APIs, 144
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112 wifi_scan_config_t, 253 bssid, 254 channel, 254 scan_time, 254 scan_type, 254 show_hidden, 254	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t Enumeration, 149 wifi_set_config WIFI STA APIs, 136 wifi_set_config_api WIFI STA APIs, 144 wifi_set_config_fp_t WIFI STA APIs, 112 wifi_sort_method_t
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112 wifi_scan_config_t, 253 bssid, 254 channel, 254 scan_time, 254 scan_type, 254 show_hidden, 254 ssid, 254 wifi_scan_get_ap_list WIFI STA APIs, 134	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t Enumeration, 149 wifi_set_config WIFI STA APIs, 136 wifi_set_config_api WIFI STA APIs, 144 wifi_set_config_fp_t WIFI STA APIs, 112 wifi_sort_method_t Enumeration, 149
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112 wifi_scan_config_t, 253 bssid, 254 channel, 254 scan_time, 254 scan_type, 254 show_hidden, 254 ssid, 254 wifi_scan_get_ap_list WIFI STA APIs, 134 wifi_scan_get_ap_list_api	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t Enumeration, 149 wifi_set_config WIFI STA APIs, 136 wifi_set_config_api WIFI STA APIs, 144 wifi_set_config_fp_t WIFI STA APIs, 112 wifi_sort_method_t Enumeration, 149 wifi_sta_config_t, 258
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112 wifi_scan_config_t, 253 bssid, 254 channel, 254 scan_time, 254 scan_type, 254 show_hidden, 254 ssid, 254 wifi_scan_get_ap_list WIFI STA APIs, 134 wifi_scan_get_ap_list_api WIFI STA APIs, 144	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t Enumeration, 149 wifi_set_config WIFI STA APIs, 136 wifi_set_config_api WIFI STA APIs, 144 wifi_set_config_fp_t WIFI STA APIs, 112 wifi_sort_method_t Enumeration, 149 wifi_sta_config_t, 258 bssid, 259
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112 wifi_scan_config_t, 253 bssid, 254 channel, 254 scan_time, 254 scan_type, 254 show_hidden, 254 ssid, 254 wifi_scan_get_ap_list WIFI STA APIs, 134 wifi_scan_get_ap_list_api WIFI STA APIs, 144 wifi_scan_get_ap_list_fp_t	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t Enumeration, 149 wifi_set_config WIFI STA APIs, 136 wifi_set_config_api WIFI STA APIs, 144 wifi_set_config_fp_t WIFI STA APIs, 112 wifi_sort_method_t Enumeration, 149 wifi_sta_config_t, 258 bssid_present, 259
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112 wifi_scan_config_t, 253 bssid, 254 channel, 254 scan_time, 254 scan_type, 254 show_hidden, 254 ssid, 254 wifi_scan_get_ap_list WIFI STA APIs, 134 wifi_scan_get_ap_list_api WIFI STA APIs, 144 wifi_scan_get_ap_list_fp_t WIFI STA APIs, 112	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t Enumeration, 149 wifi_set_config WIFI STA APIs, 136 wifi_set_config_api WIFI STA APIs, 144 wifi_set_config_fp_t WIFI STA APIs, 112 wifi_sort_method_t Enumeration, 149 wifi_sta_config_t, 258 bssid_present, 259 password, 259
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112 wifi_scan_config_t, 253 bssid, 254 channel, 254 scan_time, 254 scan_type, 254 show_hidden, 254 ssid, 254 wifi_scan_get_ap_list WIFI STA APIs, 134 wifi_scan_get_ap_list_api WIFI STA APIs, 144 wifi_scan_get_ap_list_fp_t WIFI STA APIs, 112 wifi_scan_get_ap_num	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t Enumeration, 149 wifi_set_config WIFI STA APIs, 136 wifi_set_config_api WIFI STA APIs, 144 wifi_set_config_fp_t WIFI STA APIs, 112 wifi_sort_method_t Enumeration, 149 wifi_sta_config_t, 258 bssid, 259 bssid_present, 259 password_length, 259
WIFI STA APIs, 111 wifi_install_default_event_handlers WIFI APIs, 95 wifi_mac_data_rate_t Enumeration, 147 wifi_mode_t Enumeration, 147 wifi_reason_code_t Enumeration, 148 wifi_register_event_handler WIFI APIs, 95 wifi_result_t WIFI STA APIs, 112 wifi_scan_config_t, 253 bssid, 254 channel, 254 scan_time, 254 scan_type, 254 show_hidden, 254 ssid, 254 wifi_scan_get_ap_list WIFI STA APIs, 134 wifi_scan_get_ap_list_api WIFI STA APIs, 144 wifi_scan_get_ap_list_fp_t WIFI STA APIs, 112	WIFI STA APIs, 144 wifi_scan_start_fp_t WIFI STA APIs, 112 wifi_scan_stop WIFI STA APIs, 135 wifi_scan_stop_api WIFI STA APIs, 144 wifi_scan_stop_fp_t WIFI STA APIs, 112 wifi_scan_time_t, 258 active, 258 passive, 258 wifi_scan_type_t Enumeration, 149 wifi_set_config WIFI STA APIs, 136 wifi_set_config_api WIFI STA APIs, 144 wifi_set_config_fp_t WIFI STA APIs, 112 wifi_sort_method_t Enumeration, 149 wifi_sta_config_t, 258 bssid_present, 259 password, 259

```
ssid, 259
    ssid_length, 260
    threshold, 260
wifi_sta_get_ap_info
    WIFI STA APIs, 136
wifi sta get ap info api
    WIFI STA APIs, 144
wifi_sta_get_ap_info_fp_t
    WIFI STA APIs, 113
wifi start
    WIFI STA APIs, 137
wifi_start_api
    WIFI STA APIs, 144
wifi_start_fp_t
    WIFI STA APIs, 113
wifi_stop
    WIFI STA APIs, 137
wifi_stop_api
    WIFI STA APIs, 144
wifi_stop_fp_t
    WIFI STA APIs, 113
wifi_wpa_ie_data_t, 260
    capabilities, 260
    group_cipher, 261
    key_mgmt, 261
    mgmt_group_cipher, 261
    num_pmkid, 261
    pairwise_cipher, 261
    pmkid, 261
    proto, 261
window
    LE_GAP_SCAN_PARAM_T, 185
wpa_data
    auto_conn_info_t, 157
    mw_wifi_auto_connect_ap_info_t, 229
    scan_info_t, 235
wpa_ie
    auto_conn_info_t, 157
    mw_wifi_auto_connect_ap_info_t, 229
    scan_info_t, 236
```