# **OPL1000**

ULTRA-LOW POWER 2.4GHz WI-FI + BLUETOOTH SMART SOC

## PinMux Tool User Guide



http://www.opulinks.com/

Copyright © 2019, Opulinks. All Rights Reserved.

## **OPL1000**

## **REVISION HISTORY**

Date	Version	Contents Updated	
2018-05-09	0.1	Initial Release	
2018-05-30	0.2	<ul> <li>Update section 3.4 because PWM port setting is modified in v0.5 version</li> <li>SPI setting is updated in v0.5, hence section 3.2 is updated.</li> </ul>	
2018-08-01	0.3	<ul> <li>Add two additional IO resource, IO16/IO17</li> <li>Update all images</li> </ul>	
2018-09-07	0.4	Update GPIO tab setting according to v0.7 version SW.	
2018-09-14	0.5	<ul> <li>Add include file generation description according to v0.8 version SW.</li> </ul>	



## **TABLE OF CONTENTS**

## **TABLE OF CONTENTS**

intro	2	
		2
1.2.	Abbreviations	2
1.3.	References	2
Inte	rface introduction	3
2.2.	External Pin and Parameter Configuration Dialogue	5
Exte	rnal Resource Selection and Parameter Configuration	6
3.1.	UART Selection and Parameter Configuration	6
3.2.	SPI Selection and Parameter Configuration	8
3.3.	I2C Selection and Parameter Configuration	10
3.4.	PWM Selection and Parameter Configuration	11
3.5.	AUX/ADC Selection and Parameter Configuration	12
3.6.	GPIO Selection and Parameter Configuration	14
Юр	in selection	16
Gen	erate pin multi-purpose definition document	17
Vers	ion number and user manual	21
	1.1. 1.2. 1.3. Intel 2.1. 2.2. Extel 3.1. 3.2. 3.3. 3.4. 3.5. 3.6. IO p	introduction  1.1. Scope of Document Application  1.2. Abbreviations  1.3. References  Interface introduction  2.1. Pin Configuration Result List  2.2. External Pin and Parameter Configuration Dialogue  External Resource Selection and Parameter Configuration  3.1. UART Selection and Parameter Configuration  3.2. SPI Selection and Parameter Configuration  3.3. I2C Selection and Parameter Configuration  3.4. PWM Selection and Parameter Configuration  3.5. AUX/ADC Selection and Parameter Configuration  3.6. GPIO Selection and Parameter Configuration  IO pin selection  Generate pin multi-purpose definition document  Version number and user manual



## **LIST OF FIGURES**

## **LIST OF FIGURES**

FIGURE 1: PIN-MUX TOOL INTERFACE	3
FIGURE 2: CONFIGURED IO LIST	5
FIGURE 3: EXTERNAL TAG OPTIONS	5
FIGURE 4: UART SELECTION AND PARAMETER CONFIGURATION	7
FIGURE 5: UART SIGNAL LINE CONFIGURATION UNDER NORMAL MODE	8
FIGURE 6: UART SIGNAL LINE CONFIGURATION UNDER FLOW TRAFFIC CONTROL MODE	8
Figure 7: Four Working Time-Sequences under Single Mode	8
FIGURE 8: SPI SELECTION AND PARAMETER CONFIGURATION	10
FIGURE 9: SINGLE MODE PIN CONFIGURATION	10
FIGURE 10: I2C PARAMETER CONFIGURATION	11
FIGURE 11: I2C PIN MULTI-PURPOSE SETUP	11
FIGURE 12: PWM PARAMETER CONFIGURATION	12
FIGURE 13: PWM PIN MULTI-PURPOSE SELECTION	12
FIGURE 14: AUX/ADC SELECTION	13
FIGURE 15: AUX/ADC MULTI-PURPOSE SELECTION	13
FIGURE 16: GPIO SELECTION AND PARAMETER CONFIGURATION	14
FIGURE 17: GPIO PIN MULTI-PURPOSE CONFIGURATION	15
FIGURE 18: EXTERNAL IO PIN DEFINITION	16
FIGURE 19: GENERATING DOCUMENT	17
FIGURE 20: OPL1000_PIN_MUX_DEFINE.C PART1	18
FIGURE 21: OPL1000_PIN_MUX_DEFINE.C PART2	19
Figure 22: HAL PIN CONFIG PROJECT.H HEADER DOCUMENT PIN FUNCTION DEFINITION	19



### **OPL1000**

## **LIST OF TABLES**

## **LIST OF TABLES**

Table 1: Number of External Resources Supported by OPL1000\_\_\_\_\_\_6



### 1. INTRODUCTION

### 1.1. Scope of Document Application

This document outlines the usage method for OPL1000 pin-Mux tool. Pin mux configuration software is used for the setup of OPL1000 external register parameters and IO pin setting. Peripherals include PWM, AUX(SAR ADC), SPI (master), UART (flow control optional), I2C(master or slave) and GPIO.

### 1.2. Abbreviations

Abbr.	Description		
AUX	Auxiliary ADC Module		
СРНА	Clock PHAse		
CPOL	Clock POLarity		
DevKit	Develop Kit OPL1000 board		
FW	FirmWare · Embedded Software Operating on CPU		
GPIO	General Purpose Input/Output		
12C	Inter-Integrated Circuit bus I2C		
PWM	Pulse-Width Modulation		
SPI	Serial Peripheral Interface		
UART	Universal Asynchronous Receiver / Transmitter		

### 1.3. References

[1] OPL1000 data sheet, OPL1000-DS-R04.pdf



### 2. INTERFACE INTRODUCTION

OPL1000 provides external pins used for configuring three types of communication ports (UART, I2C and SPI), as well as particular signal port (such as PWM, AUX/ADC and GPIO). As these pin configurations are multi-purpose, e.g. a particular signal line, that can be configured as UART, can also be configured as AUX/ADC or GPIO port. Pin-Mux tool offers a way to help customers flexibly and conveniently define multi-purpose mode and port parameter configuration. Pin-Mux tool output is a .c document (OPL1000\_pin\_mux\_define.c) and "ini" configuration document. ".c" document contains pin multi-purpose setup and designated port parameter configuration table, and based on this configuration table, users can utilize corresponding API to complete OPL1000 pin multi-purpose set up and port work-mode configuration.

OPL1000 Pin-Mux Interface is shown as Figure 1.

OPL1000 Pin-Mux 2. Peripheral Setting Option 1. Config Result List 3. User Manual Use Manual AUX2 IO2 IO3 IO4 IO5 IO6 IO7 IO8 IO9 IO10 IO11 IO16 2 IO3 2 AUX2 IO4 3 AUX3 105 GPIO4 SPI1\_CS 4 SPI1\_CLK **V** SPI1\_CLK 5 SPI1\_CS V **V** SPI1\_MOS 6 SPI1\_MISC 7 SPI1\_MOSI 109 SPI1\_MISO 8 UARTO\_TX IO10 10 IO11 UARTO RX 9 UARTO RX UARTO\_TX 10 UART1\_TX 11 V 12 IO17 11 UART1\_RX 12 I2C\_SDA IO18 I2C\_SDA 13 14 IO19 UART1\_RX 13 I2C\_SCL 15 IO20 14 GPIO2 16 IO21 15 GPIO4 **V** 4. Choose IO Pin After Peripheral Configuration 17 IO23 17 18 5. Output .c And .h Config Message File つ 旺凌科技 Save to OPL1000\_pin\_mux\_define\_03201332.in

Figure 1: Pin-Mux tool Interface



Interface includes four parts:

- 1. Pin configuration result list: This is the output result after right-side pins are configured.
- 2. External pin and parameter configuration dialogue box: It contains 7 tag pages, used to select external resources, including UART, SPI, I2C, PWM, AUX/ADC and GPIO, etc., and set their pin output according to their needs.
- 3. Version message and user manual: Indicate the current software version number and display of user manual of this software.
- 4. Select corresponding external pin, as a particular pin can only be configured as an external resource at a time.
- 5. Output ".c", ".h" and ".ini": Once external resource and parameter configuration is done, click "Build" button to generate ".c", ".h" and ".ini" documents.

### 2.1. Pin Configuration Result List

As this list is generated by IO take page dialogue box configuration, when the "configuration" option is not selected, pin setting list would be empty, as shown in Figure 2. Once external IO pin is setup, that is having selected corresponding multi-selection boxes, pin setting list displays pin distribution result.



Setting Setting AUX2 AUX3 UART1\_TX UART1\_RX SPI1\_CS SPI1\_CLK SPI1\_MOSI SPI1\_MISO UARTO TX UARTO\_RX I2C\_SCL I2C\_SDA 

Figure 2: Configured IO List

### 2.2. External Pin and Parameter Configuration Dialogue

External pin and parameter configuration dialogue box contains seven tag pages, with external selection and parameter configuration tag pages such as UART, SPI, I2C, PWM, AUX/ADC, and GPIO, where IO tag page is the external pin selection dialogue box. IO tag page selection is displayed on the left-side pin setting list.

Figure 3: External Tag Options



For various external resource selection and parameter configuration, please refer to Chapter 3.



## 3. EXTERNAL RESOURCE SELECTION AND PARAMETER CONFIGURATION

This chapter outlines the external selection and parameter configuration function such as UART, SPI, I2C, PWM, AUX/ADC, and GPIO, etc.

The number of external resources supported by OPL1000 is shown as the table below.

Table 1: Number of External Resources Supported by OPL1000

External Resources	Number
UART	2
I2C	1
SPI	2
PWM	6
AUX/ADC	10
GPIO	18


### 3.1. UART Selection and Parameter Configuration

OPL provides 2 ways of UART, i.e. UART0 and UART1. The setup is as shown in Figure 4.

By selecting "Enable UARTO/UART1" multi-selection dialogue boxes, it indicates that UART external is enabled, and that allows users to indicated pin configuration of every signal line in IP tag page.



Figure 4: UART Selection and Parameter Configuration



As OPL1000 UART offers two types of working modes, one is Normal, and the other is the intensified mode for flow traffic control.

When selecting Normal mode, UART has two signal lines requiring pin configuration, as shown in Figure 5.

To select the working mode for increasing volume traffic control, UART has four signal lines with pin configuration, as shown in Figure 6.


Serial-port configuration includes: baud rate, data bit, Termination bit, Calibration bit, as each parameter is selected from pull-down menu.



Figure 5: UART Signal Line Configuration under Normal Mode



Figure 6: UART Signal Line Configuration under Flow Traffic Control Mode




### 3.2. SPI Selection and Parameter Configuration

OPL1000 supports two kinds of SPI's, i.e. SPI1 and SPI2. Having clicked to enable SPI1/SPI2 multi-selection dialogue box, it means that certain external resources shall be configured as designated SPI ports. SPI supports two kinds of work modes, Single mode and Quad mode. Quad mode corresponds to high-speed SPI communication modes.

Under Single mode, CPOL and CPHA definition has 4 working time-sequences, as shown in Figure 7.

Figure 7: Four Working Time-Sequences under Single Mode






SPI resource selection and parameter configuration are as shown in Figure 8.




Figure 8: SPI Selection and Parameter Configuration



Under Single mode, SPI port has four signal line requiring configuration, as shown in Figure 9.

Figure 9: Single Mode Pin Configuration




### 3.3. I2C Selection and Parameter Configuration

OPL1000 supports one way of I2C, for Master and Slave.

By enabling "Enable I2C", it indicates that selection of I2C port configuration. The parameter configuration of I2C is as shown in Figure 10.



Figure 10: I2C Parameter Configuration



I2C has two signal lines requiring configuration, which can be selected from 16 IO pins, as shown in Figure 11.

Figure 11: I2C Pin Multi-Purpose Setup




### 3.4. PWM Selection and Parameter Configuration

OPL1000 supports sixe PWM ports. By enabling "Enable PWMx" multi-selection dialogue box, it means that certain PWM port is selected. Please note that PWM port and external pin mapping are of one-to-one corresponding relationship. For example, PWM0 means that IO23 pin is designated for PWM0. PWM selection and parameter configuration is shown in Figure 12.




Figure 12: PWM Parameter Configuration



As PWM and pins are of one-to-one corresponding relationship, therefore if pin configuration is of multi-purpose, PWM should be selected first, before selecting other communication port signal line configuration (as they of more choices), as shown in Figure 13, where 6 ports of PWM0 ~ PWM5 and an I2C communication port are selected.

Figure 13: PWM Pin Multi-Purpose Selection




### 3.5. AUX/ADC Selection and Parameter Configuration

AUX/ADC is used to configure support of ADC port. ADC port is a signal line simulating signal input, therefore there is no parameter configuration. OPL1000 supports 10 AUX/ADC ports. And just like PWM, AUXn and IO pin are of one-to-one corresponding relationship, as shown in Figure 14.




Figure 14: AUX/ADC Selection



Just like PWM, due to the one-to-one mapping relationship with IO pin, when configuring AUX port, its pin will be selected first, and then configured for other communication ports. In Figure15, AUX2, AUX7, AUX8 and I2C signal lines need to be configured. By selecting AUX port configuration first, I2C can be configured flexibly amongst the remaining pins.

Figure 15: AUX/ADC Multi-Purpose Selection






### 3.6. GPIO Selection and Parameter Configuration

OPL supports 18 GPIO signal selection. It means that the offered 18 pins can all be configured as GPIO signal. The three configurations options for GPIO signal working mode are:

(1) Input Signal GPIO\_IN, (2) Output Signal, with configuration of high level GPIO\_OUT\_HIGH, and (3) Output signal, with configuration of low level GPIO\_OUT\_LOW. When users are selecting GPIO, circuit design must also be considered at the same time.

GPIO and IO pin are also of one-to-one corresponding relationship. Selection and parameter configuration are shown in Figure 16.

Figure 16: GPIO Selection and Parameter Configuration




GPIO pin multi-purpose configuration is as shown in Figure 17. As PWM, AUX/ADC and others similar are configured with other communication pins, GPIO needs to be selected first, before defining communication pins.



## **CHAPTER THREE**

Figure 17: GPIO Pin Multi-Purpose Configuration





### 4. IO PIN SELECTION

As Chapter 3 outlines the selection of all external (communication ports and signal ports), and parameter configuration, having chosen which ports to configure, the selected external resources and options used to configure pin are displayed in IO tag pages. When signal line pin of a particular port is selected, i.e. the corresponding multi-selection boxes ticked, then it means this IP pin is occupied by this signal line, and other signal lines would not be able to access it. The same multi-selection box will be inhibited. As shown in Figure 18, once CLK of SPI1 is designated and multi-selection dialogue boxes such as IO7, SPI2\_CLK, UARTO\_RX, and I2C\_SDA in the same column as IO7 shall be inhibited.

Through IO tag list, users can clearly and intuitively know which pins can be designated to which signal line. And by clicking multi-selection dialogue box, it ensures that every selected signal line will be designated with pin resource.




Figure 18: External IO Pin Definition



## 5. GENERATE PIN MULTI-PURPOSE DEFINITION DOCUMENT

When port definition and pin distribution is defined, click "Build" button, to generate "OPL1000\_pin\_mux\_define.c" document, "hal\_pin\_config\_project.h" header document and a "ini" document. ".c" and ".h" documents are used for subsequent port initialization and pin multi-purpose configuration, while "ini" document recording the same message to be used for other purposes such as the automatic testing for pin multi-purpose module.

Figure 19: Generating Document



As the names of ".c" and ".h" documents are unchanged, as "ini" document contains data and time messages. Therefore, in the dialogue box it only displays the name of "ini" document, as ".c" and ".h" documents are stored in "pinmux.exe" under the same folder.

According to a particular application-defined pin multi-purpose solution, having utilizing pinmux tool to generate ".c" and ".h" documents, these two documents can be copied to users' own application project folder, before utilizing the corresponding API to complete pin multi-purpose configuration.

The content of OPL1000\_pin\_mux\_define.c document is shown in Figure 19 and Figure 20.



### **OPL1000**

#### Figure 20: OPL1000\_pin\_mux\_define.c Part1

```
T_OPL1000_Periph OPL1000_periph = {
 1,{
   .
{UART_IDX_0,
   OPL1000_IO20_PIN,
   OPL1000_IO21_PIN,
   BLANK_PIN,
   BLANK_PIN,
   115200,
   DATA_BIT_8,
   PARITY_NONE,
   STOP_BIT_1,
   UART_SIMPLE},
   {UART_IDX_MAX,
   BLANK_PIN,
   BLANK_PIN,
   BLANK_PIN,
   BLANK_PIN,
   DATA BIT 8,
   PARITY_NONE,
   STOP BIT 1,
   UART_SIMPLE}
 1,{I2C_SPEED_FAST,
  OPL1000_IO19_PIN,
  OPL1000_IO18_PIN,
  I2C_07BIT,
  0x7A,
  MASTER_HAS_STOP},
 2,{
   {SPI_IDX_1,
   OPL1000_IO6_PIN,
   OPL1000_IO7_PIN,
   OPL1000_IO9_PIN,
   OPL1000_IO8_PIN,
   BLANK_PIN,
   BLANK_PIN,
   1000000,
   SPI_CLK_PLOAR_HIGH_ACT,
   SPI_CLK_PHASE_START,
   SPI_FMT_MOTOROLA,
   SPI_DFS_08_bit,
   QMODE_DISABLE},
   {SPI_IDX_2,
   OPL1000_IO5_PIN,
   OPL1000_IO4_PIN,
   BLANK_PIN,
   BLANK_PIN,
   OPL1000_IO10_PIN,
   OPL1000_IO11_PIN,
   1000000,
   SPI_CLK_PLOAR_HIGH_ACT,
   SPI_CLK_PHASE_START,
   SPI_FMT_MOTOROLA,
   SPI_DFS_08_bit,
   QMODE_ENABLE},
// continue ...
```



#### Figure 21: OPL1000\_pin\_mux\_define.c Part2

```
0,{{BLANK_PIN,CLK_32KHz,CFG_SIMPLE,0,0,0,0,0,0,0,0,0,0,0,},
            {BLANK_PIN,CLK_32KHz,CFG_SIMPLE,0,0,0,0,0,0,0,0,0,0,0}},
O,{BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLANK_PIN,BLA
,BLANK_PIN,BLANK_PIN},
   O,{{BLANK_PIN,IO_OUTPUT,PULL_UP},
            {BLANK_PIN,IO_OUTPUT,PULL_UP},
            {BLANK_PIN,IO_OUTPUT,PULL_UP},
            {BLANK_PIN,IO_OUTPUT,PULL_UP},
            {BLANK_PIN,IO_OUTPUT,PULL_UP},
           {BLANK_PIN,IO_OUTPUT,PULL_UP},
            \{ BLANK\_PIN, IO\_OUTPUT, PULL\_UP \},
            {BLANK_PIN,IO_OUTPUT,PULL_UP},
            {BLANK_PIN,IO_OUTPUT,PULL_UP},
            {BLANK_PIN,IO_OUTPUT,PULL_UP},
           {BLANK_PIN,IO_OUTPUT,PULL_UP},
{BLANK_PIN,IO_OUTPUT,PULL_UP},
            {BLANK_PIN,IO_OUTPUT,PULL_UP},
           {BLANK_PIN,IO_OUTPUT,PULL_UP},
            {BLANK_PIN,IO_OUTPUT,PULL_UP},
           {BLANK_PIN,IO_OUTPUT,PULL_UP}}
};
```

hal\_pin\_config\_project.h header document defines the functional attributes of the 24 pins, from IO0 to IO23, as Figure 22 lists the definitions of Io0 to IO4.

Figure 22: hal\_pin\_config\_project.h Header Document Pin Function Definition




### **CHAPTER FIVE**

```
// IO type select
#define HAL_PIN_TYPE_IO_0 PIN_TYPE_NONE
                                              // PIN_TYPE_NONE
                          // PIN_TYPE_GPIO_INPUT
                          // PIN_TYPE_GPIO_OUTPUT_LOW
                           // PIN_TYPE_GPIO_OUTPUT_HIGH
                          // PIN_TYPE_UARTO_CTS
                          // PIN_TYPE_UART1_TX
                          // PIN TYPE I2C SCL
                           // PIN_TYPE_SPI2_IO_3
                          // PIN_TYPE_AUX_0
                          // PIN_TYPE_UART_APS_TX
                          // PIN_TYPE_UART_MSQ_RX
                           // PIN_TYPE_ICE_M3_DAT
                          // PIN_TYPE_ICE_M0_CLK
#define HAL_PIN_TYPE_IO_1 PIN_TYPE_NONE
                                             // PIN_TYPE_NONE
                          // PIN_TYPE_GPIO_INPUT
                          // PIN_TYPE_GPIO_OUTPUT_LOW
                          // PIN_TYPE_GPIO_OUTPUT_HIGH
                          // PIN_TYPE_UARTO_RTS
                          // PIN_TYPE_UART1_RX
                          // PIN_TYPE_I2C_SDA
                          // PIN_TYPE_SPI2_IO_2
                          // PIN_TYPE_AUX_1
                          // PIN_TYPE_UART_APS_RX
                          // PIN_TYPE_UART_MSQ_TX
                          // PIN_TYPE_ICE_M3_CLK
                          // PIN_TYPE_ICE_M0_DAT
#define HAL_PIN_TYPE_IO_2 PIN_TYPE_UARTO_TX
                                              // PIN_TYPE_NONE
                          // PIN_TYPE_GPIO_INPUT
                          // PIN_TYPE_GPIO_OUTPUT_LOW
                          // PIN_TYPE_GPIO_OUTPUT_HIGH
                          // PIN_TYPE_UARTO_TX
                          // PIN_TYPE_I2C_SDA
                          // PIN_TYPE_SPI2_IO_1
                          // PIN_TYPE_AUX_2
                          // PIN_TYPE_UART_APS_TX
                          // PIN_TYPE_UART_MSQ_RX
                          // PIN_TYPE_ICE_M3_DAT
                          // PIN_TYPE_ICE_M0_CLK
#define HAL_PIN_TYPE_IO_3 PIN_TYPE_UARTO_RX
                                              // PIN_TYPE_NONE
                          // PIN_TYPE_GPIO_INPUT
                          // PIN_TYPE_GPIO_OUTPUT_LOW
                          // PIN_TYPE_GPIO_OUTPUT_HIGH
                          // PIN TYPE UARTO RX
                          // PIN_TYPE_I2C_SCL
                          // PIN_TYPE_SPI2_IO_0
                          // PIN_TYPE_AUX_3
                          // PIN_TYPE_UART_APS_RX
                          // PIN_TYPE_UART_MSQ_TX
                          // PIN_TYPE_ICE_M3_CLK
                          // PIN_TYPE_ICE_M0_DAT
#define HAL_PIN_TYPE_IO_4 PIN_TYPE_UART1_TX
                                               // PIN_TYPE_NONE
                          // PIN_TYPE_GPIO_INPUT
                          // PIN_TYPE_GPIO_OUTPUT_LOW
                          // PIN_TYPE_GPIO_OUTPUT_HIGH
                          // PIN_TYPE_UART1_TX
                          // PIN_TYPE_I2C_SCL
                          // PIN_TYPE_SPI2_CLK
                          // PIN_TYPE_AUX_4
                          // PIN_TYPE_UART_APS_TX
                          // PIN_TYPE_UART_MSQ_RX
                          // PIN_TYPE_ICE_M3_DAT
                          // PIN_TYPE_ICE_M0_CLK
```



### VERSION NUMBER AND USER MANUAL

By clicking "Use Manual" button will utilize the built-in Explore of Window system to load the user manual of this software, as shown in the diagram below.





## **OPL1000**

## **C**ONTACT

sales@Opulinks.com

