Analog Interfacing



Why It's Needed

- Embedded systems often need to measure values of physical parameters
- These parameters are usually continuous (analog) and not in a digital form which computers (which operate on discrete data values) can process
- Temperature
 - Thermometer (do you have a fever?)
 - Thermostat for building, fridge, freezer
 - Car engine controller
 - Chemical reaction monitor
 - Safety (e.g. microprocessor processor thermal management)
- Light (or infrared or ultraviolet) intensity
 - Digital camera
 - IR remote control receiver
 - Tanning bed
 - UV monitor
- Rotary position
 - Wind gauge
 - Knobs


- Pressure
 - Blood pressure monitor
 - Altimeter
 - Car engine controller
 - Scuba dive computer
 - Tsunami detector
- Acceleration
 - Air bag controller
 - Vehicle stability
 - Video game remote
- Mechanical strain
- Other
 - Touch screen controller
 - EKG, EEG
 - Breathalyzer




CONVERTING BETWEEN ANALOG AND DIGITAL VALUES



Example Analog Sensor - Depth Gauge







- Sensor detects pressure and generates a proportional output voltage V_sensor
- ADC generates a proportional digital integer (code) based on V_sensor and V_ref
- Code can convert that integer to a something more useful
 - first a float representing the voltage,
 - then another float representing pressure,
 - finally another float representing depth



Getting From Analog to Digital

- A Comparator tells us "Is Vin > Vref?"
 - Compares an analog input voltage with an analog reference voltage and determines which is larger, returning a 1-bit number
 - E.g. Indicate if depth > 100 ft
 - Set Vref to voltage pressure sensor returns with 100 ft depth.
- An Analog to Digital converter [AD or ADC] tells us how large Vin is as a fraction of Vref.
 - Reads an analog input signal (usually a voltage) and produces a corresponding multi-bit number at the output.
 - E.g. calculate the depth









Digital to Analog Conversion

- May need to generate an analog voltage or current as an output signal
 - E.g. audio signal, video signal brightness.
- DAC: "Generate the analog voltage which is this fraction of Vref"
- Digital to Analog Converter equation
 - n = input code
 - N = number of bits of resolution of converter
 - Vref = reference voltage
 - Vout = output voltage. Either
 - Vout = $Vref * n/(2^N)$ or
 - Vout = $Vref * (n+1)/(2^N)$
 - The offset +1 term depends on the internal tap configuration of the DAC check the datasheet to be sure





Waveform Sampling and Quantization



- A waveform is sampled at a constant rate every Δt
 - Each such sample represents the instantaneous amplitude at the instant of sampling
 - "At 37 ms, the input is 1.91341914513451451234311...V"
 - Sampling converts a continuous time signal to a discrete time signal
- The sample can now be quantized (converted) into a digital value
 - Quantization represents a continuous (analog) value with the closest discrete (digital) value
 - "The sampled input voltage of 1.91341914513451451234311... V is best represented by the code 0x018, since it is in the range of 1.901 to 1.9980 V which corresponds to code 0x018."



Forward Transfer Function Equations

What code n will the ADC use to represent voltage V_{in} ?

General Equation

n = converted code

Vin = sampled input voltage

V+ref = upper voltage reference

V-ref = lower voltage reference

N = number of bits of resolution in ADC

$$n = \left| \frac{V_{in} - V_{-ref}}{V_{+ref} - V_{-ref}} 2^{N} + 1/2 \right|$$

Simplification with $V_{-ref} = 0 V$

$$n = \left[\frac{V_{in}}{V_{+ref}} 2^N + 1/2 \right]$$

$$n = \left[\frac{3.3V}{5V} 2^{10} + 1/2 \right] = 388$$

$$[X] = floor(X)$$
 floor(X) nearest integer I such that $I \le X$ floor(x+0.5) rounds x to the nearest integer



Inverse Transfer Function

What range of voltages $V_{in\ min}$ to $V_{in\ max}$ does code n represent?

General Equation

n = converted code

Vin_min = minimum input voltage for code n

Vin_max = maximum input voltage for code n

V+ref = upper voltage reference

V-ref = lower voltage reference

N = number of bits of resolution in ADC

$$V_{in_min} = \frac{n - \frac{1}{2}}{2^{N}} (V_{+ref} - V_{-ref}) + V_{-ref}$$

$$V_{in_max} = \frac{n + \frac{1}{2}}{2^{N}} (V_{+ref} - V_{-ref}) + V_{-ref}$$

Simplification with $V_{-ref} = 0 V$

$$V_{in_min} = \frac{n - \frac{1}{2}}{2^N} \left(V_{+ref} \right)$$

$$V_{in_max} = \frac{n + \frac{1}{2}}{2^N} \left(V_{+ref} \right)$$



What if the Reference Voltage is not known?

- Example running off an unregulated battery (to save power)
- Measure a known voltage and an unknown voltage

$$V_{unknown} = V_{known} \frac{n_{unknown}}{n_{known}}$$

- Many MCUs include an internal fixed voltage source which ADC can measure for this purpose
- Can also solve for Vref

$$V_{ref} = V_{known} \frac{2^N}{n}$$

"My ADC tells me that channel 27 returns a code of 0x6543, so I can calculate that $V_{REFSH} = 1.0V * 2^{16}/0x6543 = ...$




ANALOG TO DIGITAL CONVERSION CONCEPTS



A/D - Flash Conversion


- A multi-level voltage divider is used to set voltage levels over the complete range of conversion.
- A comparator is used at each level to determine whether the voltage is lower or higher than the level.
- The series of comparator outputs are encoded to a binary number in digital logic (a priority encoder)
- Components used
 - 2^N resistors
 - 2^{N-1} comparators
- Note
 - This particular resistor divider generates voltages which are not offset by ½ bit, so maximum error is 1 bit
 - We could change this offset voltage by using resistors of values R, 2R, 2R ... 2R, 3R (starting at bottom)





ADC - Successive Approximation Conversion

- Successively approximate input voltage by using a binary search and a DAC
- SA Register holds current approximation of result
- Set all DAC input bits to 0
- Start with DAC's most significant bit
- Repeat
 - Set next input bit for DAC to I
 - Wait for DAC and comparator to stabilize
 - If the DAC output (test voltage) is smaller than the input then set the current bit to 1, else clear the current bit to 0



ADC Performance Metrics

- Linearity measures how well the transition voltages lie on a straight line.
- Differential linearity measure the equality of the step size.
- Conversion time: between start of conversion and generation of result
- Conversion rate = inverse of conversion time



Sampling Problems

- Nyquist criterion
 - Fsample >= 2 * Fmax frequency component
 - Frequency components above $\frac{1}{2}$ Fsample are aliased, distort measured signal
- Nyquist and the real world
 - This theorem assumes we have a perfect filter with "brick wall" roll-off
 - Real world filters have more gentle roll-off
 - Inexpensive filters are even worse (e.g. first order filter is 20 dB/decade, aka 6 dB/octave)
 - So we have to choose a sampling frequency high enough that our filter attenuates aliasing components adequately



Inputs

Differential

- Use two channels, and compute difference between them
- Very good noise immunity
- Some sensors offer differential outputs (e.g. Wheatstone Bridge)

Multiplexing

- Typically share a single ADC among multiple inputs
- Need to select an input, allow time to settle before sampling


Signal Conditioning

- Amplify and filter input signal
- Protect against out-of-range inputs with clamping diodes



Sample and Hold Devices

- Some A/D converters require the input analog signal to be held constant during conversion, (e.g. successive approximation devices)
- In other cases, peak capture or sampling at a specific point in time necessitates a sampling device.
- This function is accomplished by a sample and hold device as shown to the right
- These devices are incorporated into some A/D converters






ANALOG INTERFACING PERIPHERALS



GPIO Alternative Functions

- Pins may have different features
- To enable an alternative function, set up the appropriate register
- May also have analogue paths for ADC / DAC etc.
- Advantages:
 - Saves space on the package
 - Improves flexibility








DIGITAL TO ANALOG CONVERTER



Example: Waveform Generation







- DAC can be used to generate arbitrary waveforms
 - Pregenerate lookup table
 - Update DAC output value
 - Delay
 - Repeat



C Code – Initialisation

```
void tone_init(void) {
      dac_init();
      sinewave_init();
void sinewave_init(void) {
      int n;
      for (n = 0; n < NUM\_STEPS; n++) {
             sine_table[n] = MAX_DAC_CODE * (1 + sin(n*2*PI/NUM_STEPS)) / 2;
```



C Code – Playback


```
void tone_play(int period_us, int num_cycles, wavetype wave) {
       int sample, step;
       while(num cycles-- > 0) {
               for (step = 0; step < NUM_STEPS; step++) {
                       switch(wave) {
                               case SINE: sample = sine table[step]; break;
                               case SQUARE: sample = step < NUM_STEPS / 2 ? 0 : MAX_DAC_CODE;</pre>
                                       break;
                               case RAMP: sample = (step * MAX_DAC_CODE) / NUM_STEPS; break;
                       dac_set(sample);
                       delay us(period us);
```



ANALOG COMPARATOR




Example: Power Failure Detection



- Need warning of when power has failed
 - Very limited amount of time before capacitor C1 discharges
 - Save critical information
 - Turn off output devices
 - Put system into safe mode
- Can use a comparator to compare Vcc against a fixed reference voltage Vref



Comparator Overview



- Comparator compares Sense and Vref
- Comparator output indicates if Sense > Vref (I) or Sense < Vref (0)
- Can generate an interrupt request (+, -, or +- edges)
- If the Sense input drops below Vref, fire an interrupt



C Code – Comparator


```
void comparator_isr(int state) {
        if (state) {
                 // Sense > Vref, turn off LEDs.
                 leds_set(0, 0, 0);
        } else {
                 // Sense < Vref, turn on red LED.</pre>
                 leds_set(1, 0, 0);
int main(void) {
        comparator_init();
        comparator_set_trigger(CompBoth); // ISR on both rising and falling edges.
        comparator_set_callback(comparator_isr);
```



ANALOG TO DIGITAL CONVERTER



Example: Battery Monitoring




- Operates similar to comparator based system
- Measures battery voltage, better indication of battery life than comparator
- Can provide information about battery discharge rate



Battery Discharge

Example Battery Discharge Curve



- As the battery discharges, the voltage decreases
- Measure with respect to Vref (fixed voltage reference)
- Convert to capacity with look-up table and interpolation

