

Thermoelectric Optimizer – SPB Model App

Dr. Jan-Hendrik Pöhls
July 2020
Montreal QC Canada



Introduction




Welcome to the Thermoelectric Optimizer App.

The App is based on the single-parabolic band model and can compute using empirical parameters such as Seebeck coefficient and mobility:

- > Electrical thermal conductivity
- ➤ Seebeck coefficient, mobility, Lorenz number, and thermoelectric figure of merit as function of the charge carrier concentration
- Thermoelectric figure of merit as function of charge carrier concentration and temperature
- ➤ Optimized charge carrier concentration and thermoelectric figure of merit as function of temperature versus experimental data

Introduction




- ➤ SPB model assumes that the effective mass does not change with carrier concentration (i.e., single parabolic band) and that the electron transport is limited by a single scattering mechanism:
 - ➤ Acoustic Deformation Potential (ADP) → vibrations of atoms reduce the mobility of the charge carriers
 - ➤ Polar Optical Phonon (POP) → charge carriers are scattered of the electric field of polar atoms (material needs to be hetero-polar)

or

➤ Ionized Impurity (IMP) → charge carriers are scattered by the ionization of the lattice (i.e., unbalanced local charge near a crystal impurity)


Installation



- Download the executable (i.e., Thermoelectric Optimizer.exe), the example .csv file (i.e. Example_SPB.csv), and the icon (i.e., icon_spb.ico)
- Create a new folder and move all files in the folder (please note that temporary files will be save in the folder as well)

• Please note that the App won't work if the icon is not in the same folder than the executable (.csv file can be in a different folder)


Starting the program




- Double-click of the executable and a window will open
- Don't worry if the warning appears in the window:
 MatplotlibDeprecationWarning: The MATPLOTLIBDATA
 environment variable was deprecated in Matplotlib 3.1 and will be
 removed in 3.3. exec(bytecode, module.__dict__)

• The opening of the App takes some time depending on your processor

Start Window – Input Parameters




Input parameters from experiments




- A: Compound name (required)
- B: Temperature in K (required)
 (Temperature should be above
 1 and below 10,000 K)
- C: Seebeck Coefficient in μV K⁻¹ (required; only positive values) (Seebeck coefficient should be above 0.1 and below 1,500 μV K⁻¹)
- D: Carrier Concentration in cm⁻³
 (not required; only positive values)
 (Carrier Concentration should be above 1E12 and below 1E24 cm⁻³)
- $E: Mobility \ in \ cm^2 \ V^{\text{-}1} \ s^{\text{-}1} \ (not \ required) \\ (Mobility \ should \ be \ above \ 0.01 \ and \\ below \ 10,000 \ cm^2 \ V^{\text{-}1} \ s^{\text{-}1})$
- F: Total thermal Conductivity in W m^{-1} K⁻¹ (not required) (Thermal Conductivity should be above 0 and below 10,000 W m^{-1} K⁻¹)
- G: Dielectric Constant (unitless) (not required) (Dielectric Constant should be above 1 and below 100,000)

Red is required to press 'Calculate' and 'Plot'. Green is not required.; only to compute certain parameters

Start Window - Calculation







H: Choose the scattering mechanism (5)

- Acoustic Deformation Potential
- > Polar Optical Phonon
- ► Ionized Impurity
 - > Brooks-Herring (with screening)
 - Requires Dielectric Constant
 - > Takes a long time which increases with increasing Seebeck Coefficient
- Polar Optical Phonon (Fermi)
 - > Slight overestimation at high Carrier Concentration
- ➤ Ionized Impurity (Fermi)
 - Conwell-Weisskopf (without screening)
 - > No Dielectric Constant required
 - > Fast
 - Overestimation at high Carrier Concentration
- I: Calculate the properties below (make sure required fields have a value)

Start Window - Output Parameters




NaN (not a number) is the default and only change if the parameter is computed




- J: Chemical Potential in meV (Computed from the Seebeck coefficient) *
- K: Effective mass in m_e (Computed from the Seebeck coefficient and Carrier Concentration)
- L: Intrinsic Mobility in cm² V⁻¹ s⁻¹ (Computed from the Seebeck coefficient, Carrier Concentration and Mobility)
- M : Lorenz number in W Ω K⁻² (Computed from the Seebeck coefficient) *
- N: Electronic Thermal Conductivity in W m⁻¹ K⁻¹ (Computed from the Seebeck coefficient, Carrier Concentration, and Mobility)
- O: Lattice Thermal Conductivity in W m⁻¹ K⁻¹ (Computed from the Seebeck coefficient, Carrier Concentration, Mobility, and Thermal Conductivity)
- P: Thermoelectric Figure of Merit, zT
 (Computed from the Seebeck coefficient, Carrier Concentration, Mobility, and Thermal Conductivity)

^{*} except Brooks-Herring Ionized Impurity Scattering which also requires Carrier Concentration and Dielectric Constant

Start Window – Save Information






- **Q**: Extension of File to save the above properties
- → .csv (Comma delimited file) → Can be open with Excel
- \rightarrow .json (Json file) \rightarrow Can be open with Python

R: Save Button

When the button 'Calculate' is pressed, a temporary file is produced and saved in the App folder. The information of the temporary file is used for the file to save to avoid that you change accidently the input parameters and save the incorrect input parameters with the calculated parameters.

Start Window – Plot Information



* except Brooks-Herring Ionized Impurity Scattering which also requires Carrier Concentration and Dielectric Constant

Carrier Concentration Range

S: Minimum Carrier Concentration in cm⁻³ (required; only positive values) (Carrier Concentration should be above 1E12 and below 1E24 cm⁻³)

 $\Phi^2\pi$

T: Maximum Carrier Concentration in cm⁻³ (required; only positive values) (Carrier Concentration should be above 1E12 and below 1E24 cm⁻³ and should be higher than minimum Carrier Concentration)


U : Plot button (Input parameters are required)
Create temporary file for the plot data


V : Plot Data on y-axis *

- Seebeck Coefficient (requires A, B, C, S, and T)
- Mobility (requires A, B, C, D, E, S, and T)
- Lorenz number (requires A, B, C, S, and T)
- Thermoelectric Figure of Merit (requires A, B, C, D, E, F, S, and T)

W: Save Button (save data of the plot with the extension which is set in R) 10

Start Window





X: Plot

Y: (from left to right)

House: Original Plot

Arrow left: Go to last step (if you zoomed in)

Arrow right: Go one step forward (if you went

back)

Cross: Left-click → **move graph**


Right-click → zoom in


Magnifying glass: Zoom in

Shifters : No effect

Disk: Save the plot

File Menu





Open File

Compound

Name

Seebeck Coefficient in $\mu V \ K^{-1} \rightarrow \text{needs to}$ be positive

Temperature in KCarrier Concentration in cm⁻³ \rightarrow needs to be positive


Mobility in cm² V^{-1} s⁻¹


Dielectric Constant

Example CSV file
(It needs to be in
this order and no
empty rows; empty
values are fine but
you need at least
a name, temperature
and Seebeck
coefficient for each
row; marked in red)

4	Α	В	С	D	E	F	G	Н	- 1
1 (Compound	Temperature / K	Seebeck Coefficient / mu V K -1	Carrier Concentration / cm-3	Mobility / cm2 V-1 s-1	Thermal Conductivity / W m-1 K-1	Dielectric Constant		
2 /	A1	300	140	3.00E+19	80	3.4	200		
3 /	A1	400	180	3.60E+19	60	2.7	200		
4	A1	600	220	3.90E+19	34	2.1	200		
5 1	B1	450	35	3.00E+21	10	12	10		
5 (C1	303	98	1.00E+20	112	5	80		
7 (C1	403	145	2.00E+20	97	4.6	80		
3 (C1	503	200	2.20E+20	87	4.3	80		
O									
1									
2									
3									
4									
5									
6									
7									
8									
9									
0									
1									
4	Eva	mple +			: [

Uploaded Data






A*: List of Compound names


B*: List of Temperatures for the Corresponding Compound

Changing the compound will update the temperature list and the Seebeck Coefficient, Carrier Concentration, Mobility, Thermal Conductivity and Dielectric Constant

(The same for changing the temperature)

Edit Menu






A2: Edit Graph


- > Edit the graph on the first window and optimized graphs (see later)
- > Other font, font size, or reposition it

B2: Edit Graph 3D

- > Edit the graph for the 3D plot
- ➤ Other font, font size, or change the surface to a 3D grid

Edit Graph





A_Graph: Font Size

B_Graph: Font (Choose Times New Roman or Arial) *

C_Graph: Width of the figure D_Graph: Height of the figure

E_Graph: x-point where the plot starts in the figure


F_Graph: Width of the plot


G_Graph: y-point where the plot starts in the figure

H_Graph: Height of the plot

^{*} For more fonts, please send me an email

Edit Graph 3D






A_3D_Graph: Font Size


B_3D_Graph: Font (Choose Times New Roman or Arial) *

C_3D_Graph: Width of the 3D figure D_3D_Graph: Height of the 3D figure

E_3D_Graph: Change between a surface or wired 3D Figure


Surface: Wired:






^{*} For more fonts, please send me an email

Compute Menu





A3: Compute All (enabled when a file was open)

- > Compute all the properties of a .csv file
- ➤ If Minimum and Maximum Carrier Concentration are given, compute all the properties as a function of Carrier Concentration
- ➤ Save computed data in a folder → each compound/temperature pair has its own safe file


B3: Compute Optimize Carrier Concentration

- Compute the Thermoelectric Figure of Merit as a function of Carrier Concentration and Temperature
- Compute Optimized Carrier Concentration and the corresponding Optimized Thermoelectric Figure of Merit


Thermoelectric Optimizer - 378 Model App							
Provide polynominial fitting coefficier	its of all thermoelectric para	meters					
Seebeck Coefficient Coefficients / mu V K-1	1 - A_Opt	* T^0					
Carrier Concentrations Coefficients / cm-3	1 - B_Opt	* T^0					
Mobility Coefficients / cm2 V-1 s-1	1 - C_Opt	* T^0					
Thermal Conductivity Coefficients / W m-1 K-1	1 - D_Opt	* T^0					
Temperature range / K	Min. T	Max. T	Step T				
Carrier Concentration range / cm-3	Min. n	Max. n					
Acoustic Deformation Potential	☐ 3D plot	Exp. Plot	Opt. Plot	Plot	.csv 🖃	Save	Close Window

A_Opt: Temperature-dependent Seebeck Coefficient in μ V K⁻¹ described by polynomial to the fifth order For example: $S = 100 * T^0 + 0.8 * T^1 + -1E-5 * T^2 \rightarrow$ Change List to 3 and write 100, 0.8, and -1E-5 in the three fields

- B_Opt: Temperature-dependent Carrier Concentration cm⁻³ described by polynomial to the fifth order
- C_Opt: Temperature-dependent Mobility in cm² V⁻¹ s⁻¹ described by polynomial to the fifth order
- D_Opt: Temperature-dependent Thermal Conductivity in W m⁻¹ K⁻¹ described by polynomial to the fifth order




- **E_Opt:** Minimum Temperature in K (above 1 and below 10,000 K)
- **F_Opt:** Maximum Temperature in K (above 1 and below 10,000 K and above Minimum Temperature)
- **G_Opt:** Temperature Step in K (above 1 and below 100 K)
- H_Opt: Temperature-dependent Thermal Conductivity in W m⁻¹ K⁻¹ described by polynomial to the fifth order



- **J_Opt:** Choose the scattering mechanism (5)
- > Acoustic Deformation Potential
- Polar Optical Phonon
- > Ionized Impurity
- Polar Optical Phonon (Fermi)
- Ionized Impurity (Fermi)

- **K_Opt:** Create a 3D plot (Temperature, Carrier Concentration and Thermoelectric Figure of Merit
- L_Opt: Create experimental Carrier Concentration vs Temperature and experimental Thermoelectric Figure of Merit vs Temperature
- M_Opt: Create optimized Carrier Concentration vs Temperature and optimized Thermoelectric Figure of Merit vs Temperature

(If both are clicked, the experimental Carrier Concentration and Thermoelectric Figrue of Merit are compared to the optimized values)



N_Opt: Plot the data for the corresponding plots (K, L, or M)


O_Opt: Choose the format to save the computed data (experimental versus optimized data)

- .csv file (Excel format)
- .json file (Python format)

P_Opt: Save button

Important: If the data is plotted, the main window can decrease (if the App is using in Microsoft Windows). You can change it by going \rightarrow Display Settings \rightarrow Change the size of text, apps, and other items to 100%

Questions?



• If you have questions or concerns or find some errors, please send me an email: <u>Jan.Poehls@Dal.ca</u>

• Thank you for choosing the Thermoelectric Optimizer – SPB Model App