





12.24196

Introduction to Embedded Systems

Prof. Dr.-Ing. Stefan Kowalewski | Julius Kahle, M. Sc. Summer Semester 2025

Part 3

Programmable Logic Controllers

Content


- Logic Control
- 2. PLC Technology
- 3. Programming languages
 - Function Block Diagram (FBD)
 - Ladder Diagram (LD)
 - Instruction List
- 4. Model-based Design
- 5. Sequential Controllers
 - Sequential Function Charts





Logic Control vs. Continuous Control (1)

- Introduction by examples
- Example 1: A Trip (Abschaltung, Notabschaltung)
- Representation:
 Piping and Instrumentation
 Diagram (P&ID, ISO 3511)
- A P&ID shows all major plant equipment like pipes, tanks, valves, and the main control functions
- Function of the trip: Switch off heating, when temp has reached a certain value.
- Purpose: Avoid undesired (e.g. dangerous) process states










Logic Control vs. Continuous Control (2)

- Example 2: An Interlock (Verriegelung)
- Function of the interlock: Enable only desired operator action (disable undesired ones).
- Purpose:

 Avoid undesired process
 states caused by
 undesired operator actions.







Logic Control vs. Continuous Control (3)


Example 3: A Sequence Controller (Ablaufsteuerung)

Function of a sequence controller:

Realize a desired sequence

of process steps.

- Here:
 - 1. Fill tank (open V1 until LIS+)
 - 2. Heat up (open V2 until TIS+)
 - 3. Drain tank (open V3 until LIS_)








Logic Control vs. Continuous Control (3)

Example 3: A Sequence Controller (Ablaufsteuerung)

Function of a sequence controller:
Realize a desired sequence
of process steps.

- Here:
 - 1. Fill tank (open V1 until LIS+)
 - 2. Heat up (open for m minutes)
 - 3. Drain tank (open for n minutes)








Logic Control vs. Continuous Control (4)

Example 4: A Continuous Controller

Function of a continuous controller: Keep process variable at a desired value (despite disturbances or in case of changes of the settings).








Logic Control vs. Continuous Control (5)

General Control Structure (for all three examples)







Logic Control vs. Continuous Control (6)

- Main difference between logic (trip, interlock, sequence controller) and continuous control?
- The main purpose of logic controllers is the processing of discrete variables
- Example: Trip

```
Logic Control:
```

```
temp(t) ∈ { below_limit, above_limit}
```


Continuous Control:

```
temp(t) \subset \mathbb{R} \times \{^{\circ}C\}
```





Logic Control vs. Continuous Control (6)








Logic Control vs. Continuous Control (7)

heating(t) \in { on, off, broken, inrepair}



▶ Difference?





Content

- Logic Control
- 2. PLC Technology
- 3. Programming languages
 - Function Block Diagram (FBD)
 - Ladder Diagram (LD)
 - Instruction List
- 4. Model-based Design
- 5. Sequential Controllers
 - Sequential Function Charts





Programmable Logic Controllers (1)

Device platforms for implementing logic controllers:


- Dedicated hardware ("hardwired logic")
 - German: Verbindungsprogrammierte Steuerung (VPS)
- Programmable Logic Controllers (PLC)
 - German: Speicherprogrammierbare Steuerung (SPS)
- Distributed Control Systems (DCS)
 - Prozessleitsysteme (PLS)
- Industrial PCs (IPCs)
- Soft-PLCs





Programmable Logic Controllers (2)

Examples



© Hitachi, http://www.hitachi-ies.co.jp/english/products/plc/eh_150/product_range.htm





Programmable Logic Controllers (3)

Examples





© plcs.net, http://www.geometrixar.com/plc_programming






Programmable Logic Controllers (4)

Examples





© Degensha, http://www.dengensha.com/site.cfm/nut-feeders.cfm





Programmable Logic Controllers (5)

Examples



© DirectIndustry, http://img.directindustry.com/images_di/photo-g/programmable-logic-controller-plc-359905.jpg,

http://www.walkeremd.com/Eaton-Cutler-Hammer-PLC1.htm






Programmable Logic Controllers (6)

Examples SIMATIC









64-500

© https://engineering.purdue.edu/ManLab/plc.html, http://www.pacontrol.com/siemens-plc-training.html,





Programmable Logic Controllers (7)

Examples



© http://www.hinrichsen-haustechnik.de/grafik/sps2.jpg






Programmable Logic Controllers (8)

Pyramid model of industrial automation

Layers:



Functions:

Higher Functions:

advanced continuous control recipe control alarm handling/registration visualization displaying/operating

Basic functions:

basic continuous control sequence control threshold supervision safety trips interlocks


local displays local manual operating sensing actuating





Programmable Logic Controllers (9)

PLC architecture



PAA= Prozessabbild der Ausgänge





Programmable Logic Controllers (10)


PLC operating system: Cyclic Scanning Mode





Programmable Logic Controllers (10)

PLC operating system: Cyclic Scanning Mode




One turn around = cycle (≈ ms)





Programmable Logic Controllers (11)

Execution of cyclic scans in the PLC architecture:







Programmable Logic Controllers (12)

The cycle time can vary depending on the program execution.

Example:

```
IF input=TRUE THEN GOTO END ELSE
.
. (many instructions)
.
END: END_IF
```

- Example: Program with one integer variable i, initially i:= 0.
- i:=i+1:
 - "normal" computer after execution i=1.
 - PLC: after first cycle i=1.
 - after second cycle i=2 ...





Programmable Logic Controllers (13)

Maximal reaction time (delay between process event and corresponding control action)?

worst case: 2x max. cycle time P change written in input memory input change output (process event) change (control reaction)





Programmable Logic Controllers (14)

- Maximal reaction time = 2 * maximal cycle time
- Cyclic scanning mode supports estimation of real-time behavior:
 - Determine longest program execution path.
 - Measure or estimate cycle time for this execution path.
 - Apply formula above.
- ▶ What to do, if reaction time is too long?
 - Optimize Program
 - Choose more performant PLC
 - Use interrupts





Content

- Logic Control
- 2. PLC Technology
- 3. Programming languages
 - Function Block Diagram (FBD)
 - Ladder Diagram (LD)
 - Instruction List
- 4. Model-based Design
- 5. Sequential Controllers
 - Sequential Function Charts





PLC programming languages

► Before 1992:

- "Similar" PLC languages
- either resembling electrical design or assembly
- Each PLC vendor used its own dialect
- Disadvantages?
- ➤ 1992: IEC 61131 International standardization of five PLC languages


Abbreviation	Name	German Name
FB	Function Block	Funktionsblocksprache
LD	Ladder Diagram Relay Ladder Logic (RLL)	Kontaktplan
IL	Instruction List	Anweisungsliste
ST	Structured Text	Strukturierter Text
SFC	Sequential Function Charts	Ablaufsprache





► Idea:


- Resembling switching circuit design by gates
- blocks with input and output








► Basic logic operators:







Example:









▶ Blocks are not restricted to logic operators.

NAND, ADD, MULT, TIMER










IEC 61131 languages: Ladder Diagram (LD)

Kontakt polan (KOP)

► Idea:

Resembling switching circuit design by relays ("schematics")

"contacts" and "coils"






IEC 61131 languages: Ladder Diagram (LD)

► Idea:

- Resembling switching circuit design by relays ("schematics")
- "contacts" and "coils"









IEC 61131 languages: Ladder Diagram (LD)

► Basic logic operators:











IEC 61131 languages: Ladder Diagram (LD)

► Basic logic operators:










IEC 61131 languages: Ladder Diagram (LD)

Example:








IEC 61131 languages: Ladder Diagram (LD)

► Function blocks can be integrated into LD programs:






IEC 61131: Functions vs. Function Blocks




Example of a "Function Block":






IEC 61131 Standard Function Blocks: Latches (1)

- ► How can the desired functionality be programmed using only the already known basic operators?
 - FB:









IEC 61131 Standard Function Blocks: Latches (2)

Switching off the motor?

• FB:


Off

Off

Notor

AND

LD:







IEC 61131 Standard Function Blocks: Bistables (1)


► Combination of both latches: motor motor **AND** On **OR** motor OR **AND** motor.





IEC 61131 Standard Function Blocks: Bistables ctd.


Bistable as standard Function Block:







IEC 61131 Standard Function Blocks: Bistables ctd.









IEC 61131 Standard Function Blocks: Edge Triggers

Flanzeneszenne

- ▶ Problem: A change of a variable shall be detected or indicated.
- Example:




Desired function:







IEC 61131 Standard Function Blocks: Edge Triggers (ctd.)








IEC 61131 Standard Function Blocks: Timers

- ▶ IEC 61131 defines three different timer function blocks:
 - TON Timer On Delay
 - TOF Timer Off Delay
 - TP Timer Pulse








IEC 61131 Standard Function Blocks: Timers (ctd.)

Timing diagram for TON: Eiushalt veriges








IEC 61131 Standard Function Blocks: Timers (ctd.)

Timing diagram for TOF:








IEC 61131 Standard Function Blocks: Timers (ctd.)

► Timing diagram for TP:







Anweisungsliste (AWL)

- Textual programming language ("list of instructions")
- ~ Assembly language
- Instruction syntax:

(label:)	operator	operand
e.g. END	AND	sensor1

One-register or accumulator architecture

Aktuelles Ergebnis (AE)

Accumulator is called CR ("current result")





► Basic operators: lusbouching

LD X "Load"
$$CR = X$$

AND X


 $CR \longrightarrow AND \longrightarrow CR$
 $CR := CR \land X$
 $CR \longrightarrow CR := CR \land X$
 $CR \longrightarrow CR \longrightarrow CR$
 $CR \longrightarrow CR := CR \lor X$

Also: XOR (exclusive OR)





Basic operators with negation:





Basic operators: Math instructions

GT
$$X$$
 "Greater-than" $CR := \begin{cases} 1 \text{ if } CR > X \\ 0 \text{ else} \end{cases}$

$$EQ \quad X \quad \text{"Equal"} \quad CR := \begin{cases} 1 \text{ if } CR > X \\ 0 \text{ else} \end{cases}$$

MOD X

"Modulo"

CR:= CR mod X

Also: LT, GE & LE (Less or Equal), NE (Not Equal), ADD, SUB, MUL, DIV





Basic operators (ctd.):

ST

X

"Store"

X := CR

S

X

'Set"

 $X:=\begin{cases} 1 & \text{if } CR=1\\ X & \text{if } CR=0 \end{cases}$

R

X

"Reset"

 $X:= \begin{cases} \underline{0 \text{ if } CR=1} \\ X \text{ if } CR=0 \end{cases}$





Basic operators (ctd.): GOTO instructions

JMP label "jump"

JMPC label "jump conditionally"

Go to label if CR=1

JMPCN label "jump conditionally negated"


Go to label if CR=0

Also: RET/RETC/RETCN (Return, i.e. jump to the end of the program)





Basic logic operations in IL: そに メルフ



declaration of variables



ightharpoonup Example: $f := a \land (b \lor \neg c)$

LD	b	LD	a
ORN	С	AND(b
AND	а	ORN	С
ST	f)	
		ST	f



IEC 61131 languages: Instruction List – Example


(* Methode 1 *)	(* Methode 2 *)	(* Methode 3 *)
(* Parameterversorgung: *) Free fin a Aus +#500ms-PT ET Dest	LD t#500ms ST Zeit1.PT LD Frei ST Zeit1.IN	LD t#500ms PT Zeit1 LD Frei
(* Aufruf: *) CAL Zeit1(IN:=Frei, PT:=t#500ms, Q=>Aus, (*Ausgangsp*) ET=>Wert(*Ausgangsp*))	CAL Zeit1	IN Zeit1
	(* Auswertung der Ausgangsparam. *) LD Zeit1.Q ST Aus LD Zeit1.ET ST Wert	

[Source: John & Tiegelkamp: SPS-Programmierung mit IEC 61131-3, Springer-Verlag, 4. Aufl., S. 115]






Bistables?





Function block calls in IL: Example RS



Variant 1:

ST myBistable.S

LD y

ST myBistable.R

...

CAL myBistable

Z

Variant 2:

CAL myBistable(S:=x,R:=y)
LD myBistable.Q
ST Z





myBistable.Q

LD

ST

Function block calls in IL: Example TON

```
VAR
myTimer:TON;
start,motor:BOOL;
END_VAR
```

```
LD start
ST myTimer.IN
CAL myTimer(PT:= T#1min30s)
...
LD myTimer.Q
S motor
```






Content

- Logic Control
- 2. PLC Technology
- 3. Programming languages
 - Function Block Diagram (FBD)
 - Ladder Diagram (LD)
 - Instruction List
- 4. Model-based Design
- 5. Sequential Controllers
 - Sequential Function Charts











- Problems with this approach:
- 1. Does the specification represent the originally desired behavior?
- 2. Is the specification complete and consistent
- 3. How to implement the specification?

- Instead: Build a model of the controller first.
- 1. It helps discussing/clarifying the specification.
- 2. It can be analyzed algorithmically.
- 3. Automatic code generation becomes possible.





Our model: Moore and Mealy automata.

$$A = (X, U, Y, f, g, x_0)$$

X: Set of discrete states

U: input alphabet

Y: output alphabet

 $f: X \times U \rightarrow X$


g: output function

 x_0 : initial state


state trans. fct.:

$$x'=f(x,u)$$

Moore Automaton:




Mealy Automaton:







Our example for model-based design: A function block for alarm handling



Specification:

- The RED light must be switched on as soon as DANGER becomes TRUE.
- 2. When the operator presses the RECEIPT button, the RED light is switched off and the YELLOW light is switched on.
- 3. When the danger is over, the YELLOW light can be switched off by pressing the RESET button.





Modeling the example


1. Variables, type of automata

$$x = (red, yellow) \in \{(0,0), (1,0), (0,1)\}$$

$$u = (danger, receipt, reset) \in \mathbb{B}^3$$

$$y = x$$









Code generation: Your suggestions?





Code generation

Systematic approach: Divide program into two parts:

- Check and perform transitions
- 2. Set or reset output





Model-based development of logic control programs (ctd.)

Code Generation, Solution: Variable declarations

```
VAR INPUT
 danger,receipt,reset:BOOL;
END VAR
VAR OUTPUT
 red,yellow:BOOL;
END_VAR
VAR
 X0:BOOL:=TRUE;
 X1,X2:BOOL:=FALSE;
END VAR
```





Model-based development of logic control programs (ctd.)

Code Generation, Solution: Check and perform transitions

```
LD x0
    AND danger CR:= 0
STU R XO 1
JPMC output
    LD x1
    AND receipt
57 R x1
ST S x2
    JPMC output
    LD x2
    ANDN danger
    AND reset
57W R x2
57 5 x0
```





Model-based development of logic control programs (ctd.)

Code Generation, Solution: **Set/reset outputs**

output: LD x0

R yellow

R red

LD x1

S red

R yellow

LD x2

R red

S yellow





Content

- Logic Control
- 2. PLC Technology
- 3. Programming languages
 - Function Block Diagram (FBD)
 - Ladder Diagram (LD)
 - Instruction List
- 4. Model-based Design
- 5. Sequential Controllers
 - Sequential Function Charts

LFC

Verreelen somme

Montsprade 45





Specification and Implementation of Sequence Controllers

Example: A dosing and heating unit feed **V1** LIS+ dosing tank T1 LIS **V2** heating tank T2 TIS+ **V3 V4**





Specification and Implementation of Sequence Controllers

Process specification for the example

		Steps	Control Actions	Transition Conditions
sedneuce		1.) Fill T1	by opening V1	Until LIS1 activated
		2.) Fill T2	by opening V2	Until LIS2 activated
		3.) Heat T2	by opening V3	Until TIS3 activated
		4.) Empty T2	by opening V4	Until T2 is empty
		5.) go back to step 1		





Specification and Implementation of Sequence Controllers

Consequence:


 A specification and programming language for sequence controllers must be able to represent all these elements (steps, actions, transitions, conditions, sequences, parallelism).

→ Sequential Function Chart (SFC)






1. Steps:








2. Actions:











3. Transitions:







4. Connections:










5. Branching and joining:


- Alternative
 - Start & End branch with Transitions





- Parallel
 - Start & End branch with Steps









Firing rule:

A transition of a SFC fires, if

- all preceding steps are active, and
- all succeeding steps are inactive, and
- the transition condition is true.

Strong firing rule
Weak firing rule

When a transition fires, all preceding steps become inactive and all succeeding steps become active.




Firing rule (ctd.)

If more than one transition can fire, priority rules apply.

Example:













Embedding of the SFC execution into the PLC scanning cycle:

- 1. (Read inputs.)
- 2. Execute actions or underlying programs for the active steps.
- Determine transitions which can fire.
- 4. Fire transitions.
- (Write outputs.)

Example:











Dosing and heating tank








SFC for the dosing and heating tank







SFC for the dosing and heating tank







SFC for the dosing and heating tank (complete view)

