# Schloms Process GmnH

**Job Interview Task** 

# **How to Approach the Problem**

#### Configure Raspberry Pi Networking

- Connect eth0 to the company network.
- Connect eth1 (USB Ethernet adapter) directly to the PLC.
- Assign static IP 192.168.0.10 to eth1.

#### Security considerations

- Will have to ensure the PLC allows OPC-UA connections from the Pi.
- Use authentication if required (username/password or certificates).
- We can also optionally, set up firewall rules on the raspberry pi to isolate traffic.

- PLC (OPC-UA): 192.168.0.5 (isolated network)
- Raspberry Pi:
  - eth0: 10.80.10.30 (company network)
  - eth1: 192.168.0.10 (PLC network via USB-Ethernet adapter)
- InfluxDB Server: 10.80.10.1




## How to write on raspberry pi interface eth0

- static ip\_address=10.80.10.30/24
- static routers=10.80.10.1
- static domain\_name\_servers = 8.8.8.8 interface eth1
- static ip\_address=192.168.0.10/24

### **Network Architecture**

- Raspberry Pi acts as a network bridge.
  - Two separate network segments.
- Siemens PLC isolated from company network.
- Data flow: PLC --> Raspberry Pi --> InfluxDB virtual server
- Pi has only 1 built in ethernet port
- The ETH adapter gives the raspberry pi a second ethernet port.
  - **Port 1: Company network (10.80.10.30)**
  - Port 2: PLC network (192.168.0.x)



# **Network Plan**

000

000

000

# How to Approach the Problem in simulation

```
# OPC-UA server URL
opcua_url = "opc.tcp://jannen-ThinkPad:53530/OPCUA/SimulationServer"
# opcua_url = "opc.tcp://192.168.0.5:4840" |

# NodeIDs to read from the OPC-UA server
node_ids = [
    "ns=3;i=5",
    "ns=3;i=6",
    "ns=3;i=7",
    "ns=3;i=8",
    "ns=3;i=9"
]
```

### Goals

- Machine status from PLC with OPC-UA standard.
  - To achieve this, simulate machine status data using Prosys OPC UA simulation server.
- Read this data using a Python script on a Raspberry Pi.
  - Run the python script on local PC
- Store the data in InfluxDB for monitoring and analysis.
  - Use docker to run InfluxDB virtual server.


## Prepare the Simulation

- Create a MachineStatus object in Prosys.
- Add variables (xAuto, xError, ..) with NodelDs ns=3;i=5 to ns=3;i=9.
- · Set data types to Boolean.

### Develop the Script

- Connect to OPC UA server.
- Read values every 1 second.
- Write to InfluxDB using appropriate tags and measurements.





```
# InfluxDB configuration
self.influx_host = "http://localhost:8086"
# influx_host = "10.80.10.1" # Company InfluxDB server
self.token = "UDb3euK28xX5A027jQStLnv4yJ9Hmsbx43TpCUUftiHsfV6EY4Q2RNJu1u600Ldi-R1jWcV0sluzoU8yVVGBoQ=="self.org = "jannen" # Replace with company or organization name
# bucket = "plc_data"
self.bucket = "machine_status"
```

- Uses the InfluxDB v2 client with token-based authentication.
- Writes data to a specific bucket (machine\_status) under an organization (organization\_name).

```
def run(self):
   # Connect to OPC-UA server
   opc client = Client(self.opcua url)
   try:
       opc client.connect()
       if opc client.is connected():
           print("Connected to OPC-UA Server")
       else:
           print("OPC-UA Server connection failed.")
   except Exception as e:
       print(f"Error connecting to OPC-UA Server: {e}")
   # Connect to InfluxDB
   try:
       influx client = InfluxDBClient(url=self.influx host, token=self.token, org=self.org)
       # health check
       health = requests.get(f"{self.influx host}/health")
       if health.ok and health.json().get("status") == "pass":
           write api = influx client.write api(write options=SYNCHRONOUS)
           print("Connected to InfluxDB and health check passed.")
           print("InfluxDB health check failed.")
   except Exception as e:
       print(f"Failed to connect to InfluxDB: {e}")
```

### **Establishing Connection**

- Tries to connect to the OPC-UA server and InfluxDB.
- If it fails, it catches the exception and prints an error message.
- Then it exits the method without crashing the whole program.

```
try:
    while True:
        data points = []
        # Read values from the specified nodes
        for node id in self.node ids:
            node = opc client.get node(node id)
            value = node.get value()
            print(f"Read {node id}: {value}")
            if value is None:
                print(f"Warning: Node {node id} returned None")
            data points.append({
                "measurement": "machine status",
                "tags": {
                    "node id": node id
                "fields": {
                    "value": int(value) if isinstance(value, bool) else float(value)
        if not data points:
            print("No data to write to InfluxDB, skipping this iteration.")
        # Write all points in one batch
        write api.write(bucket=self.bucket, org=self.org, record=data points, write precision=WritePrecision.NS)
        print("Batch data written to InfluxDB")
        # Wait before next read
        print("Waiting for 1 second before next read...")
        time.sleep(1)
finally:
    opc client.disconnect()
    influx client.close()
    print("Disconnected from OPC-UA Server and InfluxDB")
   print("Data collection completed.")
   print("Exiting...")
```

- Reads values every second.
- Converts boolean values to integers for consistency.
- Uses both data\_points objects to write to InfluxDB.
- Skips nodes that return None to avoid writing invalid data.
- data\_points creates a list of dictionaries in the InfluxDB line protocol format, which is typically used when writing multiple points at once using a batch write.

Video: data collection sim.webm

Git: Data Collection

# Thank you

Jannen

+49 15210317952

thyman\_bathlo@yahoo.com

https://github.com/Jannen06

