

Version: V2.1

Level: Confidential

Shenzhen Concox Information Technology Co., Ltd

GPS Tracker Communication Protocol (AT1, AT2, QBIT, AT3, AT4, AT5, AT6)

Important Revision History

Writer	Date	Version	Audit	Approval	Description
BianYuta o	2016-01-13	1.0.0			First edition
BianYuta o	2016-04-08	1.0.2			Add WIFI protocol packet
BianYuta o	2016-04-19	1.0.3			Add LBS alarm packet protocol
BianYuta o	2016-06-14	1.0.4			Modify WIFI protocol
					Add Bluetooth positioning protocol
Zhou Hongzho u	2017-01-11	1.0.5			Add SSID in GP100 WIFI protocol
	2017-06-23	1.1			Revised
	2018-5-24				Modify example
	2018-6-6	V1.5			Add Sub-protocol Number of 94 packet
	2018-9-10	V1.6			Add open cover alarm
_	2019-3-7	V1.9		_	Add AT6 voltage-battery
_	2019-3-8	V2.0		_	Add AT1 and AT2 volttage-battery
	2019-4-18	V2.1			Add GPS upload mode



Content

I. PROTOCOL PACKET FORWIAT	4
1.1 PROTOCOL NUMBER	4
I. PROTOCOL PACKET	5
2. LOGIN PACKET	5
	7
3.1. Heartbeat packet sent by terminal	
	3
	8
	11
	12
	ent by terminal12
b) Server LBS multiple bases packet response	13
· ·	
a) WiFi packet sent by terminal	
b) WIFI packet responded by sever	
a) Alarm packet sent by terminal	
b) Alarm packet response of server	
8. ALARM PACKET (LBS)	21
a) Alarm packet sent by terminal	21
b) Alarm packet response of server	23
9. ONLINE COMMAND	24
a) Online command sent by server	24
b) Online command replied by terminal (0x21)	24
	26
a) Time request sent by terminal	26
	2e
11. INFORMATION TRANSMISSION PACKET	27



	a) Information transmission packet sent by terminal	27
	b) Server Response Information Transmission Packet	30
III.AP	PPENDIX	31
1.	CODE FRAGMENT OF THE CRC-ITU LOOKUP TABLE ALGORITHM IMPLEMENTED BASED ON C LANGUAGE	31
2.	Data Flow Diagram	32
3.	VOLTAGE-BATTERY CORRESPONDENCE OF HEARTBEAT PACKET (GT710)	33
4.	VOLTAGE-BATTERY CORRESPONDENCE OF HEARTBEAT PACKET (AT1/AT2)	34
5.	VOLTAGE-BATTERY CORRESPONDENCE OF HEARTBEAT PACKET (QBIT)	35
6.	VOLTAGE-BATTERY CORRESPONDENCE OF HEARTBEAT PACKET (AT4)	35
7.	VOLTAGE-BATTERY CORRESPONDENCE OF HEARTBEAT PACKET (AT3)	36
8.	VOLTAGE-BATTERY CORRESPONDENCE OF HEARTBEAT PACKET (AT6)	36



i. Protocol Packet Format

Format	Length (Byte)	Description		
Start Bit	2	0x780x78 (packet length: 1bit) or 0x790x79 (packet length 2 bits)		
Packet Length	1(2)	Length = Protocol Number + Information Content + Information Serial Number + Error Check		
Protocol Number	1	Transmission packet type (see the following diagram for details)		
Information Content	N	Content is defined by specific application and protocol number		
Information Serial Number	2	Serial number of data sent later at each time will be automatically added '1'.		
Error Check	2	Error check (From "Packet Length" to "Information Serial Number"), are values of CRC-ITU. CRC error occur when the received information is calculated, the receiver will ignore and discard the data packet. (See Appendix 1)		
Stop Bit	2	Fixed value:0x0D 0x0A		

1.1 Protocol Number

Login Information	0x01
GPS Positioning Data (UTC)	0x22
Multiple Bases Extension Information Packet	0x28
Heartbeat Packet	0x23
Alarm Data (UTC)	0x26
LBS Alarm	0x19
Online Command	0x80
Online Command Response of Terminal	0x21
Time Check Packet	0x8A
Information Transmission Packet	0x94
WIFI Communication Protocol	0x2C



ii. Protocol Packet

2. Login packet

Description:

- Login packet is the information packet connecting the terminal and platform, it can send terminal information to platform.
- If a GPRS connection is established successfully, the terminal will send a first login message packet to the server and, within five seconds, if the terminal receives a data packet responded by the server, the connection is considered to be a normal connection; if not, the terminal will send login packet again.
- If no packet returned by server within 5 seconds, then the response of login packet is timeout.
- Terminal reboot automatically after 3 timeouts.

2.1. Login Message Packet

2.1. Logiii Wiessage Facket			
1.		Length	Description
Start Bit		2	0x78 0x78
Packet Length		1	Length = Protocol Number + Information Content + Information Serial Number + Error Check
Protoco	l Number	1	0x01
	Terminal ID	8	Example: IMEI number is 123456789123456, terminal ID is: 0x01 0x23 0x45 0x67 0x89 0x120x34 0x56
Information Content	Type Identification Code	2	Distinguish terminal type by type identification code.
	Time Zone Language	2	See the following chart for details of time zone language mark.
Information Serial Number		2	Serial number of data sent later at each time will be automatically added '1'.
Error Check		2	Error check (From "Packet Length" to "Information Serial Number"), are values of CRC-ITU. CRC error occur when the received information is calculated, the receiver will ignore and discard the data packet. (See Appendix 1)
Stop Bit		2	Fixed value:0x0D 0x0A

Example: 78 78 11 01 03 51 60 80 80 77 92 88 22 03 32 01 01 AA 53 36 0D 0A

Time Zone Language

	15	
One and a	14	
half bits	13	Time zene velve evnende 100
bit15—	12	Time zone value expands 100
bit4	11	
	10	



	9				
	8				
	7				
	6				
	5				
	4				
Lower half bit4-bit0	3	GMT			
	2	N	o definition		
	1	Language Select Bit		1	
	0	Language Select Bit		0	

Bit3 0-----Eastern time

1-----Western time

Example: Extended bit: 0x32 0x00 means GMT+8

Calculation method: 8*100=800 converts to HEX: 0X0320

Extended bit: 0x4D 0xD8 means GMT-12:45

Calculation method: 12.45*100=1245 converts to HEX: 0x04 0xDD

Here, to save 4 bytes, calculation result left shifted 4 bits and combined eastern time, western time and language bit.

2.2. Login packet response (server response)

2.	Length	Description		
Start Bit	2	0x78 0x78		
Doolsat Langth	1	Length = Protocol Number + Information Content + Information Serial		
Packet Length		Number + Error Check		
Protocol Number	1	0x01		
Information Serial	2	Serial number of data sent later at each time will be automatically added		
Number	2	17.		
		Error check (From "Packet Length" to "Information Serial Number"),		
Error Check	2	are values of CRC-ITU. CRC error occur when the received information		
Litor Check		is calculated, the receiver will ignore and discard the data packet. (See		
		Appendix 1)		
Stop Bit	2	Fixed value:0x0D 0x0A		

Example: 78 78 05 01 00 05 9F F8 0D 0A



3. Heartbeat Packet

Description:

- Heartbeat packet is a data packet to maintain the connection between the terminal and the server.
- If a GPRS connection is established successfully, the terminal will send a first login message packet to the server and, within five seconds, if the terminal receives a data packet responded by the server, the connection is considered to be a normal connection; if not, the terminal will send login packet again.
- If no packet returned by server within 5 seconds, then the response of heartbeat packet is timeout.
- Terminal reboot automatically after 3 timeouts.

3.1. Heartbeat packet sent by terminal

		T (1	
		Length	Description
		(Byte)	1
	Start Bit	2	0x78 0x78
Day	cket Length	1	Length = Protocol Number + Information Content +
rac	eket Length	1	Information Serial Number + Error Check
Prote	ocol Number	1	0x23
	Terminal		
	Information	1	See the following diagram for details
	Content		
			Transformation method: To divide by 100 after convert
			hexadecimal decimal.
			Example: 0X01,0X9F, 019F converted to decimal is 415.
	Voltage Level	2	Divide 415 by 100 get 4.15. 4.15 is the terminal' s
Information			voltage level. (See appendix for voltage-battery
Content			correspondence)
Content	GSM Signal Strength		
		1	0x00: no signal;
			0x01: extremely weak signal;
			0x02: very weak signal;
			0x03: good signal;
			0x04: strong signal.
	Language/Extended	2	latter bit 0x01 Chinese 0x02 English
	Port Status	_	and the the the terminate one 2 English
Ser	rial Number	2	Serial number of data sent later at each time will be
Seriai Number			automatically added '1'.
Error Check			Error check (From "Packet Length" to "Information Serial
		,	Number"), are values of CRC-ITU. CRC error occur when
		2	the received information is calculated, the receiver will
			ignore and discard the data packet. (See Appendix 1)
	Stop Bit	2	Fixed value: 0x0D 0x0A
			I

Example: 78 78 0B 23 C0 01 22 04 00 01 00 08 18 72 0D 0A

Terminal Information

One byte is consumed defining for various status information of the mobile phone.



В	it	Code Meaning
	D:+7	1: Oil and electricity disconnected
	Bit7	0: Oil and electricity connected
	Bit6	1: GPS tracking is on
	DIIO	0: GPS tracking is off
	Bit3~Bit5	Extended Bit
BYTE	Bit2	1: Charge On
	DILZ	0: Charge Off
	Bit1	1: ACC high
	DILI	0: ACC Low
	Bit0	1: Defense Activated
	DIW	0: Defense Deactivated

3.2. Server Responds the Heartbeat Packet

	Length (Byte)	Description
Start Bit	2	0x780x78
Packet Length	1	Length = Protocol Number + Information Content + Information Serial Number + Error Check
Protocol Number	1	0x23
Serial Number	2	Serial number of data sent later at each time will be automatically added '1'.
Error Check	2	Error check (From "Packet Length" to "Information Serial Number"), are values of CRC-ITU. CRC error occur when the received information is calculated, the receiver will ignore and discard the data packet. (See Appendix 1)
Stop Bit 2		Fixed value: 0x0D 0x0A

Example: 78 78 05 23 01 00 67 0E 0D 0A

4. GPS Location Packet

Description:

- Data packet used to transmit terminal location
- Upload locating data based on rule after successfully connected and positioned.
- Re-upload locating data after successfully connected.

4.1. Location packet sent by terminal

	Length	Description
Start Bit	2	0x78 0x78
Packet Length	1	Length = Protocol Number + Information Content + Information Serial Number + Error Check
Protocol Number	1	0x22 (UTC)



	Date Time	6	Year (1byte) Month (1byte) Day (1byte) Hour (1byte) Min (1byte) Second (1byte) (converted to a decimal) (Date Time)
	Quantity of GPS information satellites	1	The first character is GPS information length, The second character is positioning satellite number (converted to a decimal)
	Latitude	4	Convert to a decimal and divide 1800000
	Longitude	4	Convert to a decimal and divide 1800000
	Speed	1	Convert to a decimal
	Course, Status	2	Convert to binary number of 16 bits and calculate by bits (see the following diagram)
	MCC	2	Mobile Country Code(MCC) (converted to a decimal)
	MNC	1	Mobile Network Code(MNC)(converted to a decimal)
	LAC	2	Location Area Code (LAC) (converted to a decimal)
	Cell ID	3	Cell Tower ID(Cell ID)(converted to a decimal)
	ACC	1	ACC Status ACC low: 00, ACC high: 01 (not available for 06)
Information Content	Data Upload Mode	1	GPS data upload mode (06 series are excluded) 0x00 Upload by time interval 0x01 Upload by distance interval 0x02 Inflection point upload 0x03 ACC status upload 0x04 Re-upload the last GPS point when back to static. 0x05 Upload the last effective point when network recovers. 0x06 Update ephemeris and upload GPS data compulsorily 0x07 Upload location when side key triggered 0x08 Upload location after power on 0x09 Unused 0x0A Upload the last longitude and latitude when device is static; time updated 0x0D Upload the last longitude and latitude when device is static 0x0E Gpsdup upload (Upload regularly in a static state.).
	GPS Real-time	1	0x00 Real time upload 0x01 Re-upload (06 series are
	Re-upload Mileage	4	excluded) Divided by 100 after turn HEX into decimal. (Only available for devices with this function)
Seria	l Number	2	Serial number of data sent later at each time will be automatically added '1'.
Erro	Error Check		Error check (From "Packet Length" to "Information Serial Number"), are values of CRC-ITU. CRC error occur when the received information is calculated, the receiver will ignore and discard the data packet. (See Appendix 1)
St	top Bit	2	Fixed value:0x0D 0x0A
			5 C9 02 7A C8 18 0C 46 58 60 00 14 00 01 CC 00 28 7D 00 1F 71 0

Example: 78 78 22 22 0F 0C 1D 02 33 05 C9 02 7A C8 18 0C 46 58 60 00 14 00 01 CC 00 28 7D 00 1F 71 00




00 01 00 08 20 86 0D 0A

i. Course & Status

Two bytes are consumed, defining the running direction of GPS. The value ranges from 0° to 360° measured clockwise from north of 0° .

	Bit7	0
	Bit6	0
	Bit5	GPS real-time/differential
	ыіз	positioning
BYTE_1	Bit4	GPS having been positioning or not
	Bit3	East Longitude, West Longitude
	Bit2	South Latitude, North Latitude
	Bit1	
	Bit0	
	Bit7	
	Bit6	
	Bit5	Commo
DVTE 1	Bit4	Course
BYTE_2	Bit3	
	Bit2	
	Bit1	
	Bit0	

For example: the value is 0x15 0x4C, the corresponding binary is 00010101 01001100,



which means GPS tracking is on, real time GPS, location at north latitude, east longitude and the course is 332°.



4.2. Server location packet response

Location packet server no response





5. LBS Multiple Bases Extension Information Packet

- Description
- For transmitting the data packet of transmit position when terminal is not positioning.

a) LBS multiple bases extension information packet sent by terminal

		Length (Byte)	Explain
Start Bit		2	0x78 0x78
Packe	et Length	1	Length= protocol number +information content+ serial number +error check
Protoco	ol Number	1	0x28
	Date and Time (UTC)	6	year (1byte) month (1byte) day (1byte) hour (1byte)minute(1byte)second(1byte)(convert to decimal)
	MCC	2	Mobile Country Code
	MNC	1	Mobile Network Code(MNC)
	LAC	2	Mobile Network Code(MNC)
	CI	3	Cell Tower ID(Cell ID)
	RSSI	1	Received Signal Strength Indicator, range from $0x00\sim 0xFF$, $0x00$ weak, $0xFF$ strongest.
	NLAC1	2	Same as LAC
	NCI1	3	Same as CI
	NRSSI1	1	Same as RSSI
	NLAC2	2	Same as LAC
	NCI2	3	Same as CI
Info	NRSSI2	1	Same as RSSI
Content	NLAC3	2	Same as LAC
	NCI3	3	Same as CI
	NRSSI3	1	Same as RSSI
	NLAC4	2	Same as LAC
	NCI4	3	Same as CI
	NRSSI4	1	Same as RSSI
	NLAC5	2	Same as LAC
	NCI5	3	Same as CI
	NRSSI5	1	Same as RSSI
	NLAC6	2	Same as LAC
	NCI6	3	Same as CI
	NRSSI6	1	Same as RSSI
	Time leads	1	Time difference between actual time of mobile station signal reaches to base station and time of mobile station signal

www.iconcox.com



			reaches to base station when distance assumed 0
	Language	2	0x00 0x01 Chinese 0x00 0x02English
	ation Serial amber	2	The serial number of the first GPRS data (including status packet and data packet such as GPS, LBS package) sent after booting is '1', and the serial number of data sent later at each time will be automatically added '1'.
Erro	r Check	2	The check codes of data in the structure of the protocol, from the Packet Length to the Information Serial Number (including "Packet Length" and "Information Serial Number"), are values of CRC-ITU. CRC error occur when the received information is calculated, the receiver will ignore and discard the data packet.
Stop Bit		2	Fixed value: 0x0D 0x0A

b) Server LBS multiple bases packet response

LBS multiple bases server has no need to reply

6. WIFI Information Protocol (Qbit)

WIFI information packet

Description: It is used for transmitting the WIFI data packet received by terminal.

a) WiFi packet sent by terminal

	Length (Byte)	Explain
Start Bit	2	0x78 0x78
Packet Length	1	Length= protocol number +information content+ serial number +error check
Protocol Number	1	0x2C



		ı	1
	Date and		year (1byte) month (1byte) day (1byte) hour
	Time (UTC)	6	(1byte)minute(1byte)second(1byte)(convert
			to decimal)
	MCC	2	Mobile Country Code
	MNC	1	Mobile Network Code(MNC)
	LAC	2	Mobile Network Code(MNC)
	CI	3	Cell Tower ID(Cell ID)
	DCCI	1	Received Signal Strength Indicator , range from
	RSSI	1	$0x00\sim0xFF$, $0x00$ weak, $0xFF$ strongest.
	NLAC1	2	Same as LAC
	NCI1	3	Same as CI
	NRSSI1	1	Same as RSSI
	NLAC2	2	Same as LAC
	NCI2	3	Same as CI
	NRSSI2	1	Same as RSSI
	NLAC3	2	Same as LAC
	NCI3	3	Same as CI
	NRSSI3	1	Same as RSSI
	NLAC4	2	Same as LAC
	NCI4	3	Same as CI
Info	NRSSI4	1	Same as RSSI
Content	NLAC5	2	Same as LAC
	NCI5	3	Same as CI
	NRSSI5	1	Same as RSSI
	NLAC6	2	Same as LAC
	NCI6	3	Same as CI
	NRSSI6	1	Same as RSSI
	TVICESTO	1	Time difference between
		1	actual time of mobile station signal reaches to
	Time leads		base station and time of mobile station signal
			reaches to base station when distance assumed 0
	WiFi		Confirm WIFI quantity in the packet, 0: no WIFI
	quantity	1	detected
	1 3		WIFI MAC of searched signal 1(transmit
		_	according to the actual number of searched WIFI.
	WIFI MAC1	6	Search one, transmit one; search none, then
			transmit 0)
	WIFI	1	WIEL strangth of size-11
	strength 1	1	WIFI strength of signal 1
	WIFI SSID	1	ISSID Langth of SSID 1WIE
	Length 1	1	ISSID Length of SSID 1WIF
	WIFI SSID1	N	SSID content of SSID 1WIFI (0-32 Bytes)



	WIFI MAC2	6	Same as above
	WIFI strength 2	1	Same as above
	WIFI SSID Length 2	1	ISSID Length of SSID 1WIF
	WIFI SSID2	N	SSID content of SSID 1WIFI (0-32 Bytes)
	•••		
Information Number	n Serial	2	The serial number of the first GPRS data (including status packet and data packet such as GPS, LBS package) sent after booting is '1', and the serial number of data sent later at each time will be automatically added '1'.
Error Checl	ζ	2	The check codes of data in the structure of the protocol, from the Packet Length to the Information Serial Number (including "Packet Length" and "Information Serial Number"), are values of CRC-ITU. CRC error occur when the received information is calculated, the receiver will ignore and discard the data packet.
Stop Bit		2	Fixed value: 0x0D 0x0A

Example: 78 78 48 2C 10 06 0E 02 2D 35 01 CC 00 28 7D 00 1F 71 2D 28 7D 00 1E 17 25 28 7D 00 1E 23 1E 28 7D 00 1F 72 1C 28 7D 00 1F 40 12 00 00 00 00 00 00 00 00 00 00 FF 02 80 89 17 44 98 B4 5C CC 7B 35 36 61 A6 5B 00 1F A0 04 0D 0A

b) WIFI packet responded by sever

WIFI packet server has no need to respond



7. Alarm Packet (GPS)

Description:

- Transmit alarm content defined by terminal
- Server response and parse longitude and latitude into address and re-upload to terminal after receiving the alarm content
- Terminal send address to pre-set SOS number of device.

a) Alarm packet sent by terminal

Alarm packet (Single fence)

ii.		Length	Description
Start Bit		2	0x78 0x78
Packet Length		1	Length = Protocol Number + Information Content + Information Serial Number + Error Check
Proto	col Number	1	0x26 (UTC)
	Date Time	6	Year (1byte) Month (1byte) Day (1byte) Hour (1byte) Min (1byte) Second (1byte) (converted to a decimal) (Date Time)
	Quantity of GPS		The first character is GPS information length, The second
	information	1	character is positioning satellite number (converted to a
	satellites		decimal)
	Latitude	4	Convert to a decimal and divide 1800000
	Longitude	4	Convert to a decimal and divide 1800000
	Speed	1	Convert to a decimal
	Course, Status		Convert to binary number of 16 bits and calculate by bits (see
		2	the following diagram) (same as GPS packet, see GPS packet
			for details)
	I DC longth	1	LBS length in total (LBS Length+ MCC+ MNC+LAC+ Cell
mation	LDS leligui		ID=9) parse is not mandatory, can be skipped
ntent	MCC	2	Mobile Country Code(MCC) (converted to a decimal)
	MNC	_1	Mobile Network Code(MNC)(converted to a decimal)
	LAC	2	Location Area Code (LAC) (converted to a decimal)
	Cell ID	3	Cell Tower ID(Cell ID)(converted to a decimal)
	Terminal Information	1	See the following diagram
	Voltage Level	1	0x00: No Power (shutdown) 0x01: Extremely Low Battery (not enough for calling or sending text messages, etc.) 0x02: Very Low Battery (Low Battery Alarm) 0x03: Low Battery (can be used normally) 0x04: Medium 0x05: High
	Protomation	Protocol Number Date Time Quantity of GPS information satellites Latitude Longitude Speed Course, Status LBS length MCC MNC LAC Cell ID Terminal Information	Packet Length 1 Protocol Number 1 Date Time 6 Quantity of GPS information 1 satellites Latitude 4 Longitude 4 Speed 1 Course, Status 2 LBS length 1 MCC 2 MNC 1 LAC 2 Cell ID 3 Terminal Information 1 Information 1



	GSM Signal Strength	1	0x00: no signal; 0x01: extremely weak signal; 0x02: very weak signal; 0x03: good signal; 0x04: strong signal.
	Alarm/Language	2	See the following diagram
Serial Number		2	Serial number of data sent later at each time will be automatically added '1'.
Error Check		2	Error check (From "Packet Length" to "Information Serial Number"), are values of CRC-ITU. CRC error occur when the received information is calculated, the receiver will ignore and discard the data packet. (See Appendix 1)
Stop Bit		2	Fixed value:0x0D 0x0A

Example: 78 78 25 26 0F 0C 1D 03 0B 26 C9 02 7A C8 18 0C 46 58 60 00 04 00 09 01 CC 00 28 7D 00 1F 71 80 04 04 13 02 00 0C 47 2A 0D 0A

Alarm packet (Multiple fences)

	iii.		Length	Description
	Start Bit		2	0x78 0x78
	D 1 (1 1		1_	Length = Protocol Number + Information Content +
	Paci	ket Length		Information Serial Number + Error Check
	Proto	col Number	1	0x27 (UTC)
				Year (1byte) Month (1byte) Day (1byte) Hour (1byte)
		Date Time	6	Min (1byte) Second (1byte) (converted to a decimal) (Date
				Time)
		Quantity of GPS		The first character is GPS information length. The second
		information	1	character is positioning satellite number (converted to a
V		satellites		decimal)
		Latitude	4	Convert to a decimal and divide 1800000
		Longitude	4	Convert to a decimal and divide 1800000
		Speed	1	Convert to a decimal
I	nformation			Convert to binary number of 16 bits and calculate by bits (see
	Content	Course, Status	2	the following diagram) (same as GPS packet, see GPS packet
				for details)
		LBS length	1	LBS length in total (LBS Length+ MCC+ MNC+LAC+ Cell
		LDS Kingtii	1	ID=9) parse is not mandatory, can be skipped
		MCC	2	Mobile Country Code(MCC) (converted to a decimal)
		MNC	1	Mobile Network Code(MNC)(converted to a decimal)
		LAC	2	Location Area Code (LAC) (converted to a decimal)
		Cell ID	3	Cell Tower ID(Cell ID)(converted to a decimal)
		Terminal	1	See the following diagram
		Information	1	See the following diagram



	Voltage Level GSM Signal Strength		0x00: No Power (shutdown) 0x01: Extremely Low Battery (not enough for calling or sending text messages, etc.) 0x02: Very Low Battery (Low Battery Alarm) 0x03: Low Battery (can be used normally) 0x04: Medium 0x05: High 0x06: Very High
			0x00: no signal; 0x01: extremely weak signal; 0x02: very weak signal; 0x03: good signal; 0x04: strong signal.
	Alarm/Language	2	See the following diagram
	Fence Number	1	Valid bit for fence alarm.1 for fence 1, 2 for fence 2 FF is invalid.
Seri	al Number	2	Serial number of data sent later at each time will be automatically added '1'.
Err	Error Check		Error check (From "Packet Length" to "Information Serial Number"), are values of CRC-ITU. CRC error occur when the received information is calculated, the receiver will ignore and discard the data packet. (See Appendix 1)
S	Stop Bit	2	Fixed value:0x0D 0x0A

i. Terminal Information

	Bit	Code Meaning
	Bit7	1:Oil and electricity disconnected
	BII/	0: Oil and electricity connected
	Bit6	1: GPS tracking is on
	BIIO	0: GPS tracking is off
		100: SOS
		011: Low Battery Alarm
	Bit3∼Bit5	010: Power Cut Alarm
BYTE		001:Vibration Alarm
		000: Normal
		1: Charging
	DILZ	0: Not Charge
	D'/1	1: ACC high
	Bit1	0: ACC Low
	D:+0	1: Defense Activated
	Bit0	0: Defense Deactivated



i. Alarm language

. Alarm language	
	0x00: normal
	0x01: SOS
	0x02: Power cut alarm
	0x03: Vibration alarm
	0x04:Enter fence alarm
	0x05:Exit fence alarm
	0x06 Over speed alarm
	0x09 Displacement alarm
	0x0A Enter GPS dead zone alarm
	0x0BExit GPS dead zone alarm
	0x0C Power on alarm
D 4 1	0x0D GPS First fix notice
Byte 1	0x0E Low battery alarm
	0x0F Low battery protection alarm
	0x10 SIM change notice
	0x11 Power off alarm
	0x12 Airplane mode alarm
	0x13 Disassemble alarm
	0x14 Door alarm
	0x15 Low battery and shutdown alarm
	0x16 Sound control alarm
	0x17 Pseudo base-station alarm
	0x18 Open cover alarm
	0x32 Pull alarm
	0x01 Chinese
Byte 2	0x02 English
	0x00 Platform has no need to reply

b) Alarm packet response of server

	Length	Description
Start Bit	2	0x78 0x78
Do alvet Lemeth	1	Length = Protocol Number + Information Content + Information
Packet Length		Serial Number + Error Check
Protocol Number	1	0x26 (UTC)
Information Serial Number	2	Serial number of data sent later at each time will be automatically
information Serial Number		added '1'.
		Error check (From "Packet Length" to "Information Serial
Error Check	2	Number"), are values of CRC-ITU. CRC error occur when the
		received information is calculated, the receiver will ignore and



		discard the data packet. (See Appendix 1)
Stop Bit	2	Fixed value: 0x0D 0x0A

Example: 78 78 05 26 00 1C 9D 86 0D 0A





8. Alarm Packet (LBS)

Description:

- Transmit alarm content defined by terminal
- Server response and parse longitude and latitude into address and re-upload to terminal after receiving the alarm content
- Terminal send address to pre-set SOS number of device.

a) Alarm packet sent by terminal

Alarm packet

iv.		Length	Description
Start Bit		2	0x78 0x78
Pacl	Packet Length		Length = Protocol Number + Information Content + Information Serial Number + Error Check
Proto	col Number	1	0x19 (UTC)
	MCC	2	Mobile Country Code(MCC) (converted to a decimal)
	MNC	1	Mobile Network Code(MNC)(converted to a decimal)
	LAC	2	Location Area Code (LAC) (converted to a decimal)
	Cell ID	3	Cell Tower ID(Cell ID)(converted to a decimal)
	Terminal Information	1	See the following diagram
	Voltage Level GSM Signal Strength	1	0x00: No Power (shutdown) 0x01: Extremely Low Battery (not enough for calling or sending text messages, etc.) 0x02: Very Low Battery (Low Battery Alarm) 0x03: Low Battery (can be used normally) 0x04: Medium 0x05: High 0x06: Very High 0x00: no signal; 0x01: extremely weak signal; 0x02: very weak signal; 0x03: good signal; 0x04: strong signal.
	Alarm/Language	2	See the following diagram
Serial Number		2	Serial number of data sent later at each time will be automatically added '1'.
Error Check		2	Error check (From "Packet Length" to "Information Serial Number"), are values of CRC-ITU. CRC error occur when the received information is calculated, the receiver will ignore and discard the data packet. (See Appendix 1)
S	Stop Bit	2	Fixed value:0x0D 0x0A

Example: 78 78 12 19 01 CC 00 28 7D 00 1F 71 20 04 04 01 01 00 94 6C 89 0D 0A



ii. Terminal Information

	Bit	Code Meaning
	Bit7	1:Oil and electricity disconnected
	Bit/	0: Oil and electricity connected
	Bit6	1: GPS tracking is on
	DIIO	0: GPS tracking is off
		100: SOS
		011: Low Battery Alarm
	Bit3∼Bit5	010: Power Cut Alarm
BYTE		001:Vibration Alarm
		000: Normal
	Bit2	1: Charging
	DIL2	0: Not Charge
	Bit1	1: ACC high
	Biti	0: ACC Low
	Bit0	1: Defense Activated
	DIW	0: Defense Deactivated

ii. Alarm language

	Thaim language	
		0x00: normal
		0x01: SOS
		0x02: Power cut alarm
		0x03: Vibration alarm
		0x04:Enter fence alarm
		0x05:Exit fence alarm
		0x06 Over speed alarm
		0x09 Displacement alarm
	D 4 1	0x0A Enter GPS dead zone alarm
	Byte 1	0x0B Exit GPS dead zone alarm
		0x0C Power on alarm
		0x0D GPS First fix notice
		0x0E External Low battery alarm
		0x0F Low battery protection alarm
		0x10 SIM change notice
		0x11 Power off alarm
		0x12 Airplane mode alarm
		0x13 Disassemble alarm
		0x14 Door alarm
		0x15 Low battery and shutdown alarm

www.iconcox.com



	0x16 Sound control alarm
0x17 Pseudo base-station alarm	
	0x18 Open cover alarm
	0x01 Chinese
Byte 2	0x02 English
	0x00 Platform has no need to reply

b) Alarm packet response of server

	Length	Description
Start Bit	2	0x78 0x78
Daalzat Lanath	1	Length = Protocol Number + Information Content + Information
Packet Length		Serial Number + Error Check
Protocol Number	1	0x26 (UTC)
Information Serial Number	2	Serial number of data sent later at each time will be automatically
		added '1'.
Error Check	2	Error check (From "Packet Length" to "Information Serial
		Number"), are values of CRC-ITU. CRC error occur when the
		received information is calculated, the receiver will ignore and
		discard the data packet. (See Appendix 1)
Stop Bit	2	Fixed value: 0x0D 0x0A

Example: 78 78 05 26 00 1C 9D 86 0D 0A



9. Online Command

Description:

- Use server online command to control terminal to execute task.
- Terminal response results to server.
- a) Online command sent by server

		Length	Description
St	Start Bit		0x78 0x78
Longth	of data bit	1	Length = Protocol Number + Information Content + Information
Length	Of data off	1	Serial Number + Error Check
Protoc	ol Number	1	0x80
	Length of Command	1	=Server flag bit + command content length
	G FI D:	,	Leave for server identification. Terminal receives the original
Information	Server Flag Bit	4	data in Binary in response packet
Content	Command	M	Character string replied in ASCII coding. Command content is
	Content	M	compatible with SMS command.
	(Language)	2	Latter bit: 0x01 Chinese, 0x02 English
			(this bit is not mandatory)
Information	Sarial Number	2	Serial number of data sent later at each time will be automatically
IIIIOIIIIatioi	Information Serial Number		added '1'.
Check Bit			Error check (From "Packet Length" to "Information Serial
		2	Number"), are values of CRC-ITU. CRC error occur when the
			received information is calculated, the receiver will ignore and
			discard the data packet. (See Appendix 1)
Stop Bit		2	Fixed value:0x0D 0x0A

Example:

The bellowing two both works:

 $\textbf{Without language bit}: 78\ 78\ 0E\ 80\ 08\ 00\ 00\ 00\ 00\ 73\ 6F\ 73\ 23\ 00\ 01\ 6D\ 6A\ 0D\ 0A$

With language bit: 78 78 10 80 08 00 00 00 00 73 6F 73 23 00 02 00 01 9A 17 0D 0A

b) Online command replied by terminal (0x21)

Terminal reply (general command)

		Length	Description
Start Bit		2	0x79 0x79
Langth	of data bit	2	Length = Protocol Number + Information Content + Information
Length	of data bit	2	Serial Number + Error Check
Protoco	Protocol Number		0x21
	Server Flag	4	Leave for server identification. Terminal receives the original data in
I C .:	Bit		Binary in response packet
Information Content	Content	1	0x01 ASC II code
Content	Code	1	0x02 UTF16-BE code.
	Content	M	Data needed to be sent (according to content code format)
Information Serial Number		2	Serial number of data sent later at each time will be automatically



		added '1'.
Check Bit	2	Error check (From "Packet Length" to "Information Serial
		Number"), are values of CRC-ITU. CRC error occur when the
		received information is calculated, the receiver will ignore and
		discard the data packet. (See Appendix 1)
Stop Bit	2	Fixed value:0x0D 0x0A

Example: 79 79 00 9D 21 00 00 00 01 42 61 74 74 65 72 79 3A 34 2E 31 36 56 2C 4E 4F 52 4D 41 4C 3B 20 47 50 52 53 3A 4C 69 6E 6B 20 55 70 3B 20 47 53 4D 20 53 69 67 6E 61 6C 20 4C 65 76 65 6C 3A 53 74 72 6F 6E 67 3B 20 47 50 53 3A 53 65 61 72 63 68 69 6E 67 20 73 61 74 65 6C 6C 69 74 65 2C 20 53 56 53 20 55 73 65 64 20 69 6E 20 66 69 78 3A 30 28 30 29 2C 20 47 50 53 20 53 69 67 6E 61 6C 20 4C 65 76 65 6C 3A 3B 20 41 43 43 3A 4F 46 46 3B 20 44 65 66 65 6E 73 65 3A 4F 46 46 00 2E 26 DF 0D 0A



10. Time Packet

Description:

Used for checking time request sent by terminal to server

Generally, it is not mandatory to response as the device can calibrate the time by GPS:

Server can response with a UTC time if needed

a) Time request sent by terminal

Time request sent by termin			
	Length	Description	
	(Byte)	Description	
Start Bit	2	0x78 0x78	
Packet Length	1	Length = Protocol Number + Information Content +	
		Information Serial Number + Error Check	
Protocol Number	1	0x8A	
Serial Number	2	Serial number of data sent later at each time will be	
		automatically added '1'.	
Error Check	2	Error check (From "Packet Length" to "Information Serial	
		Number"), are values of CRC-ITU. CRC error occur when	
		the received information is calculated, the receiver will ignore	
		and discard the data packet. (See Appendix 1)	
Stop Bit	2	Fixed value: 0x0D0x0A	

Example: 78 78 05 8A 00 06 88 29 0D 0A

b)Server response time information

e time imormation				
	Length	Description		
art Bit	2	0x78 0x78		
D14 I4h		Length = Protocol Number + Information Content +		
et Length	1	Information Serial Number + Error Check		
ol Number	1	0x8A (UTC)		
		Year (1byte) Month (1byte) Day (1byte) Hour (1byte)		
Date Time	6	Min (1byte) Second (1byte) (converted to a decimal)		
		(Date Time		
Serial Number		Serial number of data sent later at each time will be		
		automatically added '1'.		
Error Check		Error check (From "Packet Length" to "Information		
		Serial Number"), are values of CRC-ITU. CRC error		
		occur when the received information is calculated, the		
		receiver will ignore and discard the data packet. (See		
		Appendix 1)		
Stop Bit		Fixed value: 0x0D0x0A		
	art Bit et Length ol Number Date Time I Number	Length art Bit 2 et Length 1 ol Number 1 Date Time 6 I Number 2 or Check 2		

Example: 78 78 0B 8A 0F 0C 1D 00 00 15 00 06 F0 86 0D 0A



11. Information Transmission Packet

Description:

• Terminal transmits all types of non-position data.

a) Information transmission packet sent by terminal

		Length	Description	
St	Start Bit		0x79 0x79	
Length of packet		2	Length = Protocol Number + Information Content + Information Serial Number + Error Check	
Protoc	ol Number	1	0x94	
Information Type (Sub-protocol Number)		1	00 External power voltage 01~03 (custom) 04 terminal status synchronization 05door status 08 self-detection parameters 0A iccidto add	
	Data Content	N	Different information type results in different transmission content. See the following for details.	
Information Serial Number Check Bit Stop Bit		2	Serial number of data sent later at each time will be automatically added '1'.	
		2	Error check (From "Packet Length" to "Information Serial Number"), are values of CRC-ITU. CRC error occur when the received information is calculated, the receiver will ignore and discard the data packet. (See Appendix 1)	
		2	Fixed value:0x0D0x0A	

Example: 79 79 00 7F 94 04 41 4C 4D 31 3D 43 34 3B 41 4C 4D 32 3D 43 43 3B 41 4C 4D 33 3D 34 43 3B 53 54 41 31 3D 43 30 3B 44 59 44 3D 30 31 3B 53 4F 53 3D 2C 2C 3B 43 45 4E 54 45 52 3D 3B 46 45 4E 43 45 3D 46 65 6E 63 65 2C 4F 4E 2C 30 2C 32 33 2E 31 31 31 38 30 39 2C 31 31 34 2E 34 30 39 32 36 34 2C 34 30 30 2C 49 4E 20 6F 72 20 4F 55 54 2C 30 3B 4D 49 46 49 3D 4D 49 46 49 2C 4F 46 46 00 0A 06 1E 0D 0A

Transmitted information content

When type is 00, the bit transmit external battery. This bit is two-digit hexadecimal value. Hexadecimal value converted to decimal value and divide 100

Example: 0X04,0X9F, 049F converted to decimal is 101183, then divide 100 is 11.83, which means external voltage is 11.83V

When type is 04, the bit transmits information of terminal status synchronization. The bit length extended. Transmission is ASCII code.

Definition of content identifier



Definition	Identifier	
Alarm Bit 1	ALM1	
Alarm Bit 2	ALM2	
Alarm Bit 3	ALM3	
Status Bit 1	STA1	
SOS Number	SOS	
Center Number	CENTER	
Fence	FENCE	
Fuel/Electricity	DYD	
Cutoff Status	עזע	
Mode	MODE	

ALM1 Definition (Status)

Bit	Definition	Mark
bit7	Vibration Alarm	1 ON 0 OFF
bit6	Network Alarm	1 ON 0 OFF
bit5	Phone Alarm	1 ON 0 OFF
bit4	SMS Alarm	1 ON 0 OFF
bit3	Displacement Alarm	1 ON 0 OFF
bit2	Network Alarm	1 ON 0 OFF
bit1	Phone Alarm	1 ON 0 OFF
bit0	SMS Alarm	1 ON 0 OFF

ALM2 Definition (Status)

Bit	Definition	Mark
bit7	Low Battery Alarm	1 ON 0 OFF
bit6	Network Alarm	1 ON 0 OFF
bit5	Phone Alarm	1 ON 0 OFF
bit4	SMS Alarm	1 ON 0 OFF
bit3	Low Battery Alarm	1 ON 0 OFF
bit2	Network Alarm	1 ON 0 OFF
bit1	Phone Alarm	1 ON 0 OFF
bit0	SMS Alarm	1 ON 0 OFF

ALM3 Definition (Status)

Bit	Definition	Mark
bit7	Overspeed Alarm	1 ON 0 OFF
bit6	Network Alarm	1 ON 0 OFF
bit5	Phone Alarm	1 ON 0 OFF
bit4	SMS Alarm	1 ON 0 OFF
bit3	Power Off Alarm	1 ON 0 OFF
bit2	Network Alarm	1 ON 0 OFF
bit1	Phone Alarm	1 ON 0 OFF
bit0	SMS Alarm	1 ON 0 OFF

STA1 Definition (Status)

Bit Definition	Mark
-----------------------	------

www.iconcox.com



bit7	Arm Status	1 Arm 0 Disarm
bit6	Automatically Arm	1 ON 0 OFF
bit5	Manually Arm	1 ON 0 OFF
bit4	Remotely Disarm	1 ON 0 OFF
bit3	To Be Defined	
bit2	To Be Defined	
bit1	Dis-assembly switch OFF	1 ON 0 OFF
bit0	Dis-assembly Alarm Status	1 ON 0 OFF

Fuel/Electricity Status Definition

Bit	Definition	Mark
bit7	Undefined	
bit6	Undefined	
bit5	Undefined	
bit4	Undefined	
bit3	Deferred execution caused by overspeed	1Valid bit 0 Invalid bit
bit2	Deferred execution caused by GPS unlocated	1Valid bit 0 Invalid bit
bit1	Oil/Electricity cutoff	1Valid bit 0 Invalid bit
bit0	Oil/Electricity connection	1Valid bit 0 Invalid bit

SOS definition: adopt ASCII to transmit (use "," to separate if multiple SOS numbers)

Center number definition: adopt ASCII to transmit

Fence definition: adopt ASCII to transmit

Mode: adopt ASCII to transmit(separate parameters by ", ")

Example: ALM1=FF;ALM2=FF;ALM3=FF;STA1=CO; DYD=01; SOS=12345, 2345, 5678; CENTER=987654;FENCE=FENCE,ON,0,-22.277120,-113.516763,5,IN,1; MODE=MODE,1,20,500

Notice: Not all contents are transmitted and please parse based on bits. Different products upload different contents.

When type is 05, this bit transmit external IO detection (door checking). Transmission is hexadecimal.

Bit	Definition	Mark
bit7	To Be Defined	
bit6	To Be Defined	
bit5	To Be Defined	
bit4	To Be Defined	
bit3	To Be Defined	
bit2	IO Status	1 High 0 Low
bit1	Tricaccina Status	1 High triggering
	Triggering Status	0 Low triggering



bit0	Door Status	1 ON	0 OFF	
UILU	Door Status	1 011	U OI I	

When type is 08, the bit will transmit terminal Self-checking parameters information. The position length is extended and ASCII code transmitted.

When the type is 0A, this bit transmits ICCID, which is hexadecimal

IMEI	8	eg: If IMEI is 123456789123456, the terminal ID is: 0x01 0x23 0x45 0x67 0x89 0x12 0x34 0x56
IMSI	8	eg: If IMSI is 123456789123456, the terminal ID is: 0x01 0x23 0x45 0x67 0x89 0x12 0x34 0x56
ICCID	10	eg: If ICCID is 12345123456789123456, the terminal ID is: 0X12 0x34 0x51 0x23 0x45 0x67 0x89 0x12 0x34 0x56

b) Server Response Information Transmission Packet

Server no Response




iii.Appendix

```
1. code fragment of the CRC-ITU lookup table algorithm implemented based on C language
static constU16crctab16[]=
0X0000.0X1189.0X2312.0X329B,0X4624,0X57AD,0X6536,0X74BF,
0X8C48,0X9DC1,0XAF5A,0XBED3,0XCA6C,0XDBE5,0XE97E,0XF8F7,
0X1081,0X0108,0X3393,0X221A,0X56A5,0X472C,0X75B7,0X643E,
0X9CC9,0X8D40,0XBFDB,0XAE52,0XDAED,0XCB64,0XF9FF,0XE876,
0X2102,0X308B,0X0210,0X1399,0X6726,0X76AF,0X4434,0X55BD,
0XAD4A,0XBCC3,0X8E58,0X9FD1,0XEB6E,0XFAE7,0XC87C,0XD9F5,
0X3183,0X200A,0X1291,0X0318,0X77A7,0X662E,0X54B5,0X453C,
0XBDCB,0XAC42,0X9ED9,0X8F50,0XFBEF,0XEA66,0XD8FD,0XC974,
0X4204.0X538D.0X6116.0X709F.0X0420.0X15A9.0X2732.0X36BB.
0XCE4C,0XDFC5,0XED5E,0XFCD7,0X8868,0X99E1,0XAB7A,0XBAF3,
0X5285,0X430C,0X7197,0X601E,0X14A1,0X0528,0X37B3,0X263A,
0XDECD,0XCF44,0XFDDF,0XEC56,0X98E9,0X8960,0XBBFB,0XAA72,
0X6306,0X728F,0X4014,0X519D,0X2522,0X34AB,0X0630,0X17B9,
0XEF4E,0XFEC7,0XCC5C,0XDDD5,0XA96A,0XB8E3,0X8A78,0X9BF1,
0X7387,0X620E,0X5095,0X411C,0X35A3,0X242A,0X16B1,0X0738,
0XFFCF,0XEE46,0XDCDD,0XCD54,0XB9EB,0XA862,0X9AF9,0X8B70,
0X8408,0X9581,0XA71A,0XB693,0XC22C,0XD3A5,0XE13E,0XF0B7,
0X0840,0X19C9,0X2B52,0X3ADB,0X4E64,0X5FED,0X6D76,0X7CFF,
0X9489.0X8500.0XB79B.0XA612.0XD2AD.0XC324.0XF1BF.0XE036.
0X18C1,0X0948,0X3BD3,0X2A5A,0X5EE5,0X4F6C,0X7DF7,0X6C7E,
0XA50A,0XB483,0X8618,0X9791,0XE32E,0XF2A7,0XC03C,0XD1B5,
0X2942,0X38CB,0X0A50,0X1BD9,0X6F66,0X7EEF,0X4C74,0X5DFD,
0XB58B,0XA402,0X9699,0X8710,0XF3AF,0XE226,0XD0BD,0XC134,
0X39C3,0X284A,0X1AD1,0X0B58,0X7FE7,0X6E6E,0X5CF5,0X4D7C,
0XC60C,0XD785,0XE51E,0XF497,0X8028,0X91A1,0XA33A,0XB2B3,
0X4A44,0X5BCD,0X6956,0X78DF,0X0C60,0X1DE9,0X2F72,0X3EFB,
0XD68D,0XC704,0XF59F,0XE416,0X90A9,0X8120,0XB3BB,0XA232,
0X5AC5.0X4B4C.0X79D7.0X685E.0X1CE1.0X0D68.0X3FF3.0X2E7A.
0XE70E.0XF687.0XC41C.0XD595.0XA12A.0XB0A3.0X8238.0X93B1.
0X6B46,0X7ACF,0X4854,0X59DD,0X2D62,0X3CEB,0X0E70,0X1FF9,
0XF78F,0XE606,0XD49D,0XC514,0XB1AB,0XA022,0X92B9,0X8330,
0X7BC7,0X6A4E,0X58D5,0X495C,0X3DE3,0X2C6A,0X1EF1,0X0F78,
};
//calculate the 16-bit CRC of data with predetermined length.
U16GetCrc16(constU8*pData,intnLength)
U16fcs=0xffff://initialization
while(nLength>0){
fcs=(fcs>>8)^crctab16[(fcs^*pData)&0xff];
nLength--;
pData++;
return~fcs;//negated
```



2. Data Flow Diagram





3. Voltage-Battery Correspondence of Heartbeat Packet (GT710)

Battery Percentage (/%)	Voltage
100	≥2.93
90	2.88
80	2.82
70	2.77
60	2.7
50	2.66
40	2.6
30	2.55
20	2.4
10	2.3
0	2



4. Voltage-Battery Correspondence of Heartbeat Packet (AT1/AT2)

Battery Percentage (/%)	Voltage
100	4.00
80	3.84
60	3.76
40	3.70
20	3.65
5	3.60
1	3.58



5. Voltage-Battery Correspondence of Heartbeat Packet (QBIT)

Battery Percentage (/%)	Voltage
100	4.08
80	3.90
60	3.78
40	3.7
20	3.64
5	3.59
1	3.58

6. Voltage-Battery Correspondence of Heartbeat Packet (AT4)

Battery Percentage (/%)	Voltage
100	≥4.05
90	>4
80	>3.92
70	>3.85
60	>3.79
50	>3.74
40	>3.7
30	>3.67
20	>3.63
5	>3.59



7. Voltage-Battery Correspondence of Heartbeat Packet (AT3)

Battery Percentage (/%)	Voltage
100	3.6
90	3.5
80	3.4
70	3.3
60	3.2
50	3.1
40	3
30	2.9
20	2.8
10	2.7
0	2.6

8. Voltage-Battery Correspondence of Heartbeat Packet (AT6)

Battery Percentage (/%)	Voltage
100	4.13
90	4.08
80	4
70	3.91
60	3.87
50	3.81
40	3.78
30	3.75
20	3.73
10	3.7
5	3.60
0	3.55