```
jdefo002 lab8 part1.c
May 10, 13 21:11
                                                                      Page 1/8
    * idefo002 lab8 part1.c - April 8, 2013
    * Name: Joshua DeForest-Williams jdefo002@ucr.edu
    * CS Login: idefo002
    * Partner Name: Ariana DeJaco E-mail:adeja001@ucr.edu
    * Lab Section: 022
    * Assignment: Lab#8 Exercise# Part1
    * Exercise Description: Rework the LCD and Keypad code to utilize the task sche
   duler format (Keypad code may continue to utilize a function call or may be modi
   fied into an SM task). *
                                 All code from here on out should use the task sc
   heduler
   #define F_CPU 8000000
10
   #include <avr/io.h>
12
13
   #include <avr/interrupt.h>
   #include <avr/sfr defs.h>
14
   #include <util/delay.h>
15
   17
   //Functionality - Sets bit on a PORTx
   //Parameter: Takes in a uChar for a PORTx, the pin number and the binary value
   //Returns: The new value of the PORTx
   unsigned char SetBit(unsigned char pin, unsigned char number, unsigned char bin_
21
   value)
22
           return (bin_value ? pin | (0x01 << number) : pin & ~(0x01 << number));
23
24
26
   //Functionality - Gets bit from a PINx
27
   //Parameter: Takes in a uChar for a PINx and the pin number
   //Returns: The value of the PINx
   unsigned char GetBit(unsigned char port, unsigned char number)
30
31
           return ( port & (0x01 << number) );
33
   volatile unsigned char TimerFlag = 0; // TimerISR() sets this to 1. C programmer
    should clear to 0.
36
   // Internal variables for mapping AVR's ISR to our cleaner TimerISR model.
37
   unsigned long _avr_timer_M = 1; // Start count from here, down to 0. Default 1ms
38
   unsigned long _avr_timer_cntcurr = 0; // Current internal count of 1ms ticks
   // Set TimerISR() to tick every M ms
41
   void TimerSet(unsigned long M)
43
44
           _avr_timer_M = M;
45
           _avr_timer_cntcurr = _avr_timer_M;
47
48
   void TimerOn()
49
           // AVR timer/counter controller register TCCR0
50
           TCCR0 = 0x0B; // bit3bit6=10: CTC mode (clear timer on compare)
51
           // bit2bit1bit0=011: prescaler /64
52
53
           // 00001011: 0x0B
           // SO, 8 MHz clock or 8,000,000 /64 = 125,000 ticks/s
54
           // Thus, TCNT0 register will count at 125,000 ticks/s
55
56
           // AVR output compare register OCRO.
           OCRO = 125; // Timer interrupt will be generated when TCNT0==OCRO
58
           // We want a 1 ms tick. 0.001 s * 125,000 ticks/s = 125
59
           // So when TCNT0 register equals 125,
60
           // 1 ms has passed. Thus, we compare to 125.
61
62
           // AVR timer interrupt mask register
63
           TIMSK = 0x02; // bit1: OCIEO -- enables compare match interrupt
64
65
66
           //Initialize avr counter
           TCNTO = 0;
67
```

```
jdefo002 lab8 part1.c
May 10, 13 21:11
                                                                        Page 2/8
           // TimerISR will be called every _avr_timer_cntcurr milliseconds
           avr timer cntcurr = avr timer M;
70
71
72
           //Enable global interrupts
           SREG |= 0x80; // 0x80: 1000000
73
74
75
   void TimerOff()
76
77
                 = 0x00; // bit2bit1bit0=000: timer off
78
79
80
   void TimerISR() {
81
82
           TimerFlag = 1;
83
   // In our approach, the C programmer does not touch this ISR, but rather TimerIS
86
   ISR(TIMERO_COMP_vect)
87
           // CPU automatically calls when TCNT0 == OCR0 (every 1 ms per TimerOn se
   ttings)
           _avr_timer_cntcurr--;
                                                  // Count down to 0 rather than u
   p to TOP
           if (_avr_timer_cntcurr == 0)
                   // results in a more efficient compare
91
                                                          // Call the ISR that the
                   TimerISR();
92
    user uses
93
                   _avr_timer_cntcurr = _avr_timer_M;
94
95
   // Returns '\0' if no key pressed, else returns char '1', '2', ... '9', 'A', ...
  // If multiple keys pressed, returns leftmost-topmost one
   // Keypad must be connected to port C
   /* Keypad arrangement
           PC4 PC5 PC6 PC7
101
      col 1 2 3
103 TOW
          1 | 2 | 3 | A
4 | 5 | 6 | B
7 | 8 | 9 | C
  PC0 1
105 PC1 2
106 PC2 3
107 PC3 4
108
109
110
   /* Set the LED to the value pressed in the KeyPad
   /*********************
113
   void setValueToLEDs(unsigned char value)
114
115
           PORTA = (value << 2);
           // This is for active Low PORTA = (~(value << 2)) & 0xFC;
116
117
118
   /****************************
120
   /* Gets the value from the KeyPad
   /****************************
121
   unsigned char GetKeypadKey()
123
           PORTC = 0xEF; // Enable col 4 with 0, disable others with 1M-^Rs
124
           asm("nop"); // add a delay to allow PORTC to stabilize before checking
125
           if (GetBit(PINC,0)==0) { return('1');
           if (GetBit(PINC,1)==0)
                                   return('4');
127
128
           if (GetBit(PINC,2)==0)
                                   return('7');
           if (GetBit(PINC.3) == 0) { return('*');
129
130
131
           // Check kevs in col 2
           PORTC = 0xDF; // Enable col 5 with 0, disable others with 1M-^Rs
132
           asm("nop"); // add a delay to allow PORTC to stabilize before checking
133
           if (GetBit(PINC,0)==0) { return('2');
134
           if (GetBit(PINC,1)==0)
                                   return('5');
135
           if (GetBit(PINC,2)==0)
                                   return('8');
136
           if (GetBit(PINC, 3) == 0) { return('0');
```

```
jdefo002 lab8 part1.c
May 10, 13 21:11
                                                                       Page 3/8
139
           // Check kevs in col 3
           PORTC = 0xBF; // Enable col 6 with 0, disable others with 1M-^Rs
140
           asm("nop"); // add a delay to allow PORTC to stabilize before checking
141
           if (GetBit(PINC,0)==0) { return('3');
142
           if (GetBit(PINC,1)==0) {
                                  return('6');
143
                                  return('9');
144
           if (GetBit(PINC,2)==0) {
           if (GetBit(PINC,3)==0) { return('#');
145
146
147
           // Check keys in col 4
           PORTC = 0x7F;
148
149
           asm("nop"); // add a delay to allow PORTC to stabilize before checking
           if (GetBit(PINC,0)==0) { return('A');
150
           if (GetBit(PINC,1)==0)
                                  return('B');
151
           if (GetBit(PINC,2)==0)
                                  return('C');
152
153
           if (GetBit(PINC,3)==0) { return('D');
154
           return('\0'); // default value
155
156
157
158
159
160
   /* Perform all of the initialization operations here.
   /**********************
161
162
   void Init_KeyPad_Task()
163
           DDRA = 0xFC; PORTA = 0x00; // PORTB set to output, Except for PAO and PA2
164
     PAO is input switch
           DDRC = 0xF0; PORTC = 0x0F; // PC7..4 outputs init 0s, PC3..0 inputs init
165
    1s
166
167
   /*****************************
168
169
   /* Process KeyPad Task()
   /* This method will advance the LCD task state machine one state per
170
    /*******************
172
   int Process_KeyPad_Task(int state)
173
174
           unsigned char x;
175
176
177
           x = GetKeypadKey();
           switch (x)
178
179
                   case '\0': setValueToLEDs(0x1F); break; // All 5 LEDs on
180
                   case '1': setValueToLEDs(0x01); break; // hex equivalent
181
182
                   case '2': setValueToLEDs(0x02); break;
                   case '3': setValueToLEDs(0x03); break;
183
184
                   case '4': setValueToLEDs(0x04); break;
                  case '5': setValueToLEDs(0x05); break;
185
                   case '6': setValueToLEDs(0x06); break;
                  case '7': setValueToLEDs(0x07); break;
187
                  case '8': setValueToLEDs(0x08); break;
188
                  case '9': setValueToLEDs(0x09); break;
189
                   case 'A': setValueToLEDs(0x0A); break;
190
                   case 'B': setValueToLEDs(0x0B); break;
191
                   case 'C': setValueToLEDs(0x0C); break;
192
                   case 'D': setValueToLEDs(0x0D); break;
193
                   case '*': setValueToLEDs(0x0E); break;
194
                   case '0': setValueToLEDs(0x00); break;
195
                   case '#': setValueToLEDs(0x0F); break;
196
                   default: setValueToLEDs(0x1B); break; // Should never occur. M
197
   iddle LED off.
198
199
           // return state
200
201
           return -1;
202
203
   204
205
   // Define LCD port assignments here so easier to change than if hardcoded below
  unsigned char *LCD Data = &PORTD;
                                         // LCD 8-bit data bus
```

```
jdefo002 lab8 part1.c
May 10, 13 21:11
                                                                               Page 4/8
   unsigned char *LCD_Ctrl = &PORTB;
                                              // LCD needs 2-bits for control, use por
   t B
   const unsigned char LCD_RS = 3;
                                              // LCD Reset pin is PB3
   const unsigned char LCD E = 4;
                                              // LCD Enable pin is PB4
210
   unsigned char LCD rdy q = 0; // Set by LCD interface synchSM, ready to display n
   unsigned char LCD go g = 0; // Set by user synchSM wishing to display string in
214 unsigned char LCD_string_g[17]; // Filled by user synchSM, 16 chars plus end-of-
   string char
   void LCD WriteCmdStart(unsigned char cmd) {
216
            *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_RS, 0);
            *LCD Data = cmd;
218
219
            *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_E, 1);
220
   void LCD_WriteCmdEnd()
221
222
            *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_E, 0);
223
   void LCD_WriteDataStart(unsigned char Data)
224
            *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_RS,1);
225
226
            *LCD Data = Data;
            *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_E, 1);
227
   void LCD_WriteDataEnd()
229
            *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_E, 0);
230
231
   void LCD_Cursor(unsigned char column ) {
233
            if ( column < 8 ) { // IEEE change this value to 16</pre>
                     LCD_WriteCmdStart(0x80+column);
234
235
236
            else {
                     LCD WriteCmdStart(0xB8+column); // IEEE change this value to 0xB
237
   F+column
239
240
   enum LI_States { LI_Init1, LI_Init2, LI_Init3, LI_Init4, LI_Init5, LI_Init6,
241
            LI_WaitDisplayString, LI_Clr, LI_PositionCursor, LI_DisplayChar, LI_Wait
   Go0 } LI_State;
243
   void LI_Tick() {
244
245
            static unsigned char i;
246
            switch(LI_State) { // Transitions
                     case -1:
247
                             LI_State = LI_Init1;
248
249
                             break;
250
                     case LI_Init1:
251
                             LI_State = LI_Init2;
252
                             i = 0;
                             break
253
254
                     case LI_Init2:
                             if (i<10) { // Wait 100 ms after power up</pre>
255
256
                                      LI_State = LI_Init2;
257
258
                             else {
259
                                      LI_State = LI_Init3;
260
261
                             break;
                     case LI_Init3:
262
                             LI_State = LI_Init4;
                             LCD_WriteCmdEnd();
264
                             break;
265
                     case LI Init4:
266
267
                             LI_State = LI_Init5;
268
                             LCD WriteCmdEnd();
269
                             break;
                     case LI Init5:
270
                             LI_State = LI_Init6;
271
                             LCD WriteCmdEnd();
272
273
                             break;
274
                     case LI Init6:
```

LI_State = LI_WaitDisplayString;   LCD_WriteCmdRnd();   break;	May 10, 13 21:11	jdefo002_lab8_part1.c	Page 5/8
case LI_WaitDisplayString:     if (ILCD_go_g) {         LI_State = LI_WaitDisplayString;     }     else if (LCD_go_g) {         LCD_rdy_g = 0;         LI_State = LI_Clr;     }     break;     case LI_Clr;     break;  case LI_Clr;     break;  case LI_Clr;     break;  case LI_Clr;     break;  case LI_Clr;     break;  case LI_Clr;     break;  case LI_Clr;     break;  case LI_DisplayChar;     LCD_WriteCmdEnd();     i=0;     LCD_writeDataEnd();  case LI_DisplayChar:     if (i<16) {         LCD_WriteDataEnd();     }  case LI_DisplayChar:     if (i<26) {         LCD_WriteDataEnd();     }  case LI_DisplayChar:     if (LCD_Go_g) {         LCD_WriteDataEnd();     }  case LI_WaitGo0;     i++;     }  case LI_WaitGo0;     if (LCD_go_g) {         LI_State = LI_WaitGo0;          LI_State = LI_WaitGo0;			
If (ILCD_go_g) {			
Else if (LCD_go_g) {   LCD_rwriteCmdStart(0x0f)   LCD_writeCmdStart(0x1f)   LCD_rwriteCmdStart(0x3f)   LCD_rwriteCmdStart(0x0f)			
		LI_State = LI_WaltDIsplayString,	
LCD_rdy_g = 0;   LI_State = LI_Clr;		else if (LCD go g) {	
	284		
		LI_State = LI_Clr;	
<pre>case LI_Clr:     LI_State = LI_PositionCursor;     LCD_WriteCmdEnd();     i=0;     break;  case LI_PositionCursor:     LL_State = LI_DisplayChar;     LCD_WriteCmdEnd();     break;  case LI_DisplayChar;     LCD_WriteCmdEnd();     break;  case LI_DisplayChar:     if (i&lt;16) {         LL_State = LI_PositionCursor;         LCD_WriteDataEnd();     i++;     }      else {         LL_State = LI_WaitGoO;         LCD_WriteDataEnd();     }      break;  case LI_MaitGoO;     if (!LCD_go_g) {         LL_State = LI_WaitDisplayString;     }      lelse if (LCD_go_g) {         LI_State = LI_WaitGoO;         land    land</pre>		hreak:	
LI_State = LI_PositionCursor;			
i=07   break;   case LI_PositionCursor:   LI_State = LI_DisplayChar;   LO_WriteCmdShd();   break;   case LI_DisplayChar:   LO_WriteCmdShd();   look	289		
<pre>case LI_PositionCursor:</pre>			
LI_State = LI_DisplayChar; LCD_WriteCmdEnd(); break;  case LI_DisplayChar: if (icl6) {			
LCD_WriteCmdEnd();   break;			
case LI_DisplayChar:     if (i<16) {         LI_State = LI_PositionCursor;         LCD_WriteDataEnd();         i++;         lese {	295	<pre>LCD_WriteCmdEnd();</pre>	
<pre>if (i&lt;16) {</pre>			
LI_State = LI_PositionCursor;  LCD_WriteDataEnd();			
1++;   302   303   6   6   6   6   6   6   6   6   6			
Solution		<pre>LCD_WriteDataEnd();</pre>	
## State   LI_State = LI_WaitGo0; LCD_WriteDataEnd();		i++;	
LI_State = LI_WaitGo0;		else {	
LCD_WriteDataEnd();   break;     case LI_WaitGoO:			
	305		
<pre>case LI_WaitGo0:     if (!LCD_go_g) {         LI_State = LI_WaitDisplayString;     }         LI_State = LI_WaitDisplayString; }  ll_State = LI_WaitGo0;  ll_State = LI_WaitGo0;  ll_State = LI_WaitGo0;  ll_State = LI_InitGo0;  ll_State = LI_InitI;  ll_CD_rdy_g = 0;  break;  case LI_InitI;  ll_CD_rdy_g = 0;  break;  case LI_Init2:     i++; // Waiting after power up  break;  case LI_Init3:     LCD_WriteCmdStart(0x38);  break;  case LI_Init4:     LCD_WriteCmdStart(0x06);  break;  case LI_Init5:     LCD_WriteCmdStart(0x0F);  break;  case LI_Init5:     LCD_WriteCmdStart(0x0F);  break;  case LI_Init6:     LCD_WriteCmdStart(0x01); // Clear</pre>		}	
<pre>if (!LCD_go_g) {</pre>			
LI_State = LI_WaitDisplayString;			
### ### ##############################	310	<pre>LI_State = LI_WaitDisplayString;</pre>	
LI_State = LI_WaitGo0;			
<pre>314 315</pre>			
<pre>316</pre>		}	
II_State = LI_Initl;  } // Transitions  switch(LI_State) { // State actions  case LI_Initl:  LCD_rdy_g = 0;  break;  case LI_Init2:  i++; // Waiting after power up  break;  case LI_Init3:  LCD_WriteCmdStart(0x38);  break;  case LI_Init4:  LCD_WriteCmdStart(0x06);  break;  case LI_Init5:  LCD_WriteCmdStart(0x0F);  break;  case LI_Init5:  LCD_WriteCmdStart(0x0F);  break;  case LI_Init6:  LCD_WriteCmdStart(0x01); // Clear	315	break;	
<pre>318</pre>		and the second s	
319 320			
321     case LI_Init1:       322     LCD_rdy_g = 0;       323     break;       324     case LI_Init2:       325     i++; // Waiting after power up       326     break;       327     case LI_Init3:       328     LCD_WriteCmdStart(0x38);       329     break;       330     case LI_Init4:       331     LCD_WriteCmdStart(0x06);       332     break;       333     case LI_Init5:       334     LCD_WriteCmdStart(0x0F);       335     break;       336     case LI_Init6:       337     LCD_WriteCmdStart(0x01); // Clear		) // ITAIDICIOND	
LCD_rdy_g = 0;   break;	320 switch		
break;   case LI_Init2;			
<pre>case LI_Init2:</pre>			
i++; // Waiting after power up  break;  case LI Init3:			
327	325	i++; // Waiting after power up	
LCD_WriteCmdStart(0x38); break;  so case LI_Init4:  LCD_WriteCmdStart(0x06); break;  case LI_Init5:  LCD_WriteCmdStart(0x0F); break;  LCD_WriteCmdStart(0x0F);  break;  case LI_Init5:  LCD_WriteCmdStart(0x0F); break;  case LI_Init6:  LCD_WriteCmdStart(0x01); // Clear			
break;			
330			
332 break; 333 case LI_Init5: 334 LCD_WriteCmdStart(0x0F); 335 break; 336 case LI_Init6: 337 LCD_WriteCmdStart(0x01); // Clear		<pre>case LI_Init4:</pre>	
333			
134 LCD_WriteCmdStart(0x0F); 135 break; 136 case LI_Init6: 137 LCD_WriteCmdStart(0x01); // Clear			
336 case LI_Init6: 337 LCD_WriteCmdStart(0x01); // Clear			
LCD_WriteCmdStart(0x01); // Clear	335		
	337 338	break;	
339 ///////////////////////////////////			
340 case LI_WaitDisplayString:	340	<pre>case LI_WaitDisplayString:</pre>	
$LCD_rdy_g = 1;$			
342 break; 343 case LI Clr:			
LCD_WriteCmdStart(0x01);			
345 break;		break;	
case LI_PositionCursor:			
347 LCD_Cursor(i);	347	LCD_Cursor(1);	

```
jdefo002_lab8_part1.c
May 10, 13 21:11
                                                                                 Page 6/8
                     case LI_DisplayChar:
349
                              LCD_WriteDataStart(LCD_string_g[i]);
351
                              break;
352
                     case LI_WaitGo0:
                              break;
353
                     default:
354
355
            } // State actions
356
357
    //----END LCD interface synchSM----
358
359
   // SynchSM for testing the LCD interface -- waits for button press, fills LCD wi
361
    th repeated random num
   enum LT_States { LT_s0, LT_WaitLcdRdy, LT_WaitButton, LT_FillAndDispString,
   LT_HoldGo1, LT_WaitBtnRelease } LT_State;
364
365
   void LT_Tick() {
366
            static unsigned char i, x, c;
367
368
            switch(LT_State) { // Transitions
                     case -1:
369
                              LT_State = LT_s0;
371
                              break;
372
                     case LT_s0:
                              LT_State = LT_WaitLcdRdy;
373
374
                              break;
                     case LT_WaitLcdRdy:
375
376
                              if (!LCD_rdy_g) {
377
                                       LT_State = LT_WaitLcdRdy;
378
379
                              else if (LCD_rdy_g)
                                       LT_State = LT_WaitButton;
380
                              break;
382
383
                     case LT_WaitButton:
                              if (GetBit(PINA,0)==1) {
384
                                       LT_State = LT_WaitButton;
386
                              else if (GetBit(PINA,0)==0) { // Button active low
387
                                       LT_State = LT_FillAndDispString;
388
389
390
                              break;
                     case LT_FillAndDispString:
391
392
                              LT_State = LT_HoldGo1;
393
                              break;
394
                     case LT_HoldGo1:
395
                              LCD_go_g=0;
                              LT_State = LT_WaitBtnRelease;
397
                              break;
398
                     case LT_WaitBtnRelease:
                              if (GetBit(PINA,0)==0) { // Wait for button release
399
                                       LT_State = LT_WaitBtnRelease;
400
401
                              else if (GetBit(PINA,0)==1) {
402
403
                                       LT_State = LT_WaitLcdRdy;
404
405
                              break;
                     default:
406
                              LT_State = LT_s0;
407
                     } // Transitions
408
409
            \textbf{switch}(\texttt{LT\_State}) \ \{ \ \textit{// State actions} \\
410
411
                     case LT_s0:
412
                              LCD_go_g=0;
                              strcpy(LCD_string_g, "1234567890123456"); // Init, but nev
   er seen, shows use of strcpy though
414
                              break;
                     case LT WaitLcdRdy:
415
416
                              break;
                     case LT WaitButton:
```

```
jdefo002 lab8 part1.c
May 10, 13 21:11
                                                              Page 7/8
                case LT FillAndDispString:
419
                       x = rand() % 10; // x is rand num 0-9
420
                       c = (char)(((int)'0')+x); // c is ascii of num x
421
                       422
423
424
                       LCD string q[i] = '\0'; // End-of-string char
425
                       LCD_go_g = 1; // Display string
426
427
                case LT HoldGol:
428
                       break;
429
                case LT WaitBtnRelease:
430
                       break;
431
432
                default:
433
                       break;
434
          } // State actions
435
436
   /************************
437
   /* Perform all of the initialization operations here.
438
   /****************************
439
440
   void Init_LCD_Task()
441
442
          DDRB = 0xFF; // Set port B to output
         DDRD = 0xFF; // Set port D to output
443
         DDRA = 0xFC; // PAO is an input
444
          LI State = -1;
445
          LT_State = -1;
446
447
448
   449
   /* Process_LCD_Task()
450
451
   /* This method will advance the LCD task state machine one state per
  /* timer tick.
452
   int Process_LCD_Task(int state)
454
455
          LI Tick();
456
          LT_Tick();
457
458
459
          // Don't really needed to pass state information to the scheduler
         return 1;
460
461
462
  463
  //Functionality - finds the greatest common divisor of two values
   //Parameter: Two long int's to find their GCD
466
   //Returns: GCD else 0
467
  unsigned long int findGCD(unsigned long int a, unsigned long int b)
468
          unsigned long int c;
469
470
          while(1){
                c = a % b;
471
472
          if( c == 0 ) { return b; }
473
         a = b;
474
         b = c;
475
476
  return 0;
477
478
//Struct for Tasks represent a running process in our simple real-time operating
   typedef struct _task
481
482
483
          // Tasks should have members that include: state, period,
484
          //a measurement of elapsed time, and a function pointer.
          signed char state;
                                    //Task's current state
485
          unsigned long period;
                                    //Task period
486
          unsigned long elapsedTime;
                                    //Time elapsed since last task tick
487
          int (*TickFct)(int);
                                    //Task tick function
488
489
   } task;
```

```
jdefo002 lab8 part1.c
May 10, 13 21:11
                                                                               Page 8/8
   // Implement scheduler code from PES.
491
   void RunTaskScheduler()
493
            // Initialize the tasks.
494
            Init KeyPad Task();
495
496
            Init_LCD_Task();
497
            unsigned long int LCD_Tick = 10;
498
            unsigned long int KeyPad_Tick = 50;
499
500
501
            // Calculate the GCD of the LCD and KeyPad tasks
            unsigned long int tmpGCD = findGCD(LCD_Tick, KeyPad_Tick);
502
503
504
            //Greatest common divisor for all tasks or smallest time unit for tasks.
505
            unsigned long int GCD = tmpGCD;
506
            //Recalculate GCD periods for scheduler
507
508
            unsigned long int LCD_period = LCD_Tick/GCD;
            unsigned long int KeyPad_period = KeyPad_Tick/GCD;
509
510
            // Declare an array of tasks
511
512
            static task task1, task2;
            task *tasks[] = { &task1, &task2};
513
514
            const unsigned short numTasks = sizeof(tasks)/sizeof(task*);
515
516
            task1.state = -1;//Task initial state.
517
            task1.period = LCD_period;//Task Period.
518
519
            task1.elapsedTime = LCD_period;//Task current elapsed time.
            task1.TickFct = &Process_LCD_Task;//Function pointer for the tick.
520
521
522
            // Task 2
523
            task2.state = -1://Task initial state.
            task2.period = KeyPad_period://Task Period.
524
            task2.elapsedTime = KeyPad_period;//Task current elapsed time.
526
            task2.TickFct = &Process_KeyPad_Task;//Function pointer for the tick.
527
            // Set the timer and turn it on
528
            TimerSet(GCD);
530
            TimerOn();
531
            // Run all tasks forever....
532
533
            unsigned short i; // Scheduler for-loop iterator
534
            while(1)
535
                     // Scheduler code
                     for ( i = 0; i < 2; i++ )
537
538
539
                             // Task is ready to tick
                             if ( tasks[i]->elapsedTime == tasks[i]->period )
541
542
                                      // Setting next state for task
                                      tasks[i]->state = tasks[i]->TickFct(tasks[i]->st
543
   ate);
                                      // Reset the elapsed time for next tick.
544
545
                                      tasks[i]->elapsedTime = 0;
546
                             tasks[i]->elapsedTime += 1;
547
548
549
                     // Process_LCD_Task(1);
                     while(!TimerFlag);
551
                     TimerFlag = 0;
552
553
554
555
556
   int main(void)
557
558
            // The Task scheduler does all of the real work
559
            RunTaskScheduler();
560
561
```

```
jdefo002 lab8 part2.c
May 10, 13 21:11
                                                                      Page 1/9
    * idefo002 lab8 part2.c - April 8, 2013
    * Name: Joshua DeForest-Williams jdefo002@ucr.edu
    * CS Login: idefo002
    * Partner Name: Ariana DeJaco E-mail:adeja001@ucr.edu
    * Lab Section: 022
    * Assignment: Lab#8 Exercise# Part2
    * Exercise Use the LCD code, along with a button and/or time delay to display t
   he message "CS120B is Legend... wait for it DARY!" The string will not fit on th
                                 so you will need to come up with some way to pag
   inate or scroll the text.
   #define F CPU 8000000
10
   #include <avr/io.h>
12
13
   #include <avr/interrupt.h>
   #include <avr/sfr defs.h>
14
   #include <util/delay.h>
15
   17
   //Functionality - Sets bit on a PORTx
   //Parameter: Takes in a uChar for a PORTx, the pin number and the binary value
   //Returns: The new value of the PORTx
   unsigned char SetBit(unsigned char pin, unsigned char number, unsigned char bin_
21
22
           return (bin_value ? pin | (0x01 << number) : pin & ~(0x01 << number));
23
24
26
   //Functionality - Gets bit from a PINx
27
   //Parameter: Takes in a uChar for a PINx and the pin number
   //Returns: The value of the PINx
30
   unsigned char GetBit(unsigned char port, unsigned char number)
31
           return ( port & (0x01 << number) );
33
   volatile unsigned char TimerFlag = 0; // TimerISR() sets this to 1. C programmer
    should clear to 0.
36
   // Internal variables for mapping AVR's ISR to our cleaner TimerISR model.
37
   unsigned long _avr_timer_M = 1; // Start count from here, down to 0. Default 1ms
38
   unsigned long _avr_timer_cntcurr = 0; // Current internal count of 1ms ticks
   // Set TimerISR() to tick every M ms
41
   void TimerSet(unsigned long M)
43
44
           _avr_timer_M = M;
45
           _avr_timer_cntcurr = _avr_timer_M;
47
48
   void TimerOn()
49
50
           // AVR timer/counter controller register TCCR0
           TCCR0 = 0x0B; // bit3bit6=10: CTC mode (clear timer on compare)
51
           // bit2bit1bit0=011: prescaler /64
52
53
           // 00001011: 0x0B
           // SO, 8 MHz clock or 8,000,000 /64 = 125,000 ticks/s
54
           // Thus, TCNT0 register will count at 125,000 ticks/s
55
56
           // AVR output compare register OCRO.
           OCRO = 125; // Timer interrupt will be generated when TCNT0==OCRO
58
           // We want a 1 ms tick. 0.001 s * 125,000 ticks/s = 125
59
           // So when TCNT0 register equals 125,
60
           // 1 ms has passed. Thus, we compare to 125.
61
62
           // AVR timer interrupt mask register
63
           TIMSK = 0x02; // bit1: OCIEO -- enables compare match interrupt
64
65
66
           //Initialize avr counter
           TCNTO = 0;
67
```

```
jdefo002 lab8 part2.c
May 10, 13 21:11
                                                                        Page 2/9
           // TimerISR will be called every _avr_timer_cntcurr milliseconds
           avr timer cntcurr = avr timer M;
70
71
72
           //Enable global interrupts
           SREG |= 0x80; // 0x80: 1000000
73
74
75
   void TimerOff()
76
77
           TCCR0 = 0x00; // bit2bit1bit0=000: timer off
78
79
80
   void TimerISR() {
81
82
           TimerFlag = 1;
83
   // In our approach, the C programmer does not touch this ISR, but rather TimerIS
86
   ISR(TIMERO_COMP_vect)
87
           // CPU automatically calls when TCNT0 == OCR0 (every 1 ms per TimerOn se
   ttings)
           _avr_timer_cntcurr--;
                                                  // Count down to 0 rather than u
   p to TOP
           if (_avr_timer_cntcurr == 0)
                   // results in a more efficient compare
91
                   TimerISR();
                                                          // Call the ISR that the
92
    user uses
93
                   _avr_timer_cntcurr = _avr_timer_M;
94
95
   // Returns '\0' if no key pressed, else returns char '1', '2', ... '9', 'A', ...
  // If multiple keys pressed, returns leftmost-topmost one
   // Keypad must be connected to port C
   /* Keypad arrangement
           PC4 PC5 PC6 PC7
101
      col 1 2 3
103 TOW
          1 | 2 | 3 | A
4 | 5 | 6 | B
7 | 8 | 9 | C
  PC0 1
105 PC1 2
106 PC2 3
107 PC3 4
108
109
110
   /* Set the LED to the value pressed in the KeyPad
   /*******************
113
   void setValueToLEDs(unsigned char value)
114
115
           PORTA = (value << 2);
           // This is for active Low PORTA = (~(value << 2)) & 0xFC;
116
117
118
   /****************************
120
   /* Gets the value from the KeyPad
   /****************************
121
   unsigned char GetKeypadKey()
123
           PORTC = 0xEF; // Enable col 4 with 0, disable others with 1M-^Rs
124
           asm("nop"); // add a delay to allow PORTC to stabilize before checking
125
           if (GetBit(PINC,0)==0) { return('1');
           if (GetBit(PINC,1)==0)
                                   return('4');
127
128
           if (GetBit(PINC,2)==0)
                                   return('7');
           if (GetBit(PINC.3) == 0) { return('*');
129
130
131
           // Check kevs in col 2
           PORTC = 0xDF; // Enable col 5 with 0, disable others with 1M-^Rs
132
           asm("nop"); // add a delay to allow PORTC to stabilize before checking
133
           if (GetBit(PINC,0)==0) { return('2');
134
           if (GetBit(PINC,1)==0)
                                   return('5');
135
           if (GetBit(PINC,2)==0)
                                  return('8');
136
           if (GetBit(PINC, 3) == 0) { return('0');
```

```
jdefo002 lab8 part2.c
May 10, 13 21:11
                                                                       Page 3/9
139
           // Check kevs in col 3
140
           PORTC = 0xBF; // Enable col 6 with 0, disable others with 1M-^Rs
           asm("nop"); // add a delay to allow PORTC to stabilize before checking
141
           if (GetBit(PINC,0)==0) { return('3');
142
           if (GetBit(PINC,1)==0) {
                                  return('6');
143
                                  return('9');
144
           if (GetBit(PINC,2)==0) {
           if (GetBit(PINC,3)==0) { return('#');
145
146
147
           // Check keys in col 4
148
           PORTC = 0x7F;
149
           asm("nop"); // add a delay to allow PORTC to stabilize before checking
           if (GetBit(PINC,0)==0) { return('A');
150
           if (GetBit(PINC,1)==0)
                                  return('B');
151
           if (GetBit(PINC,2)==0)
                                  return('C');
152
153
           if (GetBit(PINC,3)==0) { return('D');
154
           return('\0'); // default value
155
156
157
158
159
160
    /* Perform all of the initialization operations here.
   /***************************
161
162
   void Init_KeyPad_Task()
163
           DDRA = 0xFC; PORTA = 0x00; // PORTB set to output, Except for PAO and PA2
164
     PAO is input switch
           DDRC = 0xF0; PORTC = 0x0F; // PC7..4 outputs init 0s, PC3..0 inputs init
165
    1s
166
167
   /***********************
168
169
   /* Process KeyPad Task()
   /* This method will advance the LCD task state machine one state per
170
    /*********************
172
   int Process_KeyPad_Task(int state)
173
174
           unsigned char x;
175
176
177
           x = GetKeypadKey();
           switch (x)
178
179
                   case '\0': setValueToLEDs(0x1F); break; // All 5 LEDs on
180
                   case '1': setValueToLEDs(0x01); break; // hex equivalent
181
182
                   case '2': setValueToLEDs(0x02); break;
                   case '3': setValueToLEDs(0x03); break;
183
184
                   case '4': setValueToLEDs(0x04); break;
                  case '5': setValueToLEDs(0x05); break;
185
                   case '6': setValueToLEDs(0x06); break;
                   case '7': setValueToLEDs(0x07); break;
187
                  case '8': setValueToLEDs(0x08); break;
188
                  case '9': setValueToLEDs(0x09); break;
189
                   case 'A': setValueToLEDs(0x0A); break;
190
                   case 'B': setValueToLEDs(0x0B); break;
191
                   case 'C': setValueToLEDs(0x0C); break;
192
                   case 'D': setValueToLEDs(0x0D); break;
193
                   case '*': setValueToLEDs(0x0E); break;
194
                   case '0': setValueToLEDs(0x00); break;
195
                   case '#': setValueToLEDs(0x0F); break;
196
                   default: setValueToLEDs(0x1B); break; // Should never occur. M
197
   iddle LED off.
198
199
           // return state
200
201
           return -1;
202
203
   204
205
   // Define LCD port assignments here so easier to change than if hardcoded below
  unsigned char *LCD Data = &PORTD;
                                         // LCD 8-bit data bus
```

```
jdefo002 lab8 part2.c
May 10, 13 21:11
                                                                               Page 4/9
   unsigned char *LCD_Ctrl = &PORTB;
                                              // LCD needs 2-bits for control, use por
   t B
   const unsigned char LCD_RS = 3;
                                              // LCD Reset pin is PB3
   const unsigned char LCD E = 4;
                                              // LCD Enable pin is PB4
210
   unsigned char LCD_rdy_g = 0; // Set by LCD interface synchSM, ready to display n
212
   unsigned char LCD go g = 0; // Set by user synchSM wishing to display string in
214 unsigned char LCD_string_g[17]; // Filled by user synchSM, 16 chars plus end-of-
   string char
   void LCD WriteCmdStart(unsigned char cmd) {
216
            *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_RS, 0);
            *LCD Data = cmd;
218
219
            *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_E, 1);
220
   void LCD_WriteCmdEnd()
221
222
            *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_E, 0);
223
   void LCD_WriteDataStart(unsigned char Data)
224
            *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_RS,1);
225
226
            *LCD Data = Data;
            *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_E, 1);
227
   void LCD_WriteDataEnd()
229
            *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_E, 0);
230
231
   void LCD_Cursor(unsigned char column ) {
233
            if ( column < 8 ) { // IEEE change this value to 16</pre>
                     LCD_WriteCmdStart(0x80+column);
234
235
236
            else {
237
                     LCD WriteCmdStart(0xB8+column); // IEEE change this value to 0xB
   F+column
239
240
   enum LI_States { Initial, LI_Init1, LI_Init2, LI_Init3, LI_Init4, LI_Init5, LI_I
241
242
            LI_WaitDisplayString, LI_Clr, LI_PositionCursor, LI_DisplayChar, LI_Wait
   Go0 } LI_State;
243
   void LI_Tick() {
244
            static unsigned char i;
245
            switch(LI_State) { // Transitions
246
                     case Initial:
247
                             LI_State = LI_Init1;
248
249
                             break;
250
                     case LT Init1:
251
                             LI_State = LI_Init2;
                             i = 0;
252
253
                             break
                     case LI Init2:
254
                             if (i<10) { // Wait 100 ms after power up</pre>
255
256
                                      LI_State = LI_Init2;
257
258
                             else {
259
                                     LI_State = LI_Init3;
260
261
                             break;
                     case LI Init3:
                             LI_State = LI_Init4;
263
                             LCD WriteCmdEnd();
264
                             break;
265
                     case LI_Init4:
267
                             LI State = LI Init5;
268
                             LCD_WriteCmdEnd();
                             break;
269
                     case LI_Init5:
270
271
                             LI State = LI Init6;
                             LCD WriteCmdEnd();
272
273
```

May 10,	, 13 21:11 jdefo002_lab8_pa	art2.c Page 5/9
274	case LI_Init6:	
275	LI_State = LI_WaitDisplay	String;
276	<pre>LCD_WriteCmdEnd();</pre>	
277	break;	
278	///////////////////////////////////////	//////////////
279	case LI_WaitDisplayString:	
280	<pre>if (!LCD_go_g) {</pre>	this are the state of
281	LI_State = LI_Wai	tDisplayString;
282	}	
283	else if (LCD_go_g) {	
284 285	LCD_rdy_g = 0; LI_State = LI_Clr	• •
286	}	. ,
287	break;	
288	case LI_Clr:	
289	LI_State = LI_PositionCur	sor;
290	<pre>LCD_WriteCmdEnd();</pre>	
291	<u>i=0;</u>	
292	break;	
293	<pre>case LI_PositionCursor:</pre>	
294	LI_State = LI_DisplayChar	:;
295	LCD_WriteCmdEnd();	
296	break;	
297	case LI_DisplayChar:	
298	<b>if</b> (i<16) {	itionCurgor:
299	LI_State = LI_Pos	
300	LCD_WriteDataEnd( i++;	11
301 302	}	
303	else {	
303	LI_State = LI_Wai	t.Go0;
305	LCD_WriteDataEnd(	
306	}	•
307	break;	
308	case LI_WaitGo0:	
309	<b>if</b> (!LCD_go_g) {	
310	LI_State = LI_Wai	tDisplayString;
311	}	
312	<pre>else if (LCD_go_g) {</pre>	
313	, LI_State = LI_Wai	tGo0;
314	}	
315	break;	
316	default:	
317	LI_State = LI_Init1;	
318	} // Transitions	
319 320	<pre>switch(LI_State) { // State actions</pre>	
320	case LI_Init1:	
321	LCD_rdy_g = 0;	
323	break;	
324	case LI_Init2:	
325	i++; // Waiting after pow	ver up
326	break;	
327	<pre>case LI_Init3:</pre>	
328	LCD_WriteCmdStart(0x38);	
329	break;	
330	case LI_Init4:	
331	LCD_WriteCmdStart(0x06);	
332	break;	
333	case LI_Init5:	
334	LCD_WriteCmdStart(0x0F);	
335	break;	
336	<pre>case LI_Init6:</pre>	// Clear
337 338	break;	// CIEai
338	break; ////////////////////////////////////	///////////////////////////////////////
340	<pre>case LI_WaitDisplayString:</pre>	///////////////////////////////////////
	LCD_rdy_g = 1;	
	break;	
341		
341 342		
341 342 343	<pre>case LI_Clr:</pre>	
341 342		

```
jdefo002 lab8 part2.c
May 10, 13 21:11
                                                                               Page 6/9
                             LCD_Cursor(i);
                             break;
348
                     case LI_DisplayChar:
                             LCD_WriteDataStart(LCD_string_g[i]);
350
351
                             break;
                    case LI WaitGo0:
352
353
                             break;
                     default:
354
                             break
355
            } // State actions
356
357
358
   //----END LCD interface synchSM-----
359
   // SynchSM for testing the LCD interface -- waits for button press, fills LCD wi
   th repeated random num
   enum LT_States { Initial1, LT_s0, LT_WaitLcdRdy, LT_WaitButton, LT_FillAndDispSt
363
   LT_FillAndDispStringPartTwo, LT_HoldGo1, LT_WaitBtnRelease } LT_State;
   void LT_Tick()
            //static unsigned char i, x, c;
367
            const char* sentencePartOne = "CS120B is Legend...";
            const char* sentencePartTwo = "wait for it DARY!";
369
370
            static unsigned char previousState = 0;
            switch(LT_State) { // Transitions
371
372
                    case Initial1:
373
                             LT_State = LT_s0;
374
                             break;
375
                    case LT_s0:
376
                             LT_State = LT_WaitLcdRdy;
377
                             break;
                    case LT_WaitLcdRdy:
378
                             if (!LCD_rdy_g) {
                                     LT_State = LT_WaitLcdRdy;
380
381
                             else if (LCD_rdy_g)
382
                                      LT_State = LT_WaitButton;
384
385
                             break;
                    case LT_WaitButton:
386
387
                             if (GetBit(PINA,0)==1) {
                                     LT_State = LT_WaitButton;
388
389
                             else if (GetBit(PINA,0)==0 && ((previousState == 0) | | (
   previousState == 2)) ) { // Button active low
                                     LT_State = LT_FillAndDispStringPartOne;
392
                             else if (GetBit(PINA,0)==0 && (previousState == 1) ) {
    / Button active low
                             LT_State = LT_FillAndDispStringPartTwo;
394
395
396
                             break;
                     case LT_FillAndDispStringPartOne:
397
398
                             LT_State = LT_HoldGo1;
399
                             previousState = 1;
400
                             break;
                     case LT_FillAndDispStringPartTwo:
401
                             LT_State = LT_HoldGo1;
402
                             previousState = 2;
403
                             break;
404
405
                     case LT_HoldGol:
                             LCD_go_g=0;
406
407
                             LT_State = LT_WaitBtnRelease;
408
                             break;
409
                     case LT_WaitBtnRelease:
                             if (GetBit(PINA,0)==0) { // Wait for button release
410
                                      LT_State = LT_WaitBtnRelease;
411
412
                             else if (GetBit(PINA,0)==1) {
413
                                      LT State = LT WaitLcdRdy;
```

```
idefo002_lab8_part2.c
May 10, 13 21:11
                                                                     Page 7/9
                          break;
416
417
                  default:
                         LT State = LT s0;
418
419
                  } // Transitions
420
           switch(LT_State) { // State actions
421
422
                  case LT s0:
                         LCD_go_g=0;
423
                          strcpy(LCD_string_g, "1234567890123456"); // Init, but nev
424
   er seen, shows use of strcpy though
                         break;
425
                  case LT WaitLcdRdy:
426
                         break;
427
                  case LT_WaitButton:
428
429
                         break;
                  case LT FillAndDispStringPartOne:
430
                          strcpy(LCD_string_g, sentencePartOne);
431
432
                          LCD_string_g[strlen(sentencePartOne)] = '\0'; // End-of-
   string char
                         LCD_go_g = 1; // Display string
433
131
                         break;
435
                  case LT_FillAndDispStringPartTwo:
                          strcpy(LCD_string_g, sentencePartTwo);
436
437
                         LCD_string_g[strlen(sentencePartTwo)] = '\0'; // End-of-
   string char
                          LCD_go_g = 1; // Display string
438
                         break;
439
440
                  case LT HoldGol:
441
                          break;
                  case LT_WaitBtnRelease:
442
443
                          break;
444
                  default:
445
                          break;
           } // State actions
446
447
448
449
   /* Perform all of the initialization operations here.
450
   452
   void Init_LCD_Task()
453
           DDRB = 0xFF; // Set port B to output
454
455
          DDRD = 0xFF; // Set port D to output
456
           DDRA = 0xFC; // PA0 is an input
          I_{t}I_{t}State = -1;
457
458
           LT State = -1;
459
460
   /********************
461
   /* Process LCD Task()
   /* This method will advance the LCD task state machine one state per
463
   /* timer tick.
464
   465
   int Process_LCD_Task(int state)
466
467
468
           LI Tick();
469
           LT_Tick();
470
           // Don't really needed to pass state information to the scheduler
471
          return 1;
472
473
474
   475
   //Functionality - finds the greatest common divisor of two values
476
   //Parameter: Two long int's to find their GCD
478
   //Returns: GCD else 0
479
   unsigned long int findGCD(unsigned long int a, unsigned long int b)
480
           unsigned long int c;
481
482
           while(1){
                  \dot{c} = a \% h;
483
           if( c == 0 ) { return b;
```

```
jdefo002 lab8 part2.c
May 10, 13 21:11
                                                                           Page 8/9
           a = b;
           b = c;
486
487
488
           return 0;
489
490
   //Struct for Tasks represent a running process in our simple real-time operating
   typedef struct _task
494
            // Tasks should have members that include: state, period,
495
           //a measurement of elapsed time, and a function pointer.
496
           signed char state;
                                            //Task's current state
497
498
           unsigned long period;
                                            //Task period
499
           unsigned long elapsedTime;
                                            //Time elapsed since last task tick
           int (*TickFct)(int);
                                            //Task tick function
500
     task;
501
502
   // Implement scheduler code from PES.
503
   void RunTaskScheduler()
504
505
506
            // Initialize the tasks.
   11
           Init KevPad Task();
507
           Init LCD Task();
509
            unsigned long int LCD_Tick
510
   11
           unsigned long int KeyPad_Tick = 100;
511
512
513
           // Calculate the GCD of the LCD and KeyPad tasks
   11
           unsigned long int tmpGCD = findGCD(LCD_Tick, KeyPad_Tick);
514
515
516
           //Greatest common divisor for all tasks or smallest time unit for tasks.
           unsigned long int GCD = LCD Tick; //tmpGCD;
517
518
           //Recalculate GCD periods for scheduler
           unsigned long int LCD period = LCD Tick/GCD;
520
   11
           unsigned long int KeyPad_period = KeyPad_Tick/GCD;
521
522
            // Declare an array of tasks
           static task task1; //, task2;
524
           task *tasks[] = { &task1, &task2};
   11
525
           const unsigned short numTasks = 1; //sizeof(tasks)/sizeof(task*);
   11
526
527
528
           // Task 1
           task1.state = -1;//Task initial state.
529
530
           task1.period = LCD_period;//Task Period.
           task1.elapsedTime = LCD_period;//Task current elapsed time.
531
532
           task1.TickFct = &Process_LCD_Task;//Function pointer for the tick.
533
534
           // Task 2
           task2.state = -1;//Task initial state.
535
536
           task2.period = KeyPad_period;//Task Period.
           task2.elapsedTime = KeyPad_period;//Task current elapsed time.
537
           task2.TickFct = &Process_KeyPad_Task;//Function pointer for the tick.
538
   * /
539
540
            // Set the timer and turn it on
541
           TimerSet(GCD);
           TimerOn();
542
543
           // Run all tasks forever....
544
   11
           unsigned short i; // Scheduler for-loop iterator
545
           while(1)
546
547
                    // Scheduler code
548
           //
                    for (i = 0; i < 2; i++)
550
           11
551
                            // Task is ready to tick
                            if ( task1.elapsedTime == task1.period )
552
553
554
                                    // Setting next state for task
                                    task1.state = task1.TickFct(task1.state);
555
                                    // Reset the elapsed time for next tick.
556
```

```
May 10, 13 21:11
                                         jdefo002_lab8_part2.c
                                                                                                Page 9/9
                                              task1.elapsedTime = 0;
557
558
                                    task1.elapsedTime += 1;
559
560
               11
561
                         // Process_LCD_Task(1);
while(!TimerFlag);
TimerFlag = 0;
562
563
564
565
566
567
568
    int main(void)
569
570
               // The Task scheduler does all of the real work {\tt RunTaskScheduler();}
571
572
573 }
```

```
jdefo002 lab8 part3.c
May 10, 13 21:11
                                                                      Page 1/9
    * idefo002 lab8 part3.c - April 8, 2013
    * Name: Joshua DeForest-Williams jdefo002@ucr.edu
    * CS Login: idefo002
    * Partner Name: Ariana DeJaco E-mail:adeja001@ucr.edu
    * Lab Section: 022
    * Assignment: Lab#8 Exercise#3
    * Exercise Description: Combine the functionality of the keypad and LCD so when
    keypad is pressed and released, the character of the button pressed is displaye
           and stays displayed until a different button press occurs (May be accomp
   lished with two tasks: LCD interface & modified test harness).
10
   #define F_CPU 8000000
12
13
   #include <avr/io.h>
   #include <avr/interrupt.h>
14
   #include <avr/sfr_defs.h>
   #include <util/delay.h>
16
   //Functionality - Sets bit on a PORTx
   //Parameter: Takes in a uChar for a PORTx, the pin number and the binary value
   //Returns: The new value of the PORTx
21
   unsigned char SetBit(unsigned char pin, unsigned char number, unsigned char bin_
   value)
23
           return (bin_value ? pin | (0x01 << number) : pin & ~(0x01 << number));
24
25
26
   27
   //Functionality - Gets bit from a PINx
   //Parameter: Takes in a uChar for a PINx and the pin number
   //Returns: The value of the PINx
30
   unsigned char GetBit(unsigned char port, unsigned char number)
31
           return ( port & (0x01 << number) );
33
34
   volatile unsigned char TimerFlag = 0; // TimerISR() sets this to 1. C programmer
    should clear to 0.
   // Internal variables for mapping AVR's ISR to our cleaner TimerISR model.
38
   unsigned long \_avr\_timer\_M = 1; // Start count from here, down to 0. Default 1ms
   unsigned long _avr_timer_cntcurr = 0; // Current internal count of 1ms ticks
   // Set TimerISR() to tick every M ms
   void TimerSet(unsigned long M)
43
44
45
           _avr_timer_M = M;
          _avr_timer_cntcurr = _avr_timer_M;
47
   void TimerOn()
49
50
51
           // AVR timer/counter controller register TCCR0
           TCCR0 = 0x0B; // bit3bit6=10: CTC mode (clear timer on compare)
52
53
           // bit2bit1bit0=011: prescaler /64
           // 00001011: 0x0B
54
           // SO, 8 MHz clock or 8,000,000 /64 = 125,000 ticks/s
55
           // Thus, TCNTO register will count at 125,000 ticks/s
56
           // AVR output compare register OCRO.
58
                 = 125; // Timer interrupt will be generated when TCNT0==OCR0
59
           // We want a 1 ms tick. 0.001 s * 125,000 ticks/s = 125
60
61
           // So when TCNT0 register equals 125,
62
           // 1 ms has passed. Thus, we compare to 125.
63
           // AVR timer interrupt mask register
64
           TIMSK = 0x02; // bit1: OCIEO -- enables compare match interrupt
65
66
           //Initialize avr counter
67
           TCNT0 = 0;
```

```
jdefo002 lab8 part3.c
May 10, 13 21:11
                                                                   Page 2/9
          // TimerISR will be called every _avr_timer_cntcurr milliseconds
70
71
          _avr_timer_cntcurr = _avr_timer_M;
72
73
          //Enable global interrupts
          SREG = 0x80; // 0x80: 1000000
75
76
   void TimerOff()
77
78
          TCCR0 = 0x00; // bit2bit1bit0=000: timer off
79
80
81
   void TimerISR() {
83
          TimerFlag = 1;
84
   // In our approach, the C programmer does not touch this ISR, but rather TimerIS
   ISR(TIMER0_COMP_vect)
87
          // CPU automatically calls when TCNTO == OCRO (every 1 ms per TimerOn se
   ttings)
          _avr_timer_cntcurr--;
                                              // Count down to 0 rather than u
   p to TOP
          if (_avr_timer_cntcurr == 0)
91
92
                 // results in a more efficient compare
                 TimerISR();
                                                      // Call the ISR that the
93
    user uses
                  _avr_timer_cntcurr = _avr_timer_M;
95
96
  // Returns '\0' if no key pressed, else returns char '1', '2', ... '9', 'A', ...
98
   // If multiple keys pressed, returns leftmost-topmost one
  // Keypad must be connected to port C
101 /* Keypad arrangement
          PC4 PC5 PC6 PC7
102
     col 1 2 3 4
103
105 PC0 1 1 | 2 | 3 | A
106 PC1 2 4 | 5 | 6 | B
107 PC2 3 7 | 8 | 9 | C
108 PC3 4 * | 0 | # | D
109
   /* Set the LED to the value pressed in the KeyPad
112
   114 void setValueToLEDs(unsigned char value)
115
          PORTA = (value << 2);
116
          // This is for active Low PORTA = (~(value << 2)) & 0xFC;
117
118 }
   120
   /* Gets the value from the KeyPad
121
   unsigned char GetKeypadKey()
123
124
          PORTC = 0xEF; // Enable col 4 with 0, disable others with 1M-^Rs
125
          asm("nop"); // add a delay to allow PORTC to stabilize before checking
          if (GetBit(PINC,0)==0) { return('1');
127
                                return('4');
128
          if (GetBit(PINC,1)==0)
          if (GetBit(PINC,2)==0) { return('7');
129
          if (GetBit(PINC,3)==0) { return('*');
130
131
132
          // Check keys in col 2
          PORTC = 0xDF; // Enable col 5 with 0, disable others with 1M-^Rs
133
          asm("nop"); // add a delay to allow PORTC to stabilize before checking
134
          if (GetBit(PINC,0)==0) { return('2');
135
          if (GetBit(PINC,1)==0)
                               { return('5');
136
          if (GetBit(PINC, 2) == 0) { return('8');
```

```
jdefo002 lab8 part3.c
May 10, 13 21:11
                                                                      Page 3/9
           if (GetBit(PINC,3)==0) { return('0'); }
139
140
           // Check keys in col 3
           PORTC = 0xBF; // Enable col 6 with 0, disable others with 1M-^Rs
141
           asm("nop"); // add a delay to allow PORTC to stabilize before checking
142
           if (GetBit(PINC,0)==0) { return('3');
143
                                  return('6');
144
           if (GetBit(PINC,1)==0)
           if (GetBit(PINC,2)==0)
145
                                  return('9');
           if (GetBit(PINC,3)==0) { return('#');
146
147
           // Check keys in col 4
148
149
           PORTC = 0x7F;
           asm("nop"); // add a delay to allow PORTC to stabilize before checking
150
           if (GetBit(PINC,0)==0) { return('A');
151
           if (GetBit(PINC,1)==0)
                                  return('B');
152
                                  return('C');
153
           if (GetBit(PINC,2)==0)
           if (GetBit(PINC,3)==0) { return('D');
154
155
156
           return('\0'); // default value
157
158
159
    /************************
160
   /* Perform all of the initialization operations here.
161
   void Init_KeyPad_Task()
163
164
           DDRA = 0xFC; PORTA = 0x00; // PORTB set to output, Except for PAO and PA2
165
     PAO is input switch.
166
           DDRC = 0xF0; PORTC = 0x0F; // PC7..4 outputs init 0s, PC3..0 inputs init
    1s
167
168
    /************************
169
   /* Process_KeyPad_Task()
170
   /* This method will advance the LCD task state machine one state per
172
   unsigned char keypad_number = 0;
   unsigned char prev_key_num = 0;
176
   int Process_KeyPad_Task(int state)
177
           unsigned char x;
178
179
      prev_key_num = keypad_number;
180
           x = GetKeypadKey();
181
      keypad_number = x;
182
           switch (x)
183
184
                   case '\0': setValueToLEDs(0x1F); break; // All 5 LEDs on
                  case 'l': setValueToLEDs(0x01); break; // hex equivalent
185
                  case '2': setValueToLEDs(0x02); break;
                  case '3': setValueToLEDs(0x03); break;
187
                  case '4': setValueToLEDs(0x04); break;
188
                  case '5': setValueToLEDs(0x05); break;
189
                  case '6': setValueToLEDs(0x06); break;
190
                  case '7': setValueToLEDs(0x07); break;
191
                  case '8': setValueToLEDs(0x08); break;
192
                  case '9': setValueToLEDs(0x09); break;
193
                  case 'A': setValueToLEDs(0x0A); break;
194
                  case 'B': setValueToLEDs(0x0B); break;
195
                  case 'C': setValueToLEDs(0x0C); break;
196
                  case 'D': setValueToLEDs(0x0D); break;
197
                  case '*': setValueToLEDs(0x0E); break;
198
                  case '0': setValueToLEDs(0x00); break;
199
                  case '#': setValueToLEDs(0x0F); break;
200
                  default: setValueToLEDs(0x1B); break; // Should never occur. M
   iddle LED off.
202
203
           // return state
204
205
           return -1;
206
207
```

```
jdefo002 lab8 part3.c
May 10, 13 21:11
                                                                          Page 4/9
// Define LCD port assignments here so easier to change than if hardcoded below
unsigned char *LCD Data = &PORTD;
                                          // LCD 8-bit data bus
   unsigned char *LCD_Ctrl = &PORTB;
                                           // LCD needs 2-bits for control, use por
213 const unsigned char LCD_RS = 3;
                                           // LCD Reset pin is PB3
   const unsigned char LCD E = 4;
                                           // LCD Enable pin is PB4
214
216 unsigned char LCD_rdy_g = 0; // Set by LCD interface synchSM, ready to display n
   ew string
   unsigned char LCD_go_g = 0; // Set by user synchSM wishing to display string in
   LCD_string_g
   unsigned char LCD_string_g[17]; // Filled by user synchSM, 16 chars plus end-of-
   string char
   void LCD WriteCmdStart(unsigned char cmd)
220
           *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_RS, 0);
221
222
           *LCD_Data = cmd;
           *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_E, 1);
223
224
   void LCD_WriteCmdEnd()
225
226
            *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_E, 0);
227
   void LCD_WriteDataStart(unsigned char Data)
           *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_RS,1);
229
           *LCD Data = Data;
230
           *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_E, 1);
231
232
233
   void LCD WriteDataEnd()
           *LCD_Ctrl = SetBit(*LCD_Ctrl,LCD_E, 0);
234
235
   void LCD_Cursor(unsigned char column ) {
236
           if (column < 8) { // IEEE change this value to 16
237
                   LCD_WriteCmdStart(0x80+column);
238
           élse {
240
                   LCD_WriteCmdStart(0xB8+column); // IEEE change this value to 0xB
241
   F+column
243
244
   enum LI_States { LI_Init1, LI_Init2, LI_Init3, LI_Init4, LI_Init5, LI_Init6,
245
           LI_WaitDisplayString, LI_Clr, LI_PositionCursor, LI_DisplayChar, LI_Wait
   Go0 } LI_State;
247
   void LI_Tick() {
248
           static unsigned char i;
249
250
           switch(LI_State) { // Transitions
251
                   case -1:
252
                            LI_State = LI_Init1;
                            break;
253
254
                   case LI Init1:
                           LI_State = LI_Init2;
255
256
                            i = 0;
257
                           break;
258
                   case LI Init2:
                           if (i<10) { // Wait 100 ms after power up
260
                                   LI_State = LI_Init2;
261
262
                            else {
                                   LI_State = LI_Init3;
263
264
                            break;
265
                   case LI Init3:
266
                            LI_State = LI_Init4;
268
                           LCD WriteCmdEnd();
269
                           break;
                   case LI Init4:
270
                           LI_State = LI_Init5;
271
                           LCD WriteCmdEnd();
272
273
                           break;
                   case LI Init5:
274
```

May 10, 13 21:11	jdefo002_lab8_part3.c	Page 5/9
275	LI_State = LI_Init6;	
276 277	LCD_WriteCmdEnd(); break;	
	case LI_Init6:	
279	LI_State = LI_WaitDisplayString;	
280 281	LCD_WriteCmdEnd(); break;	
	///////////////////////////////////////	
	case LI_WaitDisplayString:	
284 285	<pre>if (!LCD_go_g) {</pre>	
286	}	
287	else if (LCD_go_g) {	
288 289	LCD_rdy_g = 0; LI_State = LI_Clr;	
290	}	
291	break;	
	<pre>case LI_Clr:     LI_State = LI_PositionCursor;</pre>	
293 294	LCD_WriteCmdEnd();	
295	i=0;	
296	<pre>break; case LI_PositionCursor:</pre>	
297 298	LI_State = LI_DisplayChar;	
299	<pre>LCD_WriteCmdEnd();</pre>	
300	break;	
301	<pre>case LI_DisplayChar:    if (i&lt;16) {</pre>	
303	LI_State = LI_PositionCursor;	
304	<pre>LCD_WriteDataEnd(); i++;</pre>	
305 306	}	
307	else {	
308	LI_State = LI_WaitGo0;	
309 310	<pre>LCD_WriteDataEnd(); }</pre>	
311	break;	
	case LI_WaitGo0:	
313 314	<pre>if (!LCD_go_g) {</pre>	
315	}	
316	<pre>else if (LCD_go_g) {</pre>	
317 318	LI_State = LI_WaitGo0; }	
319	break;	
	default:	
321 322	LI_State = LI_Init1; } // Transitions	
323		
	[_State) {	
325 326	case LI_Init1: LCD_rdy_g = 0;	
327	break;	
	case LI_Init2:	
329 330	i++; // Waiting after power up break;	
	case LI_Init3:	
332	LCD_WriteCmdStart(0x38);	
333 334	break; case LI_Init4:	
335	LCD_WriteCmdStart(0x06);	
336	break;	
337 338	<pre>case LI_Init5:         LCD_WriteCmdStart(0x0F);</pre>	
339	break;	
	case LI_Init6:	
341 342	LCD_WriteCmdStart(0x01); // Clear break;	
	///////////////////////////////////////	
	case LI_WaitDisplayString:	
345 346	<pre>LCD_rdy_g = 1; break;</pre>	
	case LI_Clr:	
L		

```
jdefo002_lab8_part3.c
May 10, 13 21:11
                                                                               Page 6/9
                             LCD_WriteCmdStart(0x01);
                             break;
349
                     case LI_PositionCursor:
                             LCD Cursor(i);
351
352
                             break;
                     case LI DisplayChar:
353
354
                             LCD_WriteDataStart(LCD_string_g[i]);
355
                     case LI WaitGo0:
356
                             break;
357
                     default:
358
359
                             break;
            } // State actions
360
361
   //----END LCD interface synchSM-----
362
363
364
365
   // SynchSM for testing the LCD interface -- waits for button press, fills LCD wi
   th repeated random num
   enum LT_States { LT_s0, LT_WaitLcdRdy, LT_WaitButton, LT_FillAndDispString,
368
   LT_HoldGo1, LT_WaitBtnRelease } LT_State;
369
   void LT_Tick() {
            static unsigned char i, x, c;
371
372
            switch(LT_State) { // Transitions
                     case -1:
373
                             LT_State = LT_s0;
374
375
                             break;
                     case LT_s0:
376
377
                             LT_State = LT_WaitLcdRdy;
378
                             break;
                     case LT_WaitLcdRdy:
379
                             if (!LCD_rdy_g) {
380
                                      LT_State = LT_WaitLcdRdy;
382
383
                             else if (LCD_rdy_g) {
                                      LT_State = LT_WaitButton;
384
386
                             break;
387
                     case LT_WaitButton:
                             if (keypad_number == prev_key_num) {
388
389
                                      LT_State = LT_WaitButton;
390
                             else if (!(keypad_number == prev_key_num)) {
391
                // Button active low
392
                                      LT_State = LT_FillAndDispString;
393
394
395
                             break;
                     case LT_FillAndDispString:
                             LT_State = LT_HoldGo1;
397
398
                             break;
                     case LT_HoldGo1:
399
400
                             LCD_go_g=0;
401
                             LT_State = LT_WaitBtnRelease;
402
                             break;
403
                     case LT_WaitBtnRelease:
                             if ((keypad_number == prev_key_num)) {
404
                 // Wait for button release
405
                                      LT_State = LT_WaitBtnRelease;
406
                             else if (!(keypad_number == prev_key_num)) {
408
409
                                      LT_State = LT_WaitLcdRdy;
410
411
                             break;
                     default:
412
413
                             LT_State = LT_s0;
                     } // Transitions
414
415
            switch(LT State) { // State actions
416
                     case LT_s0:
417
                             LCD_go_g=0;
```

```
jdefo002_lab8_part3.c
May 10, 13 21:11
                                                                 Page 7/9
                        strcpy(LCD_string_g, "1234567890123456"); // Init, but nev
   er seen, shows use of strcpy though
                        break;
420
                 case LT WaitLcdRdv:
421
422
                        break;
                 case LT WaitButton:
423
424
                        break;
425
                 case LT FillAndDispString:
                        \frac{1}{1/x} = rand() % 10; // x is rand num 0-9
426
                        x = keypad_number;
427
           c = (char)(/*((int)'0')+*/x); // c is ascii of num x
428
                        for (i=0; i<16; i++) { // Fill string with c
429
                               LCD_string_g[i] = c;
430
431
                        LCD\_string\_g[i] = '\0'; // End-of-string char
432
433
                        LCD_go_g = 1; // Display string
434
                        break;
435
                 case LT_HoldGol:
                        break;
436
                 case LT_WaitBtnRelease:
437
438
                        break;
                 default:
439
440
                        break;
          } // State actions
441
442
443
   /************************
444
   /* Perform all of the initialization operations here.
445
   /*****************************
446
447
   void Init LCD Task()
448
449
          DDRB = 0xFF; // Set port B to output
          DDRD = 0xFF; // Set port D to output
450
451
          DDRA = 0xFC; // PAO is an input
          LT State = -1;
452
          LT_State = -1;
453
454
455
   /************************
456
   /* Process_LCD_Task()
458
   /* This method will advance the LCD task state machine one state per
   /* timer tick.
459
   460
461
   int Process_LCD_Task(int state)
462
          LI Tick();
463
464
          LT_Tick();
465
466
          // Don't really needed to pass state information to the scheduler
467
          return 1;
468
469
470
   //Functionality - finds the greatest common divisor of two values
471
   //Parameter: Two long int's to find their GCD
473
   //Returns: GCD else 0
   unsigned long int findGCD(unsigned long int a, unsigned long int b)
474
475
          unsigned long int c;
476
          while(1)
477
                 c = a % b;
478
          if( c == 0 ) { return b; }
479
          a = b;
480
          b = c;
481
482
   return 0;
483
484
//Struct for Tasks represent a running process in our simple real-time operating
    system
488
   typedef struct _task
489
```

```
jdefo002 lab8 part3.c
May 10, 13 21:11
                                                                              Page 8/9
            // Tasks should have members that include: state, period,
            //a measurement of elapsed time, and a function pointer.
491
492
            signed char state;
                                              //Task's current state
493
            unsigned long period;
                                              //Task period
            unsigned long elapsedTime;
                                              //Time elapsed since last task tick
494
            int (*TickFct)(int);
                                              //Task tick function
495
496
     task;
497
   // Implement scheduler code from PES.
498
   void RunTaskScheduler()
500
501
            // Initialize the tasks.
            Init KeyPad Task();
502
            Init_LCD_Task();
503
504
505
            unsigned long int LCD_Tick = 10;
            unsigned long int KeyPad Tick = 10;
506
507
508
            // Calculate the GCD of the LCD and KeyPad tasks
            unsigned long int tmpGCD = findGCD(LCD_Tick, KeyPad_Tick);
509
510
            //Greatest common divisor for all tasks or smallest time unit for tasks.
511
512
            unsigned long int GCD = tmpGCD;
513
514
            //Recalculate GCD periods for scheduler
            unsigned long int LCD_period = LCD_Tick/GCD;
515
            unsigned long int KeyPad_period = KeyPad_Tick/GCD;
516
517
518
            // Declare an array of tasks
519
            static task task1, task2;
            task *tasks[] = { &task1, &task2};
520
521
            const unsigned short numTasks = sizeof(tasks)/sizeof(task*);
522
523
            // Task 1
            task1.state = -1;//Task initial state.
524
            task1.period = LCD_period;//Task Period.
526
            task1.elapsedTime = LCD_period;//Task current elapsed time.
            task1.TickFct = &Process_LCD_Task;//Function pointer for the tick.
527
528
            // Task 2
530
            task2.state = -1;//Task initial state.
            task2.period = KeyPad_period://Task Period.
531
            task2.elapsedTime = KeyPad_period://Task current elapsed time.
532
533
            task2.TickFct = &Process_KeyPad_Task;//Function pointer for the tick.
534
            // Set the timer and turn it on
535
536
            TimerSet(GCD);
            TimerOn();
537
538
539
            // Run all tasks forever
            unsigned short i; // Scheduler for-loop iterator
            while(1)
541
542
                     // Scheduler code
543
544
                    for (i = 0; i < 2; i++)
545
546
                             // Task is ready to tick
547
                             if ( tasks[i]->elapsedTime == tasks[i]->period )
548
                                      // Setting next state for task
549
                                      tasks[i]->state = tasks[i]->TickFct(tasks[i]->st
550
   ate);
                                      // Reset the elapsed time for next tick.
551
                                      tasks[i]->elapsedTime = 0;
552
553
                             tasks[i]->elapsedTime += 1;
554
555
556
                     // Process LCD Task(1);
557
                     while(!TimerFlag);
558
                    TimerFlag = 0;
559
560
561
```

```
jdefo002_lab8_part3.c
May 10, 13 21:11
                                                                                           Page 9/9
    int main(void)
564
565
              // The Task scheduler does all of the real work {\tt RunTaskScheduler();}
566
567
568 }
```