CPE301 - SPRING 2018

Design Assignment 01

DO NOT REMOVE THIS PAGE DURING SUBMISSION:

The student understands that all required components should be submitted in complete for grading of this assignment.

NO	SUBMISSION ITEM	COMPLETED (Y/N)	MARKS (/MAX)
1	COMPONENTS LIST AND CONNECTION BLOCK DIAGRAM w/ PINS		
2.	INITIAL CODE OF TASK 1/A		
3.	INCREMENTAL / DIFFERENTIAL CODE OF TASK 2/B		
3.	INCREMENTAL / DIFFERENTIAL CODE OF TASK 3/C		
3.	INCREMENTAL / DIFFERENTIAL CODE OF TASK 4/D		
3.	INCREMENTAL / DIFFERENTIAL CODE OF TASK 5/E		
4.	SCHEMATICS		
5.	SCREENSHOTS OF EACH TASK OUTPUT		
5.	SCREENSHOT OF EACH DEMO		
6.	VIDEO LINKS OF EACH DEMO		
7.	GOOGLECODE LINK OF THE DA		

Task 1/A: Store 300 numbers starting from the STARTADDS=0x0222 location. Populate the value of the memory location by adding high(STARTADDS) and low(STARTADDS). Use the X/ Y/Z registers as pointers to fill up 300 numbers.

a) Declaring X/Y/Z registers as pointers

```
start:
; Declare POINTERS

LDI XL, LOW(0x0222)

LDI XH, HIGH(0x0222)

LDI YL, LOW(0x0400)

LDI YH, HIGH(0x0400)

LDI ZL, LOW(0x0600)

LDI ZH, HIGH(0x0600)
```

b) Populating 300 numbers and storing them (counter checks for exactly 300 numbers)


```
; Counter register (HIGH), set to 0
   CLR R21 ; Counter register (LOW), set to 0
LDI R23, HIGH(308) ; Immediate value 300 H (0x01), count checker
LDI R24, LOW(300) ; Immediate value 300 L (0x2c), count checker
    CLR R22
                             ; R26 = 0
    LDI R22, LOW(0x0222) ; R26 = 0x22
    ADD R25, R22 ; R25 = R25 + R26
LDI R22, HIGH(0x0222) ; R26 = 0x02
; Populate and store 300 numbers
popLOOP:
                            ; R25 += R26
    ADD R25, R22
    ST X+, R25
                            ; Store number
    INC R21
                            ; increment counter (low)
    JMP check300first
; Increment higher bits
changeHighfirst:
                            ; increment higher bit
    INC R20
    CLR R21
                             ; restarts lower bits
    JMP popLOOP
; Checks if counter == 300
    BREQ changeHighfirst
check300first:
    CP R24, R21
                            ; Compare LOW(300) and R21
    BRNE popLOOP
    CP R23, R20
                            ; Compare HIGH(300) and R20
    BRNE popLOOP
```

Task 2/B: Use X/Y/Z register addressing to parse through the 300 numbers, if the number is divisible by 5 store the number starting from memory location 0x0400, else store at location starting at 0x0600. **Task 3/C**: Use X/Y/Z register addressing to simultaneously add numbers from memory location 0x0400 and 0x0600 and store the sums at R16:R17 and R18:R19 respectively. Do not worry about the overflow.

a) checking if each number is divisible by 5, goes to registers R16 and R17 if divisible by 5 and goes to registers R18 and R19 if not

```
; Loads next number number in stack
loader:
    LD R15, -X
                           ; Load number to R20 downwards the stack
    MOV R14, R15
                           ; Moves value in R16 to check if divisible by 5
; checks if %5=0
D5:
                          ; Checks for divisibility by 5
    CP R15, R22
                           ; Compare R15 and R22 (5)
                           ; Go to ISNOT5 back if R15 => R22
    BRLO ISNOTS
    CP R15, R22
                           ; Compare R15 and R22 (5)
                           ; Go to IS5 if R15 == R22
    BREQ IS5
    SUB R15, R22
                           ; R15 = R15 - 5
    CP R15, R22
                           ; Compare R15 and R22 again
    BRSH D5
                           ; Loop back if R15 => R22
; when %5 != 0 (not divisible)
ISNOT5:
    ST Z+, R14
                           ; Stores number
    ADD R18, R14
                           ; Simultaneously add number (LOW BITS)
    LDI R19, 0
                           ; We were told not to worry about overflow
                           ; Increment counter
    INC R21
    JMP check300second
; when %5 == 0 (divisible)
IS5:
    ST Y+, R14
                           ; Stores number
    ADD R16, R14
                           ; Simultaneously add number (LOW BITS)
    LDI R17, 0
                           ; We were told not to worry about overflow
    INC R21
                           ; Increment counter
    JMP check300second
```

b) running the program, R16 is 0x34 (52) and R18 is 0x60 (96), the total sum of numbers divisible by 5 is 7220 (0x1C34) and the total sum of numbers not divisible by is 28768 (0x7060)



Task 4/D: Verify your algorithm and answers using C programming a) The Code


```
#include <iostream>
#include <cmath>
using namespace std;
int main ()
  int rem, fivecount = 0, notfivecount = 0;
  int fivesum = 0, notfivesum = 0;
  int array[300];
  //stores 300 numbers
  array[0] = 36; //FIRST ELEMENT (0x22 + 0x02)
  for (int i = 1 ; i < 300 ; i++)
     if(array[i-1] == 254)
        array[i] = 0;
     else
      array[i] = array[i-1] + 2;
  //check if divisible by 5
  for (int j = 0 ; j < 300 ; j++) //TRAVERSE
     rem = array[j] % 5;
     if(rem == 0 && array[j] != 0) //IF DIVISIBLE BY 5
        fivesum += array[j];
        fivecount++:
     else //IF NOT DIVISIBLE BY 5
        notfivesum += arrav[i];
        notfivecount++;
  //print results
  cout << "#s divisible by 5: " << fivecount << endl;
  cout << "The result for numbers div. by 5: ";
  //cout << fivesum%256 << endl;
  cout << fivesum << endl;
  cout << "#s not divisible by 5: " << notfivecount << endl;</pre>
  cout << "The result for numbers not div. by 5: ";</pre>
  //cout << notfivesum%256 << endl;
  cout << notfivesum <<endl;
b) running the code
[razonjl@bobby CPE301]$ ./a.out
#s divisible by 5: 59
The result for numbers div. by 5: 7220
#s not divisible by 5: 241
The result for numbers not div. by 5: 28768
[razonjl@bobby CPE301]$
c) running the code (with %256, to confirm Task 3/C results)
[razonjl@bobby CPE301]$ ./a.out
#s divisible by 5: 59
The result for numbers div. by 5: 52
#s not divisible by 5: 241
The result for numbers not div. by 5: 96
[razonjl@bobby CPE301]$
```

Task 5/E: Determine the execution time @ 16MHz/#cycles of your algorithm using the simulation. Execution time (in microseconds) = # of cycles (64663 cycles) / frequency (16 MHz) = 4041.44

a) calculations on online scientific calculator

```
\frac{64663}{16} = 4041.4375
```

b) by changing the frequency on Atmel Studios, the stop watch's execution time changed accordingly



FULL CODE

```
start:
; Declare POINTERS
   LDI XL, LOW(0x0222)
   LDI XH, HIGH(0x0222)
   LDI YL, LOW(0x0400)
   LDI YH, HIGH(0x0400)
   LDI ZL, LOW(0x0600)
   LDI ZH, HIGH(0x0600)
; Declare variables
   CLR R16
                           ; Stores total sum of numbers that are divisible by 5, set to 0
                           ; R16 overflow
   CLR R17
   CLR R18
                           ; Stores total sum of numbers that are not divisible by 5, set to 0
   CLR R19
                           ; R18 overflow
                           ; Counter register (HIGH), set to 0
   CLR R20
   CLR R21
                           ; Counter register (LOW), set to 0
   LDI R23, HIGH(300)
                           ; Immediate value 300 H (0x01), count checker
   LDI R24, LOW(300)
                           ; Immediate value 300 L (0x2c), count checker
   CLR R22
                           ; R26 = 0
   LDI R22, LOW(0x0222)
                           R26 = 0x22
   ADD R25, R22
                           ; R25 = R25 + R26
   LDI R22, HIGH(0x0222)
                          R26 = 0x02
; Populate and store 300 numbers
popLOOP:
   ADD R25, R22
                           : R25 += R26
   ST X+, R25
                           ; Store number
   INC R21
                           ; increment counter (low)
   JMP check300first
```

```
; Increment higher bits
changeHighfirst:
    INC R20
                           ; increment higher bit
    CLR R21
                            ; restarts lower bits
    JMP popLOOP
; Checks if counter == 300
check300first:
    CPI R21, 0x00
                           ; Check to increment high bit
    BREQ changeHighfirst
    CP R24, R21
                           ; Compare LOW(300) and R21
    BRNE popLOOP
    CP R23, R20
                           ; Compare HIGH(300) and R20
    BRNE popLOOP
    CLR R20
                           ; clear counter(high)
    CLR R21
                           ; clear counter(low)
                           ; clear R22
    CLR R22
    LDI R22, 0x05
                           ; load a 5 to check if divisible
; Loads next number number in stack
loader:
    LD R15, -X
                           : Load number to R20 downwards the stack
    MOV R14, R15
                           ; Moves value in R16 to check if divisible by 5
; checks if %5=0
                           ; Checks for divisibility by 5
D5:
    CP R15, R22
                           ; Compare R15 and R22 (5)
                           ; Go to ISNOT5 back if R15 => R22
    BRLO ISNOTS
                          ; Compare R15 and R22 (5)
    CP R15, R22
    BREQ ISS
                           ; Go to IS5 if R15 == R22
                           ; R15 = R15 - 5
    SUB R15, R22
                          ; Compare R15 and R22 again
    CP R15, R22
    BRSH D5
                           ; Loop back if R15 => R22
; when %5 != 0 (not divisible)
ISNOT5:
   ST Z+, R14
                          ; Stores number
   ADD R18, R14
                          ; Simultaneously add number (LOW BITS)
   LDI R19, 0
                          ; We were told not to worry about overflow
   INC R21
                           ; Increment counter
   JMP check300second
; when %5 == 0 (divisible)
ISS:
   ST Y+, R14
                          ; Stores number
   ADD R16, R14
                          ; Simultaneously add number (LOW BITS)
   LDI R17, 0
                           ; We were told not to worry about overflow
   INC R21
                           ; Increment counter
   JMP check300second
; Increments higher bits
changeHighsecond:
   INC R20
                           ; increment higher bit
   CLR R21
                           ; restarts lower bits
   JMP loader
; Checks if counter == 300
check300second:
   CPI R21, 0x00
                          ; Check to increment high bit
   BREQ changeHighsecond ; counter reaches 256
                          ; Compare LOW(300) and R21
   CP R24, R21
                          ; loop back if R24 != R21
   BRNE loader
   CP R23, R20
                          ; Compare HIGH(300) and R20
   BRNE loader
                          ; loop back if R23 != R20
DONE:
                          ; Program end
   NOP
```

FLOW CHART start: INITIALIZE POINTERS AND VARIABLES popLoop: populate 300 numbers, then stores them with X pointer changeHighfirst: increment high bits if counter reaches 256 check300first: checks if counters equals 300 loader: parses, loads number from stack ISNOT5: IS5: D5: checks if the loaded stores number with Z stores number with Y number is divisible by pointer and adds to pointer and adds to sum 5 sum changeHighsecond: check300second: increment high bits if checks if counters counter reaches 256 equals 300 DONE: Program end

GITHUB LINK: https://github.com/JeffinVegas/EmbSys.git

Student Academic Misconduct Policy

http://studentconduct.unlv.edu/misconduct/policy.html

"This assignment submission is my own, original work".

Jeffrey Razon