CoilGen Documentation

Philipp Amrein

February 2022



Contents

0.1	Purpose	e, I	ntro	oduc	tion																	4
0.2	Installa	atio	n																			4
0.3	Code description														4							
	0.3.1	Fi	le s	truct	ure																	4
0.4	Usage																					5
	0.4.1	N	eces	ssary	inp	ut	pa	ra	me	ete	rs											5
	0.4.2	O	ptio	nal i	npu	t p	ara	am	ete	ers												5
0.5	TO DO)																				6

4 CONTENTS

0.1 Purpose, Introduction

This *CoilGen* project is supposed to be a community based tool that facilitates the design of coils within the MRI/NMR environment. A stream function approach of the Boundary Element Method is used to generate a current density to fit a freely specified target field. Further post processing is implement that processes the current density into a suitable coil layout. Up to now, the code is written in MATLAB, but future migration to python might be advantageous, especially since it does not need proprietary software licenses. The author is very willing to collaborate with anyone who wants do the translation.

0.2 Installation

The project requires MATLAB and additionally FastHenry2 for calculation of the inductance. The MATLAB version should not be older than 2020A. It also requires the MAPPING toolbox since the functions polyxpoly and inpolyon. Non-propriaty versions of these functions are also very welcome.

0.3 Code description

The algorithm is written within the main function named "coilgen.m". It can be called with various necessary and optional input parameters.

0.3.1 File structure

- Documentation_
- Examples: Here are the Matlab scripts of the different projects that calls the main algorithm *CoilGen.m* together with the input parameters
- Geometry_Data: .stl files of surface geometries for the definition of the current carrying surfaces and the target fields. It should be in the bindary format.
- sub_functions: Folder of *MATLAB* sub-functions that are called by the main function *CoilGen.m* algorithm
- Pre_Optimized_Solutions: .mat data containers pre-optimized stream functions. Please check the function load_preoptimized_data.m
- plotting: Several functions to plot results.

0.4. USAGE 5

• Results: Folder for saving results.

0.4 Usage

"Coilgen.m" must be called with the required set of input parameters. All other settings and variables are optional. If not specified the default values set. The definitions of the default values can be seen within the function *parse_inputs.m*.

0.4.1 Necessary input parameters

- *coil_mesh_file*: The name of the *.stl* file for the current carrying surface. It must be in the *Geometry_Data* folder.
- field_shape: The functional that specifies the target field i.e. the z component of the magnetic field i.e. B_z . In general, it can be any function of the Cartesian coordinates x, y, z. To generate a linear transverse gradient specify: $field_shape = 'y'$. This variable must be a character array.

Other examples:

- field_shape='x' (linear x-Gradient)
- field_shape='y' (linear y-Gradient)
- field_shape='z' (linear z-Gradient)
- field_shape='x.* $sin(\alpha) y$.* $cos(\alpha)$ ' (linear x-Gradient rotated with angle α around the z-axis)
- field_shape='2. *x. *y' (Spherical harmonic S2 shim field)
- field_shape='1' (constant field, B0 offset)

The x, y, z coordinates refer to the coordinate system which is also used for the coordinates of the surface geometry. **Important**: Use the MATLAB .* operator for element wise multiplication.

0.4.2 Optional input parameters

All other settings and variables are optional. If not specified the default values set. The definitions of the default values can be seen within the function parse_inputs.m.

• coil_mesh_file: The name of the .stl file