BOOTSTRAPPING

In which you will inspect and modify a bootloader for an embedded system.

Purpose and outcomes

The process of starting software execution on a physical platform — booting [1] — is not trivial. In this lab we will investigate the early boot process for the BeagleBoneBlack board. Observing this low-level hardware/software interaction will require using (and learning about) a number of practical concepts and tools:

- the embedded system / SoC boot process
- disk partitioning
- Unix tools relevant to embedded systems
- Das U-Boot, a commonly-used bootloader

After completing this lab, you should have a good understanding of what happens in an embedded system from power-on to the beginning of OS boot.

Preparation

Answer all of the following questions. Explain and provide evidence for your claims.

If you are doing this lab on Ubuntu 18.04, you will need to install the <code>gcc-arm-none-eabi</code> package (apt install gcc-arm-none-eabi). Completing this lab on macOS is not supported, but it may work if you install the <code>gcc-arm-embedded cask from Homebrew</code>. On recent versions of macOS you will need to open the <code>arm-none-eabi-objdump</code> binary explicitly to override default security settings, as that binary isn't signed.

BeagleBoneBlack boot overview

Familiarize yourself with the following reference documents:

- §6.7 of the <u>BeagleBoneBlack System Reference Manual</u>(BBB SRM)
- §26.1.6 of the <u>TI AM335x and AMIC110 Sitara processors Technical Reference Manual (TRM)</u> (AM335x TRM)
- §3.1.1.2.2 of the <u>TI Processor SDK reference</u>

Using these reference documents, answer the following questions.

- 1. According to §3.1.1.2.2, paragraph "Boot Flow" of the TI Processor SDK reference, what are the four stages of the bootloading process for an AM335x processor?
 - 1. ROM Code: the first block of code that is automatically run on device start-up or after power-on reset (POR). It is hardcoded into the device and cannot be changed by the user. The ROM code has two main functions:
 - Configuration of the device and initialization of primary peripherals
 - Readies the device for next bootloader
 - 2. SPL (Secondary Program Loader) or MLO (MMC Card Loader): the first stage of U-Boot, and must be loaded from one of the boot sources into internal RAM. The SPL has very limited configuration or user interaction, and mainly serves to initialize the external DDR memory and set-up the boot process for the next bootloader stage: U-Boot.

- 3. U-Boot: U-Boot allows for powerful command-based control over the kernel boot environment via a serial terminal. The user has control over a number of parameters such as boot arguments and the kernel boot command. In addition, U-Boot environment variables can be configured.
- 4. Linux Kernel: The loading of the kernel image is typically performed through the use of scripts stored in the U-Boot environment.
- 2. According to Figure 39 of the BBB SRM or Table 26-7 of the AM335x TRM, which device will the processor boot ROM first attempt to boot from if pins SYSBOOT[4:0] are set to 11100b?

SYSBOOT[15:14]	SYSBOOT[13:12]	SYSBOOT[11:10]	SYSBOOT[9]	SYSBOOT[8]	SYSBOOT[7:6]	SYSBOOT[5]	SYSBOOT[4:0]	Boot Sequence			
00b = 19.2MHz 01b = 24MHz 10b = 25MHz 11b = 26MHz	00b (all other values reserved)	Don't care for ROM code	Don't care for ROM code	Don't care for ROM code	Don't care for ROM code	0 = CLKOUT1 disabled 1 = CLKOUT1 enabled	11100b	MMC1	MMC0	UART0	USB0 <u>[5]</u>
00b = 19.2MHz 01b = 24MHz 10b = 25MHz 11b = 26MHz	00b (all other values reserved)	Don't care for ROM code	Don't care for ROM code	Don't care for ROM code	Don't care for ROM code	0 = CLKOUT1 disabled 1 = CLKOUT1 enabled	11000b	SPI0	MMC0	USB0 <u>[5</u>]	UART0

the processor will first look for the **eMMC** on the MMC1 port.

- 3. According to §26.1.8.5 of the AM335x TRM:
 - 1. Where can the MMC LOader (MLO) be found on the internal or external SD Card / MultiMediaCard (MMC) in FAT mode?

It is only located in the **root directory** on an active primary partition of type FAT12/16 or FAT32. For a FAT12/16 file system, the Root Directory has a fixed location which is cluster 0. For a FAT32 file system, its cluster location is given by *BPB_RootClus*. To

2. What is a Master Boot Record (MBR)?

The Master Boot Record is the 1st sector of a memory device. It is made out of some executable code and 4 partition entries

- 3. What bytes would be recognized by the AM335x as a valid boot Partition Type within an MBR Partition Entry?
 - 01h for FAT12
 - 04h, 06h, 0Eh for FAT16
 - 0Bh, 0Ch, 0Fh for FAT32

Disk partitions

Using the Wikipedia entry on partition types [2], answer the following questions.

1. Which partition IDs are used for the various flavours of FAT (File Allocation Table) filesystems?

FAT12 - 0x01

FAT16 - 0x04

FAT16B - 0x06

exFAT - 0x07

Logical sectored FAT12/FAT16 (Commodore) - 0x08

FAT32 (CHS) - 0x0B

FAT32 (LBA) - 0x0C

FAT16B (LBA) - 0x0E

Logical sectored FAT12/FAT16 (Leading Edge) - 0x11

Hidden FAT12 (IBM) - 0x11

Bootable FAT - 0x12

Logical sectored FAT12/FAT16 (AST) - 0x14

Hidden FAT16 (IBM) - 0x14

Hidden FAT16B (IBM) - 0x16

Hidden exFAT (IBM) - 0x17

Hidden FAT32 (IBM) - 0x1B

Hidden FAT32 with LBA (corresponds with Och) - 0x1C

Hidden FAT16 with LBA (corresponds with OEh) - 0x1E

Logical sectored FAT12 or FAT16(NEC) - 0x24

Logical sectored FAT12 or FAT16(ATT) - 0x56

Hidden FAT12 (corresponds to E1h) - 0x61

Hidden FAT16 (corresponds to E4h) - 0x64

Hidden read-only FAT16 (corresponds to E6h) - 0x66

etc

- 2. What is the difference between LBA and CHS modes? Which came first? Which is more commonly-used today? Why?
 - Cylinder-Head-Sector(CHS) was an earlier method for addressing hard disks. Sectors can be addressed by CHS coordinates (C, H, S).
 - Logical block addressing (LBA): blocks are located by an integer index, with the first block being LBA 0, the second LBA 1, and so on.

LBA is more commonly-used today. Because LBA is simpler. Using LBA, the hard disk is simply addressed as a single, large device, which simply counts the existing blocks starting at 0.

3. Which partition ID is used for modern Linux filesystems? (give both base-10 and base-16 representations)

Modern Linux filesystems use the ext4 filesystem. The partition ID is 0x83 - 131

4. Which partition ID is used for a FreeBSD slice? (give both base-10 and base-16 representations)

FreeBSD slices use the BSD slice filesystem. The partition ID is 0xA5 - 165

Disk and file inspection tools

Questions in this section will refer to the object file <u>8894.0</u> (which contains the definition of a <u>main</u> function). You should download this file to a Unix-like system (BSD, MacOS, Linux, Solaris, etc.), from which you should be able to examine it with the tools below.

Consult the manual pages for the following Unix tools and answer the associated questions.

1. dd(1)

1. what does this tool do?

dd(1) copies a file, converting and formatting according to the operands.

2. give a command line that you could use to copy 32 kib from one file to another.

since the operand count=N means copy only N input blocks, one block has 512 bytes.

32 kib = 64 blocks

```
$dd if=srcfile of=dstfile count=64
```

2. hexdump(1)

1. Run hexdump -C 8894.o | head -n12. What do you observe in offsets 0-B0h?

```
xy@xy-vm:~/Desktop$ hexdump -C 8894.0 | head -n12
00000000 7f 45 4c 46 01 01 01 00 00 00 00 00 00 00 00
|.ELF....|
(.....
00000020 74 01 00 00 00 00 05 34 00 00 00 00 28 00
|t....(.|
|.....
00000040 42 f2 be 21 ff f7 fe ff 00 23 18 46 80 bd 00 bf
|B..!....#.F....|
00000050 43 6f 6e 67 72 61 74 75 6c 61 74 69 6f 6e 73 20
|Congratulations |
00000060 6f 6e 20 63 6f 6d 70 6c 65 74 69 6e 67 20 45 4e |on
completing EN|
00000070 47 49 20 25 64 21 0a 00 00 47 43 43 3a 20 28 63 |GI
%d!...GCC: (c|
00000080 72 6f 73 73 74 6f 6f 6c 2d 4e 47 20 6c 69 6e 61 |rosstool-NG
linal
000000090 72 6f 2d 31 2e 31 33 2e 31 2d 34 2e 38 2d 32 30 |ro-1.13.1-
4.8-20|
000000a0 31 34 2e 30 34 20 2d 20 4c 69 6e 61 72 6f 20 47 |14.04 -
Linaro G
000000b0 43 43 20 34 2e 38 2d 32 30 31 34 2e 30 34 29 20 | CC 4.8-
2014.04) |
```

The string ".ELF(t4(@B!#.F Congratulations on completing ENGI %d! GCC: (crosstool-NG linaro-1.13.1-4.8-2014.04 - Linaro GCC 4.8-2014.04)"

- 2. Read pages 4–2, 4–4, 4–5 and 4–7 of the <u>System V Application Binary Interface</u> <u>specification</u>, Edition 4.1 (also known as the "Generic ABI" or gABI, since it does not include architecture-specific details). Using this specification and your <u>hexdump(1)</u> output, answer the following questions, justifying your conclusions from your observations:
 - 1. What ELF version does <u>8894.0</u> conform to?

Byte 7 tells us which version of the ELF format the file is using. Thus 8894.0 conforms to the current ELF version 1 as the byte 7 is 01.

2. Is it a 32- or 64-bit object file?

Byte 5 tells us whether we're using a the 32-bit or 64-bit ELF format. Thus it is a 32-bit object file since the byte 5 is 01.

3. Is it compiled for a little- or big-endian machine?

It is compiled for a little-endian machine since the numerical values in the header are stored with little-endianness.

4. What type of object file is this (shared? executable? relocatable?)?

Bytes 17 and 18 are a two-byte fieldm, which is the 'type' of our ELF file. The value is 0x0001 = 1, which is Relocatable file.

3. What can you infer about the behaviour of this code, based purely on what you can see in your hexdump(1) output?

The "Congratulations" string is a format print. Thus it prints "Congratulations on completing ENGI x", where x is a signed integer from the user input.

3. objdump(1)

1. What does the objdump -s command do?

It displays the full contents of the requested sections by default display.

It displays the full contents of the requested sections, by default displaying the contents of all non-empty sections.

2. What does the objdump -d command do?

It displays the asembler mnemonics for the machine instructions in the object file. Only disassembles sections which should contain instructions.

- 1. For the linguistically curious, "boot" is short for <u>"bootstrap"</u>, a word that is derived rather colourfully from the concept of pulling oneself up by one's own bootstraps. However, there is <u>debate on the etymology of the word</u>.
- <u>2</u>. Wikipedia is not typically referenced as a canonical source of archival information. However, there is no authoritative listing of partition IDs, so this is about as good as we're going to get. Another listing (no more or less authoritative) can be found <u>here</u>, or alternatively, you can <u>use the source</u> (Luke).