Lab Exercise #3: Interrupt Subroutines and UART Serial Communication

Frank Li | NetID: jl13581 | Email: jl13581@nyu.edu | Section C1

1. Background

On our Adafruit Circuit Playground Classic board, there is one USART channel, which is USART1. Universal Asynchronous Receiver-Transmitter (UART) is a hardware communication protocol that uses asynchronous serial communication with configurable speed. It is one of the simplest and most commonly used protocols. In UART communication, data is transmitted in the form of packets, which include a start bit, data bits, an optional parity bit, and stop bits. UART does not require a clock signal, making it simpler to implement compared to synchronous communication protocols. However, it is limited by the need for both devices to agree on the baud rate and the potential for data corruption if the baud rates are not perfectly matched.

2. Experimental Procedure

2.a UART Setup

For the first part of the lab, we set up the USART based on the datasheet of the microcontroller we are using, which is ATMega32U4. According to the lab manual, we know that the expected set ups are:

Parameter	Value
Bit Rate	9,600
Data Bits	8
Parity	None
Stop Bits	1
Mode	Asynchronous/Normal Speed

Based on the above information, and the datasheet, we can set up the registers as follows:

I first set UCSR1A, UCSR1B, and UCSR1C to zero to make sure they were set to defual before further modifications, then I set the bits RXEN1 and TXEN1 in UCSR1B to enable the receiver and transmitter, respectively. I also set the bits UCSZ10 and UCSZ11 in UCSR1C to set the data bits to 8. Finally, I set the UBRR1 register to 51 to set the baud rate to 9600. The calculation of the UBRR1 register is based on the formula given in the datasheet:

$$UBRR1 = \frac{f_{osc}}{16 \times \text{Baud Rate}} - 1$$
$$= \frac{8\text{MHz}}{16 \times 9600} - 1$$
$$= 51.08$$

In this case, based on the calculation result, I set the UBRR1 to 51. This code is for Team A, so the interrupt on receiver is not enabled. To enable it, we just need to add UCSR1B |= (1<<RXCIE1).

2.b UART Receive ISR

For the second part of the lab, we set up the ISR for the USART receive interrupt. The ISR is triggered when the USART receives a byte of data. If the value is 0x31, we turn on the LED on the board. Otherwise, we turn off the LED:


```
ISR(USART1_RX_vect) {
    if (UDR1 == 0x31) {
        PORTC |= (1<<PC7);
    } else {
        PORTC &= ~(1<<PC7);
    }
}</pre>
```

2.c UART Transmit

Only Team A need to transmit data to the other board, thus the transmision function is only in Team A's code. When sending values via USART, we actually directly write the value to the register UDR1. As the lab manual required, when we pressed one button (right button in our implementation), the value "0x31" will be sent. Otherwise, the value "0x30" will be sent. In order to make the checking active at all time, we wrote it in the loop() function of Team A's board:

According to the lab manual, when we pressed the button, the data is transmitted and the LED on Team A's board is also lighted up.

2.d Final Setup






Figure 1: Final Setup

Figure 2: Testing

3. Concusion

In this lab, we learned how to set up the USART on the ATMega32U4 microcontroller. We also learned how to set up the interrupt service routine for the USART receive interrupt. We also learned how to transmit data via USART and successfully fulfilled requirements and tasks in the lab manual.

4. Code

4.a Team A

```
#include <Arduino.h>
void setup() {
    UCSR1A = 0x00;
                            // UCSRA set as default.
    UCSR1B = 0x00;
                             // UCSRB set as default.
    UCSR1C = 0x00;
                            // UCSRC set as default.
    UCSR1B |= (1<<RXEN1) | // Enable receiver</pre>
            (1<<TXEN1);
                             // Enable transmitter
    UCSR1C |= (1<<UCSZ10) |
            (1<<UCSZ11);
                             // 8-bit data
    UBRR1 = 51; // UBRR1 = (fosc / (16 * Baud Rate)) - 1
                         = (8MHz / (16 * 9600)) - 1 = 51.08
    DDRF &= ~(1<<PF6);
                            // Right button PF6 as input
    DDRC |= (1<<PC7);
                            // Set PC7 as output
    PORTC &= ~(1<<PC7);
                            // Set LED to off
}
void loop() {
    // Team A
    if(PINF & (1<<PF6)){</pre>
        PORTC |= (1<<PC7); // Set LED to on
        UDR1 = 0x31;
                            // Send 1
    } else {
```

```
PORTC &= ~(1<<PC7); // Set LED to off
UDR1 = 0x30; // Send 0
}</pre>
```

4.b Team B

```
#include <Arduino.h>
void setup() {
    UCSR1A = 0x00; // UCSRA set as default.
    UCSR1B = 0x00; // UCSRB set as default.
    UCSR1C = 0x00; // UCSRC set as default.
    UCSR1B |= (1<<RXEN1) | // Enable receiver</pre>
    (1<<TXEN1) |
                             // Enable transmitter
    (1<<RXCIE1)|
                            // Enable RX Interrupt
    (1<<TXCIE1);
                            // Enable TX Interrupt
    UCSR1C |= (1<<UCSZ10) |
    (1<<UCSZ11);
                             // 8-bit data
    UBRR1 = 51;
                             // UBRR1 = (fosc / (16 * Baud Rate)) - 1
                                     = (8MHz / (16 * 9600)) - 1 = 51.08
   DDRF &= ~(1<<PF6);

DDRC |= (1<<PC7);

PORTC &= ~(1<<PC7);
                            // Right button PF6 as input
                             // Set PC7 as output
                             // Set LED to off
    sei();
}
ISR(USART1_RX_vect){
    if (UDR1 == 0x31){
        PORTC |= (1<<PC7);
    } else{
        PORTC &= ~(1<<PC7);
}
void loop() {
```