



# **Chapter 3**Data and Signals


#### 3-4 TRANSMISSION IMPAIRMENT

Signals travel through transmission media, which are not perfect. The imperfection causes signal impairment. This means that the signal at the beginning of the medium is not the same as the signal at the end of the medium. What is sent is not what is received. Three causes of impairment are attenuation, distortion, and noise.

#### Topics discussed in this section:

- Attenuation
- Distortion
- Noise

#### Figure 3.25 Causes of impairment



#### **Attenuation**


- Means loss of energy -> weaker signal
- When a signal travels through a medium it loses energy overcoming the resistance of the medium
- Amplifiers are used to compensate for this loss of energy by amplifying the signal.

#### Measurement of Attenuation

 To show the loss or gain of energy the unit "decibel" is used.

```
dB = 10log_{10}P_2/P_1
P_1 - input signal
P_2 - output signal
```

#### Figure 3.26 Attenuation





Suppose a signal travels through a transmission medium and its power is reduced to one-half. This means that  $P_2$  is  $(1/2)P_1$ . In this case, the attenuation (loss of power) can be calculated as

$$10 \log_{10} \frac{P_2}{P_1} = 10 \log_{10} \frac{0.5P_1}{P_1} = 10 \log_{10} 0.5 = 10(-0.3) = -3 \text{ dB}$$

A loss of 3 dB (-3 dB) is equivalent to losing one-half the power.

## Example 3.27

A signal travels through an amplifier, and its power is increased 10 times. This means that  $P_2 = 10P_1$ . In this case, the amplification (gain of power) can be calculated as

$$10\log_{10}\frac{P_2}{P_1} = 10\log_{10}\frac{10P_1}{P_1}$$

$$= 10 \log_{10} 10 = 10(1) = 10 \text{ dB}$$

# Example 3.29

Sometimes the decibel is used to measure signal power in milliwatts.

\*In this case, it is referred to as  $dB_m$  and is calculated as  $dB_m = 10 \log 10 P_m$ , where  $P_m$  is the power in milliwatts. \*Calculate the power of a signal with  $dB_m = -30$ .

#### **Solution**

### We can calculate the power in the signal as

$$dB_{m} = 10 \log_{10} P_{m} = -30$$

$$\log_{10} P_{m} = -3 \qquad P_{m} = 10^{-3} \text{ mW}$$

#### Example 3.30

The loss in a cable is usually defined in decibels per kilometer (dB/km). If the signal at the beginning of a cable with -0.3 dB/km has a power of 2 mW, what is the power of the signal at 5 km?

#### **Solution**

The loss in the cable in decibels is  $5 \times (-0.3) = -1.5$  dB. We can calculate the power as

$$dB = 10 \log_{10} \frac{P_2}{P_1} = -1.5$$


$$\frac{P_2}{P_1} = 10^{-0.15} = 0.71$$

$$P_2 = 0.71P_1 = 0.7 \times 2 = 1.4 \text{ mW}$$


#### Distortion

- Means that the signal changes its form or shape
- Distortion occurs in composite signals
- Each frequency component has its own propagation speed traveling through a medium.
- The different components therefore arrive with different delays at the receiver.
- That means that the signals have different phases at the receiver than they did at the source.

#### Figure 3.28 Distortion



At the sender



At the receiver

#### Noise

- There are different types of noise
  - Thermal random noise of electrons in the wire creates an extra signal
  - Induced from motors and appliances, devices act are transmitter antenna and medium as receiving antenna.
  - Crosstalk same as above but between two wires.
  - Impulse Spikes that result from power lines, lighning, etc.

#### Thermal Noise

 Thermal noise is the random motion of electrons in a wire which creates an extra signal not originally sent by the transmitter.

#### **Induced Noise**

- Induced noise comes from sources such as motors and appliances.
- These devices act as a sending antenna, and the transmission medium acts as the receiving antenna.


#### Cross Talk

 Crosstalk is the effect of one wire on the other. One wire acts as a sending antenna and the other as the receiving antenna.

### Impulse Noise

 Impulse noise is a spike (a signal with high energy in a very short time) that comes from power lines, lightning, and so on.

#### Figure 3.29 Noise



To find the theoretical bit rate limit, we need to know the ratio of the signal power to the noise power. The signal-to-noise ratio is defined as

SNR = Average Signal Power/Average Noise Power

SNR is the ratio of what is wanted (signal), to what is not wanted (Noise)

High SNR means the signal is less courrupted by noise.

Low SNR means the signal is more cprrupted by noise

### Signal to Noise Ratio (SNR)

- To measure the quality of a system the SNR is often used. It indicates the strength of the signal wrt the noise power in the system.
- It is the ratio between two powers.
- It is usually given in dB and referred to as SNR<sub>dB.</sub>

# Example 3.31

The power of a signal is 10 mW and the power of the noise is 1  $\mu$ W; what are the values of SNR and SNR<sub>dB</sub>?

# Solution The values of SNR and $SNR_{dB}$ can be calculated as follows:

$$SNR = \frac{10,000 \ \mu\text{W}}{1 \ \text{mW}} = 10,000$$
$$SNR_{dB} = 10 \log_{10} 10,000 = 10 \log_{10} 10^4 = 40$$




### The values of SNR and SNR<sub>dB</sub> for a noiseless channel are

$$SNR = \frac{\text{signal power}}{0} = \infty$$
$$SNR_{dB} = 10 \log_{10} \infty = \infty$$

We can never achieve this ratio in real life; it is an ideal.

#### Figure 3.30 Two cases of SNR: a high SNR and a low SNR



a. Large SNR

