


#### **ECE4700J Computer Architecture**



# Topic 6

#### Single Instruction Multiple Data (SIMD)

Xinfei Guo xinfei.guo@sjtu.edu.cn


July 1st, 2024



# T6 learning goals

- SIMD
  - Section I: Introduction to SIMD
  - Section II: A Case Study GPU


# Why parallel computing?





# Flynn's Classification of Computers

- Michael J Flynn (Stanford) classified computers on the basis of multiplicity of instruction stream and data streams in a computer system.
- Instruction stream: is the sequence of instructions as executed by the machine.
- Data stream: is a sequence of data including input, or partial or temporary result, called by the instruction stream.
- Instructions are decoded by the control unit and then ctrl unit send the instructions to the processing units for execution.
- Data Stream flows between the processors and memory bi directionally




source: Wiki

## Parallelism is the key!

- Instruction level parallelism (ILP)
  - Execute independent instructions from one instruction stream in parallel (pipelining, superscalar, VLIW)
- Data-Level Parallelism (DLP)
  - Execute multiple operations of the same type in parallel (vector/SIMD execution)
- Thread-Level Parallelism (TLP)
  - Execute independent instruction streams in parallel (multithreading, multiple cores)




# Flynn's Classification





# SISD (What we learned up to now)


- Single Instruction Single Data
- takes data from a single address in memory and performs a single instruction on the data.
- single processor systems (microcontrollers)
- Low power requirements as only a single core






#### **MIMD**

- Multiple Instruction Multiple Data
- Multiple autonomous processors perform operations on difference pieces of data, either independently or as part of shared memory space.
- Most modern desktop / laptop / mobile processors are MIMD processors.
- Great to perform a variety of processor and data intensive tasks (such as video editing, game rendering)



#### **MISD**


- Multiple Instruction Single Data
- Different systems perform operations on the data and all the results must agree.
- Used on flight control systems where fault detection is critical.
- Not used commercially.







#### SIMD

- Single Instruction Multiple Data
- These instructions can be performed sequentially, taking advantage of pipelining, or in parallel using multiple processors.
- Example: Vector Architectures, GPUs
- Very efficient where you need to perform instruction on large amounts of data



### SISD vs. SIMD








### How to View a SIMD Machine

- Think of soldiers all in a unit.
- The commander selects certain soldiers as active for example, the first row.
- The commander barks out an order to all the active soldiers, who execute the order synchronously.
  - The remaining soldiers do not execute orders until they are reactivated.



# Why SIMD?

- SIMD architectures can exploit significant data-level parallelism for:
  - Matrix-oriented scientific computing
  - Media-oriented image and sound processors

- SIMD is more energy efficient than MIMD
  - Only needs to fetch one instruction per data operation
  - Makes SIMD attractive for personal mobile devices
- SIMD allows programmer to continue to think sequentially



### Multimedia / Scientific Applications

- Image
  - Graphics : 3D games, movies
  - Image recognition
  - Video encoding/decoding : JPEG, MPEG4
- Sound
  - Encoding/decoding: IP phone, MP3
  - Speech recognition
  - Digital signal processing: Cell phones
- Scientific applications
  - Double precision Matrix-Matrix multiplication (DGEMM)
  - Y[] = a\*X[] + Y[] (SAXPY)


#### SIMD Parallelism


- Vector architectures
- SIMD extensions
- Graphics Processor Units (GPUs)
- For x86 processors:
  - Expect two additional cores per chip per year
  - SIMD width to double every four years
  - Potential speedup from SIMD to be twice that from MIMD!



## **Description of Vector Processors**

- CPU that implements an instruction set that operates on 1-D arrays, called vectors
- Vectors contain multiple data elements
- Many scientific/commercial programs use vectors
- Number of data elements per vector is typically referred to as the vector length
- Both instructions and data are pipelined to reduce decoding time







## **Advantages of Vector Processors**

- Require Lower Instruction Bandwidth
  - Reduced by fewer fetches and decodes
- Easier Addressing of Main Memory
  - Load/Store units access memory with known patterns
- Elimination of Memory Wastage
  - Unlike cache access, every data element that is requested by the processor is actually used – no cache misses
  - Latency only occurs once per vector during pipelined loading
- Simplification of Control Hazards
  - Loop-related control hazards from the loop are eliminated
- Scalable Platform
  - Increase performance by using more hardware resources
- Reduced Code Size
  - Short, single instruction can describe N operations




### **Vector Architectures**

- Basic idea:
  - Read sets of data elements into "vector registers"
  - Operate on those registers
  - Disperse the results back into memory
- Registers are controlled by compiler
  - Used to hide memory latency
  - Leverage memory bandwidth


### **Vector Architectures**

- All vector operations occur between vector registers
- If necessary, operands are fetched from main memory into a set of vector registers (load-store unit)
- Includes all vector machines since the late 1980s:
  - Convex, Cray, Fujitsu, Hitachi, NEC





## **Components of Vector Processors**

- Vector Registers
  - Typically 8-32 vector registers with 64 128 64-bit elements
  - Each contains a vector of double-precision numbers
  - Register size determines the maximum vector length
  - Each includes at least 2 read and 1 write ports
- Vector Functional Units (FUs)
  - Fully pipelined, new operation every cycle
  - Performs arithmetic and logic operations
  - Typically 4-8 different units
- Vector Load-Store Units (LSUs)
  - Moves vectors between memory and registers
- Scalar Registers
  - Single elements for interconnecting FUs, LSUs, and registers



# **Vector FUs and Memory Systems**





Can sustain parallel accesses if they go to different banks

# **VMIPS (2001)**

- Example architecture: RV64V
  - Loosely based on Cray-1
  - 32 62-bit vector registers
    - Register file has 16 read ports and 8 write ports
  - Vector functional units
    - Fully pipelined
    - Data and control hazards are detected
  - Vector load-store unit
    - Fully pipelined
    - One word per clock cycle after initial latency
  - Scalar registers
    - 31 general-purpose registers
    - 32 floating-point registers



#### **VMIPS Instructions**

- .vv: two vector operands
- .vs and .sv: vector and scalar operands
- LV/SV: vector load and vector store from address
- Example: DAXPY

```
vsetdcfg 4*FP64
                      # Enable 4 DP FP vregs
fld
         f0,a
                       # Load scalar a
vld
         v0,x5
                       # Load vector X
         v1,v0,f0
                      # Vector-scalar mult
vmul
vld
         v2,x6
                      # Load vector Y
         v3,v1,v2
vadd
                      # Vector-vector add
                       # Store the sum
         v3,x6
vst
vdisable
                      # Disable vector regs
```

8 instructions, 258 for RV64V (scalar code)

#### **Vector Execution Time**

- Execution time depends on three factors:
  - Length of operand vectors
  - Structural hazards
  - Data dependencies
- RV64V functional units consume one element per clock cycle
  - Execution time is approximately the vector length
- Convoy
  - Set of vector instructions that could potentially execute together



#### Chimes

 Sequences with read-after-write dependency hazards placed in same convoy via chaining

#### Chaining

 Allows a vector operation to start as soon as the individual elements of its vector source operand become available

#### Chime

- Unit of time to execute one convey
- m conveys executes in m chimes for vector length n
- For vector length of *n*, requires *m* x *n* clock cycles

### **Example**

vIdv0,x5# Load vector Xvmulv1,v0,f0# Vector-scalar multiplyvIdv2,x6# Load vector Yvaddv3,v1,v2# Vector-vector addvstv3,x6# Store the sum


#### Convoys:

1 vld vmul2 vld vadd3 vst


3 chimes, 2 FP ops per result, cycles per FLOP = 1.5 For 64 element vectors, requires 32 x 3 = 96 clock cycles

### Performance Optimization - Vector Chaining

- Vector chaining: Data forwarding from one vector functional unit to another (recall data forwarding)
- Results of one pipeline are fed into operand registers of another pipeline




#### Performance Optimization - Scatter and Gather



SIMD operate on multiple pieces of data at the same time, in parallel

The idea is to find a way to "gather" data from far-flung locations, work with them as a **single vector**, and then, if desired, take the results and "scatter" them back out into their original far-flung locations.



What if you want to be able to do is exactly that same thing, but without the requirement that addresses be contiguous?



### Performance Optimization - Scatter and Gather


- Retrieves data elements scattered throughout memory and packs them into sequential vectors in vector registers
  - Promotes data locality and reduces data pollution
  - Use indirection (index vectors) to combine elements into vector registers
  - A gather operation takes an index vector and fetches the vector whose elements are at the addresses given by adding a base address to the offsets given in the index vector.
  - After these elements are operated on in a dense form, the sparse vector can be stored in an expanded form by a scatter store, using the same index vector.

Want to vectorize loops with indirect accesses:

```
for (i=0; i<N; i++)
A[i] = B[i] + C[D[i]]
```

Indexed load instruction (*Gather*)

```
LV vD, rD  # Load indices in D vector
LVI vC, rC, vD  # Load indirect from rC base
LV vB, rB  # Load B vector
ADDV.D vA,vB,vC  # Do add
SV vA, rA  # Store result
```





### **Performance Optimization – Strip Mining**

- What if # data elements > # elements in a vector register?
  - Need to break loops so that each iteration operates on # elements in a vector register
    - E.g., 527 data elements, 64-element VREGs
    - 8 iterations where Vector length = 64
    - 1 iteration where length = 15 (need to change value of vector length)
  - Strip Mining (used in compilers)

Generates code to allow vector operands whose size is less than or greater than size

of vector registers

```
i = 0;
VL = n mod MVL;
for (j=0; j<n/MVL; j++) {
    for(i<VL; i++)
        {Y(i)=a*X(i)+Y(i)}
      VL = MVL;
}
```

### **Performance Optimization – Masked Operations**

What if some operations should not be executed on a vector?

```
loop: if (a[i] != 0) then b[i]=a[i]*b[i]
goto loop
This loop cannot normally be vectorized because of the conditional execution of the body; however, if the inner loop could be run for the iterations for which a[i] != 0
```

- Idea: Masked operations
  - VMASK register is a bit mask determining which data element should not be acted upon



# **Another Example with Masking**

Α	В	VMASK	
1	2	0	
2	2	1	
3	2	1	
4	10	0	
-5	-4	0	
0	-3	1	
6	5	1	
-7	-8	1	

Steps to execute loop

- 1. Compare A, B to get VMASK
- Masked store of A into C
- 3. Complement VMASK
- 4. Masked store of B into C




#### **Masked Vector Instructions**

#### Simple Implementation

 execute all N operations, turn off result writeback according to mask


#### Density-Time Implementation

 scan mask vector and only execute elements with non-zero masks



### **Vector Instruction Level Parallelism**

- Can overlap execution of multiple vector instructions
  - example machine has 32 elements per vector register and 8 lanes
  - Complete 24 operations/cycle while issuing 1 short instruction/cycle





## Other Performance Optimizations


- Increase Memory Bandwidth
  - Memory banks are used to reduce load/store latency
  - Allow multiple simultaneous outstanding memory requests
- Multiple Parallel Lanes, or Pipes
  - Allows vector operation to be performed in parallel on multiple elements of the vector



#### **Packed SIMD Extensions**

64b							
32b			32b				
16	5b	16	5b	16	5b	16	5b
8b	8b	8b	8b	8b	8b	8b	8b

- Short vectors added to existing microprocessors ISAs, for multimedia
- Use existing 64-bit registers split into 2x32b or 4x16b or 8x8b
  - Lincoln Labs TX-2 from 1957 had 36b datapath split into 2x18b or 4x9b
  - Newer designs have wider registers
    - 128b for PowerPC Altivec, Intel SSE2/3/4
    - 256b for Intel AVX
- Single instruction operates on all elements within register



#### **SIMD Extensions**

- Media applications operate on data types narrower than the native word size
  - Example: disconnect carry chains to "partition" adder
- Limitations, compared to vector instructions:
  - Number of data operands encoded into op code
  - No sophisticated addressing modes (strided, scatter-gather)
  - No mask registers

Instruction category	Operands
Unsigned add/subtract	Thirty-two 8-bit, sixteen 16-bit, eight 32-bit, or four 64-bit
Maximum/minimum	Thirty-two 8-bit, sixteen 16-bit, eight 32-bit, or four 64-bit
Average	Thirty-two 8-bit, sixteen 16-bit, eight 32-bit, or four 64-bit
Shift right/left	Thirty-two 8-bit, sixteen 16-bit, eight 32-bit, or four 64-bit
Floating point	Sixteen 16-bit, eight 32-bit, four 64-bit, or two 128-bit



## SIMD Challenges

- Larger registers and functional units use more chip area and power
- Difficult to parallelize some algorithms (Amdahl's Law)
- Parallelization requires explicit instructions from the programmer or compiler

# Today's SIMD

- SIMD functionality is sometimes embedded in sequential machines.
- Others are being build as part of hybrid architectures.
- Some SIMD and SIMD-like features are included in some multi/many core processing units
- Some SIMD-like architectures have been build as special purpose machines, although some of these could classify as general purpose.
  - Some of this work has been proprietary.
  - The fact that a parallel computer is SIMD or SIMD-like is often not advertised by the company building them.



# Where are we Heading?

T6: GPUs

# Acknowledgement

Slides in this topic are inspired in part by material developed and copyright by:

- ARM Courseware
- Prof. Eric Welch & James Evans @ RIT
- Prof. Mikko H. Lipasti @ U of Wisconsin Madison
- Prof. Joe Devietti @ Upenn, CIS 571
- Prof. Ron Dreslinski @ UMich, EECS 470
- Prof. Hakim Weatherspoon @ Cornell, CS 3410
- Prof. Krste Asanovic @ UCB, CS252
- Xinfei Guo @ JI, VE370 2021 SU



### **Action Items**

- Reading Materials
  - Ch. 4.1 4.3