# SMART GRIDS: FROM TRADITIONAL TO MODERNIZED RESILIENT SYSTEMS

Víctor Escala García

Josep Fanals Batllori

Pol Heredia Julbe

Roger Izquierdo Toro

Palina Nicolas

# SMART GRIDS

Master's degree in Energy Engineering

Master's degree in Electric Power Systems and Drives



# CONTENTS

1	Introduction								
2	Phase 1								
	2.1	Operating costs	6						
	2.2	Problem identification	7						
	2.3	Solution suggestion	8						
3	ase 2	9							
	3.1	Addition of lines	9						
		3.1.1 Formulation	9						
		3.1.2 Results	11						
	3.2	Rising the voltage level	11						
		3.2.1 Description	11						
		3.2.2 Results	11						
4 Code									
Bibliography									

# 1. INTRODUCTION

## 2. PHASE 1

A system such as the one displayed in Figure 1 is analyzed. The network operates at the transmission level and feds dispersed demand points that symbolyze distribution grids. The grid has an interconnection with a transmission grid, and at the same time, some power is provided by the nuclear power plant. Initially, there are no renewable power plants nor storage systems, which compromises the security of the grid.




Figure 1. Overview of the network

The first step to analyze the system is to know the demand and the generation profile. In order to model them, the hourly demand and generation data of Spain have been collected [1]. To obtain a typical working day, a statistical analysis has been performed taking into account only the days from the 1st of January to the 31st of March, from Tuesday to Thursday and removing the national holidays. The result then has been normalized. analyze the system is This way, the consumption profile is obtained by from the product of the normalized demand and the peak power consumption of 375 MW for load type I and 140 MW for type II. For the generation profile, for simplicity, it has been assumed that the nuclear power plant follows the demand curve, i.e., it is not acting as a constant generator.

Bus Hour	1	2	3	4	5	6	8	9	10	11	12
0	1.050	0.963	0.989	0.972	0.937	1.000	1.031	0.986	1.000	0.984	0.950
1	1.050	0.974	0.998	0.982	0.952	1.000	1.035	0.995	1.008	0.993	0.963
2	1.050	0.981	1.003	0.988	0.961	1.000	1.037	1.001	1.013	0.998	0.972
3	1.050	0.984	1.005	0.990	0.965	1.000	1.038	1.003	1.015	1.000	0.975
4	1.050	0.985	1.006	0.991	0.966	1.000	1.038	1.004	1.015	1.001	0.976
5	1.050	0.981	1.003	0.988	0.961	1.000	1.037	1.001	1.013	0.998	0.972
6	1.050	0.967	0.992	0.975	0.942	1.000	1.032	0.989	1.003	0.987	0.955
7	1.050	0.938	0.969	0.950	0.905	1.000	1.022	0.965	0.983	0.964	0.920
8	1.050	0.915	0.952	0.931	0.876	1.000	1.014	0.947	0.967	0.946	0.893
9	1.050	0.904	0.944	0.921	0.862	1.000	1.010	0.938	0.960	0.938	0.880
10	1.050	0.900	0.941	0.918	0.856	1.000	1.009	0.935	0.957	0.935	0.875
11	1.050	0.901	0.941	0.919	0.857	1.000	1.009	0.936	0.958	0.935	0.876
12	1.050	0.904	0.944	0.921	0.861	1.000	1.010	0.938	0.960	0.938	0.879
13	1.050	0.906	0.945	0.923	0.864	1.000	1.011	0.939	0.961	0.939	0.882
14	1.050	0.916	0.953	0.931	0.877	1.000	1.014	0.948	0.968	0.947	0.894
15	1.050	0.922	0.957	0.936	0.884	1.000	1.016	0.953	0.972	0.952	0.901
16	1.050	0.925	0.960	0.939	0.889	1.000	1.018	0.955	0.974	0.954	0.905
17	1.050	0.926	0.961	0.940	0.890	1.000	1.018	0.956	0.975	0.955	0.906
18	1.050	0.921	0.957	0.936	0.884	1.000	1.016	0.952	0.972	0.951	0.900
19	1.050	0.903	0.943	0.920	0.860	1.000	1.010	0.937	0.959	0.937	0.878
20	1.050	0.891	0.933	0.910	0.844	1.000	1.005	0.927	0.950	0.927	0.863
21	1.050	0.897	0.939	0.915	0.853	1.000	1.008	0.933	0.955	0.932	0.871
22	1.050	0.921	0.957	0.936	0.884	1.000	1.016	0.952	0.972	0.951	0.900
23	1.050	0.946	0.975	0.957	0.915	1.000	1.025	0.972	0.988	0.970	0.929

Table 1. Voltage profile, in pu, for 24 hours




Figure 2. Voltage profile during 24 hours for the initial grid. The low-voltage buses are plotted in solid lines; the high-voltage ones are in dashed lines.

Load Hour	8-10	10-9	9-11	9-12	11-6
0	26.423	19.999	9.388	30.774	63.562
1	24.385	18.464	8.850	28.312	59.190
2	23.089	17.491	8.517	26.761	56.451
3	22.549	17.087	8.381	26.117	55.319
4	22.458	17.019	8.358	26.009	55.130
5	23.082	17.486	8.515	26.752	56.435
6	25.729	19.475	9.203	29.932	62.065
7	30.615	23.176	10.549	35.928	72.752
8	34.100	25.846	11.559	40.331	80.765
9	35.690	27.073	12.031	42.383	84.443
10	36.296	27.542	12.213	43.173	85.847
11	36.166	27.441	12.174	43.002	85.544
12	35.740	27.111	12.046	42.448	84.558
13	35.480	26.910	11.969	42.110	83.956
14	33.997	25.766	11.528	40.198	80.526
15	33.090	25.069	11.262	39.042	78.435
16	32.569	24.669	11.110	38.381	77.234
17	32.392	24.534	11.059	38.158	76.828
18	33.187	25.143	11.290	39.165	78.657
19	35.865	27.208	12.084	42.610	84.847
20	37.641	28.588	12.620	44.945	88.969
21	36.689	27.847	12.332	43.688	86.759
22	33.143	25.110	11.278	39.109	78.557
23	29.319	22.190	10.183	34.319	69.877

Table 2. Percentual loading of the lines for a full day operation



Figure 3. Representation of the percentual loading of the lines during 24 hours

#### 2.1. Operating costs

Regarding the operating costs, some estimations are made in order to asses the influence of importing energy and the impact of faults on lines and transformers.

First, the cost of importing energy depends on the time zone: valley, flat or peak. The analysis that follows considers a working day, which is precisely the date for which the voltages and loading profiles have been shown in Figures 2 and 3 respectively. The cost of importing the energy is mathematically expressed as:

$$C_{imp} = \sum_{k=1}^{n=24} P_{s,k} c(k), \tag{1}$$

where  $C_{imp}$  stands for the cost of importing energy for a full day, k denotes the index of a given hour, n the total number of hours in a day,  $P_{s,k}$  the energy provided by the slack bus (interconnection point) in MWh at hour k, and c(k) the cost at a certain hour in  $\epsilon$ /MWh. This last term is equal to  $45 \epsilon$ /MWh from 0 to 8 hours,  $65 \epsilon$ /MWh from 8 to 10, 14 to 18 and 22 to 24 hours, and  $90 \epsilon$ /MWh from 10 to 14 and 18 to 22 hours.

Equation 1 can be treated as a weighting sum. With the generation data obtained from the timeseries power flow, the total importing cost of importing energy becomes 418753.03 €/day, or about 152.84 M€ in a full year. It is important to note that the study related to the cost of importing energy is decoupled from the fault analysis. This is not a hundred percent realistic, because it could be that a switch trips and hence a line or a transformer are disconnected. Then, it could happen that the interconnection has to provide more power. However, since the probabilities are extremely low, they are discarded when computing this cost.

On the other hand, there are the costs due to faults in transformers or lines. About 0.05 failures per km and year are expected in lines, while transformers are meant to fail 0.15 times a year. The penalty for not providing energy is  $180 \in /MWh$ . Given that the length of the lines has an impact on its probability of failure, Table 3 shows the length and the subsequent failures per year.

Line	Length (km)	Failures/year
8-10	100.00	5.00
10-9	50.00	2.50
9-11	70.71	3.54
9-12	111.80	5.59
11-6	111.80	5.59

Table 3. Length and failures per year of all active lines

Figure 3 shows that the line connected to the interconnection point operates at a high load. It is critical to note that if line 8-10 fails, the slack should provide all power, but this would result in exceeding the thermal capacity of the line. Thus, if line 8-10 fails, no power can reach the loads.

In the case of line failures, there is a total disconnection time of 2.5 hours; instead, for transformers it is 8 hours. The expected time that an element will be disconnected in a year is found by multiplying the aforementioned disconnection time by the number of failures that take place during a year. Table 4 displays the yearly disconnection time and explains the consequences spotted by

Element	Disconnection time (h)	Consequences
Line 8-10	12.50	No load served - divergence
		_
Line $9-10$	6.25	No load served - divergence
Line 9-11	8.85	Loads at buses 2, 3 and 5 unserved
Line 9-12	13.98	Load at bus 5 unserved
Line 11-6	13.98	No load served
Trafo 1-8	1.20	No load served - divergence
Trafo 2-9	1.20	Load at bus 2 unserved
Trafo 3-10	1.20	Load at bus 3 unserved
Trafo 4-11	1.20	Load at bus 4 unserved
Trafo 5-12	1.20	Load at bus 5 unserved

running the power flow. This will allow to estimate the penalties due disconnection.

Table 4. Disconnection time and consequences of losing each element

Once the unserved loads and the associated disconnection times are known, the next step has to do with applying the penalty as follows:

$$C_{discon} \approx \sum_{i=1}^{10} \overline{P}_{uns,i} t_{discon,i} C_p, \tag{2}$$

where  $C_{discon}$  is the total disconnection cost, i represents the index of the line or transformer with a total of 10 elements prone to be disconnected (see Table 4),  $\overline{P}_{uns,i}$  is the mean unserved power,  $t_{discon,i}$  the disconnection time, and  $C_p$  the penalty cost to apply. Equation 2 is an approximation in the sense that the unserved power varies according to the time of the day. To not overcomplicate the problem, it has been decided to pick a representative value such as the average.

The application of Equation 2 yields a total yearly penalty cost of  $4.99 \text{ M} \in$ . For the most part, it is due to the disconnection of lines. Meshing more the system would decrease this cost, but on the other side, it would increase the investment cost. Hence, there is a trade-off between cost and reliability.

All the calculations related to costs have not set an inferior limit to the voltages. However, some of them are likely to be unacceptable in reality. The project will proceed to discuss solutions to this issue in the following phases.

### 2.2. Problem identification

The network modeled presents some serious issues. First, in case of fault, the demand cannot be covered. The network is a ramified line but does not have any interconnection within the system. If a fault occurs, the two branches are not connected and have to support the demand of the remaining part on its own. In the case of the nuclear power plant, it cannot produce enough energy to fulfill all the demand and in the case of the interconnection, if it was to cover all, it would be overloaded.

This leads to the second problem the network faces, there is a risk of overloading. This may happen in case or fault or if the the nuclear power plant shuts down because there is no other source of generation. This could lead to burning hence security and material damage issue. A third drawback is the high impact of the interruptions. As many line are single lines and there are

no multiple connections, only ramifications, a fault has a high chance to directly disconnect the network. Finally, the voltage cannot be kept constant enough. It is usually accepted to fluctuate 10% around the nominal 1 p.u. while in the current transmission network, the voltage reaches almost 0.8 p.u..

#### 2.3. Solution suggestion

As some of the lines present some overloading and demand coverage problems, we suggest improving lines to better ones which are able to transport more power. In order to do so, the critical lines could be changed from single to double lines and/or even change the conductors to thicker cables which allow a larger amount of power flow. Another approach would be to add more lines to the grid to overcome the demand coverage but we must also be aware that when adding new lines to the system we are also increasing the possibility of line failures which may affect interruptibility and cause economic losses to the system.

On the other hand, adding generation points to the system would also help overcome the stated problems in the previous point. If power is more accessible in different locations, the demand can be fulfilled from various points without saturating the most critical lines while evenly distributing the generation. Finally, another solution could be to change the 220 kV existing lines to 400 kV ones in order to allow these to transport higher amounts of power. With this change, only the amount of power transported would be around three times higher than the current one. However, it has to be taken into account that there would have to be an additional transformer to adapt the 220 kV from the interconnection to 400 kV, and the rest of the transformers would have to be replaced to match nominal voltages.

#### 3. PHASE 2

This chapter considers upgrading the system by means of installing additional lines. In the previous analysis, it was visible that the disconnection of specific lines resulted in an unsolvable problem. Often, no solution was obtained as a result of an exceedingly high demand compared to the available generation. The criteria N-1 was therefore not met, yet it is usually treated as a requirement by control center operators [2], [3].

The central aim of this chapter is reaching a robust grid, where a single failure does not compromise the full system. Several solutions were proposed, such as meshing the network, rising the voltage level, etc. This chapter is devoted to exploring the implications of such proposals. First, a more theoretical explanation describing the formulation is presented, and then, the analysis of results takes place. These results include electrical magnitudes as well as economic data. An optimal configuration is finally provided.

#### 3.1. Addition of lines

Recall that the original system depicted in Figure 1 was for the most part a radial system, in the sense that there was no redundancy in the connection of lines. The operating costs are non-negligible since a significant amount of energy cannot be delivered during faults. To combat this issue, the installation of various new lines (in red) is contemplated, as shown in Figure 4.

By installing new lines, an additional installation cost has to be considered, but a reduction on the operating costs is expected. It is worth worth mentioning that not all contemplated new lines ought to be installed. Rather, by adding one or two of them, the system could already be operating under the desired conditions. There is a cost-benefit tradeoff, so only a few specific new lines will be selected.

#### 3.1.1. Formulation

The formulation of the topology deserves special attention. Mathematically, it is defined as:

$$\{\mathcal{N} \in \mathcal{P}([n]) \mid |\mathcal{N}| = k\},\tag{3}$$

where  $\mathcal{N}$  denotes a subset, that is, possible topology out of the full set of configurations  $\mathcal{P}([n])$ ,  $[n] = \{\mathbf{1}_{\sigma_1}, \mathbf{1}_{\sigma_2}, ..., \mathbf{1}_{\sigma_n}\}$  represents the set of elements that cause variations on the topology, and k symbolizes the total amount of possibilities. In the contingency analysis, the set [n] is a function of the state of the elements (mainly, lines). These can be in service or out of service, so can be regarded as boolean variables. The employed notation, of the form  $\mathbf{1}_{\sigma_i}$ , is 1 if the indicator variable  $\sigma_i$  holds true; otherwise, it is 0. The indicator variable, in the case under study, is simply the state of each particular line.

Note that the whole set  $\mathcal{P}$  can be further divided into the set composed of the original lines  $\mathcal{A}$ , and the set of new lines  $\mathcal{B}$ . Let j indicate the number of lines in the original set  $\mathcal{A}$ , and n-j the amount of lines in the new set  $\mathcal{B}$ . In the particularized case shown in Figure 4, j=6 and n-j=8.




Figure 4. Overview of the network with the addition of lines

Thus, these subsets are expanded and explicitly become:

$$\begin{cases} \mathcal{A} = \{\mathbf{1}_{\sigma_1}, \mathbf{1}_{\sigma_2}, ..., \mathbf{1}_{\sigma_j}\}, \\ \mathcal{B} = \{\mathbf{1}_{\sigma_{j+1}}, \mathbf{1}_{\sigma_{j+2}}, ..., \mathbf{1}_{\sigma_n}\}. \end{cases}$$
(4)

To perform the contingency analysis, we consider that one of the original lines if faulted. For instance, if line i ends up disconnected,  $\sigma_i \leftarrow \texttt{false}$  while the rest of original lines  $\sigma_r \leftarrow \texttt{true}$  for  $r = \{1, 2, ..., i-1, i+1, ..., j\}$ .

On the other hand, in the subset  $\mathcal{B}$  it is not straightforward to estimate which lines should be connected or disconnected. Perhaps installing a single additional line is enough to meet the N-1 criteria, or maybe more lines are required. Hence, it has been decided that all permutations have to be analyzed. Since  $\sigma$  are boolean variables, the total number k of contingencies to simulate are:

$$k = j2^{(n-j)},\tag{5}$$

so if j = 6 and n - j = 8, this results in k = 1536 different topologies. Thus, a total of 1536 timeseries power flows are computed.

Security analysis in power systems has been traditionally based on the usage of the DC power flow [4], [5]. It offers the advantage of being non-iterative (and consequently, fast), and allows to determine the influence of faults with the usage of transmission factors. However, its solution is

just an approximation. Since the amount of situations remains reasonable, it has been decided to solve them with the typical Newton-Raphson up to the default precision of  $1 \cdot 10^{-8}$  MVA [6].

The general procedure to perform the contingency analysis is shown in Algorithm 1.

# Algorithm 1: Pseudocode to solve the contingencies

```
Input: net initialized class, j, n
      Output: stored results
 1 Generate permutations \forall \boldsymbol{\sigma}_q where g = [1, 2, ..., 2^{(n-j)}]
 2 for i = [1, 2, ..., j] do
             \sigma_i \leftarrow \mathtt{false}
             \sigma_r \leftarrow \mathsf{true}, where r \neq i and r \leq j
             \mathcal{A} \leftarrow \{\mathbf{1}_{\sigma_1}, \mathbf{1}_{\sigma_2}, ..., \mathbf{1}_{\sigma_j}\}
             for g=\left[1,2,...,2^{\left(n-j\right)}\right] do
 6
                    [\sigma_{j+1}, \sigma_{j+2}, ..., \sigma_n] \leftarrow \boldsymbol{\sigma}_g
                    \mathcal{B} \leftarrow \{\mathbf{1}_{\sigma_{j+1}}, \mathbf{1}_{\sigma_{j+2}}, ..., \mathbf{1}_{\sigma_n}\}
\mathcal{N} \leftarrow \mathcal{A} \cup \mathcal{B}
 8
 9
                    pandapower.timeseries.run_timeseries(\mathcal{N},net)
10
                    Store results
```

## 3.1.2. Results

# 3.2. Rising the voltage level

# 3.2.1. Description

# 3.2.2. Results

#### 4. CODE

```
1 import pandapower as pp
2 import pandas as pd
3 import numpy as np
 4 \quad {\tt import \ pandapower.control \ as \ control}
5\, import pandapower.networks as nw
 6\, import pandapower.timeseries as timeseries
7 \quad {\tt from \ pandapower.timeseries.data\_sources.frame\_data \ import \ DFData}
8 from pandapower.plotting import simple_plot
10 from line_param_calc import calc_line
11
12
13
14 pd.set_option('display.max_rows', 500)
15 \  \, {\tt pd.set\_option('display.max\_columns', 500)}
16 pd.set_option('display.width', 1000)
18 \ \mathsf{def} \ \mathsf{initialize\_net(path\_bus,\ path\_geodata,\ path\_line,\ path\_demand,\ path\_busload,\ path\_generation}
        , path_busgen, path_trafo):
19
20
       initialize the grid from the .csv files
21
22
       :param path_bus: path to the bus .csv file
23
       :param geodata: path to the geodata .csv file
       :param path_line: path to the line .csv file
24
25
       :param path_demand: path to the normalized demand .csv file
26
       :param busload: path to the bus-load look up table .csv file
27
       :param path_generation: path to the normalized generation .csv file
28
       :param busgen: path to the bus-generator look up table .csv file
29
       :param trafo: path to the trafo .csv file
30
       :return: the net class
31
32
33
       def create_bus(path_bus, path_geodata):
34
35
            adapts the data from the bus file (if needed)
36
37
           :param path_bus:
           :param path_geodata:
39
            :return: the net with the buses added
40
41
42
           df_bus = pd.read_csv(path_bus)
43
           df_geodata = pd.read_csv(path_geodata)
44
45
           net.bus = df_bus
46
47
            # adapt geodata
48
           for 11 in range(len(df_geodata)):
49
                indx_bus = pp.get_element_index(net, "bus", df_geodata['name'][11])
50
                df_geodata['name'][11] = indx_bus
51
52
           net.bus_geodata = df_geodata
53
54
            return net
55
56
57
       def create_line(path_line):
58
59
            adapts the data from the line file
61
           :param path_line:
62
            :return: the net with the lines added
63
64
         df_line = pd.read_csv(path_line)
```

```
66
            for _, line in df_line.iterrows():
 67
                 from_bus = pp.get_element_index(net, "bus", line.from_bus)
 68
                to_bus = pp.get_element_index(net, "bus", line.to_bus)
 69
 70
                rr. xx. cc. imax = calc line(line.a.
 71
                                              line.b,
 72
                                              line.c.
 73
                                               line.d,
 74
                                              line.e.
 75
                                              line.max_i,
 76
                                              int(line.parallel))
 77
 78
                 pp.create_line_from_parameters(net,
                                                 from bus,
 80
                                                 to_bus,
 81
                                                 length km=line.length.
 82
                                                 r_ohm_per_km=rr,
 83
                                                 x_ohm_per_km=xx,
 84
                                                 c_nf_per_km=cc,
 85
                                                 max i ka=imax.
 86
                                                 name=line.name_1,
 87
                                                 parallel=line.parallel)
 89
            return net
 90
 91
 92
        def create_load(path_demand, path_busload, path_bus):
 93
 94
            adapts the load files
 95
 96
            :param path_demand:
 97
            :param path_busload:
 98
            :param path_bus:
 99
            :return: the net with the loads added
100
101
102
            df_demand = pd.read_csv(path_demand)
103
            df_busload = pd.read_csv(path_busload)
104
            df_bus = pd.read_csv(path_bus)
105
106
            # create basic load dataframe
107
            \mbox{\tt\#} find the bus index of each load
108
            load_indx = []
109
            for _, load in df_busload.iterrows():
110
                 bus_load = pp.get_element_index(net, "bus", load.bus)
111
                load_indx.append(bus_load)
112
113
            load_indx = pd.DataFrame(load_indx)
114
            load_indx = load_indx.rename(columns={0: "bus"})
115
116
            # load name and peak power
117
            load_name = df_busload['bus']
118
            load_pmw = df_busload['p_mw']
119
            load_gmvar = df_busload['q_mvar']
120
121
            # merge in a full dataframe
122
            headers = ["name", "bus", "p_mw", "q_mvar"]
            df_load = pd.concat([load_name, load_indx, load_pmw, load_qmvar], axis=1)
123
124
            df_load.columns.values[0] = "name"
125
126
            # create time series from the basic load df
127
            Nt = len(df_demand)
            N1 = len(df_load)
128
129
            pmw_ts = np.zeros((Nt, N1), dtype=float)
130
            qmvar_ts = np.zeros((Nt, N1), dtype=float)
131
            for i in range(Nt): # number of time periods
132
               pmw_ts[i,:] = df_load['p_mw'][:] * df_demand['norm'][i]
```

```
133
                                          qmvar_ts[i,:] = df_load['q_mvar'][:] * df_demand['norm'][i]
134
135
                               # form loads as a static picture (initial time)
136
                               for ll in range(len(df_busload)):
137
                                         pp.create_load(net, bus=load_indx['bus'][11], p_mw=pmw_ts[0, 11], q_mvar=qmvar_ts[0,
                          11], name=load_name[11], index=int(11))
138
139
140
                               df_pload_ts = pd.DataFrame(pmw_ts, index=list(range(Nt)), columns=net.load.index)
141
                               df_qload_ts = pd.DataFrame(qmvar_ts, index=list(range(Nt)), columns=net.load.index)
142
                                ds_pload_ts = DFData(df_pload_ts)
143
                               ds_qload_ts = DFData(df_qload_ts)
                               const_load = control.ConstControl(net, element='load', element_index=net.load.index,
144
                        variable='p_mw', data_source=ds_pload_ts, profile_name=net.load.index)
145
                              const_load = control.ConstControl(net, element='load', element_index=net.load.index,
                        variable='q_mvar', data_source=ds_qload_ts, profile_name=net.load.index) # add the
                        reactive like this?
146
147
                               return net
148
149
150
                     def create_generator(path_generation, path_busgen, path_bus):
151
152
                                adapts the generation files
153
154
                                :param path_generation:
155
                                :param path_busgenerator:
156
                               :param path_bus:
157
                                :return: the net with the generators added
158
159
160
                               df_generation = pd.read_csv(path_generation)
161
                                df_busgen = pd.read_csv(path_busgen)
162
                               df_bus = pd.read_csv(path_bus)
163
164
                               # create basic generator dataframe
165
                                # find the bus index of each gen
166
                                gen_indx = []
167
                                for _, gen in df_busgen.iterrows():
168
                                          bus_gen = pp.get_element_index(net, "bus", gen.bus)
169
                                          gen_indx.append(bus_gen)
170
171
                                gen_indx = pd.DataFrame(gen_indx)
172
                                gen_indx = gen_indx.rename(columns={0: "bus"})
173
174
                                # load name and peak power
175
                                gen_name = df_busgen['bus']
176
                                gen_pmw = df_busgen['p_mw']
                                gen_vpu = df_busgen['vm_pu']
177
178
179
                               # merge in a full dataframe
180
                                headers = ["name", "bus", "p_mw", "vm_pu"]
181
                                df_gen = pd.concat([gen_name, gen_indx, gen_pmw, gen_vpu], axis=1)
182
                               df_gen.columns.values[0] = "name"
183
184
                               # create time series from the basic load df
185
                                Nt = len(df_generation)
186
                               Ng = len(df_gen)
187
                               pmw_ts = np.zeros((Nt, Ng), dtype=float)
188
                               for i in range(Nt): # number of time periods % \left( \frac{1}{2}\right) =\frac{1}{2}\left( \frac{1}{2}\right) +\frac{1}{2}\left( \frac{1}{2}\right) +\frac{1}{2}\left(
                                          pmw_ts[i,:] = df_gen['p_mw'][:] * df_generation['norm'][i]
189
190
191
                                # gen structure for 1 t
102
                                for ll in range(len(df_busgen)):
193
                                          pp.create_gen(net, bus=gen_indx['bus'][11], p_mw=pmw_ts[0, 11], vm_pu=gen_vpu[11],
                        name=gen_name[11], index=int(11))
194
```

```
195
196
             # timeseries
197
            df_gen_ts = pd.DataFrame(pmw_ts, index=list(range(Nt)), columns=net.gen.index)
ds_gen_ts = DFData(df_gen_ts)
198
            const_gen = control.ConstControl(net, element='gen', element_index=net.gen.index,
199
         variable='p_mw', data_source=ds_gen_ts, profile_name=net.gen.index)
200
201
             return net
202
203
204
        def create_intercon(path_bus):
205
206
             defines the interconnection (slack bus)
207
208
            :param path_bus:
209
             :return: the net with the interconnection added
210
211
212
            df_bus = pd.read_csv(path_bus)
213
214
             # find the slack index
215
             slack_indx = 0
216
            for ll in range(len(df_bus)):
217
                 # slack_indx = pp.get_element_index(net, "bus", bb.name)
                 if df_bus['name'][11] == 'intercon':
218
219
                     slack_indx = pp.get_element_index(net, "bus", df_bus['name'][11])
220
221
            pp.create_ext_grid(net, slack_indx, vm_pu=1.0, va_degree=0)
222
223
224
225
226
        def create_trafo(path_trafo):
227
228
             defines the transformers
229
230
            :param path_trafo:
231
             :return: the net with the transformers {\tt added}
232
233
234
            df_trafo = pd.read_csv(path_trafo)
235
236
             # for trafo in df_trafo:
237
             for _, trafo in df_trafo.iterrows():
238
                 hv_bus = pp.get_element_index(net, "bus", trafo.hv_bus)
239
                lv_bus = pp.get_element_index(net, "bus", trafo.lv_bus)
240
241
                 pp.create_transformer_from_parameters(net,
242
243
                                                         lv_bus,
244
                                                         trafo.sn_mva,
245
                                                         trafo.vn_hv_kv,
246
                                                         trafo.vn_lv_kv,
247
                                                         trafo.vkr_percent,
248
                                                         trafo.vk_percent,
249
                                                         trafo.pfe_kw,
250
                                                         trafo.i0_percent)
251
252
            return net
253
254
255
256
257
258
259
        # create empty network
260
        net = pp.create_empty_network()
```

```
261
262
        # buses
263
        net = create_bus(path_bus, path_geodata)
264
265
        # lines
266
        net = create_line(path_line)
267
268
269
        net = create_load(path_demand, path_busload, path_bus)
270
271
        # gens
272
        net = create_generator(path_generation, path_busgen, path_bus)
273
274
        # interconnection
275
        net = create_intercon(path_bus)
276
277
278
        net = create_trafo(path_trafo)
279
280
281
282
        return net
283
284
285 if __name__ == "__main__":
286
        # load paths
287
        path_bus = 'Datafiles/bus1.csv'
288
        path_geodata = 'Datafiles/geodata1.csv'
289
        path_line = 'Datafiles/line1.csv'
290
        path_demand = 'Datafiles/demand1.csv'
291
        path_busload = 'Datafiles/bus_load1.csv'
292
        path_generation = 'Datafiles/generation1.csv'
293
        path_busgen = 'Datafiles/bus_gen1.csv'
294
        path_trafo = 'Datafiles/trafo1.csv'
295
296
        # define net
297
        net = initialize_net(path_bus, path_geodata, path_line, path_demand, path_busload,
        path_generation, path_busgen, path_trafo)
298
299
        # run timeseries
300
        ow = timeseries.OutputWriter(net, output_path="./Results/", output_file_type=".xlsx")
301
        ow.log_variable('res_bus', 'vm_pu')
302
        ow.log_variable('res_line', 'loading_percent')
303
        timeseries.run_timeseries(net)
304
305
        # run diagnostic
306
        # pp.diagnostic(net)
307
        print(net.bus)
308
309
        # plot
310
        # pp.plotting.simple_plot(net)
311
        # simple_plot(net)
```

Listing 4.1. Main code in Python with the Pandapower library

```
1 import numpy as np
3 def calc_line(a, b, c, d, e, immax, npar, Rca, Dext, kgg):
4
5
       calculate r, x, c, and return also Imax
6
      :param a: horizontal distance between A1 and C2
7
8
      :param b: horizontal distance between B1 and B2
9
      :param c: horizontal distance between C1 and A2
10
       :param d: vertical distance between A1 and B1
11
       :param e: vertical distance between B1 and C1
12 :param immax: max current in A
```

```
13
       :param npar: number of parallel lines (1 or 2)
14
       :param Rca: ac resistance in ohm/km
15
       :param Dext: external diameter in mm
16
       :param kg: factor of roughly 0.8
17
       :return: r, x, c, imax
18
19
20
        def single_line(a, b, immax, Rca, Dext, kgg):
21
22
           calculate the R, X, C parameters, also return Imax
23
24
           :param a: horizontal distance between A and C
            :param b: vertical distance between A and B
25
26
           :param immax: max current in A
27
           :param Rca: ac resistance in ohm/km
28
           :param Dext: external diameter in mm
29
           :param kg: factor of roughly 0.8
30
31
            :return: R, X, C, Imax, in the units desired by pandapower
32
33
           # cardinal: https://www.elandcables.com/media/38193/acsr-astm-b-aluminium-conductor-
34
        steel-reinforced.pdf
35
           # 54 Al + 7 St, Imax = 888.98 A
36
37
           w = 2 * np.pi * 50 # rad / s
38
           Imax = immax * 1e-3 # kA
39
           \# Stot = 547.3 * 1e-6 \# m2, the total section
40
            \# R_ac_75 = 0.07316 * 1e-3 # ohm / m
41
           \# kg = 0.809 \# from the slides in a 54 + 7
42
           R_ac_75 = Rca * 1e-3 # ohm / m, should we correct by temperatures?
43
           Stot = np.pi * Dext ** 2 / 4 * 1e-6 # m2, the total section
44
45
           kg = kgg
46
47
           r = np.sqrt(Stot / np.pi) # considering the total section
48
49
           dab = np.sqrt((a / 2) ** 2 + b ** 2)
50
           dbc = np.sqrt((a / 2) ** 2 + b ** 2)
           dca = a
51
52
53
           GMD = (dab * dbc * dca) ** (1 / 3)
           GMR = kg * r
54
           RMG = r
55
56
57
           L = 4 * np.pi * 1e-7 / (2 * np.pi) * np.log(GMD / GMR) # H / m
58
59
           C = 2 * np.pi * 1e-9 / (36 * np.pi) / np.log(GMD / RMG) # F / m
60
61
            # in the units pandapower wants
62
           R_km = R_ac_75 * 1e3 # ohm / km
           X_{km} = L * w * 1e3 # ohm / km
63
            C_{km} = C * 1e9 * 1e3 # nF / km
64
66
           return R_km, X_km, C_km, Imax
67
68
69
       def double_line(a, b, c, d, e, immax, Rca, Dext, kgg):
70
71
            calculate the R, X, C parameters, also return Imax
72
73
           :param a: horizontal distance between A1 and C2
74
           :param b: horizontal distance between B1 and B2
75
           :param c: horizontal distance between C1 and A2
76
           :param d: vertical distance between A1 and B1
77
            :param e: vertical distance between B1 and C1
           :param immax: max current in A
78
```

```
79
            :param Rca: ac resistance in ohm/km
 80
            :param Dext: external diameter in mm
 81
            :param kgg: factor of roughly 0.8
 82
            :return: R, X, C, Imax, in the units desired by pandapower
 83
 84
 85
            # cardinal: https://www.elandcables.com/media/38193/acsr-astm-b-aluminium-conductor-
         steel-reinforced.pdf
            # 54 Al + 7 St, Imax = 888.98 A
 86
 87
 88
            w = 2 * np.pi * 50 # rad / s
 89
            Imax = immax * 1e-3 * 2 \# kA, for the full line, x2
            \# Stot = 547.3 * 1e-6 \# m2, the total section
 90
 91
            \# R_ac_75 = 0.07316 * 1e-3 # ohm / m
 92
            \# kg = 0.809 \# from the slides in a 54 + 7
 93
 94
            R_ac_75 = Rca * 1e-3 # ohm / m, should we correct by temperatures?
 95
            Stot = np.pi * Dext ** 2 / 4 * 1e-6 # m2, the total section
 96
            kg = kgg
 97
 98
99
100
            r = np.sqrt(Stot / np.pi) # considering the total section
101
102
            da1b1 = np.sqrt((b / 2 - a / 2) ** 2 + d ** 2)
            da1b2 = np.sqrt((a / 2 + b / 2) ** 2 + d ** 2)
103
            da2b1 = np.sqrt((c / 2 + b / 2) ** 2 + e ** 2)
104
105
            da2b2 = np.sqrt((b / 2 - c / 2) ** 2 + e ** 2)
106
            db1c1 = np.sqrt((b / 2 - c / 2) ** 2 + e ** 2)
107
            db1c2 = np.sqrt((b / 2 + a / 2) ** 2 + d ** 2)
108
109
            db2c1 = np.sqrt((b / 2 + c / 2) ** 2 + e ** 2)
110
            db2c2 = np.sqrt((b / 2 - a / 2) ** 2 + d ** 2)
111
112
            dc1a1 = np.sqrt((a / 2 - c / 2) ** 2 + (d + e) ** 2)
113
            dc1a2 = c
114
            dc2a1 = a
115
            dc2a2 = np.sqrt((a / 2 - c / 2) ** 2 + (d + e) ** 2)
116
117
            dab = (da1b1 * da1b2 * da2b1 * da2b2) ** (1 / 4)
118
            dbc = (db1c1 * db1c2 * db2c1 * db2c2) ** (1 / 4)
119
            dca = (dc1a1 * dc1a2 * dc2a1 * dc2a2) ** (1 / 4)
120
121
            rp = kg * r
122
123
            da1a2 = np.sqrt((a / 2 + c / 2) ** 2 + (d + e) ** 2)
124
            db1b2 = b
125
            dc1c2 = np.sqrt((c / 2 + a / 2) ** 2 + (d + e) ** 2)
126
127
            drap = np.sqrt(rp * da1a2)
128
            drbp = np.sqrt(rp * db1b2)
129
            drcp = np.sqrt(rp * dc1c2)
130
131
            dra = np.sqrt(r * da1a2)
132
            drb = np.sqrt(r * db1b2)
133
            drc = np.sqrt(r * dc1c2)
134
135
            GMD = (dab * dbc * dca) ** (1 / 3)
136
            GMR = (drap * drbp * drcp) ** (1 / 3)
137
            RMG = (dra * drb * drc) ** (1 / 3)
138
139
            L = 4 * np.pi * 1e-7 / (2 * np.pi) * np.log(GMD / GMR) # H / m
140
141
            C = 2 * np.pi * 1e-9 / (36 * np.pi) / np.log(GMD / RMG) # F / m
142
143
            # in the units pandapower wants
            R_km = R_ac_75 / 2 * 1e3 # ohm / km, like 2 resistances in parallel
144
```

```
C_km = C * 1e9 * 1e3 # nF / km
146
147
148
          return R_km, X_km, C_km, Imax
149
150
       if npar == 1:
151
          rr, xx, cc, imm = single_line(a, b, immax, Rca, Dext, kgg)
152
       elif npar == 2:
153
         rr, xx, cc, imm = double_line(a, b, c, d, e, immax, Rca, Dext, kgg)
154
155
          print('Error: number of parallel lines is not 1 nor 2')
156
157
       return rr, xx, cc, imm
158
159 # rr, xx, cc, ii = double_line(11, 2, 4, 5, 6, 1000)
160 # print(rr, xx, cc, ii)
```

Listing 4.2. Code for the calculation of lines

#### **BIBLIOGRAPHY**

- [1] Red Eléctrica de España, Sistema de información del operador del sistema (esios). perfiles de demanda y generación. https://www.esios.ree.es/es?locale=en, Accessed: 2021-10-25.
- [2] Q. Wang and J. D. McCalley, "Risk and "n-1" criteria coordination for real-time operations," IEEE Transactions on Power Systems, vol. 28, no. 3, pp. 3505–3506, 2013.
- [3] A. Gourtani, H. Xu, D. Pozo, and T.-D. Nguyen, "Robust unit commitment with n-1 security criteria," *Mathematical Methods of Operations Research*, vol. 83, no. 3, pp. 373–408, 2016.
- [4] B. Stott, J. Jardim, and O. Alsaç, "Dc power flow revisited," *IEEE Transactions on Power Systems*, vol. 24, no. 3, pp. 1290–1300, 2009.
- [5] F. Capitanescu, J. M. Ramos, P. Panciatici, D. Kirschen, A. M. Marcolini, L. Platbrood, and L. Wehenkel, "State-of-the-art, challenges, and future trends in security constrained optimal power flow," *Electric Power Systems Research*, vol. 81, no. 8, pp. 1731–1741, 2011.
- [6] L. Thurner, A. Scheidler, F. Schafer, J. H. Menke, J. Dollichon, F. Meier, S. Meinecke, and M. Braun, "Pandapower - an open source python tool for convenient modeling, analysis and optimization of electric power systems," *IEEE Transactions on Power Systems*, 2018, ISSN: 0885-8950. DOI: 10.1109/TPWRS.2018.2829021. [Online]. Available: https://arxiv.org/abs/ 1709.06743.