Lesson 2

App.c

```
$ cat app.c
#include "uart.h"
unsigned char string_buffer [100] = " Learn In Depth : << Joseph Nader Sophy >> ";
unsigned char const string_buffer_2[100] = "to create ro data section";

void main(void)
{
uart_send_string(string_buffer);
}
```

Uart.c

Uart.h

```
$ cat uart.h

#ifndef _UART_H_

#define _UART_H_

void uart_send_string(unsigned char *p_tx_string);

!#endif
```

Sections

```
$ arm-none-eabi-objdump.exe -h app.o
            file format elf32-littlearm
app.o:
Sections:
Idx Name
                    Size
                                          LMA
                                                     File off
                               VMA
                                                                Algn
  0 .text
                    00000018
                               00000000 00000000
                                                     00000034
                    CONTENTS, ALLOC, LOAD, RELOC,
                                                     READONLY, CODE
                   CONTENTS,
00000064 00000000 000000
CONTENTS, ALLOC, LOAD, DATA
00000000 00000000 00000000
  1 .data
                                                     0000004c
  2 .bss
                                                                2**0
                                                     000000b0
  3 .rodata
                    00000064
                               00000000 00000000 000000ь0
                                                                2**2
                    CONTENTS, ALLOC, LOAD, READONLY, DATA
  4 .debug_info
                    00000083 00000000 00000000 00000114
                                                                2**0
                    CONTENTS, RELOC, READONLY, DEBUGGING
  5 .debug_abbrev 00000061
                                                                2**0
                               00000000 00000000 00000197
                    CONTENTS, READONLY, DEBUGGING
                    0000002c 00000000 00000000 000001f8
  6 .debug_loc
                                                                2**0
  CONTENTS, READONLY, DEBUGGING 7 .debug_aranges 00000020 00000000 00000000
                                                                 2**0
                                                     00000224
                    CONTENTS, RELOC, READONLY, DEBUGGING
  8 .debug_line
                    00000035
                              00000000 00000000 00000244
                                                                2**0
                    CONTENTS, RELOC, READONLY, DEBUGGING
  9 .debug_str
                              00000000
                                          00000000 00000279
                                                                2**0
                    000000b0
                    CONTENTS, READONLY,
00000012 00000000
                                          DEBUGGING
                                          00000000 00000329
                                                                2**0
 10 .comment
 CONTENTS, READONLY
11 .ARM.attributes 00000032 00000000 00000000 0000033b
                                                                  2**0
                    CONTENTS, READONLY
 12 .debug_frame
                    0000002c 00000000 00000000 00000370
                    CONTENTS, RELOC, READONLY, DEBUGGING
```

Diassemply file from bin

#arm-none-eabi-objdump.exe -D app.o > app.s

```
🔚 app.c 🗵 🔡 uart.h 🗵 🔚 uart.c 🗵 🔡 app.o 🗵 🔡 app.s 🗵
 1
 2
                  file format elf32-littlearm
       app.o:
  3
  4
  5
       Disassembly of section .text:
  6
  7
       000000000 <main>:
 8
          0:
              e92d4800
                           push
                                   {fp, lr}
 9
               e28db004
                           add fp, sp, #4
          4:
 10
          8:
               e59f0004
                           ldr r0, [pc, #4]
                                               ; 14 < main + 0x14 >
 11
               ebfffffe
                           bl 0 <uart_send_string>
          c:
 12
         10:
               e8bd8800
                           pop {fp, pc}
 13
         14:
                           andeq
                                  r0, r0, r0
 14
 15
       Disassembly of section .data:
 16
 17
       00000000 <string buffer>:
 18
             61654c20
                           cmnvs
                                   r5, r0, lsr #24
          0:
          4:
 19
              49206e72
                           stmdbmi r0!, {r1, r4, r5, r6, r9, s1, fp, sp, lr}
 20
                           strbvs r2, [r4, #-110]; 0x6e
          8:
             6544206e
 21
          c:
              20687470
                           rsbcs
                                   r7, r8, r0, ror r4
 22
         10:
               3c3c203a
                           ldccc
                                   0, cr2, [ip], #-232; 0xffffff18
 23
         14:
               736f4a20
                           cmnvc
                                   pc, #32, 20 ; 0x20000
 24
                                   r7, r8, r5, rrx
         18:
               20687065
                           rsbcs
 25
               6564614e
                           strbvs r6, [r4, #-334]!
         1c:
                                                      ; 0x14e
         20:
             6f532072
                                   0x00532072
 26
                           SVCVS
 27
         24:
              20796870
                           rsbscs r6, r9, r0, ror r8
 28
         28: 00203e3e
                           eoreq r3, r0, lr, lsr lr
 29
           . . .
 30
 31
       Disassembly of section .rodata:
 32
 33
       00000000 <string buffer 2>:
 34
                           tegvs r0, #116, 30 ; 0x1d0
          0: 63206f74
                           strbtvc r6, [r1], #-1394
          4:
               74616572
 36
          8:
               6f722065
                                  0x00722065
                           SVCVS
 37
          c:
               74616420
                           strbtvc r6, [r1], #-1056
                                                      ; 0x420
         10:
               65732061
                           ldrbvs r2, [r3, #-97]!; 0x61
```

Display the full content of all sections

```
NINGW64:/c/Users/hp/Desktop/Diploma_Repo/Masteering_In_Embeded_System/Unit_3_Embedded_C/Assignment_Lesson_2
                  MINGW64 ~/Desktop/Diploma_Repo/Masteering_In_Embeded_System/Unit_3_Embedded_C/As
   arm-none-eabi-objdump.exe -s app.o
app.o:
Contents of section .text:
0000 00482de9 04b08de2 04009fe5 feffffeb .H-......
0010 0088bde8 00000000
 0010 00880488 000000000
001ents of section .data:
0000 204c6561 726e2049 6e204465 70746820
0010 3a203c3c 204a6f73 65706820 4e616465 : << Joseph Nade
0020 7220536f 70687920 3e3e2000 00000000 r Sophy >> ....
 0060 000000000
Contents of section .rodata:
0000 746f2063 72656174 6520726f 20646174 to create ro dat
0010 61207365 6374696f 6e000000 00000000 a section.....
  0060 00000000

Contents of section debug_info:
0000 7f000000 02000000 00000401 17000000
0010 01970000 0330000 00000000 0180000 3
0020 00000000 00000103 52000000 R. R.
0040 4b00000 044b0000 06630005 04070e00 K. K. c.
0050 0000050 10800000 00009400 00000103
0060 3b00000 01050300 0000006 23000000 #.
0070 01047d00 00000105 03000000 00073b00 }
0080 0000000
Contents of section debug abbase

      0080 000000
      ...

      Contents of section .debug_abbrev:
      ...

      0000 01110125 0e130b03 0e1b0e11 01120110
      .%...

      0010 06000002 2e003f0c 030e3a0b 3b0b270c
      ...

      0020 11011201 40069642 0c000003 01014913
      ...

      0030 01130000 04210049 132f0b00 00052400
      ...

      0040 0b0b3e0b 030e0000 06340003 0e3a0b3b
      ...

      0050 0b49133f 0c020a00 00072600 49130000
      I.7.

      ...
      ...

 0030 02040001 01
 0030 02040001 01 .....

0010 0756e7369 676e6564 20636861 72007369 unsigned char.si

0010 7a657479 70650047 4e552043 20342e37 zetype.GNU C 4.7
0030 1e06
Contents of section .debug_frame:
0000 0c000000 ffffffff 0100027c 0e0c0d00
0010 18000000 00000000 00000000 18000000
0020 420e088b 028e0142 0c0b0400
```

Startup.s:

Compile and analyze it

\$ arm-none-eabi-as.exe -mcpu=arm926ej-s startup.s -o startup.o \$ arm-none-eabi-objdump.exe -h startup.o

```
hp@Joseph MINGW64 ~/Desktop/Diploma_Repo/Masteering_In_Embeded_Syste
nment_Lesson_2 (main)
$ arm-none-eabi-objdump.exe -h startup.o
                 file format elf32-littlearm
startup.o:
Sections:
Idx Name
                    Size
                                           LMA
                                                      File off
                                                                  Algn
                                VMA
                    00000010 00000000 00000000 00000034
  0 .text
                    CONTENTS, ALLOC, LOAD, RELOC, READONLY, CODE
                    00000000 00000000 00000000 00000044
CONTENTS, ALLOC, LOAD, DATA
00000000 00000000 00000000 00000044
  1 .data
  2 .bss
                    ALLOC
  3 .ARM.attributes 00000022 00000000 00000000 00000044 2**0
                    CONTENTS, READONLY
```

Linker_Script:

```
ENTRY (reset)
  2
      MEMORY
  3
  4
      Mem (rwx) : ORIGIN = 0 \times 000000000, LENGTH = 64M
  5
  6
      SECTIONS
  7
  8
          . = 0 \times 10000;
  9
          .startup joseph :
 10
          startup.o(.text)
 11
 12
          } > Mem
 13
          .text Nader:
 14
 15
          *(.text) *(.rodata)
 16
          }> Mem
 17
          .data Sophy:
 18
 19
          *(.data)
 20
          } > Mem
 21
          .bss unintialized global :
 22
 23
          *(.bss) *(COMMON)
 24
          } > Mem
 25
          . = . + 0x1000 ; /*4 kb of stack */
 26
          stack top = . ;
 27
```

To read the symbols you can use nm cross tool chain bin utility

Let us now to linking all the objects:

\$ arm-none-eabi-ld -T linker_script.ld -Map=output.map
app.o uart.o startup.o -o learn-in-depth.elf

Analyze the executable file

\$ arm-none-eabi-nm.exe learn-in-depth.elf

```
nment_Lesson_2 (main)
$ arm-none-eabi-nm.exe learn-in-depth.elf
00000010 T main
000000000 T reset
00001140 D stack_top
00000008 t stop
000000dc D string_buffer
00000078 T string_buffer_2
000000028 T uart_send_string
```

Sections

```
arm-none-eabi-objdump.exe -h learn-in-depth.elf
learn-in-depth.elf:
                        file format elf32-littlearm
Sections:
Idx Name
                  Size
                                                 File off Algn
                            VMA
 0 .startup_joseph 00000010 00000000 00000000 00008000
                  CONTENTS, ALLOC, LOAD, READONLY, CODE
                  000000cc 00000010 00000010 00008010
 1 .text_Nader
                  CONTENTS, ALLOC, LOAD, READONLY, CODE
                  00000064 000000dc
 2 .data_Sophy
                                      000000dc 000080dc
                  CONTENTS, ALLOC, LOAD, DATA
  3 .ARM.attributes 0000002e 00000000 00000000 00008140
                  CONTENTS, READONLY
 4 .comment
                  00000011 00000000
                                      00000000
                                                0000816e 2**0
                  CONTENTS, READONLY
  5 .debug_info
                  000000df 00000000
CONTENTS, READONLY,
                                                0000817f
                                      00000000
                                      DEBUGGING
 6 .debug_abbrev 000000b2 00000000 CONTENTS, READONLY,
                                      00000000
                                                0000825e
                                      DEBUGGING
 7 .debug_loc
                  00000058 00000000
                                                00008310
                                                          2**0
                                      00000000
                  CONTENTS, READONLY,
                                      DEBUGGING
 8 .debug_aranges 00000040 00000000
                                       00000000
                                                 00008368 2**0
                  CONTENTS, READONLY, DEBUGGING
 9 .debug_line
                  00000072
                            00000000
                                      00000000
                                                000083a8
                  CONTENTS, READONLY, DEBUGGING
 10 .debug_str
                  000000d4
                            00000000
                                      00000000
                                                0000841a
                  CONTENTS, READONLY, DEBUGGING
                                      00000000 000084f0
 11 .debug_frame
                  00000054 00000000
                                                           2**2
                  CONTENTS, READONLY, DEBUGGING
```

Output.map

Name Origin Length Attr	ibutes
Mem 0x00000000 0x04000000 xrw	
default 0x0000000 0xfffffff	
Linker script and memory map	
0x00010000 . = $0x10000$	
.startup_joseph	
0x00000000 0x10	
startup.o(.text)	
.text 0x00000000 0x10 startup.o	
0x00000000 reset	
.text_Nader	
*(.text)	
.text 0x00000010 0x18 app.o	
0x00000010 main	
.text 0x00000028 0x50 uart.o	
0x00000028 uart_send_string	
*(.rodata)	
.rodata 0x00000078 0x64 app.o	
0x00000078 string_buffer_2	
.glue 7 0x000000dc 0x0	
.glue 7 0x00000000 0x0 linker stubs	
- -	
.glue 7t 0x000000dc 0x0	
.glue_7t	
.vfp11_veneer 0x000000dc 0x0	
.vfp11_veneer 0x00000000 0x0 linker stubs	
.v4 bx 0x000000dc 0x0	
$.v\overline{4}$ bx 0x00000000 0x0 linker stubs	

arm-none-eabi-objcopy.exe -O binary learn-in-depth.elf learnoo.bin

hp@Joseph MINGW64 ~/Desktop/Diploma_Repo/Masteering_In_Embeded_System/Unit_3_Embedded_C/Assignment_Lesson_3 (main) \$qemu-system-arm -M versatilepb -m 128M -nographic -kernel learnoo.elf Learn In Depth : << Joseph Nader Sophy >>