What are Field Programmable Gate Arrays (FPGAs)?

- Like PLDs programmable at users site
- Two dimensional array of customizable logic block placed in an interconnect array
- Employs logic and interconnect structure capable of implementing multi-level logic
- Scalable in proportion with logic removing many of the size limitations of PLD derived two level architecture

Why Field Programmable Gate Arrays (FPGAs)?

- Fast-turnaround prototype implementation
- Supported by CAD/EDA tools
- High density
- High speed
- Programmable and versatile
- Flexible
- Reusable
- Large amounts of logic gates, registers, RAM and routing resources
- Quick time-to-market
- SRAM FPGA provide the benefits of custom CMOS

Field Programmable Gate Arrays (FPGAs)

FPGA Developers























CPLDs vs FPGAs

- CPLDs, with their PAL-derived, easy-to-understand AND-OR structure, offer a single-chip solution with fast pin-to-pin delays, even for wide input functions
- The limited complexity (< 500 flip-flops) means that most CPLDs are used for "glue logic" functions
- FPGAs offer much higher complexity, up to 150,000 flip-flops, and their idle power consumption is reasonably low, although it is sharply increasing in the newest families
- FPGAs offer more logic flexibility and more sophisticated system features than CPLDs: clock management, on-chip RAM, DSP functions, (multipliers), and even on-chip microprocessors and Multi-Gigabit Transceivers.
- Use CPLDs for small designs
- Use FPGAs for larger and more complex designs

ASIC Vs FPGA

ASIC

- Low cost for large volume
- Area and power efficient
- High frequencies can be achieved
- Huge testing cost in term of time and money

■ FPGA

- Low development cost solution
- Larger area, power and speed
- Less design and testing time
- Short time to market

Applications of FPGAs

- For design prototyping
- For emulation
- As hardware accelerator
- In place of ASIC
 - Less time to market
- Complete System on Chip (SoC) solution

Programming technology


- Anti-fuse based
 - All the contacts or open initially
 - Programming converts selected locations as conducting
 - One time programmable (OTP)
- SRAM based
- EEROM or Flash based
- Tradeoffs
 - Anti-fuse is less area, less power consuming
 - EERAM takes more time for programming
 - SRAM is technology leaders

Major FPGA Vendors

- SRAM-based FPGAs
 - Xilinx Inc.
 - Altera Corp.
 - Atmel
 - Lattice Semiconductor
- Flash & antifuse FPGAs
 - Actel Corp.
 - Quick Logic Corp.
- Xilinx + Altera \rightarrow Share over $\approx 60\%$ of the market

Structure of FPGA


Structure of FPGA



Configurable Logic Block (CLB)


- Combinational logic generated in a lookup table (LUT)
 - Any function of available inputs
 - Function Generator
- LUT output feeds CLB output or D input of flip-flop
 - Combinational output
 - Registered output

Virtex CLB




Configurable Logic Block (CLB)

Virtex CLB: Internal structure of a Slice




- lacktriangle Look-up table with N-inputs can be used to implement any combinatorial function of N inputs
- LUT is programmed with the truth-table
- Address lines as inputs, data lines as output (read mode)
- Truth Table written during configuration (write mode)




Programmable Logic

$$\# Y = (A . B) + C$$

MUX Based



LUT Based




■ Can be used as LUT and FFs independently




■ Can be used as LUT followed with FFs



- Two 4-input LUTs are MUXed for 5-inputs using F5 MUX
- F5 MUX output may be connected with FF




- Two 5 inputs are MUXed using F6 for a 6-input LUTs
- F6 MUX output may be connected with FF.




LUT as Distributed RAM

- LUT is written while configuring FPGA, when used for logic implementation
- Write control signals are available to be connected to routing wires so that it can be used as RAM when it is not used for logic implementation
- In Virtex E, four 16x1 distributed RAM per CLB
- These can be combined to make various memory sizes and data widths
- Since, it is spread across CLBs, it is called Distributed RAM
- Since, it is spread across, access latency can vary

An example of programming an FPGA




An example of programming an FPGA




Carry and Control Logic

- Each CLB contains separate logic and routing for the fast generation of sum & carry signals
 - Increases efficiency and performance of adders, subtractors, accumulators, comparators, and counters
- Carry logic is independent of normal logic and routing resources



Carry and Control Logic

Virtex CLB




Carry Chain

Adder


$$S_i = A_i \oplus B_i \oplus C_i$$

$$C_{i+1} = A_i \cdot B_i + (A_i \oplus B_i)C_i$$

- Requires two lookup tables $(S_i \text{ and } C_{i+1})$ at each stage
- This along with routing makes adder big and slow
- Hence, dedicated carry chain to make adder faster and implementing C_{i+1}



Carry Chain in a Slice



Carry Chain

- For adders use the operator '+' to be able to use carry chains
- For higher level functions like counters etc.; synthesis tool infer and use carry chains
- The AND gates are for partial product generation in multipliers
- In some FPGAs, carry chain has features to cascade (AND/OR) the LUT outputs

FPGA Configuration / Programming

- Writing to Configuration Memory
- Configuring options in Logic Blocks
 - Writing LUTs with Truth Tables
 - Combining LUTs
 - Using LUTs as memory
 - Selecting clocks, Set/Reset for FFs
 - Configuring various MUXes in Slices
- Using special resources (RAM, FIFOs, etc..)
- Programming Switch matrices
- Programming I/O blocks

Logic Block Size

■ Coarse Grain:


- Owing to SRAM interconnection area (6 transistors) the Logic Blocks are made large in SRAM based FPGAs
- Utilization is made high with configurability within the logic block

■ Fine Grain:

- Few, simple logic elements in a block
- High utilization of logic block
- Fine grain FPGA involves more interconnection & programmable switches (overhead)
 - ► Larger chip area
 - ► Lower performance


Logic Block Size: Coarse Grain

Structure of Coarse Grain Architecture



Logic Block Size: Fine Grain

Structure of Fine Grain Architecture




Fine-grained vs. Coarse-grained

- Fine grain is general purpose
 - Slow and area-inefficient, but high parallelism
- Coarse grain is application domain-specific
 - Coarse grain is highly area-efficient
 - Extremely high performance

FPGAs: Basic I/O Block

Structure of Basic I/O Block



FPGAs: IOB Functionality

- IOB provides interface between the package pins and CLBs
- Each IOB can work as uni- or bi-directional I/O
- Outputs can be forced into High Impedance
- Inputs and outputs can be registered
 - Advised for high-performance I/O
- Inputs can be delayed

Computer-Aided Design

- Can't design FPGAs by hand
 - Way too much logic to manage, hard to make changes
- Hardware description languages
 - Specify functionality of logic at a high level
- Validation high-level simulation to catch specification errors
 - Verify pin-outs and connections to other system components
 - Low-level to verify mapping and check performance
- Logic synthesis
 - Process of compiling HDL program into logic gates and flip-flops
- Technology mapping
 - Map the logic onto elements available in the implementation technology (LUTs for Xilinx FPGAs)

Computer-Aided Design (Contd.)

- Placement and routing
 - Assign logic blocks to functions
 - Make wiring connections
- Timing analysis verify paths
 - Determine delays as routed
 - Look at critical paths and ways to improve
- Partitioning and constraining
 - if design does not fit or is unroutable as placed split into multiple chips
 - if design it too slow prioritize critical paths, fix placement of cells, etc.
 - few tools to help with these tasks exist today
- Generate programming files bits to be loaded into chip for configuration

Xilinx CAD Tools

- Verilog (or VHDL) use to specify logic at a high-level
 - Combine with schematics, library components
- Synplicity
 - Compiles Verilog to logic
 - Maps logic to the FPGA cells
 - Optimizes logic
- Xilinx APR automatic place and route (simulated annealing)
 - Provides controllability through constraints
 - Handles global signals
- Xilinx Xdelay measure delay properties of mapping and aid in iteration
- Xilinx XACT design editor to view final mapping results

Applications of FPGAs

- Implementation of random logic
 - Easier changes at system-level (one device is modified)
 - Can eliminate need for full-custom chips
- Prototyping
 - Ensemble of gate arrays used to emulate a circuit to be manufactured
 - Get more/better/faster debugging done than possible with simulation
- Reconfigurable hardware
 - One h/w block is used to implement more than one function
 - Functions must be mutually-exclusive in time
 - Can greatly reduce cost while enhancing flexibility
 - RAM-based only option
- Special-purpose computation engines
 - Hardware dedicated to solving one (or class of) problem(s)
 - Accelerators attached to general-purpose computers

References

- 1) Christophe Bobda, "Introduction to Reconfigurable Computing Architectures, Algorithms and Applications", Springer, 2010.
- 2) Neeraj Goel, "FPGA Architecture, Technologies, and Tools", Lecture Slide, IIT Delhi.
- 3) Kuruvilla Varghese, "Digital System Design", Lecture Slide, DESE, Indian Institute of Science.
- 4) C. Maxfield, "The Design Warrior's Guide to FPGAs", Newnes, 2004.
- 5) Scott Hauck and Andre Dehon (Eds.), "Reconfigurable Computing The Theory and Practice of FPGA Based Computation", Elsevier / Morgan Kaufmann, 2008.