


## **Technology Constraints**

# PRSITION OF THE PROPERTY OF TH

## **Technology Constraints**

Constraints in technology push architecture too



- Power Wall: Thermal Design Power (TDP) constraint
- Memory Wall: Constraint in bandwidth to memory
- Variability: Limits in the precision of manufacturing technology
- Processor must be designed to meet all constraints

### Power Wall



- Power<sub>CPU</sub> = Power<sub>dynamic</sub> + Power<sub>leakage</sub> Power<sub>dynamic</sub>  $\propto$  A \* N \* CFV<sup>2</sup> Power<sub>leakage</sub>  $\propto$  f(N, V, V<sub>th</sub>)  $\propto$  N \* V \* e<sup>-Vth</sup>
  - Leakage power is also called static power
  - This total CPU power cannot exceed TDP
- Moore's Law transistor scaling means two things:

  - Reductions in C does not compensate for increases in N
- Architects must use tricks to keep power in check
  - To keep packing more transistors to increase performance

# TESBURCH


### 1. Reducing Dynamic Power

- Power<sub>dynamic</sub> ( $\propto$  A \* N \* CFV<sup>2</sup>) + Power<sub>leakage</sub> ( $\propto$  N \* V \* e<sup>-Vth</sup>)
- Reducing A (Activity): Clock gating
  - Disables the clock signal to unused parts of the chip (idle cores)
  - Wake-up is instantaneous (the moment clock signal goes in)
- Reducing F (Frequency) and V (Supply Voltage)
  - When F is reduced, V can also be reduced (The RC curve and water pressure, remember?)
  - Dynamic Voltage Frequency Scaling (DVFS) done on multi-cores
    - ☐ Slow down low-priority cores, speed up high-priority cores

# THE STREET

## **DVFS and Transistor Speed**

RC Charging Curve of V<sub>G</sub>



■ Delay (T) increases with supply voltage ( $V_{dd}$ ) decrease  $\rightarrow$  Frequency (1/T) decreases with  $V_{dd}$  decrease

# THE CANAL PROPERTY OF THE CANAL PROPERTY OF


## 2. Reducing Leakage Power

- Power<sub>dynamic</sub> ( $\propto$  A \* N \* CFV<sup>2</sup>) + Power<sub>leakage</sub> ( $\propto$  N \* V \* e<sup>-Vth</sup>)
- Reducing N (Transistor Number): Power gating
  - Disables power to unused parts of the chip (unused cores)
  - Eliminates dynamic power and leakage power to those parts
  - Drawback: wake-up takes a much longer time than clock gating
    - ☐ Delay for supply voltage to stabilize
    - ☐ Delay to backup and restore CPU state to/from memory
- Reducing V (Supply Voltage): DVFS also helps here
  - Only the voltage scaling part, not the frequency scaling



## OS Manages Power

- Who decides which cores to clock gate and power gate?
- Who decides how to apply DVFS to the cores?
- ACPI (Advanced Configuration and Power Interface)
  - OS performs power management using this interface
    - □ OS knows best which threads to prioritize for best user experience
  - Open standard interface to system firmware
    - ☐ Firmware sends signals to processor cores to control them





## 3. Simpler Processor Design

- Plenty of transistors but not enough power
  - Power becomes the ultimate currency in processor design
- Complex logic for performance is power hungry
  - Not easy to eke out the last bit of performance out of a program
  - Diminishing returns on performance for power investment
- Push towards simpler architectures:
  - Multi-cores: Run multiple programs (threads) on simple cores
  - GPUs: Run each instruction on massively parallel compute units
  - Caches: Memory caches are power efficient (low dynamic power)

## STATE OF THE PARTY OF THE PARTY

## **Memory** Wall

- Refers to both latency (ns) and bandwidth (GB/s)
  - CPU frequency and overall performance increased dramatically
  - Memory (DRAM) latency and bandwidth have lagged far behind

#### ■ Why?


Limit on the number of CPU / DRAM pins that can be soldered on





- DRAM manufacturers have traditionally prioritized capacity
- DDR1 (1998): 1.6 GB/s → DDR4 (2014): 25.6 GB/s (Impressive? Not so much compared to CPU performance)

### **Memory** Wall




Source: SC16 Invited Talk "Memory Bandwidth and System Balance in HPC Systems" by John D. McCalpin

FLOPS = floating point operations per second (performance)

## THE THE TABLE TO T

## **Memory** Wall

- Where did the Memory Wall push architecture?
- **Caches:** If hit in cache, no need to go to memory
  - Caching reduces both data access latency/bandwidth
- 3D-Stacked Memory: Stack CPU on top of memory
  - Drill vias, or holes, through silicon to bond CPU with memory
  - Through silicon vias (TSVs) have low latency / high bandwidth




## THI CAN THE STATE OF THE STATE

### **Variability**

- Variability: differences in speed of individual transistors
  - If fab can't ensure uniformity of transistors, speeds will differ
  - Speed differences mostly come from variations in V<sub>th</sub>: low V<sub>th</sub> → cycle time ↓ but leakage power ↑ high V<sub>th</sub> → cycle time ↑ but leakage power ↓
- If unlucky and a logic path has lots of *slow* transistors
  - → CPU may miss clock cycle time if path is exercised
  - → CPU must be discarded, since it malfunctions
- If unlucky and a region has too many fast transistors
  - $\rightarrow$  Region may generate too much heat due to low  $V_{th}$
  - → CPU must be discarded, due to overheating
- Leads to low chip yield

### Wafer Yield






Lower yield leads to higher production cost

## THI CAN THE STATE OF THE STATE

## **Variability**

- Where did Variability push architecture?
- Product binning: Sell slower CPUs at a cheaper "bin"
  - And rate slower CPUs at a lower CPU frequency
  - Instead of discarding them as "malfunctioning"
- Multi-cores: Easy to disable one or two buggy cores
  - Compared to single core where subcomponents must be disabled
  - When cores are disabled, sold as a cheaper chip
- Limited pipelining: pipelining exacerbates variability
  - With long stages, many transistors so tend to even each other out
  - With short stages, few transistors so probable all are slow



SILV	RSI7	6
	SBUR	A STATE OF THE STA

Model	# Cores	# Threads	Base Clock	All Core Turbo	Turbo Boost	Total L3 Cache	PL1 TDP	
i9-10900K	10	20	3.7	4.8	5.1	20	125	
i9-10900KF	10	20	3.7	4.8	5.1	20	125	
i9-10900	10	20	2.8	4.5	5.0	20	65	
i9-10900F	10	20	2.8	4.5	5.0	20	65	
i9-10900T	10	20	1.9	3.7	4.5	20	35	
i7-10700K	8	16	3.8	4.7	5.0	16	125	
i7-10700KF	8	16	3.8	4.7	5.0	16	125	
i7-10700	8	16	2.9	4.6	7.7	16	65	
i7-10700F	8	16	2.9	4.6	4.7	16	65	
i7-10700T	8	16	2.0	3.7	4.4	16	35	}
i5-10600K	6	12	4.1	4.5	4.8	12	125	
i5-10600K	6	12	4.1	4.5	4.8	12	125	
i5-10600	6	12	3.3	4.4	4.8	12	65	
i5-10600T	6	12	2.4	3.7	4.0	12	35	
i5-10500	6	12	3.1	4.2	4.5	12	65	+
i5-10500T	6	12	2.3	3.5	3.8	12	35	
i5-10400	6	12	2.9	4.0	4.3	12	65	
i5-10400F	6	12	2.9	4.0	4.3	12	65	
i5-10400T	6	12	2.0	3.2	3.6	12	35	

Why the close to 4X difference? Clock difference is just 2X!

Produced from one wafer

4 out of 10 cores were discarded.

Source: https://www.techspot.com/article/2039-chip-binning/

<sup>\*</sup> TDP is calculated using the Base Clock frequency at a nominal supply voltage

## Opportunities for Speed Improvement

- So Dennard Scaling is dead
  - Free CPU frequency gains are no longer there
- And we are walled in by technology constraints
  - Power wall
  - Memory wall
  - Variability
  - ...
- Where do architects go look for performance?

## STATE OF THE STATE

### **Improving Execution Time**

Execution time = 
$$\frac{\text{instructions}}{\text{program}}$$
 X  $\frac{\text{cycles}}{\text{instructions}}$  X  $\frac{\text{seconds}}{\text{cycle}}$ 

- Improving  $\frac{\text{seconds}}{\text{cycle}}$ :
  - Pipelining can lead to higher frequencies
- Improving  $\frac{\text{cycles}}{\text{instructions}}$ :
  - Caching can reduce cycles for memory instructions
  - Superscalars can execute multiple instructions per cycle
  - Multi-cores execute multi-instructions from multi-threads
- Improving  $\frac{\text{instructions}}{\text{program}}$ :
  - GPUs are SIMD (Single Instruction Multiple Data) processors

### What about Other Performance Goals?

- We talked a lot about execution speed
- But there are other performance goals such as:
  - Energy efficiency
  - Reliability
  - Security
  - ...
- In this class, we will mainly focus on speed
  - Not that other goals are not important
  - We will touch upon other goals when relevant
  - Performance will be used synonymously with speed



## Textbook Chapters

Please review Chapter 1 of the textbook.