

Lab 24: Soldering the RIFF Box Adapter

Continuity for 1-VCC:



Continuity for 3-TRST:



Continuity for 5-TDI:




Continuity for 7-TMS:




Continuity for 9-TCK:




Continuity for 11-RTCK:



Continuity for 13-TDO:




Continuity for 15-NRST:




Continuity for 18-GND:



Glue on the Bottom of Board:




Joints on the Molex Side of Board:



Note: I had to go back and fix the solder for 3, 7, and 18. I also clipped the excess wires off.

Joints on the Molex Side of Board:



Here's the board after I fixed the solder and tested all wires for continuity.



All the joints here were good.

