

3.13.4 Operational amplifier in:

3.13.4.1 inverting amplifier configuration (A-level only)

Content

Derivation of $\frac{V_{\text{out}}}{V_{\text{in}}} = -\frac{R_f}{R_{\text{in}}}$, calculations.

Meaning of virtual earth, virtual-earth analysis.

$$\frac{V_{\text{out}}}{V_{\text{in}}} = 1 + \frac{R_f}{R_1}$$

Derivation is not required.

3.13.4.3 summing amplifier configuration (A-level only)

Content

$$V_{\text{out}} = -R_f \left(\frac{V_1}{R_1} + \frac{V_2}{R_2} + \frac{V_3}{R_3} + \dots \right)$$

Difference amplifier configuration.

Derivation is not required.

$$V_{\text{out}} = (V_+ - V_-) \frac{R_f}{R_1}$$

Derivation is not required.

3.13.4.4 Real operational amplifiers (A-level only)

Content

Limitations of real operational amplifiers.

Frequency response curve.

gain × *bandwidth* = *constant* for a given device.