CMPE 443 PRINCIPLES OF EMBEDDED SYSTEMS DESIGN PRELAB #010 "UART"

1) Problem Definition

In this prelab, you will use a potentiometer and serial communication. You can use your PRELAB9 code for getting the ADC values. You will send the ADC values to the PC (with the "\r\n") at every 500ms. You will use interrupt for UART.

You can use various programs for showing the serial communication output. You can use Putty or a different alternative which is suitable for your OS.

https://www.cyberciti.biz/hardware/5-linux-unix-commands-for-connecting-to-the-serial-console/

Serial Communication configuration:

- 9600 Baud
- 8 Data Bits
- 1 Bit Stop
- No Parity

2) UART

- Which UART is connected to STM32 USB Virtual COM Port (VCP)?

LPUART1

Which pins are TX/RX?

TX: PG7 RX: PG8

- Enable Clock for Power Interface

RCC APB1ENR1 |= 1 << 28;

- Change the regulator mode to Low-power mode

PWR->CR1 |= 1 << 14;

- Make VDDIO2 valid

PWR->CR2 |= 1 << 9;

- Change the clock source of Low-power UART to SYSCLK

RCC_CCIPR1 |= 1 << 10;

Student ID: 2018400174 Name Surname: Karahan Sarıtaş

- Enable Clock for Low-power UART

```
RCC APB1ENR2 |= 1;
```

- Enable Clock for GPIO

```
RCC_AHB2ENR |= 1 << 6;
```

- Change the functionality of the pin

```
GPIOG->MODER &= ~(1 << 14);
GPIOG->AFRL |= 0b1000 << 28;
```

- Change LPUART baud rate (BRR) for 9600 Baud rate

```
LPUART1->BRR = 0x1A0AA; // 4Mhz * 256 / x = 9600
```

- Enable FIFO mode for UART

```
LPUART1->CR1 |= 1 << 29;
```

- Enable Transmitter and Receiver for UART

```
LPUART1->CR1 |= 1 << 3; // TE

LPUART1->CR1 |= 1 << 2; // RE
```

- Enable Interrupt and LPUART

```
LPUART1->CR1 |= 1 << 5; // RXFNEIE: RXFIFO not empty interrupt enable

LPUART1->CR1 |= 1 << 7; // TXFNFIE: TXFIFO not full interrupt enable

NVIC_ISER->ISER2 |= 1 << 2;

LPUART1->CR1 |= 1; // UE: LPUART enable
```

3) Code

In this prelab, you need to write code as described at the problem definition.

4) Submission

You will submit one zip file which contains this document and your project (all the files with the last configuration)

The naming of the zip file should be:

PRELAB<exp num>_<StudentID>.zip

5) Related Videos and Links

Student ID: 2018400174 Name Surname: Karahan Sarıtaş

UART:

 $\underline{https://www.youtube.com/watch?v=EqMF-aEyLgQ}$