

COMPUTER ORGANIZATION AND DESIGN

The Hardware/Software Interface



Chapter 2

Instructions: Language of the Computer

Instruction Set


- The repertoire of instructions of a computer
- Different computers have different instruction sets
 - But with many aspects in common
- Early computers had very simple instruction sets
 - Simplified implementation
- Many modern computers also have simple instruction sets


The MIPS Instruction Set

- Used as the example throughout the book
- Stanford MIPS commercialized by MIPS Technologies (<u>www.mips.com</u>)
- Large share of embedded core market
 - Applications in consumer electronics, network/storage equipment, cameras, printers, ...
- Typical of many modern ISAs
 - See MIPS Reference Data tear-out card, and Appendixes B and E

Brief Historical Perspective on ISAs

Accumulators (early stored-program computers had one register!)





Intel 8008 in 1972 was an accumulator

EDSAC (Electronic Delay Storage Automatic Calculator) in 1949

- Requires a memory-based operand-addressing mode
 - Example Instructions: add 200
 - Add the accumulator to the word in memory at address 200
 - Place the sum back in the accumulator

Brief Historical Perspective on ISAs

- Next step, more registers...
 - Dedicated registers
 - E.g. indices for array references in data transfer instructions, separate accumulators for multiply or
 - divide instructions, top-of-stack pointer.



Intel 8086
"extended accumulator"
Processor for IBM PCs

- Extended Accumulator
 - One operand may be in memory (like previous accumulators).
 - Or, all the operands may be registers (like MIPS).

Brief Historical Perspective on ISAs

- Next step, more registers...
 - General-purpose registers
 - Registers can be used for any purpose
 - E.g. MIPS, ARM, x86

- Register-memory architectures
 - One operand may be in memory (e.g. accumulators)
 - E.g. x86 (i.e. 80386 processors)
- Register-register architectures (aka load-store)
 - All operands must be in registers
 - E.g. MIPS, ARM

Basic ISA Classes

Accumulator Architectures (1 register):

```
1 address add A load A
```

Stack Architectures (O register)

```
0 address add
```

1 address push A

- General Purpose Register Architectures
 - register-memory (one operand in memory)

```
add Ra C
```

 Load-Store (or register-register) (operands always in registers)

```
add Ra Rb Rc
```

Comparing Number of Instructions

Code sequence for (C = A + B) for four classes of instruction sets:

Stack	Accumulator	Register (register-memory)	Register (load-store)
Push A	Load A	Load R1,A	Load R1,A
Push B	Add B	Add R1,B	Load R2,B
Add	Store C	Store C, R1	Add R3,R1,R2
Pop C			Store C,R3

General Purpose Register Architectures are Dominant!!

- Advantages of Registers
 - registers are faster than memory
 - registers are easier for a compiler to use
 - e.g., (A*B) (C*D) (E*F) can do multiplies in any order vs. stack.
 - registers can hold variables
 - memory traffic is reduced, so program is speed up

MIPS Design Principles

Simplicity favors regularity

- fixed size instructions
- small number of instruction formats
- opcode always the first 6 bits

Smaller ISA is faster

- limited instruction set
- limited number of registers in register file
- limited number of addressing modes

Make the common case fast

- arithmetic operands from the register file (load-store machine)
- allow instructions to contain immediate operands

Good design demands good compromises

three instruction formats

Reduced Instruction Set Computer

- MIPS = Reduced Instruction Set Computer (RISC)
 - ≈ 200 instructions, 32 bits each, 3 formats
 - all operands in registers
 - almost all are 32 bits each
 - ≈ 5 addressing mode: Mem[reg + imm]
- x86 = Complex Instruction Set Computer (CISC)
 - > 1000 instructions, 1 to 15 bytes each
 - operands in dedicated registers, general purpose registers, memory, on stack, ...
 - can be 1, 2, 4, 8 bytes, signed or unsigned
 - 10s of addressing modes
 - e.g. Mem[segment + reg + reg*scale + offset]

RISC vs CISC Philosophy

RISC

- Regularity & simplicity
- Leaner means faster
- Optimize the common case
- Energy efficiency

Embedded Systems
Phones/Tablets

CISC

- Compilers can be smart
- Transistors are plentiful
- Legacy is important
- Code size counts
- Micro-code!

Desktops/Servers

MIPS arithmetic

There are 32 32-bit registers in MIPS

- MIPS convention: two characters followed by a \$ sign.
 - \$zero (register 0)
 - \$t0-\$t7 (maps to registers 8-15) (temporary registers)
 - \$s0-\$s7 (maps to registers 16-23)
 - for registers correspond to variables.

Arithmetic instructions have 3 operands.

Operand order is fixed (destination first)

C code: A = B + C

MIPS code: add \$s0, \$s1, \$s2

(associated with variables by compiler)

MIPS arithmetic

- Design Principle 1: simplicity favors regularity.
 - Regularity makes implementation simpler
 - Simplicity enables higher performance at lower cost

Of course this complicates some things.

```
C code: a = b + c + d;

(Assume that A,B,C,D are assigned to registers $s0, $s1, $s2, $s3.)

MIPS code: add $s0, $s1, $s2 add $s0, $s0, $s3
```

- Operands must be registers, only 32 registers provided.
- Each register contains 32 bits.

Register Operands

- Arithmetic instructions use register operands
- MIPS has a 32 × 32-bit register file
 - Use for frequently accessed data
 - Numbered 0 to 31
 - 32-bit data called a "word"
- Assembler names
 - \$t0, \$t1, ..., \$t9 for temporary values
 - \$s0, \$s1, ..., \$s7 for saved variables

Design Principle 2: Smaller ISA is faster

(Large number of registers may increase clock cycle time since it takes electronic signals longer when they must travel farther.)

Register Operand Example

C code:

```
f = (g + h) - (i + j);


• f, ..., j in $s0, ..., $s4
```

Compiled MIPS code:

```
add $t0, $s1, $s2
add $t1, $s3, $s4
sub $s0, $t0, $t1
```

MIPS Register File

- Holds thirty-two 32-bit registers
 - Two read ports and
 - One write port



Register File

- Registers faster than main memory
 - But register files with more locations are slower (e.g., a 64 word file could be as much as 50% slower than a 32 word file)
 - Read/write port increase impacts speed quadratically
- Easier for a compiler to use
 - e.g., (A*B) (C*D) (E*F) can do multiplies in any order
- Can hold variables so that code density improves
 (since register are named with fewer bits than a memory location)

|MIPS Register Convention

Name	Register Number	Usage	Preserve on call?
\$zero	0	constant 0	n.a.
\$at	1	reserved for assembler	n.a.
\$v0 - \$v1	2-3	returned values	no
\$a0 - \$a3	4-7	arguments	yes
\$t0 - \$t7	8-15	temporaries	no
\$s0 - \$s7	16-23	saved values	yes
\$t8 - \$t9	24-25	temporaries	no
\$gp	28	global pointer	yes
\$sp	29	stack pointer	yes
\$fp	30	frame pointer	yes
\$ra	31	return addr	yes


Preserve on call = callee saves and restores them

Memory Operands

- Main memory used for composite data
 - Arrays, structures, dynamic data
- To apply arithmetic operations
 - Load values from memory into registers
 - Store result from register to memory
- Memory is byte addressed
 - Each address identifies an 8-bit byte
- Words are aligned in memory
 - Address must be a multiple of 4
- MIPS is Big Endian
 - Most-significant byte at least address of a word
 - c.f. Little Endian: least-significant byte at least address

Memory Organization

For MIPS, a word is 32 bits or 4 bytes.




Registers hold 32 bits of data

- 2³² bytes with byte addresses from 0 to 2³² 1
- 2³⁰ words with byte addresses 0, 4, 8, ... 2³²-4
- Words are aligned i.e., what are the least 2 significant bits of a word address?

Byte Addresses (Big Endian and Little Endian)

- Since 8-bit bytes are so useful, most architectures address individual bytes in memory
 - The memory address of a word must be a multiple of 4 (alignment restriction)
- Big Endian: leftmost byte is word address
 IBM 360/370, Motorola 68k, MIPS, Sparc, HP PA
- Little Endian: rightmost byte is word address
 Intel 80x86, DEC Vax, DEC Alpha



Memory Operand Example 1

C code:

```
g = h + A[8];
```

- g in \$s1, h in \$s2, base address of A in \$s3
- Compiled MIPS code:
 - Index 8 requires offset of 32
 - 4 bytes per word

Memory Operand Example 2

- C code: A[12] = h + A[8];
 - h in \$s2, base address of A in \$s3
- Compiled MIPS code:
 - Index 8 requires offset of 32

```
lw $t0, 32($s3)  # load word
add $t0, $s2, $t0
sw $t0, 48($s3)  # store word
```

Remember: arithmetic operands are registers, not memory!

Can't write: add 48(\$s3), \$s2, 32(\$s3)

Registers vs. Memory

- Registers are faster to access than memory
- Operating on memory data requires loads and stores
 - More instructions to be executed
- Compiler must use registers for variables as much as possible
 - Only spill to memory for less frequently used variables
 - Register optimization is important!

Immediate Operands

- Constant data specified in an instruction addi \$s3, \$s3, 4
- No subtract immediate instruction
 - Just use a negative constant addi \$s2, \$s1, -1
- Design Principle 3: Make the common case fast
 - Small constants are common
 - Immediate operand avoids a load instruction

The Constant Zero

- MIPS register 0 (\$zero) is the constant 0
 - Cannot be overwritten
- Useful for common operations
 - E.g., move between registers add \$t2, \$s1, \$zero

Unsigned Binary Integers

Given an n-bit number

$$x = x_{n-1} 2^{n-1} + x_{n-2} 2^{n-2} + \dots + x_1 2^1 + x_0 2^0$$

- Range: 0 to +2ⁿ − 1
- Example
 - 0000 0000 0000 0000 0000 0000 1011₂ = 0 + ... + $1 \times 2^3 + 0 \times 2^2 + 1 \times 2^1 + 1 \times 2^0$ = 0 + ... + 8 + 0 + 2 + 1 = 11_{10}
- Using 32 bits
 - 0 to +4,294,967,295

2s-Complement Signed Integers

Given an n-bit number

$$x = -x_{n-1}2^{n-1} + x_{n-2}2^{n-2} + \dots + x_12^1 + x_02^0$$

- Range: -2^{n-1} to $+2^{n-1}-1$
- Example
- Using 32 bits
 - -2,147,483,648 to +2,147,483,647

2s-Complement Signed Integers

- Bit 31 is sign bit
 - 1 for negative numbers
 - 0 for non-negative numbers
- $-(-2^{n-1})$ can't be represented
- Non-negative numbers have the same unsigned and 2s-complement representation
- Some specific numbers
 - 0: 0000 0000 ... 0000
 - —1: 1111 1111 ... 1111
 - Most-negative: 1000 0000 ... 0000
 - Most-positive: 0111 1111 ... 1111

Signed Negation

- Complement and add 1
 - Complement means $1 \rightarrow 0, 0 \rightarrow 1$

$$x + \overline{x} = 1111...111_2 = -1$$

 $\overline{x} + 1 = -x$

- Example: negate +2
 - $+2 = 0000 0000 \dots 0010_2$
 - $-2 = 1111 \ 1111 \dots \ 1101_2 + 1$ = 1111 \ 1111 \ \dots \ \ 1110_2

Sign Extension

- Representing a number using more bits
 - Preserve the numeric value
- In MIPS instruction set
 - addi: extend immediate value
 - 1b, 1h: extend loaded byte/halfword
 - beq, bne: extend the displacement
- Replicate the sign bit to the left
 - c.f. unsigned values: extend with 0s
- Examples: 8-bit to 16-bit
 - +2: 0000 0010 => 0000 0000 0000 0010
 - -2: 1111 1110 => 1111 1111 1111 1110

Representing Instructions

- Instructions are encoded in binary
 - Called machine code
- MIPS instructions
 - Encoded as 32-bit instruction words
 - Small number of formats encoding operation code (opcode), register numbers, ...
 - Regularity!
- Register numbers
 - \$t0 \$t7 are reg's 8 15
 - \$t8 \$t9 are reg's 24 25
 - \$s0 \$s7 are reg's 16 23

MIPS R-format Instructions

ор	rs	rt	rd	shamt	funct
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

Instruction fields

- op: operation code (opcode)
- rs: first source register number
- rt: second source register number
- rd: destination register number
- shamt: shift amount (00000 for now)
- funct: function code (extends opcode)

R-format Example

op	rs	rt	rd	shamt	funct
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

add \$t0, \$s1, \$s2

special	\$s1	\$s2	\$t0	0	add
0	17	18	8	0	32
000000	10001	10010	01000	00000	100000

 $00000010001100100100000000100000_2 = 02324020_{16}$

Hexadecimal

- Base 16
 - Compact representation of bit strings
 - 4 bits per hex digit

0	0000	4	0100	8	1000	С	1100
1	0001	5	0101	9	1001	d	1101
2	0010	6	0110	а	1010	е	1110
3	0011	7	0111	b	1011	f	1111

- Example: eca8 6420
 - 1110 1100 1010 1000 0110 0100 0010 0000

MIPS I-format Instructions



- Immediate arithmetic and load/store instructions
 - rt: destination or source register number
 - Constant: -2¹⁵ to +2¹⁵ 1
 - Address: offset added to base address in rs
- Design Principle 4: Good design demands good compromises
 - Different formats complicate decoding, but allow 32-bit instructions uniformly
 - Keep formats as similar as possible


Stored Program Computers

The BIG Picture

Memory

Accounting program

Source code in C for editor program



- Instructions represented in binary, just like data
- Instructions and data stored in memory
- Programs can operate on programs
 - e.g., compilers, linkers, ...
- Binary compatibility allows compiled programs to work on different computers
 - Standardized ISAs

Logical Operations

Instructions for bitwise manipulation

Operation	С	Java	MIPS
Shift left	<<	<<	sll
Shift right	>>	>>>	srl
Bitwise AND	&	&	and, andi
Bitwise OR			or, ori
Bitwise NOT	~	~	nor

 Useful for extracting and inserting groups of bits in a word

Shift Operations



- shamt: how many positions to shift
- Shift left logical
 - Shift left and fill with 0 bits
 - s11 by i bits multiplies by 2i
- Shift right logical
 - Shift right and fill with 0 bits
 - srl by i bits divides by 2i (unsigned only)

AND Operations

- Useful to mask bits in a word
 - Select some bits, clear others to 0

```
and $t0, $t1, $t2
```

```
$t2 | 0000 0000 0000 0000 00<mark>00 11</mark>01 1100 0000
```

OR Operations

- Useful to include bits in a word
 - Set some bits to 1, leave others unchanged

```
or $t0, $t1, $t2
```

\$t0 | 0000 0000 0000 0000 00<mark>11 11</mark>01 1100 0000

NOT Operations

- Useful to invert bits in a word
 - Change 0 to 1, and 1 to 0
- MIPS has NOR 3-operand instruction
 - a NOR b == NOT (a OR b)

```
nor $t0, $t1, $zero ← ____
```

Register 0: always read as zero

```
$t1 | 0000 0000 0000 0001 1100 0000 0000
```

```
$t0 | 1111 1111 1111 1100 0011 1111 1111
```

Conditional Operations


- Branch to a labeled instruction if a condition is true
 - Otherwise, continue sequentially
- beq rs, rt, L1
 - if (rs == rt) branch to instruction labeled L1;
- bne rs, rt, L1
 - if (rs != rt) branch to instruction labeled L1;
- j L1
 - unconditional jump to instruction labeled L1

Compiling If Statements

C code:

```
if (i==j) f = g+h;
else f = g-h;
```

- f, g, ... in \$s0, \$s1, ...
- Compiled MIPS code:



```
bne $s3, $s4, Else
add $s0, $s1, $s2
j Exit
Else: sub $s0, $s1, $s2
```

Exit: *...

Assembler calculates addresses

Compiling Loop Statements

C code:


```
while (save[i] == k) i += 1;
```

- i in \$s3, k in \$s5, address of save in \$s6
- Compiled MIPS code:

```
Loop: sll $t1, $s3, 2
add $t1, $t1, $s6
lw $t0, 0($t1)
bne $t0, $s5, Exit
addi $s3, $s3, 1
j Loop
Exit: ...
```

Basic Blocks

- A basic block is a sequence of instructions with
 - No embedded branches (except at end)
 - No branch targets (except at beginning)



- A compiler identifies basic blocks for optimization
- An advanced processor can accelerate execution of basic blocks

More Conditional Operations

- Set result to 1 if a condition is true
 - Otherwise, set to 0
- slt rd, rs, rt
 - if (rs < rt) rd = 1; else rd = 0;
- slti rt, rs, constant
 - if (rs < constant) rt = 1; else rt = 0;</p>
- Use in combination with beq, bne

```
slt $t0, $s1, $s2 # if ($s1 < $s2)
bne $t0, $zero, L # branch to L
```

Branch Instruction Design

- Why not blt, bge, etc?
- Hardware for <, ≥, ... slower than =, ≠</p>
 - Combining with branch involves more work per instruction, requiring a slower clock
 - All instructions penalized!
- beq and bne are the common case
- This is a good design compromise

Signed vs. Unsigned

- Signed comparison: slt, slti
- Unsigned comparison: sltu, sltui
- Example

 - slt \$t0, \$s0, \$s1 # signed
 -1 < +1 ⇒ \$t0 = 1</pre>
 - sltu \$t0, \$s0, \$s1 # unsigned
 - $-4,294,967,295 > +1 \Rightarrow $t0 = 0$

Procedure Calling

- Steps required
 - 1. Place parameters in registers
 - 2. Transfer control to procedure
 - 3. Acquire storage for procedure
 - 4. Perform procedure's operations
 - 5. Place result in register for caller
 - 6. Return to place of call

Register Usage

- \$a0 \$a3: arguments (reg's 4 7)
- \$v0, \$v1: result values (reg's 2 and 3)
- \$t0 \$t9: temporaries
 - Can be overwritten by callee
- \$s0 \$s7: saved
 - Must be saved/restored by callee
- \$gp: global pointer for static data (reg 28)
- \$sp: stack pointer (reg 29)
- \$fp: frame pointer (reg 30)
- \$ra: return address (reg 31)

Procedure Call Instructions

- Procedure call: jump and link jal ProcedureAddress
 - Address of following instruction put in \$ra
 - Jumps to target address
- Procedure return: jump register jr \$ra
 - Copies \$ra to program counter
 - Can also be used for computed jumps
 - e.g., for case/switch statements

Leaf Procedure Example

C code:

```
int leaf_example (int g, h, i, j)
{ int f;
    f = (g + h) - (i + j);
    return f;
}
```

- Arguments g, ..., j in \$a0, ..., \$a3
- f in \$s0 (hence, need to save \$s0 on stack)
- Result in \$v0

Leaf Procedure Example

MIPS code:

leaf_ex	kample	e:		
addi	\$sp,	\$sp,	-4	
SW	\$s0,	0(\$s	o)	Save \$s0 on stack
add	\$t0,	\$a0,	\$a1	
add	\$t1,	\$a2,	\$a3	Procedure body
sub	\$s0,	\$t0,	\$t1	
add			\$zero	Result
٦w	\$s0,	0(\$s	o)	Doctoro do
addi	\$sp,	\$sp,	4	Restore \$s0
jr	\$ra			Return

*** Code is different than the one given in page 99. (read first paragraph in page 100)

Non-Leaf Procedures

- Procedures that call other procedures
- For nested call, caller needs to save on the stack:
 - Its return address
 - Any arguments and temporaries needed after the call
- Restore from the stack after the call

Non-Leaf Procedure Example

C code:

```
int fact (int n)
{
  if (n < 1) return f;
  else return n * fact(n - 1);
}</pre>
```


- Argument n in \$a0
- Result in \$v0

Non-Leaf Procedure Example

MIPS code:

```
fact:
                            # adjust stack for 2 items
       addi $sp, $sp, -8
0040
       sw $ra, 4($sp)
                            # save return address
0044
       sw $a0, 0($sp)
                            # save argument
0048
       slti $t0, $a0, 1
                             # test for n < 1
004C
       beq $t0, $zero, L1
0050
       addi $v0, $zero, 1
                            # if so, result is 1
0054
       addi $sp, $sp, 8
                             # pop 2 items from stack
0058
       jr
                                and return
005C
            $ra
0060 L1: addi $a0, $a0, -1
                             # else decrement n
       jal
0064
            fact
                             # recursive call
       lw $a0, 0($sp)
                             # restore original n
0068
                            # and return address
       lw $ra, 4($sp)
006C
       addi $sp, $sp, 8
                             # pop 2 items from stack
0070
            $v0, $a0, $v0
                             # multiply to get result
0074
       mu1
       jr
            $ra
                             # and return
0078
```


Local Data on the Stack



- Local data allocated by callee
 - e.g., C automatic variables
- Procedure frame (activation record)
 - Used by some compilers to manage stack storage

Memory Layout

- Text: program code
- Static data: global variables
 - e.g., static variables in C, constant arrays and strings
 - \$gp initialized to address allowing ±offsets into this segment
- Dynamic data: heap
 - E.g., malloc in C, new in Java
- Stack: automatic storage



Character Data

- Byte-encoded character sets
 - ASCII: 128 characters
 - 95 graphic, 33 control
 - Latin-1: 256 characters
 - ASCII, +96 more graphic characters
- Unicode: 32-bit character set
 - Used in Java, C++ wide characters, ...
 - Most of the world's alphabets, plus symbols
 - UTF-8, UTF-16: variable-length encodings

Byte/Halfword Operations

- Could use bitwise operations
- MIPS byte/halfword load/store
 - String processing is a common case

```
lb rt, offset(rs) lh rt, offset(rs)
```

Sign extend to 32 bits in rt

```
lbu rt, offset(rs) lhu rt, offset(rs)
```

- Zero extend to 32 bits in rt
- sb rt, offset(rs) sh rt, offset(rs)
 - Store just rightmost byte/halfword

String Copy Example

i in \$s0

C code (null-terminated string)

```
void strcpy (char x[], char y[])
{ int i;
    i = 0;
    while ((x[i]=y[i])!='\0')
        i += 1;
}
• Addresses of x, y in $a0, $a1
```

String Copy Example

MIPS code:

```
strcpy:
   addi $sp, $sp, -4
                         # adjust stack for 1 item
   sw $s0, 0($sp)
                         # save $s0
   add $s0, $zero, $zero # i = 0
L1: add $t1, $s0, $a1  # addr of y[i] in $t1
   1bu $t2, 0($t1)
                         # $t2 = y[i]
                         # addr of x[i] in $t3
   add $t3, $s0, $a0
   sb $t2, 0($t3)
                         \# x[i] = y[i]
                         # exit loop if y[i] == 0
   beq $t2, $zero, L2
                         \# i = i + 1
   addi $s0, $s0, 1
                         # next iteration of loop
        L1
L2: lw $s0, 0($sp)
                         # restore saved $s0
   addi $sp, $sp, 4
                         # pop 1 item from stack
                         # and return
        $ra
   jr
```

32-bit Constants

- Most constants are small
 - 16-bit immediate is sufficient
- For the occasional 32-bit constant lui rt, constant
 - Copies 16-bit constant to left 16 bits of rt
 - Clears right 16 bits of rt to 0

Branch Addressing

- Branch instructions specify
 - Opcode, two registers, target address
- Most branch targets are near branch
 - Forward or backward

ор	rs	rt	constant or address
6 bits	5 bits	5 bits	16 bits

- PC-relative addressing
 - Target address = PC + offset × 4
 - PC already incremented by 4 by this time

Jump Addressing

- Jump (j and jal) targets could be anywhere in text segment
 - Encode full address in instruction

ор	address
6 bits	26 bits

- (Pseudo)Direct jump addressing
 - Target address = $PC_{31...28}$: (address × 4)

Target Addressing Example

- Loop code from earlier example
 - Assume Loop at location 80000

Loop:	s11	\$t1,	\$s3,	2	80000	0	0	19	9	4	0
	add	\$t1,	\$t1,	\$ s6	80004	0	9	22	9	0	32
	٦w	\$t0,	0(\$t	1)	80008	35	9	8		0	
	bne	\$t0,	\$s5,	Exit	80012	5	8	21	****	2	
	addi	\$s3,	\$s3,	1	80016	8	19	19	N N N N N N N N N N N N N N N N N N N	1	
	j	Loop			80020	2	N N N N N N N N N N N N N N N N N N N	***	20000		
Exit:					80024	-					

Branching Far Away

- If branch target is too far to encode with 16-bit offset, assembler rewrites the code
- Example


```
beq $s0,$s1, L1

↓
bne $s0,$s1, L2

j L1


L2: ...
```

Addressing Mode Summary




PC-Relative Addressing & Pseudo-Direct Addressing

from the low order 16 bits of the branch instruction



Pseudo-Direct Addressing



A Quick Summary

MIPS operands

Name	Example	Comments		
	\$s0-\$s7, \$t0-\$t9, \$zero,	Fast locations for data. In MIPS, data must be in registers to perform		
32 registers	\$a0-\$a3, \$v0-\$v1, \$gp,	arithmetic. MIPS register \$zero always equals 0. Register \$at is		
\$fp, \$sp, \$ra, \$at r		reserved for the assembler to handle large constants.		
	7 2 3	Accessed only by data transfer instructions. MIPS uses byte addresses, so		
2 ³⁰ memory	Memory[4],,	sequential words differ by 4. Memory holds data structures, such as arrays,		
	Memory[4294967292]	and spilled registers, such as those saved on procedure calls.		

MIPS assembly language

Category	Instruction	Example	Meaning	Comments
	add	add \$s1, \$s2, \$s3	\$s1 = \$s2 + \$s3	Three operands; data in registers
Arithmetic	subtract	sub \$s1, \$s2, \$s3	\$s1 = \$s2 - \$s3	Three operands; data in registers
	add immediate	addi \$s1, \$s2, 100	\$s1 = \$s2 + 100	Used to add constants
	load word	lw \$s1, 100(\$s2)	\$s1 = Memory[\$s2 + 100]	Word from memory to register
	store word	sw \$s1, 100(\$s2)		Word from register to memory
Data transfer	load byte	lb \$s1, 100(\$s2)	\$s1 = Memory[\$s2 + 100]	Byte from memory to register
	store byte	sb \$s1, 100(\$s2)	Memory[\$s2 + 100] = \$s1	Byte from register to memory
	load upper immediate	lui \$s1, 100	\$s1 = 100 * 2 ¹⁶	Loads constant in upper 16 bits
	branch on equal	beq \$s1, \$s2, 25	if (\$s1 == \$s2) go to PC + 4 + 100	Equal test; PC-relative branch
Conditional	branch on not equal	bne \$s1, \$s2, 25	if (\$s1 != \$s2) go to PC + 4 + 100	Not equal test; PC-relative
branch	set on less than	slt \$s1, \$s2, \$s3	if (\$s2 < \$s3) \$s1 = 1; else \$s1 = 0	Compare less than; for beq, bne
	set less than immediate	slti \$s1, \$s2, 100	if (\$s2 < 100) \$s1 = 1; else \$s1 = 0	Compare less than constant
_	jump	j 2500	go to 10000	Jump to target address
Uncondi-	jump register	jr \$ra	go to \$ra	For switch, procedure return
tional jump	jump and link	jal 2500	\$ra = PC + 4; go to 10000	For procedure call

Synchronization


- Two processors sharing an area of memory
 - P1 writes, then P2 reads
 - Data race if P1 and P2 don't synchronize
 - Result depends of order of accesses
- Hardware support required
 - Atomic read/write memory operation
 - No other access to the location allowed between the read and write
- Could be a single instruction
 - E.g., atomic swap of register

 memory
 - Or an atomic pair of instructions

Synchronization in MIPS

- Load linked: 11 rt, offset(rs)
- Store conditional: sc rt, offset(rs)
 - Succeeds if location not changed since the 11
 - Returns 1 in rt
 - Fails if location is changed
 - Returns 0 in rt
- Example: atomic swap (to test/set lock variable)

Translation and Startup



Assembler Pseudoinstructions

- Most assembler instructions represent machine instructions one-to-one
- Pseudoinstructions: figments of the assembler's imagination

```
move $t0, $t1 \rightarrow add $t0, $zero, $t1 blt $t0, $t1, L \rightarrow slt $at, $t0, $t1 bne $at, $zero, L
```

\$at (register 1): assembler temporary

Producing an Object Module

- Assembler (or compiler) translates program into machine instructions
- Provides information for building a complete program from the pieces
 - Header: described contents of object module
 - Text segment: translated instructions
 - Static data segment: data allocated for the life of the program
 - Relocation info: for contents that depend on absolute location of loaded program
 - Symbol table: global definitions and external refs
 - Debug info: for associating with source code

Linking Object Modules

- Produces an executable image
 - 1. Merges segments
 - 2. Resolve labels (determine their addresses)
 - 3. Patch location-dependent and external refs
- Could leave location dependencies for fixing by a relocating loader
 - But with virtual memory, no need to do this
 - Program can be loaded into absolute location in virtual memory space

Loading a Program

- Load from image file on disk into memory
 - 1. Read header to determine segment sizes
 - 2. Create virtual address space
 - 3. Copy text and initialized data into memory
 - Or set page table entries so they can be faulted in
 - 4. Set up arguments on stack
 - 5. Initialize registers (including \$sp, \$fp, \$gp)
 - 6. Jump to startup routine
 - Copies arguments to \$a0, ... and calls main
 - When main returns, do exit syscall

Dynamic Linking

- Only link/load library procedure when it is called
 - Requires procedure code to be relocatable
 - Avoids image bloat caused by static linking of all (transitively) referenced libraries
 - Automatically picks up new library versions


Lazy Linkage

Indirection table


Stub: Loads routine ID, Jump to linker/loader

Linker/loader code

Dynamically mapped code




a. First call to DLL routine



b. Subsequent calls to DLL routine

Starting Java Applications



Compiles
bytecodes of
"hot" methods
into native
code for host
machine

C Sort Example

- Illustrates use of assembly instructions for a C bubble sort function
- Swap procedure (leaf)
 void swap(int v[], int k)
 {
 int temp;
 temp = v[k];
 v[k] = v[k+1];
 v[k+1] = temp;
 }
 - v in \$a0, k in \$a1, temp in \$t0

The Procedure Swap

The Sort Procedure in C

```
Non-leaf (calls swap)
  void sort (int v[], int n)
     int i, j;
     for (i = 0; i < n; i += 1) {
       for (j = i - 1;
             j >= 0 \&\& v[j] > v[j + 1];
             i -= 1) {
         swap(v,j);
 v in $a0, k in $a1, i in $s0, j in $s1
```

The Procedure Body


```
move $s2, $a0
                             # save $a0 into $s2
                                                             Move
       move $s3, $a1  # save $a1 into $s3
                                                             params
       move $s0, $zero # i = 0
                                                             Outer loop
for1tst: s1t $t0, $s0, $s3 # <math>$t0 = 0 if $s0 \ge $s3 (i \ge n)
        beq t0, zero, exit1 # go to exit1 if s0 \ge s3 (i \ge n)
        addi $$1, $$0, -1  # j = i - 1
for2tst: s1ti t0, s1, 0 # t0 = 1 if s1 < 0 (j < 0)
        bne t0, zero, exit2 # go to exit2 if s1 < 0 (j < 0)
        sll $t1, $s1, 2 # $t1 = j * 4
                                                             Inner loop
        add t2, s2, t1 # t2 = v + (j * 4)
       1w $t3, 0($t2) # $t3 = v[j]
       1w $t4, 4($t2) # $t4 = v[j + 1]
        \$1t \$t0, \$t4, \$t3  # \$t0 = 0 if \$t4 \ge \$t3
        beg t0, zero, exit2 # go to exit2 if t4 \ge t3
       move $a0, $s2  # 1st param of swap is v (old $a0)
                                                             Pass
       move $a1, $s1 # 2nd param of swap is j
                                                             params
                                                             & call
        jal swap # call swap procedure
        addi $s1, $s1, -1 # i -= 1
                                                             Inner loop
                     # jump to test of inner loop
        i for2tst
exit2:
       addi $s0, $s0, 1 # i += 1
                                                             Outer loop
        i for1tst
                             # jump to test of outer loop
```


The Full Procedure


```
addi $sp,$sp, -20
                            # make room on stack for 5 registers
sort:
        sw $ra, 16($sp)
                            # save $ra on stack
        sw $s3,12($sp)
                            # save $s3 on stack
        sw $s2, 8($sp) # save $s2 on stack
        sw $s1, 4($sp)
                            # save $s1 on stack
                            # save $s0 on stack
        sw $s0, 0($sp)
                            # procedure body
        exit1: lw $s0, 0($sp) # restore $s0 from stack
        lw $s1, 4($sp) # restore $s1 from stack
       lw $s2, 8($sp) # restore $s2 from stack
       lw $s3,12($sp) # restore $s3 from stack
       lw $ra,16($sp) # restore $ra from stack
        addi $sp,$sp, 20
                            # restore stack pointer
        ir $ra
                            # return to calling routine
```


Effect of Compiler Optimization

Compiled with gcc for Pentium 4 under Linux










Effect of Language and Algorithm



Lessons Learnt

- Instruction count and CPI are not good performance indicators in isolation
- Compiler optimizations are sensitive to the algorithm
- Java/JIT compiled code is significantly faster than JVM interpreted
 - Comparable to optimized C in some cases
- Nothing can fix a dumb algorithm!

Arrays vs. Pointers

- Array indexing involves
 - Multiplying index by element size
 - Adding to array base address
- Pointers correspond directly to memory addresses
 - Can avoid indexing complexity

Example: Clearing and Array

```
clear1(int array[], int size) {
                                        clear2(int *array, int size) {
 int i;
                                          int *p;
 for (i = 0; i < size; i += 1)
                                          for (p = \&array[0]; p < \&array[size];
   array[i] = 0;
                                               p = p + 1
                                            *p = 0:
                                        }
                      \# i = 0
      move $t0,$zero
                                               move t0,a0 # p = & array[0]
loop1: sll $t1.$t0.2  # $t1 = i * 4
                                               sll $t1,$a1,2 # $t1 = size * 4
      add $t2,$a0,$t1 # $t2 =
                                               add t2,a0,t1 # t2 =
                       # &array[i]
                                                                   &array[size]
      sw zero, 0(t2) # array[i] = 0
                                        loop2: sw zero,0(t0) \# Memory[p] = 0
                                               addi t0.t0.4 \# p = p + 4
      addi $t0,$t0,1 # i = i + 1
      s1t $t3.$t0.$a1 # $t3 =
                                               s1t $t3.$t0.$t2 # $t3 =
                         (i < size)
                                                               #(p<&array[size])
      bne $t3,$zero,loop1 # if (...)
                                               bne $t3,$zero,loop2 # if (...)
                          # goto loop1
                                                                   # goto loop2
```

Comparison of Array vs. Ptr

- Multiply "strength reduced" to shift
- Array version requires shift to be inside loop
 - Part of index calculation for incremented in
 - c.f. incrementing pointer
- Compiler can achieve same effect as manual use of pointers
 - Induction variable elimination
 - Better to make program clearer and safer

ARM & MIPS Similarities


- ARM: the most popular embedded core
- Similar basic set of instructions to MIPS

	ARM	MIPS
Date announced	1985	1985
Instruction size	32 bits	32 bits
Address space	32-bit flat	32-bit flat
Data alignment	Aligned	Aligned
Data addressing modes	9	3
Registers	15 × 32-bit	31 × 32-bit
Input/output	Memory mapped	Memory mapped

Compare and Branch in ARM

- Uses condition codes for result of an arithmetic/logical instruction
 - Negative, zero, carry, overflow
 - Compare instructions to set condition codes without keeping the result
- Each instruction can be conditional
 - Top 4 bits of instruction word: condition value
 - Can avoid branches over single instructions

Instruction Encoding



The Intel x86 ISA

- Evolution with backward compatibility
 - 8080 (1974): 8-bit microprocessor
 - Accumulator, plus 3 index-register pairs
 - 8086 (1978): 16-bit extension to 8080
 - Complex instruction set (CISC)
 - 8087 (1980): floating-point coprocessor
 - Adds FP instructions and register stack
 - 80286 (1982): 24-bit addresses, MMU
 - Segmented memory mapping and protection
 - 80386 (1985): 32-bit extension (now IA-32)
 - Additional addressing modes and operations
 - Paged memory mapping as well as segments


The Intel x86 ISA

- Further evolution...
 - i486 (1989): pipelined, on-chip caches and FPU
 - Compatible competitors: AMD, Cyrix, ...
 - Pentium (1993): superscalar, 64-bit datapath
 - Later versions added MMX (Multi-Media eXtension) instructions
 - The infamous FDIV bug
 - Pentium Pro (1995), Pentium II (1997)
 - New microarchitecture (see Colwell, The Pentium Chronicles)
 - Pentium III (1999)
 - Added SSE (Streaming SIMD Extensions) and associated registers
 - Pentium 4 (2001)
 - New microarchitecture
 - Added SSE2 instructions

The Intel x86 ISA

- And further...
 - AMD64 (2003): extended architecture to 64 bits
 - EM64T Extended Memory 64 Technology (2004)
 - AMD64 adopted by Intel (with refinements)
 - Added SSE3 instructions
 - Intel Core (2006)
 - Added SSE4 instructions, virtual machine support
 - AMD64 (announced 2007): SSE5 instructions
 - Intel declined to follow, instead...
 - Advanced Vector Extension (announced 2008)
 - Longer SSE registers, more instructions
- If Intel didn't extend with compatibility, its competitors would!
 - Technical elegance ≠ market success

Basic x86 Registers



Basic x86 Addressing Modes


Two operands per instruction

Source/dest operand	Second source operand	
Register	Register	
Register	Immediate	
Register	Memory	
Memory	Register	
Memory	Immediate	

Memory addressing modes

- Address in register
- Address = R_{base} + displacement
- Address = R_{base} + 2^{scale} × R_{index} (scale = 0, 1, 2, or 3)
- Address = R_{base} + 2^{scale} × R_{index} + displacement

x86 Instruction Encoding



- Variable length encoding
 - Postfix bytes specify addressing mode
 - Prefix bytes modify operation
 - Operand length, repetition, locking, ...

Implementing IA-32

- Complex instruction set makes implementation difficult
 - Hardware translates instructions to simpler microoperations
 - Simple instructions: 1–1
 - Complex instructions: 1–many
 - Microengine similar to RISC
 - Market share makes this economically viable
- Comparable performance to RISC
 - Compilers avoid complex instructions

ARM v8 Instructions


- In moving to 64-bit, ARM did a complete overhaul
- ARM v8 resembles MIPS
 - Changes from v7:
 - No conditional execution field
 - Immediate field is 12-bit constant
 - Dropped load/store multiple
 - PC is no longer a GPR
 - GPR set expanded to 32
 - Addressing modes work for all word sizes
 - Divide instruction
 - Branch if equal/branch if not equal instructions

Fallacies

- Powerful instruction ⇒ higher performance
 - Fewer instructions required
 - But complex instructions are hard to implement
 - May slow down all instructions, including simple ones
 - Compilers are good at making fast code from simple instructions
- Use assembly code for high performance
 - But modern compilers are better at dealing with modern processors
 - More lines of code ⇒ more errors and less productivity

Fallacies

- Backward compatibility ⇒ instruction set doesn't change
 - But they do accrete more instructions



Pitfalls

- Sequential words are not at sequential addresses
 - Increment by 4, not by 1!
- Keeping a pointer to an automatic variable after procedure returns
 - e.g., passing pointer back via an argument
 - Pointer becomes invalid when stack popped

Concluding Remarks

- Design principles
 - 1. Simplicity favors regularity
 - 2. Smaller is faster
 - 3. Make the common case fast
 - 4. Good design demands good compromises
- Layers of software/hardware
 - Compiler, assembler, hardware
- MIPS: typical of RISC ISAs
 - c.f. x86

Concluding Remarks

- Measure MIPS instruction executions in benchmark programs
 - Consider making the common case fast
 - Consider compromises

Instruction class	MIPS examples	SPEC2006 Int	SPEC2006 FP
Arithmetic	add, sub, addi	16%	48%
Data transfer	lw, sw, lb, lbu, lh, lhu, sb, lui	35%	36%
Logical	and, or, nor, andi, ori, sll, srl	12%	4%
Cond. Branch	beq, bne, slt, slti, sltiu	34%	8%
Jump	j, jr, jal	2%	0%