Infosec Institute NSA BIOS BACKDOOR A.K.A GOD MODE

ISTITUTE MALWARE PART 2: BULLDOZER



NSA BIOS Backdoor a.k.a God Mode Malware Part 2: BULLDOZER

This article is the second part of a series on NSA BIOS Backdoor internals. This part focuses BULLDOZER, a hardware implant acting as malware dropper and wireless communication "hub" for NSA covert operation. Despite BULLDOZER is a hardware, I still use the word "malware" when referring to it because it's a malicious hardware. Perhaps, the term malware should refer to both malicious software and malicious hardware, instead of only referring to the former.


I'd like to point out why the BULLDOZER is classified as "god mode" malware. Contrary to DEITYBOUNCE, BULLDOZER is not a name in the realms of "gods". However, BULLDOZER provides capabilities similar to "god mode" cheat in video games—which made the player using it close to being invincible—to its payload, GINSU. Therefore, it's still suitable to be called god mode malware. The presence of BULLDOZER is very hard to detect even with the most sophisticated anti malware tool during its possible deployment timeframe. As for GINSU, we will look into GINSU in detail in the next installment of this series.

The NSA ANT Server document—leaked by Edward Snowden—describes BULLDOZER briefly. This article presents analysis on BULLDOZER based on technical implications of the information provided by the NSA document. Despite lacking in many technical details, we could still draw technically-sound analysis on BULLDOZER based on BIOS and hardware technology at the day BULLDOZER became operational, just like in the DEITYBOUNCE case :-)

Introduction to GINSU-BULLDOZER Malware Combo

BULLDOZER doesn't work in isolation. It has to be paired with the GINSU malware to be able to work. As you will see in the next installment of this article, GINSU is a malicious PCI expansion ROM. Therefore, at this point let's just assume that GINSU is indeed a malicious PCI expansion ROM and BULLDOZER is the hardware where GINSU runs. This means BULLDOZER is a PCI add-in card, which is in line with the information in the NSA ANT server document.

Before we proceed to analyze BULLDOZER, let's look at the context where BULLDOZER and GINSU work. GINSU and BULLDOZER are software and hardware combo that must be present at the same time to work. We need to look at the context where GINSU and BULLDOZER operate in order to understand their inner working. Figure 1 shows the deployment of GINSU and BULLDOZER in the target network.



(TS//SI//REL) GINSU Extended Concept of Operations

Figure 1 GINSU Extended Concept of Operations. Courtesy: NSA ANT Product Data

Figure 1 shows BULLDOZER hardware implanted in one of the machine in the target network. The NSA Remote Operation Center (ROC) communicates via OMNIGAT with the exploited machine through an unspecified wireless network. This implies the GINSU-BULLDOZER malware combo targets machines in air-gapped networks or machines located in network that is hard—but not impossible—to penetrate. In the latter case, using machines with malware-implanted hardware is more economical and/or stealthier compared to using "ordinary" computer network intrusion approach.

Let's look closer to technical information revealed by the NSA ANT product data document, before we proceed to deeper technical analysis. The NSA ANT server product data document mentions:

- 1. GINSU provides software application persistence for the Computer Network Exploitation (CNE) implant—codenamed KONGUR—on systems with the PCI bus hardware implant, BULLDOZER.
- 2. The technique supports any desktop PC system that contains at least one PCI connector (slot) and uses Microsoft Windows 9x, 2000, 2003 server, XP, or Vista. The PCI slot is required for the BULLDOZER hardware implant installation.
- 3. BULLDOZER is installed in target system as PCI hardware implant through "interdiction"—fancy words for: installing additional hardware in the target system while being shipped to its destination.
- 4. After fielding, if KONGUR is removed from the system as a result of operating system upgrade or reinstallation, GINSU can be set to trigger on the next reboot of the system to restore the software implant.

It's clear that there are *three* different components in the GINSU-BULLDOZER combo from the four points of information above and from Figure 1. They are as follows:

- 1. The first component is GINSU. The GINSU code name is actually rather funny because it refers to knife that was very popular in 1980s and 1990s via direct selling marketing. Perhaps, creator of the GINSU malware refers to Ginsu knife's above average capability to cut through various materials. GINSU is possibly a malicious PCI expansion ROM—PCI expansion ROM is also called PCI option ROM in many PCI-related specifications, I will use both terms in this article. GINSU might share some modules with DEITYBOUNCE because both are malicious PCI expansion ROM—see DEITYBOUNCE analysis at http://resources.infosecinstitute.com/nsa-bios-backdoorgod-mode-malware-deitybounce/. However, it differs in many other aspects. First, GINSU runs on NSA custom PCI add-in card, codenamed BULLDOZER. Therefore, GINSU could be much larger in size compared to DEITYBOUNCE because NSA controls the size of the flash ROM on the PCI add-in card. This means GINSU could incorporate a lot more functions compared to DEITYBOUNCE. Second, the type of PCI add-in card type that GINSU might use. From Figure 1, GINSU hardware (BULLDOZER) seems to masquerade as WLAN PCI add-in card or other kinds of PCI add-in card for wireless communication. This implies the PCI class code for the BULLDOZER hardware that contains GINSU probably is not PCI mass storage controller like the one used by DEITYBOUNCE. Instead, the BULLDOZER PCI chip very possibly uses PCI wireless controller class code.
- 2. The second component is named BULLDOZER. This codename perhaps refers to the capability of BULLDOZER to push large quantities of materials to their intended place, which in the context of GINSU provides the capability to push the final payload (KONGUR) to the target systems. In this particular malware context, BULLDOZER refers to the PCI add-in card (hardware) implant installed in the target machine. BULLDOZER is a custom PCI add-in card. It very probably masquerade as PCI WLAN add-in card because it provides a wireless communication function that requires certain kind of antenna. However, this doesn't prevent BULLDOZER from masquerading as other kind of PCI add-in card, but the presence of physically larger antenna in PCI WLAN card could boost the wireless signal strength. Therefore, NSA might use PCI WLAN card form factor to their advantage. We will look deeper into BULLDOZER implementation later.
- 3. The third (last) component is named KONGUR. KONGUR is a bit mysterious name. It may refer to Kongur Tagh Mountain in China's Xinjiang-Uyghur Autonomous Region. This could possibly means that GINSU-BULLDOZER combo was devised for a campaign to infiltrate Chinese computer systems. After all, Xinjiang-Uyghur Autonomous Region is famous for its people rebellion against the Chinese central government. This doesn't mean that GINSU-BULLDOZER combo wasn't used against other targets in other campaigns though. KONGUR is a Windows malware that targets Windows 9x, 2000, XP, Server 2003 and Vista. GINSU provides the delivery and reinstallation mechanism for KONGUR. We can view KONGUR as the payload of the GINSU-BULLDOZER combo. It's possible that KONGUR could also work in Windows Vista derivatives, such as Windows 7 and Windows Server 2008, or even later Microsoft operating system (OS), such as Windows 8, Server 2012, and 8.1 because KONGUR also targets Windows Vista and we don't know which 0-day exploit it uses and whether the 0-day exploit has already been patched or not.

This article don't delve deep into KONGUR and GINSU, the focus is on its hardware delivery mechanism, the BULLDOZER malware. The GINSU-BULLDOZER malware combo is the second NSA BIOS malware that we looked into that "abuse" PCI expansion ROM—after DEITYBOUNCE. Well, we could say that NSA is quite fond of this technique. As you will see later, it's a justified fondness though. Anyway, this hypotheses on GINSU-BULDOZER combo is bound to have subtle inaccuracies because I have no sample of the malware combo to back-up my assertions. I'm very open to constructive criticism in this regard.

Now, we are going to look into BULLDOZER technical details. However, if you're not yet familiar with PCI bus protocol, please read the first part article (http://resources.infosecinstitute.com/nsa-bios-backdoorgod-mode-malware-deitybounce/). There are links in that article that further breaks down the required prerequisite knowledge, just in case you're not up to speed yet.

BULLDOZER: NSA Malicious PCI Add-In Card

In this section we delve into details of the procedures that NSA probably carry-out to create the BULLDOZER hardware implant. Surely, the exact type of hardware used by NSA may very well be different. However, I try to draw the closest analogy possible from the public domain knowledge base.

Despite NSA's superiority compared to the private sectors, all of us are bound to the laws of physics and must adhere to hardware protocol in the target systems. Therefore, NSA's approach to build BULLDOZER couldn't be that much of a difference than the explanation in this article. In the *BULLDOZER Implementation Recap* section, I try to draw the most logical hypotheses on the BULLDOZER hardware implant based on the explanation of the process in designing and creating a PCI add-in card similar to BULLDOZER.

PCI add-in cards are installed on PCI expansion slots on the motherboard. Figure 2 shows a PCI add-in card sample. This PCI add-in card is a PCI WLAN card. Figure 2 highlights the PCI "controller" chip from Ralink—a WLAN controller—and the PCI slot connector in the add-in card. The term "controller" is a generic name given to chip that implements the core function in a PCI add-in card. PCI hardware development documentation typically uses this term, as does PCI-related specifications.




Figure 2 PCI add-in card sample. Courtesy: D-Link.

I use a PCI WLAN card as an example because GINSU extended concept of operation implies that the BULLDOZER hardware implant is a PCI wireless controller card. As to what kind of wireless protocol it uses, we don't know. But, the point is, BULLDOZER could masquerade as PCI WLAN card for maximum stealth. It would look innocuous that way. Figure 2 doesn't show the presence of any flash ROM in the PCI add-in card. PCI add-in card typically stores the PCI option ROM code in flash ROM. The purpose of Figure 2 is just to show you the typical appearance of PCI add-in card for wireless communication. We'll get into the flash ROM stuff later on.

PCI Add-In Card in OEM Desktop PC Circa 2008

Now, let's look at how a typical 2008 desktop PC which could be implanted with such card. One of desktop PC from system builder that still has PCI slot(s) in 2008 is Lenovo ThinkCentre M57 Desktop PC. I choose Lenovo desktop PC as an example because its products were widely used in China—besides other parts of the world. It could probably one of the victim of GINSU-BULLDOZER campaign. Who knows? Lenovo ThinkCentre M57 have two PCI slots. Let's say NSA "interdict" such system. They can install BULLDOZER in it and then replace the user guide as well to make the BULLDOZER implant look like

legitimate PCI add-in card that comes with the PC, just in case the user checks the manual before using the system.




Figure 3 Lenovo ThinkCentre M57 PCI Add-In Card Replacement Instructions (edited version of the original ThinkCentre Hardware Maintenance Manual instructions). Courtesy: Lenovo.

Lenovo ThinkCentre Hardware Maintenance Manual even comes with instructions to replace failed PCI add-in card. Figure 3 shows the instruction to replace a PCI add-in card in an "exploded view" style. Hardware replacement instructions shown in Figure 3 is a pedestrian task to do, any NSA field agent can do that.

PCI Wireless Communication Add-In Card Hardware and Software Co-Development

Now, let's look at the steps to develop a PCI wireless communication add-in card in general, because we presume that BULLDOZER falls within this PCI add-in card category. I'm quite sure NSA also follows the approach explained here despite being a very advanced spying agency. Only the tools and hardware it uses probably different—perhaps, custom-made.

From cost point of view, using Commercial Off-The-Shelf (COTS) approach in creating BULLDOZER hardware would be more cost effective, i.e. using tools already in the market which cost much less than custom tools. COTS benefited from economic of scale and competition in the market compared to custom tools. Moreover, from operational standpoint, the GINSU-BULLDOZER target systems would likely evolve after five years, which dictate the use of new tool. Therefore, obsolescence which usually plague COTS solution is not a problem in the GINSU-BULLDOZER campaign. The latter fact strengthened my suspicion that NSA very probably use the COTS approach. We'll look at this COTS approach shortly.

The "crude" steps to develop a PCI add-in card and its assorted software in general—via the COTS approach—are as follows:

1. High-level design. This step involved the high-level decision on what kind of PCI controller chip would be created for the PCI add-in card and what features the chip would implement and what

- auxiliary support chip(s) are required. For example, in the case of PCI wireless communication add-in card, typically you will need a separate Digital Signal Processor (DSP) chip or you need to buy the DSP logic design from a DSP vendor and incorporate that design into your PCI Field Programmable Gate-Array (FPGA).
- 2. Hardware prototyping, this step involves creating the PCI controller chip prototype with PCI FPGA development board. Typically, the language used to develop the PCI controller chip in the FPGA is either VHDL or Verilog. This mostly depends on the FPGA vendor.
- 3. Software (device driver) development. This step involves creating prototype device driver for the PCI add-in card for the target Operating System (OS). For example, if the device would be marketed for mostly Windows user, then creating Windows device driver would take priority. As for other target OS, it would be developed later or probably not at all if market demands on the alternative OS doesn't justify the cost involved in developing the driver. This step is typically carried-out in parallel to hardware prototyping once the first iteration of the FPGA version of the chip is available. Some FPGA vendors provide a "template" driver for certain target OS to help with the driver development. This way, the PCI controller chip development can run in parallel with the chip design. There are also third-party "driver template" vendors which are endorsed by the FPGA vendors, such as Jungo Windriver—see http://www.jungo.com/st/products/windriver/.
- 4. Chip fabrication, also known as the making of the Application Specific Integrated Circuit (ASIC). In this step, the first design revision of the chip is finished and the design is sent to chip fabrication plant for fabrication, such as TSMC, UMC or other contract semiconductor fab. This is an optional step though, because some low-volume PCI add-in card these days are made out of FPGA anyway. If the cost of chip fabrication doesn't makes economic sense against creating the product out of FPGA, then the final product uses FPGA anyway. Well, NSA has several semiconductor fabs—for example, see http://www.chron.com/news/houston-texas/houston/article/NSA-plant-in-San-Antonio-shrouded-in-secrecy-4604109.php. One of the NSA's fab probably was used to fabricate BULLDOZER PCI controller chip.
- 5. Compatibility test on the PCI hardware-software "combo". The chip vendor carry out the compatibility testing first. If the target OS is Windows, Microsoft also carry out additional compatibility testing. In Windows platform, there is this so-called "WHQL" testing. WHQL stands for Windows Hardware Quality Labs. Windows Hardware Quality Labs testing or WHQL Testing is Microsoft's testing process which involves running a series of tests on third-party hardware or software, and then submitting the log files from these tests to Microsoft for review. In case the primary target OS is not Windows, only the test from the hardware vendor is carried out. NSA very probably also carry out this kind of tests, but for an entirely different purpose, i.e. to make sure the driver works as stealthy as possible or to mislead the user to think the driver is just ordinary PCI device driver.

Steps 2 and 3 are actually iterative steps. The PCI hardware prototype goes through several iteration until it matures and ready for fabrication. Step 4 could also happen as an iterative step, i.e. there are several revisions of the chip. The first revision might have a flaw or performance weakness that must be improved, despite being a functional design. In the commercial world, ASICs typically have several

revisions. Each revision is marked as a "stepping". You would find the word "stepping" mentioned in many CPU, chipset or System-on-Chip (SoC) technical documentation.

"Simulating" BULLDOZER Hardware

Now, let's look into the process of developing a specific PCI add-in card, i.e. PCI add-in card with wireless communication as its primary function. We focus on this kind of PCI add-in card because BULLDOZER connects to the outside world—to OMNIGAT in Figure 1—via an unspecified wireless connection. For this purpose, we look into the hardware prototyping step in more detail. Let's start with some important design decisions in order to emulate BULLDOZER capabilities, as follows:

- The prototype must have the required hardware to develop a custom wireless communication protocol. The reason is because the wireless communication protocol used by BULLDOZER to communicate with OMNIGAT must be as stealth as possible despite probably using the same physical antenna as a PCI WLAN card.
- The prototype must have an implemented PCI expansion ROM hardware. The reason is because GINSU is a malicious PCI expansion ROM code that must be stored in a functional PCI expansion ROM chip to work.
- 3. GINSU is configurable, at the very least it can be optionally triggered—based on the NSA ANT server document. This means there must be some sort of non-volatile memory in the prototype to store GINSU parameters. It could be in the form of Non-Volatile RAM (NVRAM) chip, like in the DEITYBOUNCE case. Storing the configuration data in flash ROM or other kinds of ROM is quite unlikely given the nature of flash ROM which requires rather complicated procedure to rewrite.

The next step is to choose the prototyping kit for the hardware. There are many PCI FPGA prototyping board in the market. We will look into one of them from Sundance (http://www.sundance.com). Sundance is probably a very obscure vendor to you. However, this vendor is one of the vendors that provides PCI development board for Software-Defined Radio (SDR) application. You might be asking, why I pick a PCI SDR development board as an example? The reason is simple, because SDR is the best approach when you want to develop your own wireless protocol. You can tune the frequency, the type of modulation, transmitter power profile and other parameters needed to make the protocol as stealthy as possible.

BULLDOZER Hardware "Simulation" with Sundance SMT8096 SDR Development Kit

There are usually more than one FPGA in typical PCI SDR development board. We are going to look into one of Sundance products which were available in the market before 2008—the year GINSU-BULLDOZER malware combo was operational. I pick Sundance SMT8096 SDR development kit as the example in this article. This kit was available in the market circa 2005. The kit consists of several connected boards with a "PCI carrier" board acting as the host of all of the connected boards. The PCI carrier board connects the entire kit to the PCI slot in the development PC. Figure 4 shows the entire Sundance SMT8096 SDR development kit hardware.




Figure 4 Sundance SMT8096 SDR development kit. Courtesy: Sundance Multiprocessor Technology Ltd.

Figure 4 shows the components of the Sundance SMT8096 SDR development kit. As you can see, the development kit consists of several circuit boards as follows:

- SMT395-VP30 board, which contains Texas Instrument TI DSP C6416T chip and Xilinx Virtex II
 Pro FPGA. TI DSP C6416T chip provides the primary signal processing in the development
 kit, while the Virtex II FPGA provides the reconfigurable signal processing part. Actually, it's
 the FPGA in this board that provides the term "software" in the "software-defined" part of
 the SDR abbreviation.
- SMT350 board provides the Analog-to-Digital Converter (ADC) / Digital-to-Analog Converter (DAC) functions. This board provides two functions. First, it receives the analog input from the input antenna and then converts that input into its equivalent digital representation before feeding the result to the signal processing board. Second, it receives the digital output of the signal processing board and convert that digital signal into analog signal to be fed into the output antenna. The input and output antenna could be the same or different. Depending on the overall design of the SDR solution.
- SMT368 board provides yet another FPGA, a Xilinx Virtex 4 SX35 FPGA. This board provides "protocol/data-format" conversion function as you can see in Figure 5 (Sundance SMT8096 SDR development kit block diagram).
- SMT310Q is the PCI carrier board. It's this board that connect to the host (desktop PC) motherboard via the PCI connector. This board provides the PCI logical and physical interface into the host PC.

Figure 5 shows the block diagram of the entire SDR development kit. It helps to understand interactions between the SDR development kit components.




Figure 5 Sundance SMT8096 Development Kit Block Diagram. Courtesy: Sundance Multiprocessor Technology Ltd.

Let's look into SMT310Q PCI carrier board because this board is the visible one from the motherboard BIOS perspective. We'll focus on the technology required to communicate with the host PC instead of the technology required for the wireless communication because we have no further clues on the latter. Moreover, I'm not an expert in radio communication technology in anyway.

SMT310Q PCI carrier board has a QuickLogic V363EPC PCI bridge chip, which conforms to PCI 2.1 specification. This chip was developed by V3 Semiconductor, before the company was bought by QuickLogic. V363EPC PCI Bridge connects the devices on the SMT8096 development kit to the host PC motherboard—both logically and electrically—via the PCI slot connector. This PCI bridge chip *is not* a PCI-to-PCI bridge, rather, it's a bridge between the custom bus used in the SMT8096 development kit and the PCI bus in the host PC. The correct term is *Local Bus to PCI Bridge*. Local bus in this context

refers to the custom bus in the SMT8096 development kit—used for communication between the chips in the development kit boards.

At this point we have made the important design decisions, have picked the PCI hardware development kit to work with and have look into the PCI-specific chip in the development kit. It's time to get into details of the design implementation. The steps to implement the design are as follows:

- 1. Assuming the wireless communication protocol has been defined thoroughly, the first step is to implement the protocol in the form of DSP chip firmware code and FPGA designs. The DSP chip firmware code consists of initialization code required to initialize the DSP chip itself, code to initialize the interconnection between the DSP chip and the Local Bus to PCI Bridge via the Local Bus interface, and code for other auxiliary functions. Assuming we use the Sundance SMT8096 kit, this step consists of creating the firmware code for the Texas Instrument TIC6416T DSP chip and creating the FPGA designs for the Xilinx Virtex-II and Xilinx Virtex-4 SX35. We are not going to delve into the details of this step as we don't know the specifics of the wireless communication protocol.
- 2. The second step is to customize the hardware to support PCI expansion ROM. This is required because we assume the GINSU malware is a malicious PCI expansion ROM code. In this step we configure the SMT310Q carrier board to support PCI expansion ROM because this board is the one that interfaces with the host (x86/x64 desktop) PCI bus, both at the logical and physical level. We have to enable the Expansion ROM Base Address Register (XROMBAR) in QuickLogic V363EPC PCI bridge chip (Local Bus to PCI Bridge) in the SMT310Q carrier board via hardware configuration and we have to provide flash ROM chip to store the PCI expansion ROM code on the board as well. If you're not familiar with XROMBAR, refer to my *Malicious Code Execution in PCI Expansion ROM* article (http://resources.infosecinstitute.com/pci-expansion-rom/) for the details.

Now, let's focus on the last step, customizing the hardware required for the PCI expansion ROM to work. It's the SMT310Q carrier board that implements the PCI bus protocol support in SMT8096 PCI SDR development kit. Therefore, we are going to scrutinize the SMT310Q carrier board to find out how we can implement PCI expansion ROM on it. We start with the board block diagram. Figure 6 shows SMT310Q block diagram. The block diagram is not physical block diagram of the board. Instead, it's a logical block diagram depicting logical interconnections between the board components.




Figure 6 SMT310Q Block Diagram. Courtesy: Sundance Multiprocessor Technology Ltd.

Figure 6 shows blocks marked as TIM, i.e. TIM 1, TIM 2 and so on. TIM is an abbreviation for Texas Instrument Modules. TIM is a standard interconnection between board using Texas Instrument DSP chip and other board(s). I couldn't find the latest version of TIM specification. However, you can find TIM version 1.01 on the net. Despite TIM implies that a DSP that should be connected via this interconnect, but in reality, anything that conform to the specification can be connected. It's important to know about TIM because we are going to use it to "wire" the PCI expansion ROM and also to "wire" NVRAM into the SMT310Q carrier board later.

Figure 6 shows the QuickLogic V363EPC PCI bridge—marked as V3 PCI Bridge—connects to the TIMs via the 32-bit Global Bus. The 32-bit Global Bus corresponds to the *LAD[31:0]* multiplexed address and data lines in QuickLogic V363EPC datasheet. This means, the logical and physical connection from QuickLogic V363EPC to PCI expansion ROM and the NVRAM in our design will be based on the Global Bus.

Now, let's look at how QuickLogic V363EPC exposes devices wired to the TIMs into the host x86/x64 CPU address space. QuickLogic V363EPC uses the so-called "data transfer apertures" to map devices

connected through *LAD*[31:0] into the host x86/x64 CPU address space. These apertures are basically address range claimed by the PCI Base Address Registers (BARs) in QuickLogic V363EPC. QuickLogic V363EPC datasheet uses different naming scheme for PCI BARs. Figure 7 shows the PCI BARs marked as PCI_BASEx registers. The PCI_MAPx registers in Figure 7 control the amount of memory or I/O range claimed by the PCI_BASEx registers. If you are new PCI configuration space registers, my *Malicious Code Execution in PCI Expansion ROM* article (http://resources.infosecinstitute.com/pci-expansion-rom/) has a deeper explanation on the subject. You can compare the "standard" PCI configuration space registers explained there and the ones shown in Figure 7.

REGISTER OFFSET						
31	16 15 0			q		
PCI_D	EVICE	PCI_VENDOR		00H		
PCI_	STAT	PCI_CMD		04H		
	PCI_C	C_REV Class Cod	e and Revision ID	08H		
	0CH					
PCI_IO_BASE	10H					
	PCI_BASE0 PCI BARs					
	PCI_BASE1					
	reserved					
PCI_S	SUB_ID	PCI_SUB_	VENDOR	2CH		
	PCI-	ROM XROMBA	R	30H		
	34-38H					
	3CH					
	40H					
PCI_MAP1	44H					
	48H					
	4CH					
	50H					
	54H					
	58H					
LB_MAP0		rese	rved	5CH		
LB_MAP1		rese	rved	60H		
LB_I	MAP2	LB_B	ASE2	64H		
	68H					
LB_IO	_BASE	rese	rved	6CH		
FIFO_P	RIORITY	FIFO_CFG		70H		
LB_IMASK	LB_ISTAT	FIFO_	STAT	74H		
LB_	CFG	SYSTEM		78H		
reserved		PCI_	CFG	7CH		

Figure 7 QuickLogic V363EPC PCI configuration registers. Courtesy: QuickLogic V363EPC datasheet.

Let's look deeper into the "data transfer aperture" in QuickLogic V363EPC. The "aperture" is basically address remapping logic, i.e. it remaps addresses from the host x86/x64 CPU address space into the local address space in the SMT310Q PCI add-in board. If you're new to address remapping, you read sample on the concept in http://resources.infosecinstitute.com/system-address-map-initialization-

<u>x86x64-architecture-part-2-pci-express-based-systems/</u>. Figure 8 shows simplified block diagram of the QuickLogic V363EPC aperture logic (address remapper).




Figure 8 QuickLogic V363EPC Aperture Logic

Figure 8 shows QuickLogic V363EPC claims two different ranges in the PCI address space of the host x86/x64 CPU address space. We are only going to delve into the first range claimed by PCI_BASE0 register. This is the relevant excerpt from QuickLogic V363EPC datasheet:

"4.1.8 Special Function Modes for PCI-to-Local Bus Apertures

PCI-to-Local bus aperture 0 shares some functionality with the expansion ROM base aperture. The address decoder for PCI-to-Local aperture 0 is shared with the expansion ROM base register. When the expansion ROM base is enabled, the decoder will only bridge accesses within the ROM window. When the ROM is disabled, PCI-to-Local bus aperture 0 will function as described above. Typically, the expansion ROM is used only during BIOS boot, if at all. The expansion ROM base register can be completely disabled via software."

The excerpt above clarify the PCI expansion ROM mapping. Basically, it says that when the PCI expansion ROM chip mapping is enabled via the XROMBAR register, the aperture will be used only for accesses to the PCI expansion ROM chip, no other chip can claim the transaction via the aperture.

XROMBAR in QuickLogic V363EPC chip must be enabled in order to support PCI expansion ROM. This is a quite complicated task. We must find the default XROMBAR register value in the chip. The XROMBAR is named PCI ROM register in QuickLogic V363EPC datasheet, as you can see in Figure 7.

QuickLogic V363EPC datasheet mentions that PCI_ROM (XROMBAR) *default* value upon power-on is 00h. This means the XROMBAR is disabled because its least significant bit is zero—per PCI specification.

However, this is not a problem as the *default* values of the PCI configuration space registers in QuickLogic V363EPC PCI bridge can be made *configurable*. There are hardware "straps" that controls the default values of the PCI configuration space registers in QuickLogic V363EPC. One of the "straps" configuration instructs QuickLogic V363EPC to "download" its PCI configuration space registers default values from external serial EEPROM chip. *Pay attention that this serial EEPROM chip is an entirely different chip from the PCI expansion ROM chip*. Figure 9 shows the "straps" option for V363EPC PCI configuration space registers.

EEPROM Port Connection	RETRY_EN	RST_OUT	Comment
SDA pulled high, No EEPROM	1	1	Typically used for initalization via local processor
SDA Tied Low, No EEPROM	0	0	Typically used for initalization via PCI
SDA ^a and SCL connected to valid EEPROM device	From EEPROM	From EEPROM	Initalization from EEPROM

a.SDA should have a pull up resistor in order to function properly with an EEPROM device

Figure 9 QuickLogic V363EPC PCI Configuration Space Registers Default Values Initialization "straps" Option. Courtesy: QuickLogic V363EPC datasheet.

Figure 9 shows there are two "straps" that control the default value initialization in V363EPC, i.e. SDA and SCL. Both of these "straps" are actually pins on the V363EPC chip. As you can see, when SDA and SCL are connected to serial EEPROM, the PCI configuration space registers default values will be initialized from serial EEPROM. The SDA and SCL pins adhere to I²C protocol. I²C is a serial protocol to connect microcontroller and other peripheral chips in a cost efficient manner, i.e. in as small number of pins as possible because pins and traces on a circuit board are costly to design and manufacture. SDA stands for Serial Data and SCL stands for Serial Clock respectively.




Figure 10 V363EPC to serial EEPROM connection circuit schematic. Courtesy: QuickLogic V363EPC datasheet.

Figure 10 shows the circuit schematic to implement loading default PCI configuration space registers from EEPROM. Now we know how to "force" V3636EPC PCI configuration space registers default values to our liking.

Once the pull-up resistors are set up to configure QuickLogic V363EPC to use serial EEPROM, the QuickLogic V363EPC PCI configuration space registers default values are stored in serial EEPROM and automatically loaded to QuickLogic V363EPC PCI configuration space after power-on or PCI bus reset, prior to PCI bus initialization by the motherboard BIOS. This means we can configure the XROMBAR default value via contents of the serial EEPROM. Therefore, the PCI_ROM (XROMBAR) can be enabled.

Another PCI configuration register to take into account is the PCI_MAP0 register. The PCI_MAP0 register—highlighted in red box in Figure 7—controls whether the PCI_ROM register is enabled or not. It also controls size of the ROM chip to be exposed through the PCI_ROM register. Let's look into details of the PCI_MAP0 register. Figure 11 shows the relevant excerpt for PCI_MAP0 register from QuickLogic V363EPC datasheet.

PCI_MAP0: PCI BUS TO LOCAL BUS ADDRESS MAP 0

Mnemonic: PCI_MAP0
Offset: 40H

Size: 32 bits

PCI_MAP0						
Bits	Mnemonic	Туре	Reset Value	Description		
31-16	MAP_ADR	FRW	0H	Map Address: These bits correspond to bits LAD[31:16] in local address space when a PCI to Local access is made. The lower bits of MAP_ADR are masked off according to the ADR_SIZE bits in the PCI_MAP registers.		
15	RD_POST_INH	FRW	ОН	Read Posting Inhibit: When set '1' the very first read of a burst read from the corresponding aperture will not generate a STOP regardless of the latency of the access.		
14-12	-	R	0H	reserved		
11-10	ROM_SIZE	FRW	ОН	ROM Size: Determines the size of the expansion ROM address decoder: 00 = expansion ROM base register disabled 01 = 4K byte expansion ROM (A[31:12] significant) 10 = 16K byte expansion ROM (A[31:14] significant) 11 = 64K byte expansion ROM (A[31:16] significant)		
9-8	SWAP	FRW	0H	Byte Swap Control: Selects byte lane swapping for read and write cycles according to the following table: SWAP D[31:24] D[23:26] D[15:8] D[7:0] no swap, 32 00 Q[31:24] Q[23:16] Q[15:8] Q[7:0] bit 01 Q[15:8] Q[7:0] Q[31:24] Q[23:16] 8 bit 10 Q[7:0] Q[15:8] Q[23:16] Q[31:24] 11 Auto Swap Auto Swap: When local bus BE[3:0] = "1100" or "0011" then a 16 bit swap is done. When local bus BE[3:0] = "1110", "1101", "1011" or "0111" then an 8 bit swap is done. Any other combination results in non-swapped data.		

Figure 11 PCI MAPO register description. Courtesy: QuickLogic V363EPC datasheet

Figure 11 shows the ROM_SIZE bits in PCI_MAPO register highlighted in yellow. The bits determine size of the PCI expansion ROM to be decoded by QuickLogic V363EPC. As you can see, the chip supports PCI expansion ROM with size up-to 64KB. Perhaps, this size is not up-to what a malicious PCI expansion ROM payload requires. However, a malicious PCI expansion ROM code can load additional code from other memory storage in the PCI add-in card when the ROM code executes. You must configure the ROM_SIZE bits default value to the correct value according to your hardware design. Entries in Figure 11 that have their "type" column marked as FRW means the default value of the bits are determined by the contents of the serial EEPROM if serial EEPROM support is activated via SDA and SCL "straps". Therefore, all you need to do is place the correct value in the serial EEPROM to configure their default values.

There is one more PCI configuration space register to take into account to implement BULLDOZER hardware, the *Class Code register*. The PCI Class Code register consists of three sub-part: the base class,

sub-class and interface. Figure 12 shows the class code selections for PCI Wireless Controller class of devices.

Base Class	Sub-Class	Interface	Meaning
0Dh	00	00h	iRDA compatible controller
	01h	00h	Consumer IR controller
	10h	00h	RF controller
	11h	00h	Bluetooth
	12h	00h	Broadband
	20h	00h	Ethernet (802.11a – 5 GHz)
	21h	00h	Ethernet (802.11b - 2.4 GHz)
	80h	00h	Other type of wireless controller

Figure 12 PCI Wireless Controller Class Code

As you see in Figure 12, we have to set the class code in our BULLDOZER chip design to base class 0Dh, sub-class 21h and interface 00h to make it masquerade as PCI WLAN chipset that conforms to WLAN protocol revision B. Figure 7 shows the location of the Class Code register in the QuickLogic V363EPC chip. All you need to do is to store the correct class code in the serial EEPROM used to initialize contents of QuickLogic V363EPC PCI configuration space registers. This way our BULLDOZER design conforms to the PCI specification nicely.

At this point we can control QuickLogic V363EPC PCI configuration space registers default values. We also have gained the required knowledge to map a PCI expansion ROM chip into the host x86/x64 CPU address space. The thing that's left to design is the way to store BULLDOZER configuration.

Let's assume that we design the BULLDOZER configuration in an NVRAM chip. We can connect the NVRAM chip to SMT310Q PCI carrier board via the TIM interface, just like the PCI expansion ROM chip. The process to design the interconnection is similar to what we have done for the PCI expansion ROM chip. Except that we must expose the chip to code running on the host x86/x64 CPU via different aperture, for example by using PCI-to-Local Aperture 1.

Now, we know everything we need to implement a BULLDOZER hardware. There is one more thing left though, the "kill switch", i.e. the hardware to "destroy" evidence, just in case an operation involving BULLDOZER hardware got botched.

Implementing "Kill Switch": Military-Grade Electronics Speculation

It's a standard procedure to have a kill switch in military electronics. Kill switch is a mechanism that enable you to destroy hardware or software remotely that render the hardware or software beyond repair. The destruction must be sufficient to prevent the software or hardware from being analyzed by anyone. There are several reasons to have kill switch. First, you don't want an adversary to find evidence to implicate you in the event that an operation failed. Second, you don't want your adversary to know your highly valued technology. There are other strategic reasons to have a kill switch, but those two suffice to conduct research into implementing a kill switch in BULLDOZER.

BULLLDOZER is a hardware that consists of several electronic chips "bounded" together via circuit board. Therefore, what we need to know is the technique to destroy the key chips in a circuit board at moment notice. Surely, we turn to physics to solve this problem. From my experience as an overclocker in the past, I knew very well that you can physically destroy a chip by inducing *electromigration* on it.

From Wikipedia: Electromigration is the transport of material caused by the gradual movement of the ions in a conductor due to the momentum transfer between conducting electrons and diffusing metal atoms.

Electromigration in simple terms means: the breakdown of metal interconnect inside a semiconductor chip due to migration of metal ions that construct the metal interconnect to unwanted location. To put it simply, electromigration causes the metal interconnect inside the chip to be destroyed, akin to—but different from—corrosion in metal subjected to harsh environment. In many cases, electromigration can cause unwanted short circuits inside the chip. Figure 13 shows electromigration illustration. As you can see, the copper ion (Cu⁺) moves in opposite direction from the electrons. The copper ion is previously a part of the copper interconnect inside the semiconductor chip. The copper ion "migrate" to different part of the chip due to electromigration.




Figure 13 Electromigration. Courtesy: Wikipedia

There are many ways to induce electromigration on a semiconductor chip. However, I would focus only on one of it: via overvoltage. You can induce electromigration by feeding excess voltage into a chip or into certain parts of a chip.

The problem now is designing a circuit to overvoltage only certain part of a semiconductor chip. Let's assume that we don't want to overvoltage the entire chip, because we have previously assume that BULLDOZER masquerade as PCI WLAN chip. Therefore, you only want to destroy the part that implement the custom stealthy wireless communication protocol, not the part that implement WLAN protocol. If the WLAN function suddenly destroyed, you would rise suspicion on the target.

One of the way to create large voltage inside an electronic circuit is by using the so-called "charge pump". A charge pump is a DC to DC converter that uses capacitors as energy storage elements to create either a higher or lower voltage power source. As far as I know, it's quite trivial to implement capacitor in a semiconductor chip. Therefore, using charge pump to create our required overvoltage source should be achievable. Figure 14 shows one of the charge pump design.




Figure 14 Dickson Charge Pump Design with MOSFETs. Courtesy: Wikipedia

 V_{in} in Figure 14 is the source voltage that's going to be "multiplied". V_{o} in Figure 14 is the output voltage, i.e. a multiplication of the input voltage. As you can see, we can create voltage several times higher than the source voltage inside a semiconductor chip by using a charge pump. I have used charge pump in one of my work in the past. It's made of discrete electronics parts though. The output voltage usually not an exact multiply of the input voltage due to losses in the "multiplier" circuit. I suspect that a charge pump design implemented inside semiconductor chip provides better "voltage multiplication" function compared to discrete ones.

At this point we have all the things needed to create a kill switch. Your circuit design only need to incorporate the charge pump into the design. You can use control register in an FPGA to feed the logic on whether to activate the charge pump or not. You can devise certain byte pattern to turn on the charge pump to destroy your prized malicious logic parts in the PCI add-in card.

There are surely many ways to implement a kill switch. Using a charge pump is only one of the many. I present it here merely out of my "intuition" to solve the problem of creating kill switch. The military surely has more tricks up in their sleeve.

BULLDOZER Implementation Recap

We have gathered all the techniques needed to build a "BULLDOZER-equivalent" hardware in the previous sections. Surely, this is based on our earlier assumption that BULLDOZER masquerade as PCI WLAN add-in card. Now, let's compose a recap, building on those newly acquired techniques and our assumptions in the beginning of this article. The recap are as follows:

- 1. BULLDOZER is a malicious PCI add-in card that masquerade as PCI WLAN card. It implements the correct PCI class code to masquerade as PCI WLAN card.
- 2. BULLDOZER implements PCI expansion ROM because it's the delivery mechanism to "inject" GINSU malware code into the x86/x64 host system.
- 3. BULLDOZER uses SDR to implement a stealthy wireless communication protocol to communicate with OMNIGAT.
- 4. BULLDOZER was designed by using SDR FPGA prototyping tools before being fabricated as ASIC in NSA's semiconductor fab. NSA could use either Altera, Xilinx or internally-developed FPGA prototyping tools.
- 5. BULLDOZER exposes the PCI expansion ROM chip via the XROMBAR in its PCI configuration space. The size of PCI expansion ROM chip exposed through XROMBAR is limited to 16MB, per

- the PCI specification. However, one can devise "custom" code to download additional content from BULLDOZER PCI add-in card to system RAM as needed during the PCI expansion ROM execution. 16MB is already a large space for malicious firmware-level code though.
- 6. It's not yet clear whether one desktop PC implanted with BULLDOZER is enough or more is required to make it work. However, the GINSU extended concept of operation implies that one BULLDOZER-implanted desktop PC is enough.
- A possibility not covered in this article is NSA licensed design for the non-stealthy PCI WLAN
 controller chip part of BULLDOZER from commercial vendor such as Broadcom or Ralink. This
 could shorten BULLDOZER design and implementation timeframe quite a lot.
- 8. Another possibility not covered here is BULLDOZER PCI chip being a multifunction PCI chip. The PCI bus protocol supports single physical PCI controller chip that contains multiple functions. We don't delve into that possibility here though.
- 9. As for the chip marking for the BULLDOZER PCI WLAN controller chip could easily carried out by NSA fab. Well, with the right tool, anyone can even print the "I Love You" phrase as a legitimate-looking chip marking, like the one shown in Andrew "Bunnie" Huang blog: http://www.bunniestudios.com/blog/?p=3435.

That is all about our BULLDOZER implementation recap. It's quite a long journey, but we now have a clearer picture on BULLDOZER hardware implementation.

Closing Thoughts: BULLDOZER Evolution

Given that BULLDOZER was fielded almost six years ago, the present day BULLDOZER cranking out of NSA's fab must have evolved. Perhaps, into a PCI Express add-in card. It's quite trivial to migrate the BULLDOZER design explained in this article into PCI Express (PCIe) though. Therefore, NSA shouldn't have any difficulty to carry-out the protocol conversion. PCIe is compatible to PCI in the logical level of the protocol. Therefore, most of the non-physical design can be carried over from the PCI version of BULLDOZER design explained here. We should look into the "evolved" BULLDOZER in the future.