The Operation Manual for

PμSL 3D-Printer

in portable mode

(McKay 304)

Tianyu Gu
Sicong Shan
Bertoldi Group

April 9, 2015

Contents

1 Device Introduction **3**
1.1 Hardware . . . 3
1.1.1 projector . . . 3
1.1.2 Convex Lens . . . 3
1.1.3 Mirror . . . 4
1.1.4 Linear Stage . . . 4
1.2 Software . . . 4
1.3 Materials . . . 5

2 Normal Operation Procedure **5**
2.1 Preperation . . . 5
2.2 Printing . . . 6

3 Appendix **7**
3.1 Convex lens adjustment . . . 7
3.2 Mirror adjustment . . . 7

1 Device Introduction

The projection microstereolithography (PμSL) a novel freeform 3D micro-fabrication technology which is capable of rapidly fabricating highly complex 3D microstructures in a layer-by-layer fashion. This device use a digital data projector and simple optical components like a convex lens and a mirror. Image will be projected on the photosensitive resin surface, polymerizing liquid resin into a desired 3D solid structure.

This device is a minimum system of projection micro stereolithography (PμSL) 3D-printer, adopting the technology from Howon Jove [1]. The devcie is with low resolution (about 200μm) but very easy operation and large printing area. It's built for testing the characteristic of new materials like curing time, curing depth, fluidity and so on.

In this section, I will introduce the hardware, the software and the materials we used for the device.

1.1 Hardware

1.1.1 projector

The projector is core part of the device. It is connected to the computer and the desktop background will be projected out. Just change the background when you want to be project different images. **Push the power button** to turn on the projector and **double-push** to turn it off. **Rotating the ring** on the projector lens can adjusting the focial length and making the image sharper.

1.1.2 Convex Lens

The convex lens is used to decrease the projected image as well as shorten the image distance. Then image is able to projected on the sample holder fix on the linear stage next to the projector. A light barrier is set in front of the lens. It's used to block the optical path. As the convex lens is well adjusted, it's strongly adviced not to adjust it again in general use. But if you have to, please see the appendix 3.1 at the end of this manual.

[1] http://www.jove.com/video/4457/micro-3d-printing-using-digital-projector-its-application-study-soft

1.1.3 Mirror

The mirror rotate the main optical axis and let the image be just pojected on the sample holder. Note that the mirror should be placed in a specific distance in front of the lens. More details about this will be introduce in section 1.1.4. If you have to adjust the mirror, please see the appendix 3.2.

1.1.4 Linear Stage

The linear stage is another core part. There's a sample holder fixed on it. Rotate the knob clockwise can lower the stage (as well as the sample holder) and counterclockwise upper the stage. The stage is fixed on a bign base and the mirror mentioned above is fixed on it too. So Let's define the *stage assembly* as *stage + base + sample holder + mirror*.

1.2 Software

The portable printer actually do not need any softwares because it meant to be operated manually. But there are still some works on computer.

- When you need to **change the projecter's image output**, you should change the desktop background of the computer by **right click - set background**.

- **An python program is written to help with the operation**. It can give out vocal instructions to assist you to do the right action at the right time. Four parameters should be set everytime you open the program. The *number of layers* you need to print (depends on the height of sample and each layer), the *thickness of each layer*, the *first layer curing time*, the *other layers curing time* (both need to be tested with different materials and also depend on the cross-linking density you need) and the *fluid flowing time* (depends on the fluidity of the material, should be set long enough for the material liquid level covering the whole sample within this time).
  After you finishing inputing the parameters, the vocal assistance will start in 10 seconds.

1.3 Materials

// TODO

2 Normal Operation Procedure

In this section, I will introduce the normal operation precedure for the 3d-printer. Just follow the steps. **To your own safety, always wear gloves before doing anything and wash hands after experiments.**

2.1 Preperation

- **Step 1** : Put the stage in right place. The mirror shall be about $\sim \frac{1}{2}$ inch in front of the lens. Also make sure that the screws on corners are embedded into the holes on the table.

- **Step 2** : Check the position of linear stage. Make sure that the inital position is 5mm as shown in picture.

- **Step 3** : Now **open** the computer. **Set** 'tst.png' as desktop background. **Turn on** the projector and **open** the light barrier by rotating it.

- **Step 4** : **Put** a small piece of black paper on sample holder. **Ajust** the focal length by rotating the ring shown in picture until the image is sharp enough.

- **Step 5** : **Remove** the black paper and **close** the light barrier, now the device is ready for printing.

2.2 Printing

- **Step 1** : **Add** about 20ml of material into a beaker outside. Take away the stage assembly so that the beaker can be put on the marker. Then put the stage assembly back carefully on the marker on table.

- **Step 2** : **Add** material carefully with a small syringe. When the liquid level is just above the printing panel, it's ready to print.

- **Step 3** : **Set** the image you need to print as desktop background. **Open** 'voice.py' and input the parameters. Then Go back to the printer immediately. See more in Sec1.2.

- **Step 4** : Follow the voice instruction. When hearing 'Projecting', **open** the light barrier. After several seconds set in step 1, you will hear 'finish' which means you should **close** the barrier.

- **Step 5** : When hearing 'lower the stage', **lower** the linear stage. The distance depends on the layer height of you sample.

- **Step 6** : **Repeat** step 2 & 3. When hearing 'Fabrication finish', the sample is done. **Take away** the stage and **cut** the sample off carefully with a blade.

- **Step 7** : **Clean up** the sample holder with isopropanol then **put** the stage back.

3 Appendix

3.1 Convex lens adjustment

- The knob X and knob Z can adjust the position of the convex lens in X, Z dimension as well as the rotation in X, Z axis. And the screw Y can adjust the lens' position in Y dimension. You should make sure that the lens is central and vertical with the main optical axis, which means it should be parallel and aligned with the imaging lens of the projector. The distance between convex and imaging lens will make sense to the imaging distance.

3.2 Mirror adjustment

- The knob U, V, W can adjust the position and the rotation in three dimensions. First you should adjust the mirror coarsely and let the image projected on the sample holder. Not being in the center is OK, you can make fine adjustment in the next step.

- Then you need to do the fine adjustment. The knob A can rotate the mirror and let the image move in Y axis. The knob B can rotate the mirror too and let the image move in X axis. So you just need to rotate the knob and make the image pojected in the center of the sample holder.