



# Digital Electronics and Computer Architecture

SCHOOL OF COMPUTER SCIENCE AND ENGINEERING



# Digital Electronics and Computer Architecture

- Examination scheme: Total Marks-150
  - 60 Marks Class Continuous Assessment
  - 50 Marks Laboratory Continuous Assessment
  - 40 Marks End Examination



# **Digital Electronics and Computer Architecture**

#### **Course Objectives:**

By participating in and understanding all facets of this Course a student will be able:

- 1. To learn number systems, Boolean algebra and to introduce the concepts of digital logic families.
- 2. To develop skills for design and implementation of combinational logic circuits.
- 3. To develop skills for design and implementation of sequential circuits
- 4. To understand the functions, characteristics of various components of computer, instruction set, addressing mode of computer architecture and Pipeline Hazards
- 5. To acquire the knowledge of Control unit architecture and Memory Organization



# **Digital Electronics and Computer Architecture**

#### **Course Outcomes:**

On completion of course, students will be able to

- 1. Identify and use the basic logic gates and solve logic equations with various reduction techniques of digital logic circuits.
- 2. Design and implement combinational logic circuits
- 3. Design and implement sequential logic circuits
- 4. Recognize the functions and organization of various blocks of CPU. Describe CPU instruction characteristics used in Pipelining concept and its relevance with Processor's performance.
- 5. Demonstrate computer architecture concepts related control unit and memory



#### **Module 1 Computer Arithmetic:**

• Introduction to digital logic families, Introduction to Number System and Codes, Sign Magnitude representation, 1's and 2's complement, Binary Arithmetic: Addition, Subtraction of signed numbers, multiplication of positive numbers, Integer Arithmetic, Floating point representation and operations – IEEE standard, Boolean Algebra, Logic Gates, Minimization of logic functions using K map (SOP and POS)

#### **Module 2 Combinational Logic Design:**

• Design examples: Arithmetic circuits, Comparator, Code converters, Parity generators and checkers, Arithmetic and Logic Unit, design of adder and fast adder, look ahead carry generator, Implementation of SOP and POS using MUX, DMUX, DECODER.

#### **Module 3 Sequential Logic Design:**

• 1-bit Memory Cell, Flip flops, Conversion of flip flops, Design of ripple counters and synchronous counters, Modulus of the counter, Sequence generator, Lock out condition. Shift registers, Applications of Shift registers (ring and twisted ring counters), Moore and Mealy Models- State diagram, State Tables and Design Procedure, Sequence detector.

5



#### **Module 4 Fundamental of Computer Architectures:**

- Structure and Function, basic operational concepts of bus structures Memory locations and addresses functions. Types of computer units (CPU, Memory, I/O, System Bus), Von Neumann & Harvard architecture, Key characteristics of RISC & CISC.
- ALU: Multiplication Block diagram, Hardware implementation of unsigned binary and signed number, Booth's Algorithm, Division Algorithms (Unsigned Binary).
- Processor organization, Register organization- user visible registers, control and status registers-Case Study 8086. Instruction Cycle- The machine cycle and Data flow. Types of operands, Types of operations, Types of instructions, Addressing modes and Instruction Formats- instruction length, allocation of bits, variable length instructions instruction formats - Case Study- 8086. Processor and Instruction Pipelining, Pipeline Performance, Pipeline Hazards - Structural, Data, Control.



#### **Module 5 Control Unit and Memory System:**

- Hardwired control, Micro-programmed control- micro instructions, micro-program sequencing, wide branch addressing, microinstruction with next address field, prefetching microinstructions and emulation.
- Memory hierarchy, characteristics, Cache Memory- Cache memory principles, Elements of cache design- cache address, size, mapping functions, replacement algorithms, write policy, line size, number of cache, one level and two level cache, performance characteristics of two level cache- locality & operations, main memory and secondary storage. Pentium IV cache organization



#### **List of Assignments:**

- 1. Design and Implement Code Converters using logic gates
- 2. Design and Implement Combinational Logic Design using MUX/Decoder ICs
- 3. Design and Implement asynchronous counter using JK- Flip flop.
- 4. Design and Implement MOD-N asynchronous counter using JK- Flip flop /IC7490.
- 5. Design and implement Synchronous Counter
- 6. Design of a sequence detector
- 7. Write an assembly language program (ALP) to display 2-digit and 4-digit hex numbers using 64- bit assembly language programming
- 8. Write an assembly language program (ALP) to accept 2-digit and 4-digit hex numbers user input using 64- bit assembly language programming.
- 9. Write an assembly language program (ALP) to implement addition and subtraction of 8-bit numbers (Using user input, macro and procedure).
- 10. Write an ALP to perform basic string operations. (length and Reverse)



### **Fundamental of Computer Architectures**

- Computer has two important terminologies associated with it.
  - Computer Architecture
  - Computer Organization
- Computer Architecture:


Describes features of a computer family (notably the instructions) and not the specific implementation, just like architecture of a house- Instruction set, Addressing types.

Computer Organization:

The internal arrangement of computer, which includes the design of the processor, memory and input/output circuits.



# **Fundamental of Computer Architectures**





### **Fundamental of Computer Architectures**


#### • Structure & Function:

- Structure: is the way in which components relate to each other. (interrelated)
- Function: is the **operation** of individual components as part of the structure.



### **Computer Structure**

- Two methods are used in specifying Computer Structure
- Top-Down and Down-Top.




Computer as a Structure includes basic building blocks as:

- **CPU:** Controls the operation of the computer and performs its data processing functions.
- Main memory: Stores data
- I/O: Moves data between the computer and its external environment
- **System interconnection:** Provided for communication among CPU, main memory, and I/O.




# The Computer: Top Down Structure






# **Structure - Top Level**






#### **Structure - ALU**






### **Structure – Control Unit**






### **Computer functions**



- Computer functions are:
  - -Data movement
  - -Data storage
  - -Data processing
  - -Control



### **Computer functions**




- Computer functions are:
  - -Data movement
  - -Data storage
  - -Data processing
  - -Control



#### **Data Movement**

#### • Data movement:


- The computer's operating environment consists of devices that serve as either sources or destinations of data.
- When data are received from or delivered to a device that is **directly connected to the computer**, the process is known as *input-output* (I/O), and the device is referred to as a *peripheral*.
- When data are moved over longer distances, to or from a remote device, the process is known as *data communications*.





### **Storage (Read or Write)**


- Even if the computer is processing data on the fly (i.e., data come in and get processed, and the results go out immediately), the computer must **temporarily store** at least those pieces of data that are being worked on at any given moment.
- Thus, there is at least a **short-term data storage** function. Equally important, the computer performs a **long-term data storage function**.
- Files of data are stored on the computer for subsequent retrieval and update. SUB AL,BL






# **Processing Function**

### Processing from/to storage



### **Processing from storage to I/O**






#### **Functions**

- 1. Data processing: Data may take a wide variety of forms, and the range of processing requirements is broad.
- **2. Data storage:** Even if the computer is processing data on the fly, the computer must temporarily store thus, there is at least a short-term data storage function. Equally important, the computer performs a long- term data storage function. Files of data are stored on the computer for subsequent retrieval and update.
- **3. Data movement:** The computer's operating environment consists of devices that serve as either sources or destinations of data. When data are received from or delivered to a device that is **directly connected to the computer**, the process is known as *input—output (I/O)*, and the device is referred to as a *peripheral*. When data are moved over longer distances, to or from a remote device, the process is known as *data communications*.
- **4. Control:** Within the computer, a control unit manages the **computer's resources** and orchestrates (coordinates) the performance of its functional parts in response to instructions.




• The CPU and memory are normally connected by three groups of connections, each called a bus: data bus, address bus and control bus



Connecting CPU and memory using three buses




- Group of wires which carries information form CPU to peripherals or vice versa
- Single bus structure: Common bus used to communicate between peripherals and microprocessor





- To improve performance multi-bus structure can be used
- In two bus structure : One bus can be used to fetch instruction other can be used to fetch data, required for execution.
- Thus improving the performance, but cost increases





- Address bus: unidirectional: group of wires which carries address information bits form processor to peripherals (16,20,24 or more parallel signal lines)
- **Data bus**: bidirectional : group of wires which carries data information bit form processor to peripherals and vice versa
- **Control bus**: bidirectional: group of wires which carries control signals form processor to peripherals and vice versa




### **Memory Locations and Addresses**

- Main memory is the second major subsystem in a computer. It consists
  of a collection of storage locations, each with a unique identifier, called an
  address.
- Data is transferred to and from memory in groups of bits called words. A word can be a group of 8 bits, 16 bits, 32 bits or 64 bits (and growing).
- If the word is 8 bits, it is referred to as a **byte**. The term "byte" is so common in computer science that sometimes a 16-bit word is referred to as a 2-byte word, or a 32-bit word is referred to as a 4-byte word.



### **Memory Locations and Addresses**






### **Address space**

- To access a word in memory requires an identifier. Although programmers use a name to identify a word (or a collection of words), at the hardware level each word is identified by an address.
- The total number of uniquely identifiable locations in memory is called the address space.
- For example, a memory with 64 kilobytes (16 address line required) and a word size of 1 byte has an address space that ranges from 0 to 65,535.




# Computer Units





#### Von Neumann Machine



Historically there have been 2 types of Computers:

- 1. Fixed Program Computers Their function is very specific and they couldn't be programmed, e.g. Calculators. ADD AL,BL
- **2. Stored Program Computers -** These can be programmed to carry out many different tasks, applications are stored on them, hence the name.

Von Neumann Machine is a general purpose computer with store program concept




#### Von Neumann Machine

- The modern computers are based on a **stored-program concept** introduced by **John Von Neumann**. In this stored-program concept, programs and data are stored in a **separate storage unit called memories** and are treated the same.
- Stored Program concept
- Main memory storing programs (code) and data
- ALU operating on binary data
- Control unit interpreting instructions from memory and executing
- Input and output equipment operated by control unit
- It is also known as **IAS** computer:
- Princeton Institute for Advanced Studies (IAS)
- Completed 1952




# IAS Machine (Institute for Advanced Studies)





#### Harvard Architecture

- Harvard Architecture introduce the separate memory concept.
- Data and instruction memory blocks becomes separate entity.
- Provides dedicated bus for connecting it.
- Separate connection allows to access data and instruction simultaneously.
- It overcomes the bottleneck of Von Neumann Machine with single memory block.





### IAS Machine (Institute for Advanced Studies)

#### Memory buffer register (MBR):

• Contains a word to be stored in memory or sent to the I/O unit, or is used to receive a word from memory or from the I/O unit.

#### Memory address register (MAR): 12 bits

• Specifies the address in memory of the word to be written from or read into the MBR.

#### Instruction register (IR):

• Contains the 8-bit opcode instruction being executed.

#### Instruction buffer register (IBR):

• Holds temporarily the right hand instruction from a word in memory.

#### PC:


• Connected to the internal address bus, the Program Counter holds the address in memory of the next program instruction. Notice that it doesn't connect directly to the memory, but must go via the MAR.


#### Accumulator (AC) and Multiplier Quotient (MQ):

- Hold temporary operands and result of ALU operation.
- Ex. 40bit \*40 bit=80 bit then AC=MSB (40 bit) and MQ=LSB (40 bit)



#### **IAS Machine Instruction Format**






**Instruction word** 

- Opcode is an instruction that tells processor what to do with the variable or data written besides it. Ex MOV: 8BH; LOAD:3AH; STOR:32H; ADD:86H
- Oprand is a variable that stores data(and data can be a memory address or any data that we want to process).
- e.g. **MOV** AL,BL
- here instruction MOV is an opcode. AL & BL are oprands.

Opcode is processor's Operational Code which is designed during the manufacturing of the chip. Which means you can not change the opcode unless you change the HARDWARE design of the processor.






#### Memory:

- 1. LOAD M(X) 500, ADD M(X) 501
- 2. STOR M(X) 500, (Other Instruction) 500=7

500 3 501 4

Ref:: https://www.youtube.com/watch?v=mVbxrQE4f90






#### Memory:

- 1. LOAD M(X) 500, ADD M(X) 501
- 2. STOR M(X) 500, (Other Instruction)

5003

5014





Memory:

1. LOAD M(X) 500,

ADD M(X) 501


2. STOR M(X) 500,

(Other Instruction)

5003

5014s







# Memory: 2. STOR M(X) 500, (Other Instruction) 5003 5014



#### Von Neumann Architecture

#### Harvard Architecture







## **Comparison of Von Neumann and Harvard**

Von Neumann Architecture	Harvard Architecture
It is named after the mathematician and early computer scientist John Von Neumann.	The name is originated from "Harvard Mark I" a relay based old computer.
It required only one memory for their instruction and data.	It required two memories for their instruction and data.
<b>Design</b> of the von Neumann architecture is simple.	Design of Harvard architecture is complicated.
Von Neumann architecture is required only one bus for instruction and data.	Harvard architecture is required separate bus for instruction and data.
Processor needs <b>two clock</b> cycles to complete an instruction. ADD AL,BL	Processor can complete an instruction in one cycle
Low performance as compared to Harvard architecture.	Easier to pipeline, so high performance can be achieve.
It is cheaper.	Comparatively high cost.



#### **RISC and CISC Machines**

#### **Reduced Instruction Set Architecture**

- Focus on hardware simplification
- Uses basic instruction
- Reduce the cycles per instruction at the cost of the number of instructions per program.
- Complex Instruction Set Architecture
- Try to perform functions like load, evaluate and store operation with single instruction. Example Multiply command
- Approach attempts to minimize the number of instructions per program but at the cost of an increase in the number of cycles per instruction.



## **RISC and CISC Machines**

BASIS FOR COMPARISON	RISC (Reduced Instruction Set Computer)	CISC (Complex Instruction Set Computer)
Emphasis on	Software	Hardware
Includes	Single clock	Multi-clock
Instruction-set size	Small	Large
Instruction formats	fixed (32-bit) format	Varying formats (16-64 bits each instruction).
Addressing modes used	Limited to 3-5	12-24
General purpose registers used	32-192	8-24 al bl, cl
Memory inferences	Register to register	Memory to memory
Cache design	Split data cache and instruction cache.	Unified cache for instructions and data.
Clock rate	50-150 MHz	33-50 MHz
CPU Control	Hardwired without control memory.	Microcoded using control memory (ROM).



## **RISC and CISC Machines**


BASIS FOR COMPARISON	RISC (Reduced Instruction Set Computer)	CISC (Complex Instruction Set Computer)
Pipeline	High Pipelined	Not or less Pipelined
Data Transfer	Register to Register	Memory to Memory
Instruction refer to the Memory	Only load and store	All
Used in	Portable devices, Apple iPod, Smart phone, Tablets	Desktop, Laptops
Set of instructions	Highly optimized	Less optimized
RAM is required to store instruction	High	Very less
Instruction decoding logic	Simple	Complex
Program length	Large	Small
Example: Multiply 2 Numbers	LW A, 203 ;Load LW B, 502 ;Load MULT A,B SW 203,A ;Store	MULT 203,502




## Arithmetic and Logical Unit




## ALU Inputs and Outputs








#### Block Diagram: Hardware for Addition and Subtraction






$$0101 = 5 \\ + 1110 = -2 \\ 10011 = 3$$


$$1001 = -7 + 0101 = 5 1110 = -2 (a) (-7) + (+5)$$

$$1100 = -4 
+1111 = -1 
11011 = -5 
(d) (-4) + (-1)$$




## Multiplication (Unsigned Binary Integers 11\*13=143)







## Hardware Implementation of Unsigned Binary Multiplication Operation





## Booth's Algorithm (Signed Number Multiplication)


- > Used to reduce number of operations
- For signed multiplication
- ➤ Generate 2n bit product
- Treats positive and negative numbers uniformly (called 2s compliment method)
- Recoding of Multiplier is performed
- ➤ Rules of recording Use implied zero at LSB and start scanning LSB to MSB

Rules for recoded number					
0-1	-1				
1-0	1				
0-0	0				
1-1	0				

```
1.0011100 = Recoded 0 1 0 0 - 1 0
```

$$2.\ 101100\ 0 = Recorded\ -11\ 0\ -1\ 0\ 0$$







#### Booths Algorithm using Tabular Method.


**Example** Consider the multiplication of the two positive numbers M = 0111 (7) and Q = 0011 (3) and assuming that n = 4. The steps needed are tabulated below.

M	$\boldsymbol{A}$	Q	Q(-1)		
0111	0000	0011	0	Initial value	
0111	1001	0011	0	A = A - M	
0111	1100	1001	1	ASR	End cycle #1
0111	1110	0100	1	ASR	End cycle #2
0111	0101	0100	1	A = A + M	
0111	0010	1010	0	ASR	End cycle #3
0111	0001	0101	1	ASR	End cycle #4
	+	21 (correct r	esult)		



	Booth's Algorithm (Signed Number) 19*12=228															
Multiplican	d 1	9	Binary= <b>010011</b>													
Two's Con	npleme	nt of N	/lultiplicand = 101101													
		_	_													
Multiplier	1	2	Binary- 001100													
Poseded Mul	tiplior is	- 0.0	1100 0	0 - In	nplied	7ero				0	1	0	0	1	1	19
Recoded Mul Recoded Mul				0-111	ipiieu	Leiu				0	1	0	-1	0	0	12
Necoded Widi	tiplier is									0		-		-	0	12
			Sign Extension	0	0	0	0	0	0	0	0	0	0	0	0	
			-	0	0	0	0	0	0	0	0	0	0	0	+	
			Two's Complement of Multiplicand	1	1	1	1	1	0	1	1	0	1	+	+	
				0	0	0	0	0	0	0	0	0	+	+	+	
				0	0	0	1	0	0	1	1	+	+	+	+	
				0	0	0	0	0	0	0	+	+	+	+	+	
			Carry		1	1	_		1	1	_		_	_	_	
	Ignore fir	nal carry	1	0		0	0	1	1	1	0	0	1	0	0	
				2 <sup>11</sup>	2 <sup>10</sup>	29	2 <sup>8</sup>	27	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	$2^3$	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>	
				0	0	0	0	128	64	32	0	0	4	0	0	228








Booth's Algorithm (Signed Number) : (-13)*(-20)=260															
Multiplicand	-13	Binary - 001101													
Two's Comple	ment of Multip	olicand = 110011													
Two's Comple	ement of 01	10011 = 001101													
Multiplier	-20	Binary- 010100													
Two	o's Complemen	t of 20= 101100													
Recoded N	1ultiplier is =	101100 <b>0</b>			0 - Imp	lied Zer	o		1	1	0	0	1	1	-13
Recoded I	Multiplier is = -	-110-100							-1	1	0	-1	0	0	-20
		Sign Extension													_
			0	0	0	0	0	0	0	0	0	0	0	0	
			0	0	0	0	0	0	0	0	0	0	0	+	
		Two's Complement of	0	0	(	_	0	0	1	1	0	1			
		Multiplicand	0	0	0	0	0	0	1	1	0	1	+	+	
			0	0	0	0	0	0	0	0	0	+	+	+	
			1	1	1	1	0	0	1	1	+	+	+	+	
			0	0	0	1	1	0	1	+	+	+	+	+	
											_				
		Carry	1	1	1	1	1	0	1						
	Discard Carry 1			0	0	1	0	0	0	0	0	0	0	0	
					2 <sup>9</sup>	28	27	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>	
					0	256	0	0	0	0	0	4	0	0	260



## Processor Organization




## 8086 Microprocessor





## Processor Organization: CPU with System Bus




To understand the organization of the processor, let us consider the requirements placed on the processor, the things that it must do:

- Fetch instruction: The processor reads an instruction from memory (register, cache, main memory).
- **Interpret instruction:** The instruction is decoded to determine what action is required.

- Fetch data: The execution of an instruction may require reading data from memory or an I/O module.
- Process data: The execution of an instruction may require performing some arithmetic or logical operation on data.
- Write data: The results of an execution may require writing data to memory or an I/O module.



## **CPU Internal Structure**






## **Register Organization**

A computer system employs a memory hierarchy. At higher levels of the hierarchy, memory is faster, smaller, and more expensive (per bit). Within the processor, there is a set of registers that function as a level of memory above main memory and cache in the hierarchy. The registers in the processor perform two roles:

- User-visible registers: Enable the machine- or assembly language programmer to minimize main memory references by optimizing use of registers.
- Control and status registers: Used by the control unit to control the operation of the processor and by privileged, operating system programs to control the execution of programs.





## **Register Organization**


1. User-visible registers: General Purpose, Segment Registers, Index Pointers and Stack Pointer, Condition Codes (Flag Register)



- 2. Control and status registers (Not Visible to user):
- Program Counter (PC)
- Instruction Decoding Register (IR)
- Memory Address Register (MAR)
- Memory PSW (Program Status Word)
- Buffer Register (MBR)
- Condition Codes + other status information
- The current state of processor is stored in a register called Processor Status Word (PSW).
- Six are status flags and three are control flags.



## Instruction Cycle



an instruction cycle includes the following stages:

- Fetch: Read the next instruction from memory into the processor.
- Execute: Interpret the opcode and perform the indicated operation.
- **Interrupt:** If interrupts are enabled and an interrupt has occurred, save the current process state and service the interrupt.

The Indirect Cycle: if indirect addressing is used, then additional memory accesses are required.




## **Instruction Cycle**

- It is the time in which a single instruction is fetched from memory, decoded, and executed.
- An Instruction Cycle requires the following sub cycle:
- 1.Fetch: Read next instruction from memory into the processor
- 2.Indirect Cycle (Decode Cycle): May require memory access to fetch operands, therefore more memory accesses.
- 3.Interrupt: Save current instruction and service the interrupt 256 (int 0-int 255) 20=1MB=256\*4 CS 2 IP 2 IVT 00000 FFFFFH
- 4.Execute: Interpret the opcode and perform the indicated operation




## Indirect Cycle

- May require memory access to fetch operands.
- Indirect addressing requires more memory accesses.
- Can be thought of as additional instruction sub cycle.





## **Data Flow**



The exact sequence of events during an instruction cycle depends on the design of the processor. Here indicate in general terms what must happen.

Let us assume that a processor that employs a memory address register (MAR),

a memory buffer register (MBR), a program counter (PC), and an instruction register (IR).


During the *fetch cycle*, an instruction is read from memory. As shown in fig.

The flow of data during this cycle. The PC contains the address of the next instruction to be fetched. This address is moved to the MAR and placed on the address bus.

The control unit requests a memory read, and the result is placed on the data bus and copied into the MBR and then moved to the IR. Meanwhile, the PC is incremented by 1, preparatory for the next fetch.



## **Data Flow**



Once the fetch cycle is over, the control unit examines the contents of the IR to determine if it contains an operand specifier using indirect addressing. If so, an *indirect cycle* is performed. As shown in Figure, this is a simple cycle. The rightmost

N bits of the MBR, which contain the address reference, are transferred to the MAR. Then the control unit requests a memory read, to get the desired address of the operand into the MBR.

The fetch and indirect cycles are simple and predictable.

The *execute cycle* takes many forms; the form depends on which of the various machine instructions is in the IR. This cycle may involve transferring data among registers, read or write from memory or I/O, and/or the invocation of the ALU.



# Addressing Modes



## Why Addressing Modes?

- An addressing mode specifies how to calculate the effective memory address of an operand by using information held in registers and/or constants contained within a machine instruction.
- Ex. Immediate addressing Mode:
- MOV DL, 08H
- MOV CX, 4929 H



## Addressing Modes

<ol> <li>Register Addressing</li> <li>Immediate Addressing</li> </ol>	Group I: Addressing modes for register and immediate data
<ul> <li>3. Direct Addressing</li> <li>4. Register Indirect Addressing</li> <li>5. Based Addressing</li> <li>6. Indexed Addressing</li> <li>7. Based Index Addressing</li> <li>8. String Addressing</li> </ul>	Group II: Addressing modes for memory data
9. Direct I/O port Addressing 10. Indirect I/O port Addressing	Group III: Addressing modes for I/O ports
11. Relative Addressing	Group IV: Relative Addressing mode
12. Implied Addressing	Group V: Implied Addressing mode




# Pipelining




## What is Pipelining?

- Laundry Example
- 1. Washer takes 30 minutes
- 2. Dryer takes 40 minutes
- 3. Folder takes 20 minutes









Dry 40 min




fold 20 min

Total= 1Hr 30 min / 90 min



### What is Pipelining?




Sequential laundry takes 6 hours for 4 loads (90 min+90 min + 90 min + 90 min = 360 Min)

If they learned pipelining, how long would laundry take?



# What is Pipelining?






### **Instruction Pipelining**

#### Instruction processing is subdivided:

- Fetch and Execute instruction
- 1st Stage Fetch an instruction and buffers it.
- 2<sup>nd</sup> Stage—Temporarily free until first stage passes it the buffered instruction.
- While the second stage is executing the instruction, the first stage fetches and buffers the next instruction.
- Instruction prefetch or fetch overlap.
- Purpose?→ To speed up instruction execution.



### **Two-Stage Instruction Pipeline (8086)**






### **Instruction Processing**

- 1. Fetch instruction (FI)
- 2. Decode instruction (DI)
- 3. Calculate operands (CO)
- 4. Fetch operands (FO)
- 5. Execute instruction (EI)
- 6. Write operand (WO)
- Successive instructions in a program sequence will overlap in execution.




#### Timing Diagram for Instruction Pipeline Operation





### **Instruction Pipeline**



- 1. FI: Fetch instruction
- 2. DI: Decode instruction
- **3. CO**: Calculate operands
- **4. FO**: Fetch operands
- 5. EI: Execute instruction
- **6. WO:** Write operan

MOV AL,BL

30 JNZ 1000h


**I15 1000:SUB BL,CL** 

1500 JZ 2000

**2000: ADD AL,BL** 



# Alternative Pipeline description



(a) No branches

-										
	FI	DI	CO	FO	EI	wo				
1	11	8 8								
2	12	11		-						
3	13	12	11							
4	14	13	12	11						
5	15	14	13	12	11					
6	16	15	14	13	12	11	l			
7	17	16	15	14	13	12				
8	115					13				
9	116	115								
10		116	115							
11			116	115						
12				116	115					
13					116	115				
14						116				
	(b) With conditional branch									



### Pipeline Hazards


- Pipeline hazards are situations that prevent the next instruction in the instruction stream from executing during its designated clock cycles.
- Any condition that causes a **stall** in the pipeline operations can be called a hazard.
- In the design of pipelined computer processors, a **pipeline stall** is a delay in execution of an instruction in order to resolve a hazard.

- Structural Hazard
- Data Hazard
- Control Hazard



#### Structural Hazard

**Resource (Structural) Hazards -** Two (or more) instructions in pipeline need same resource. Executed in serial rather than parallel for part of pipeline Also called *structural hazard* 





#### **Data Hazard**

#### • Read after Write (RAW), or true dependency

- -An instruction modifies a register or memory location  $\begin{array}{l}
  A \leftarrow 3 + A \\
  B \leftarrow 4 \times A
  \end{array}$
- -Succeeding instruction reads data in that location
- -Hazard if read takes place before write complete
- Write after Read (WAR), or <u>antidependency</u>
  - -An instruction reads a register or memory location MUL BX, AX
  - -Succeeding instruction writes to location
  - -Hazard if write completes before read takes place
- Write after Write (WAW), or <u>output dependency</u>
  - -Two instructions both write to same location
  - -Hazard if writes take place in reverse of order intended sequence.



#### Data Hazard

- We must ensure that the results obtained when instructions are executed in a pipelined processor are identical to those obtained when the same instructions are executed sequentially.
- Hazard occurs

$$A \leftarrow 3 + A$$
  
 $B \leftarrow 4 \times A$ 

No hazard

$$A \leftarrow 5 \times C$$
  
 $B \leftarrow 20 + C$ 

- When two operations depend on each other, they must be executed sequentially in the correct order.
- Another example:

Mul R2, R3, R4 Add R5, R4, R6



# Data Hazard Diagram

- Conflict in access of an operand location
- Two instructions to be executed in sequence
- > Both access a particular memory or register operand
- > If in strict sequence, no problem occurs

	Clock cycle												
	1	2	3	4	5	6	7	8	9	10			
ADD EAX, EBX	FI	DI	FO	EI	WO								
SUB ECX, EAX		FI	DI	Idle		FO	EI	WO					
13			FI			DI	FO	EI	WO				
14						FI	DI	FO	EI	wo			



#### Control Hazard (Branch Hazard)

#### Pipeline makes wrong decision on branch prediction.

- Brings instructions into pipeline that must subsequently be **discarded** (CALL, JUMP, LOOP, JC, JNC etc)
- Dealing with Branches
- -Multiple Streams
  - -Prefetch Branch Target
  - -Loop Buffer
  - -Branch Prediction
  - -Delayed Branching