



Kush Patel


HARDWARE PRODUCTION TECH

***Sensor: VL53L1X Time-of-Flight
Distance Sensor
I²C Address: 0x29***

```
File Edit Tabs Help
pi@raspberrypi:~ $ sudo i2cdetect -y 1
   0  1  2  3  4  5  6  7  8  9  a  b  c  d  e  f
00:                -- -- -- -- -- -- -- -- -- --
10: -- -- -- -- -- -- -- -- -- -- -- 1c -- -- --
20: -- -- -- -- -- -- -- 29 -- -- -- -- -- -- --
30: -- -- -- -- -- -- -- -- -- -- -- -- -- -- --
40: -- -- -- -- -- -- UU -- -- -- -- -- -- -- --
50: -- -- -- -- -- -- -- -- -- -- -- 5c -- -- 5f
60: -- -- -- -- -- -- -- -- -- 6a -- -- -- -- --
70: -- -- -- -- -- -- -- -- -- -- -- -- -- -- --
pi@raspberrypi:~ $
```

SUCCESSFUL I²C DETECTION SHOWING VL53L1X RESPONDING AT 0X29

VL53L1X Live Readings




A screenshot of a terminal window with a menu bar containing 'File', 'Edit', 'Tabs', and 'Help'. The terminal displays a series of 'Distance: ' followed by a numerical value and 'mm'. The values fluctuate between 0 and 10 mm, with some values appearing multiple times in a row.

```
File Edit Tabs Help
Distance: 1 mm
Distance: 1 mm
Distance: 1 mm
Distance: 1 mm
Distance: 1 mm
Distance: 1 mm
Distance: 1 mm
Distance: 0 mm
Distance: 2 mm
Distance: 2 mm
Distance: 1 mm
Distance: 1 mm
Distance: 2 mm
Distance: 2 mm
Distance: 1 mm
Distance: 1 mm
Distance: 2 mm
Distance: 2 mm
Distance: 4 mm
Distance: 4 mm
Distance: 4 mm
Distance: 4 mm
Distance: 9 mm
Distance: 10 mm
Distance: 10 mm
Distance: 0 mm
Distance: 0 mm
Distance: 3 mm
Distance: 3 mm
Distance: 3 mm
```

VL53L1X CONTINUOUSLY MEASURING DISTANCE IN MILLIMETERS
THROUGH I²C (ADDRESS 0X29)

VL53L1X Mounted to Hardware Case



VL53L1X MOUNTED SECURELY TO THE HARDWARE CASE FOR
STABLE DISTANCE MEASUREMENT.