Documentation for transient pore pressure model for predicting slope failure constrained by remote sensing data

Simon M. Mudd, Boris Gailleton, School of Geosciences, University of Edinburgh (b.gailleton@sms.ed.ac.uk)

Table of Contents

| 1. Foreword | 1 |
|--|----|
| 2. Introduction | 2 |
| 2.1. Parameters | 2 |
| 2.2. Global approach | 2 |
| 2.3. Model output | 2 |
| 2.3.1. For a single simulation | 3 |
| 2.3.2. For Monte-Carlo Runs | 3 |
| 3. Installation | 4 |
| 3.1. The code | 4 |
| 3.2. Compiling the model | 4 |
| 3.3. Installing the python package | 4 |
| 3.3.1. Optional: Getting a python environment with conda | 4 |
| 4. Preprocessing the precipitation data | 6 |
| 5. Running the model for a single soil column | 7 |
| 5.1. Simulation | 7 |
| 5.2. Model outputs | 8 |
| 5.3. Spatial analysis | 8 |
| 6. Monte Carlo analysis to constrain the model | 10 |
| 6.1. Building the model | 10 |
| 6.2. Running the simulation | 10 |
| 6.3. Outputs | 11 |
| 6.4 Performance | 12 |

Chapter 1. Foreword

This document describes both installation and running of a slope stability model developed for combining remote sensing and rainfall data. It also explains the outputs that can be used to explore model results.

Chapter 2. Introduction

WP 4 aims to evaluate the performance of using remote sensing data to detect and anticipate landslide activity. Simulating slope failure involves a very high degree of uncertainty. A common approach consists in modelling steady state pore pressure in response to a threshold rainfall event to generate static safety maps. An alternative approach is to simulate the transient pore pressure to consider the time-evolution of the effect of precipitation and soil water content on slope stability. Such a model is highly case-dependent and requires a significant amount of expensive and time-consuming in-situ monitoring of soil hydraulic, mechanical and hydrogeologic features. The aim of this code is to use an already-monitored site to apply the Iverson (2000) model and compare the performance of the model constrained with in-situ data with the model constrained with remote-sensing derived data. The following documentation proposes a protocol to run the model from the different data sets and how to visualise and explore the outputs. The core of the modelling code is written in C++ to ensure computational efficiency. The automation for multiple simulations and I/O management is written in python.

2.1. Parameters

A number of parameters are required by model:

- The model needs precipitation data input to simulate the transient pore pressure evolution in the modeled soil column. This data has to be formated as *precipitation intensity* in length unit per time unit, preferably in seconds.
- Hydraulic parameters from the modelled soil: the hydraulic diffusivity (*D0*), the Hydraulic conductivity (*Ksat*), the steady-state infiltration rates (*Iz/Kz*).
- The depth of the water table and of the substrate.
- The mechanical soil properties, soil cohesion (soil capacity to resist to motion), friction angle, weight of soil and weight of water.
- The landscape property: topographic slope.
- The model resolution.

2.2. Global approach

For a specific site, neither remote-sensed nor in-situ data would constrain discrete values for each parameters. We therefore run the model using a Monte Carlo sampling schemes on range of possible parameters. In the case of testing the model against in-situ data, ranges of parameters are determined by different mechanical and hydraulic tests. Calibration is achieved with field observation of ground motion. In the case of testing the model against remote-sensed constraints, the ranges of parameters are suggested from general ranges in the literature and calibrating failures are recorded from InSAR data that detect ground motion.

2.3. Model output

The main applicable output of the model is a factor of safety (FS) for a soil columns that determines

when the slope is subjected to fail. This factor of safety is an absolute value defined by equation 18 in Iverson (2000). It suggests failure when the FS is \leftarrow 1. This factor of safety is calculated for a given time and depth of the modelled soil column, driven by a rainfall time series.

2.3.1. For a single simulation

The models outputs table-like csv files which include the factor of safety and the pore pressure as a time series. It also can output factor of safety maps for a given time and a given Digital Elevation Model (DEM) to identify the area at risk.

2.3.2. For Monte-Carlo Runs

The python tools control the Monte-Carlo runs of the simulations. Because of the significant number of runs involved, all the csv outputs are concatenated into a hdf5 data file, which is easily readable from python. Time series of factor of safety for all the simulations can be synthesised into a distribution of detected landslide in time. These can be correlated with calibration data (e.g. observed or measured ground motion from InSAR or in-situ monitoring) to determine "successful" simulations. Once "successful" runs have been defined, visualisation of the parameter sets that leaded to failure detection can be used to constrain the model.

Chapter 3. Installation

All the code has been developed, tested and run on UNIX platform. It requires uses of a C++ compiler and a python 3 environment.

3.1. The code

The code has been developed within the open-source [LSDTopoTools]https://lsdtopotools.github.io/research software suite. The deliverable has been packaged into a zip file with the final report and contains all the code required for running the analysis.

3.2. Compiling the model

The C++ code requires compilation into an executable before use. This can be done with the GNU g++ compiler, installed in most UNIX and IOS distributions. The Analysis_driver folder in the root folder contains a make file that automates the compilation. Navigate to the directory where this make file in a terminal window and compile with:

```
make -f iverson_model.make
```

It generates an executable file named iverson_model.exe in the same folder and is ready to be used.

3.3. Installing the python package

The python package can be installed in any python environment satisfying the following dependencies: numpy, scipy, pandas, pytables and matplotlib. The package is downloaded with the github repository in the folder python_tools and can be installed in the python environment using pip install . in the python_tools folder.

3.3.1. Optional: Getting a python environment with conda

If it is required to install a python environment from scratch, miniconda environment manager is an easy, clean and open-source solution. It can be downloaded from [here]https://repo.continuum.io/miniconda/. Choose any python 3 installer compatible with your operating system. Once installed it offers a clean method to manage different python environments with different combinations of packages installed. Once install, run the following command to create an environment:

```
conda create -n iverson_python
```

This creates a python environment named iverson_python. Whenever you start a session you can activate this environment with:

conda activate iverson_python

When the environment has been successfully activated if (iverson_python) is stated at the beginning of the command line. After the first activation, the dependencies can be installed with:

conda install -c conda-forge numpy scipy pandas pytables matplotlib

This only needs to be run once. All installed packages will remain available at the reactivation of the environment.

Chapter 4. Preprocessing the precipitation data

Precipitation data drives the transient pore pressure model. The data can be from local instruments, global datasets or simulations. The data needs to be in a csv (Comma-separated-values) files containing the following columns:

```
duration_s,intensity_mm_sec
```

Where duration_s represent a duration in seconds and intensity_mm_sec is the corresponding precipitation intensity in mm per seconds. The intensity column usually requires unit conversion from common datasets. For example, 15 mm of rain in 3 hours becomes 15/10800=0.001389 mm/second.

Chapter 5. Running the model for a single soil column

The following instructions describe how to run the code and visualise the output for a single soil column simulated.

5.1. Simulation

Once compiled, the C++ executable can be run from the command-line and need to be directed to a **parameter file**. The **parameter file** is a text file containing a series of values telling the C++ model what parameters to use. The parameter files can be written as follow in a text file:

```
# This is a parameter file for the Iverson model
# Lines beginning with # are comments and are not read by the softwares
# The read path represent the path where the data will be read
read path: /path/to/file/
# The write path represent the path where the data will be written (Can be the same
than the read path)
write path: /path/to/file/
# Write fname is the prefix of the written files
write fname: 20150711_20160809_filtered
# Name of the csv file containing the preprocessed precipitation data
rainfall_csv: preprocessed_data.csv
# Parameters for the models
D 0: 0.000005
K sat: 0.00000005
d: 2
Iz_over_K_steady: 0.2
alpha: 0.51
friction_angle: 0.38
cohesion: 12000
weight_of_soil: 19000
weight_of_water: 9800
depth_spacing: 0.1
n_depths: 35
#end of file
```

The executable needs to know the path and the name of the parameter file to read them correctly. From a terminal in the folder containing the compiled executable, the following command will run the model:

./iverson_model.exe /path/to/the/parameter/file/ name_of_the_parameter_file.param

Note that the parameter file is a text file and can be saved with any extensions (e.g., .param, .driver). The following parameters can be provided to the model.

| Parameter | Description |
|------------------|--|
| rainfall_csv | the name of the preprocessed csv file with the rainfall time series. |
| D_0 | Hydraulic diffusivity |
| K_sat | Hydraulic conductivity |
| d | Depth of water table |
| Iz_over_K_steady | Steady-state infiltration rate |
| alpha | Topographic slope |
| friction_angle | Critical friction angle for the soil |
| cohesion | Soil cohesion |
| weight_of_soil | Volumic weight of the soil |
| weight_of_water | Columic weight of the water |
| depth_spacing | Model resolution |
| n_depths | Number of discretisation |

5.2. Model outputs

The C++ model produces 6 csv files containing the evolution of various characteristics of the soil column. Four csv files contain the time series of the different components of the Factor of Safety (FS) functions of time and depth. The independent components of FS are described in equations 28 (a,b and c) of Iverson (2000) and their time series are in files XXX_time_series_depth_Fcomp.csv , where XXX is the write fname in the parameter file and Fcomp the corresponding component. It also output the final FS as well as the evolution of the transient pore pressure (Psi) in the file time_series_depth_Psi.csv. All of these files have the same structure:

- The first column is Depth
- All the following columns are the corresponding values for each simulated time, where the first row is time.

5.3. Spatial analysis

Each model run therefore predicts the evolution of the factor of safety for a single soil column through time. Once a time has been identifies, a raster can be fed to the model to generate a risk map. The raster, assumed to be represented by the simulations, will be downsampled, the slope will be calculated and factor of safety is calculated for each soil column. The following lines can be added to the parameter file to enable the spatial analysis:

full_1D_output: false
spatial_analysis: true
reload_alpha: false
resample_slope: true
resample_slope_res: 6
topo_raster: insar_area_PP
alpha_to_reload:
polyfit_window_radius: 1
n_threads: 4
time_of_spatial_analysis: 19818000

Where full_1D_output: false disables other ouputs, spatial_analysis: true enables the analysis, reload_alpha: false enable/disable the reloading of previously calculated slope map, resample_slope determines if the raster is down-sampled before slope calculation (for speed purposes) with a new resolution detailed with resample_slope_res, topo_raster is the name of the raster witout its extension (it has to be an ENVI bil file), polyfit_window_radius is the precision of slope calculation, n_threads is the number of threads to use for multithreading and time_of_spatial_analysis is the identify time on the precipitation time series. It produces a raster with the factor of safety for each soil column.

Chapter 6. Monte Carlo analysis to constrain the model

The Monte-Caro analysis requires running a large (>10000) number of simulations in order to produce representative results. The software uses python as scripting language to automate the simulations and save/load/process the data. The installation section explains how to set up a python environment. The environment must be used to run python scripts. The Monte Carlo analysis is designed to define ranges of each of the 9 parameters in the model. It does this by running simulations that randomly sample these parameters within a predifined parameter space, and testing the resulting factor of safety time series against observed ground motion. The advantage is that running all the combinations would take several years of computation, whereas random sampling covers most of the spectrum in significantly less simulations.

6.1. Building the model

The model needs to be initialised with ranges of parameters as follow:

Most of the parameters are self-explanatory: range_X define the minimum and maximum values for the corresponding parameter; OMS_X define the precision step of the random sampling (D_0 and Ksat are in log space); n_depths defines the number of depth to be investigated, program points to the path+name of the exe file (compiled model); path_to_rainfall_csv and rainfall_csv points to the rainfall csv file and finally path_to_root_analysis points to the root directory of the analysis (many subdirectories may be created below).

6.2. Running the simulation

To run the simulation, simply add the following line of code on the same script:

```
my_simulation.run_MonteCarlo(failure_time_s = 540460, n_proc = 4, n_tests = 1000)
```

Where failure_time_s is an optional feature if a specific time is chased: it would add a data to the output expressing the time of first failure compare to that one (it does not affect the other outputs);

n_proc defines the number of processors to be used in parallel: the code is pleasingly parallel which means all the tasks are independent from each others and can be run at the same time; n_test defines the number of simulations to run. For example, we ran 70000 simulation on 24 cores on our server with a broad range of parameter taken from literature with the following script:

```
from plot_iverson_lsdtt.sensitivity_analysis import MonteCarloIverson
program =
"/home/s1675537/PhD/DataStoreBoris/dev_LSD/LSDTT_Development/src/Analysis_driver/Ivers
on.exe"
MySim = MonteCarloIverson(program = program, path to rainfall csv = "./", rainfall csv
= "preprocessed_data.csv", path_to_root_analysis = "./test_from_in_situ/",
depth\_spacing = 0.1,
    n_{e} = 32, range_{D_0} = [5e-7, 5e-5], range_{E} = [5e-10, 5e-10]
7],range_Iz_over_K_steady = [0.1,0.8], range_d = [1,3], range_alpha = [0.5,1.1],
range_friction_angle = [0.3,0.5],
        range cohesion = [15500,16500], range weight of soil = [15000,20000],
range_weight_of_water = [9800,9800],
        OMS_D_0 = 0.05, OMS_Ksat = 0.05, OMS_d = 0.05, OMS_alpha = 0.05,
OMS friction angle = 0.03, OMS cohesion = 100, OMS weight of soil =
100,OMS_weight_of_water = 100, OMS_Iz_over_Kz = 0.05)
MySim.run_MonteCarlo(failure_time_s = 0, n_proc = 24, n_tests = 200000, save_to_db =
True)
```

6.3. Outputs



While the model is running, a significant amount of temporary output data will be generated. This is due to the fact that the model write some results to the disk before appending them every n_proc runs in a final file. Do not delete it as the software does it automatically.

The most important output is a csv file (can be open by any common software) named failure_global.csv. It contains a synthesis of each simulation with (i) the parameters tested and (ii) the time of failure. It allowed us to produce the histograms of time of failure and isolate successful parameters.

Another file is generated containing more details about each run (time series): because of the significant amount of data produced by the simulations, the software uses the hdf5 data structure via pandas to manage it. We strongly advice to use pandas in python to explore the data. One can open a file with the list of keys as follow:

```
import pandas as pd

glob = pd.HDFStore("test_from_in_situ/db_of_failure.hd5")
print(glob.keys())
glob.close()
```



To access the dataframe of one single run and potentially save it for more data mining:

```
import pandas as pd

glob = pd.HDFStore("test_from_in_situ/db_of_failure.hd5")

df = glob["name_of_my_key"]

df.to_csv("/path/plus/name.csv", index = False)

glob.close()
```

6.4. Performance

Assessing performance can be difficult: due to the high number of simulations run within the Monte Carlo framework, there are many unsucessful similations, but the general pattern still highlights the failure quite well. The following code produces first order performance metrics based on the file produced by the python package. It takes the time of observed failures and an interval to calculate the ratio of successful simulations. It can be used to isolate the successful combination of parameters that lead to real failures.

```
import pandas as pd
# Load the dataframe
df = pd.read_csv("failure_global.csv")
# Gater the interval
sttest = []
endtt = []
interval = 3600 * 24 * 5 # 5 days to seconds
for i in [1.1e7,1.48e7,1.85e7,2e7]: # this array contains the times of observed
failure in seconds
    sttest.append(i - interval)
    endtt.append(i + interval)
# number of elements
n_total = df.shape[0]
# Sorting my failure times to isolate the successful ones
lsofdf = []
for i in range(len(sttest)):
    lsofdf.append(df[(df["first_failure"]>sttest[i]) & (df["first_failure"]<endtt[i])]</pre>
)
QDF = pd.concat(lsofdf)
# printing the results
print("Total number of run: %s " %(n_total))
print("Total number of successful run: %s " %(QDF.shape[0]))
print("Total number of run showing constant failure: %s "
%(df[df["first_failure"]==0].shape[0]))
print("Ratio of success: %s " %(QDF.shape[0]/n_total ))
print("Ratio of success ignoring 0: %s " %( QDF.shape[0] / (
df[df["first_failure"]!=0].shape[0]) ) )
```