**MODULE-3** 


# **MEMORY SYSTEM:**

**Syllabus:** Basic Concepts, Semiconductor RAM Memories, Read Only Memories, Speed, Size, and Cost, Cache Memories – Mapping Functions, Replacement Algorithms, Performance Considerations, Virtual Memories, Secondary Storage.

### 1.BASIC CONCEPTS

The maximum size of the Main Memory (MM) that can be used in any computer is determined by its addressing scheme. For example, a 16-bit computer that generates 16-bit addresses is capable of addressing upto  $2^{16} = 64$ K memory locations. If a machine generates 32-bit addresses, it can access upto  $2^{32} = 4$ G memory locations. This number represents the size of address space of the computer.

- If MAR is k-bits long then
  - $\rightarrow$  memory may contain upto  $2^{K}$  addressable-locations
- If MDR is n-bits long, then
  - → n-bits of data are transferred between the memory and processor.
- The data-transfer takes place over the processor-bus (Figure 8.1).
- The processor-bus has
  - 1) Address-Line
  - 2) Data-line &
  - 3) Control-Line (R/W", MFC Memory Function Completed).
- The Control-Line is used for coordinating data-transfer.
- The processor reads the data from the memory by
  - ightarrow loading the address of the required memory-location into MAR and
  - $\rightarrow$  setting the R/W" line to 1.



- The memory responds by
  - → placing the data from the addressed-location onto the data-lines and
  - $\rightarrow$  confirms this action by asserting MFC signal.
- Upon receipt of MFC signal, the processor loads the data from the data-lines into MDR.
- The processor writes the data into the memory-location by
  - $\rightarrow$  loading the address of this location into MAR &
  - $\rightarrow$  setting the R/W" line to 0.

#### **Memory Access Times: -**

It is a useful measure of the speed of the memory unit. It is the time that elapses between the initiation of an operation and the completion of that operation (for example, the time between READ and MFC).

**Memory Cycle Time :-** It is an important measure of the memory system. It is the minimum time delay required between the initiations of two successive memory operations (for example, the time between two successive READ operations). The cycle time is usually slightly longer than the access time.

**RAM:** A memory unit is called a Random Access Memory if any location can be accessed for a READ or WRITE operation in some fixed amount of time that is independent of the locations address. Main memory units are of this type. This distinguishes them from serial or partly serial access storage devices such as magnetic tapes and disks which are used as the secondary storage device.

#### Cache Memory:-

#### **Cache Memory**

- > It is a small, fast memory that is inserted between
  - → larger slower main-memory and
  - $\rightarrow$  processor.
- ➤ It holds the currently active segments of a program and their data.

#### **Virtual Memory**

- The address generated by the processor is referred to as a virtual/logical address.
- > The virtual-address-space is mapped onto the physical-memory where data are actually stored.
- > The mapping-function is implemented by MMU. (MMU = memory management unit).
- ➤ Only the active portion of the address-space is mapped into locations in the physical-memory.
- ➤ The remaining virtual-addresses are mapped onto the bulk storage devices such as magnetic disk.
- > As the active portion of the virtual-address-space changes during program execution, the MMU
  - → changes the mapping-function &
  - → transfers the data between disk and memory.
- ➤ During every memory-cycle, MMU determines whether the addressed-page is in the memory. If the page is in the memory.

Then, the proper word is accessed and execution proceeds.

Otherwise, a page containing desired word is transferred from disk to memory.

- Memory can be classified as follows:
  - 1) RAM which can be further classified as follows:
    - i) Static RAM
    - ii) Dynamic RAM (DRAM) which can be further classified as synchronous & asynchronous DRAM
  - 2) ROM which can be further classified as follows:
    - i) PROM
    - ii) EPROM
    - iii) EEPROM &
    - iv) Flash Memory which can be further classified as Flash Cards & Flash Drives.

### 2.SEMICONDUCTOR RAM MEMORIES

### INTERNAL ORGANIZATION OF MEMORY CHIPS

- Memory-cells are organized in the form of array (Figure 8.2).
- Each cell is capable of storing 1-bit of information.
- Each row of cells forms a memory-word.
- All cells of a row are connected to a common line called as **Word-Line**.
- The cells in each column are connected to **Sense/Write** circuit by 2-bit-lines.
- The Sense/Write circuits are connected to data-input or output lines of the chip.
- During a write-operation, the sense/write circuit
  - → receive input information &
  - → store input info in the cells of the selected word.
- The data-input and data-output of each Sense/Write circuit are connected to a single bidirectional data-line.
- Data-line can be connected to a data-bus of the computer.




Figure 8.2 Organization of bit cells in a memory chip.

- Following 2 control lines are also used:
  - 1)  $R/W' \rightarrow$  Specifies the required operation.
  - 2) CS' → Chip Select input selects a given chip in the multi-chip memory-system.

Bit Organization	Requirement of external connection for address, data and control lines
128 (16x8)	14
(1024) 128x8(1k)	19

The required 10-bit address is divided into two groups of 5 bits each to form the row and column addresses for the cell array. A row address selects a row of 32 cells, all of which are accessed in parallel. However, according to the column address, only one of these cells is connected to the external data line by the output multiplexer and input demultiplexer.





Figure 5.3 Organization of a  $1K \times 1$  memory chip.

### STATIC MEMORIES

Memories that consist of circuits capable of retaining their state as long as power is applied are known as **static memories**.

- Two inverters are cross connected to form a latch (Figure 8.4).
- The latch is connected to 2-bit-lines by transistors T<sub>1</sub> and T<sub>2</sub>.
- The transistors act as switches that can be opened/closed under the control of the word-line.



• When the word-line is at ground level, the transistors are turned off and the latch retain its state.

### **Read Operation**


- To read the state of the cell, the word-line is activated to close switches T<sub>1</sub> and T<sub>2</sub>.
- If the cell is in state 1, the signal on bit-line b is high and the signal on the bit-line b' is low.
- Thus, b and b" are complement of each other.
- Sense/Write circuit
  - → monitors the state of b & b" and
  - $\rightarrow$  sets the output accordingly.

### **Write Operation**

- The state of the cell is set by
  - $\rightarrow$  placing the appropriate value on bit-line b and its complement on b' and
  - $\rightarrow$  then activating the word-line. This forces the cell into the corresponding state.
- The required signal on the bit-lines is generated by Sense/Write circuit.

#### CMOS Cell

A CMOS realization of the static RAM cell is given below:



- Transistor pairs (T<sub>3</sub>, T<sub>5</sub>) and (T<sub>4</sub>, T<sub>6</sub>) form the inverters in the latch (Figure 8.5).
- In state 1, the voltage at point X is high by having T<sub>5</sub>, T<sub>6</sub> ON and T<sub>4</sub>, T<sub>5</sub> are OFF.
- Thus, T<sub>1</sub> and T<sub>2</sub> returned ON (Closed), bit-line b and b" will have high and low signals respectively.
- Advantages:
  - 1) It has low power consumption "." the current flows in the cell only when the cell is active.
  - 2) Static RAM's can be accessed quickly. It access time is few nanoseconds.
- **Disadvantage:** SRAMs are said to be volatile memories ".' their contents are lost when power is interrupted.

### ASYNCHRONOUS DRAMS

- Less expensive RAMs can be implemented if simple cells are used.
- Such cells cannot retain their state indefinitely. Hence they are called **Dynamic RAM (DRAM).**
- The information stored in a dynamic memory-cell in the form of a charge on a capacitor.
- This charge can be maintained only for tens of milliseconds.
- The contents must be periodically refreshed by restoring this capacitor charge to its full value.





Figure 8.6 A single-transistor dynamic memory cell.

- In order to store information in the cell, the transistor T is turned "ON' (Figure 8.6).
- The appropriate voltage is applied to the bit-line which charges the capacitor.
- After the transistor is turned off, the capacitor begins to discharge.
- Hence, info. stored in cell can be retrieved correctly before threshold value of capacitor drops down.
- During a read-operation,
  - → transistor is turned "ON"
  - $\rightarrow$  a sense amplifier detects whether the charge on the capacitor is above the threshold value.
    - ➤ If (charge on capacitor) > (threshold value) → Bit-line will have logic value "1".
    - $\succ$  If (charge on capacitor) < (threshold value)  $\rightarrow$  Bit-line will set to logic value "0".




A 16 bit DRAM chip, configured as 2Mx8, as shown above. The cells are organized in the form of a  $4K \times 4K$  array. The 4096 cells in each row are divided into 512 groups of 8, so that a row can store 512 bytes of data.

- 21 bit address is needed to access a byte in the memory. 21 bit is divided as follows:
  - 1) 12 address bits are needed to select a row.
    - i.e.  $A_{8-0} \rightarrow$  specifies row-address of a byte.
  - 2) 9 bits are needed to specify a group of 8 bits in the selected row.
    - i.e.  $A_{20-9} \rightarrow$  specifies column-address of a byte.
- · During Read/Write-operation,
  - $\rightarrow$  row-address is applied first.
  - $\rightarrow$  row-address is loaded into row-latch in response to a signal pulse on **RAS'** input of chip. (RAS = Row-address Strobe CAS = Column-address Strobe)
- When a Read-operation is initiated, all cells on the selected row are read and refreshed.
- Shortly after the row-address is loaded, the column-address is
  - $\rightarrow$  applied to the address pins &
  - $\rightarrow$  loaded into CAS'.
- The information in the latch is decoded.
- The appropriate group of 8 Sense/Write circuits is selected.
  - R/W'=1(read-operation)  $\rightarrow$  Output values of selected circuits are transferred to data-lines D<sub>0</sub>-D<sub>7</sub>.
    - **R/W'=0**(write-operation)  $\rightarrow$  Information on D<sub>0</sub>-D<sub>7</sub> are transferred to the selected circuits.
- RAS' & CAS' are active-low so that they cause latching of address when they change from

high to low.

- To ensure that the contents of DRAMs are maintained, each row of cells is accessed periodically.
- A special memory-circuit provides the necessary control signals RAS' & CAS' that govern the timing.
- The processor must take into account the delay in the response of the memory.




### **Fast Page Mode**

- > Transferring the bytes in sequential order is achieved by applying the consecutive sequence of column-address under the control of successive CAS' signals.
- > This scheme allows transferring a block of data at a faster rate.
- ➤ The block of transfer capability is called as fast page mode


### SYNCHRONOUS DRAM

- The operations are directly synchronized with clock signal (Figure 8.8).
- The address and data connections are buffered by means of registers.
- The output of each sense amplifier is connected to a latch.
- A Read-operation causes the contents of all cells in the selected row to be loaded in these latches.
- Data held in latches that correspond to selected columns are transferred into data-output register.
- Thus, data becoming available on the data-output pins.



- First, the row-address is latched under control of RAS' signal (Figure 8.9).
- The memory typically takes 2 or 3 clock cycles to activate the selected row.

Then, the column-address is latched under the control of CAS' signal



- Figure 8.9 A burst read of length 4 in an SDRAM.
- After a delay of one clock cycle, the first set of data bits is placed on the data-lines.
- SDRAM automatically increments column-address to access next 3 sets of bits in the selected row.

### **Latency & Bandwidth**

• A good indication of performance is given by 2 parameters: 1) Latency 2) Bandwidth.

#### Latency

- It refers to the amount of time it takes to transfer a word of data to or from the memory.
- For a transfer of single word, the latency provides the complete indication of memory performance.
- For a block transfer, the latency denotes the time it takes to transfer the first word of data.


#### **Bandwidth**

- It is defined as the number of bits or bytes that can be transferred in one second.
- Bandwidth mainly depends on
  - 1) The speed of access to the stored data &
  - 2) The number of bits that can be accessed in parallel.

### **Double Data Rate Sdram (DDR-SDRAM)**

- The standard SDRAM performs all actions on the rising edge of the clock signal.
- The DDR-SDRAM transfer data on both the edges (loading edge, trailing edge).
- The Bandwidth of DDR-SDRAM is doubled for long burst transfer.
- To make it possible to access the data at high rate, the cell array is organized into two banks.
- Each bank can be accessed separately.
- Consecutive words of a given block are stored in different banks.
- Such interleaving of words allows simultaneous access to two words.
- The two words are transferred on successive edge of the clock.

### STRUCTURE OF LARGER MEMORIES



#### **Static Memory Systems**

Implementing a memory unit of 2M words of 32 bits each.

- Using 512x8 static memory chips. Each column consists of 4 chips. Each chip implements one byte <u>position</u>.
- A chip is selected by setting its chip select control line to 1. Selected chip places its data on the data output line, outputs of other chips are in high impedance state.
- 21 bits to address a 32-bit word. High order 2 bits are needed to select the row, by activating the four Chip Select signals.
- 19 bits are used to access specific byte locations inside the selected chip.

### **Dynamic Memory System**

- The physical implementation is done in the form of memory-modules.
- If a large memory is built by placing DRAM chips directly on the Motherboard, then it will occupy large amount of space on the board.
- These packaging consideration have led to the development of larger memory units known as SIMM"s & DIMM"s.
  - 1) SIMM → Single Inline memory-module
  - 2) DIMM → Dual Inline memory-module
- SIMM/DIMM consists of many memory-chips on small board that plugs into a socket on motherboard.

### MEMORY-SYSTEM CONSIDERATION

The choose of RAM chip for a given application depends on the factors like cost, speed, power dissipation and size of chip.

### **Memory Controller**

- To reduce the number of pins, the dynamic memory-chips use multiplexed-address inputs.
- The address is divided into 2 parts:

### 1) High Order Address Bit

- > Select a row in cell array.
- ➤ It is provided first and latched into memory-chips under the control of RAS' signal.

### 2) Low Order Address Bit

- > Selects a column.
- > They are provided on same address pins and latched using CAS" signals.
- The Multiplexing of address bit is usually done by **Memory Controller Circuit** (Figure 5.11).
- The Controller accepts a complete address & R/W" signal from the processor.
- A Request signal indicates a memory access operation is needed.
- Then, the Controller




Figure 5.11 Use of a memory controller.

- $\rightarrow$  forwards the row & column portions of the address to the memory.
- → generates RAS' & CAS" signals &
- → sends R/W' & CS' signals to the memory.

### **RAMBUS MEMORY**

- The usage of wide bus is expensive.
- Rambus developed the implementation of narrow bus.
- Rambus technology is a fast signaling method used to transfer information between chips.
- The signals consist of much smaller voltage swings around a reference voltage V<sub>ref</sub>.

- The reference voltage is about 2V.
- The two logical values are represented by 0.3V swings above and below V<sub>ref</sub>.
- This type of signaling is generally is known as **Differential Signalling**.
- Rambus provides a complete specification for design of communication called as **Rambus Channel**.
- Rambus memory has a clock frequency of 400 MHz.
- The data are transmitted on both the edges of clock so that effective data-transfer rate is 800MHZ.
- Circuitry needed to interface to Rambus channel is included on chip. Such chips are called **RDRAM.** (RDRAM = Rambus DRAMs).
- Rambus channel has:
  - 1) 9 Data-lines (1st-8th line -> Transfer the data, 9th line-> Parity checking).
  - 2) Control-Line &
  - 3) Power line.
- A two channel rambus has 18 data-lines which has no separate Address-Lines.
- Communication between processor and RDRAM modules is carried out by means of packets transmitted on the data-lines.
- There are 3 types of packets:
  - 1) Request
  - 2) Acknowledge &
  - 3) Data.

# 3.READ ONLY MEMORIES

- Both SRAM and DRAM chips are volatile, i.e. They lose the stored information if power is turned off.
- Many application requires non-volatile memory which retains the stored information if power is turned off.
- For ex:

OS software has to be loaded from disk to memory i.e. it requires non-volatile memory.

• Non-volatile memory is used in embedded system.


### **ROM**

- Since the normal operation involves only reading of stored data, a memory of this type is called ROM.
  - $\triangleright$  **At Logic value '0'**  $\square$  Transistor(T) is connected to the ground point (P).

Transistor switch is closed & voltage on bit-line nearly drops to zero (Figure 8.11).

➤ At Logic value '1' 
☐ Transistor

switch is open. The bit-line remains at high voltage.



- To read the state of the cell, the word-line is activated.
- A Sense circuit at the end of the bit-line generates the proper output value.

### **Types Of Rom**

- Different types of non-volatile memory are
  - 1) PROM
  - 2) EPROM
  - 3) EEPROM &
  - 4) Flash Memory (Flash Cards & Flash Drives)

#### PROM (PROGRAMMABLE ROM)

- PROM allows the data to be loaded by the user.
- Programmability is achieved by inserting a "fuse' at point P in a ROM cell.
- Before PROM is programmed, the memory contains all 0"s.
- User can insert 1"s at required location by burning-out fuse using high current-pulse.
- This process is irreversible.

### Advantages:

- 1) It provides flexibility.
- 2) It is faster.
- 3) It is less expensive because they can be programmed directly by the user.

### **EPROM (ERASABLE REPROGRAMMABLE ROM)**

- EPROM allows
  - $\rightarrow$  stored data to be erased and
  - → new data to be loaded.
- In cell, a connection to ground is always made at "P' and a special transistor is used.
- The transistor has the ability to function as
  - $\rightarrow$  a normal transistor or
  - → a disabled transistor that is always turned "off.
- Transistor can be programmed to behave as a permanently open switch, by injecting charge into it.
- Erasure requires dissipating the charges trapped in the transistor of memory-cells. This can be done by exposing the chip to ultra-violet light.

#### Advantages:

- 1) It provides flexibility during the development-phase of digital-system.
- 2) It is capable of retaining the stored information for a long time.

#### Disadvantages:

- 1) The chip must be physically removed from the circuit for reprogramming.
- 2) The entire contents need to be erased by UV light.

### **EEPROM (ELECTRICALLY ERASABLE ROM)**

### Advantages:

- 1) It can be both programmed and erased electrically.
- 2) It allows the erasing of all cell contents selectively.
- **Disadvantage:** It requires different voltage for erasing, writing and reading the stored data.

#### **FLASH MEMORY**

- In EEPROM, it is possible to read & write the contents of a single cell.
- In Flash device, it is possible to read contents of a single cell & write entire contents of a block.
- Prior to writing, the previous contents of the block are erased.
  - Eg. In MP3 player, the flash memory stores the data that represents sound.
- Single flash chips cannot provide sufficient storage capacity for embedded-system.

### Advantages:

- 1) Flash drives have greater density which leads to higher capacity & low cost per bit.
- 2) It requires single power supply voltage & consumes less power.
- There are 2 methods for implementing larger memory: 1) Flash Cards & 2) Flash Drives

### 1) Flash Cards

- > One way of constructing larger module is to mount flash-chips on a small card.
- > Such flash-card have standard interface.

- ➤ The card is simply plugged into a conveniently accessible slot.
- ➤ Memory-size of the card can be 8, 32 or 64MB.
- > Eg: A minute of music can be stored in 1MB of memory. Hence 64MB flash cards can store an hour of music.

### 2) Flash Drives

- ➤ Larger flash memory can be developed by replacing the hard disk-drive.
- > The flash drives are designed to fully emulate the hard disk.
- > The flash drives are solid state electronic devices that have no movable parts.

### **Advantages:**

- 1) They have shorter seek & access time which results in faster response.
- 2) They have low power consumption. ... they are attractive for battery driven

application.

3) They are insensitive to vibration.

### **Disadvantages:**


- 1) The capacity of flash drive (<1GB) is less than hard disk (>1GB).
- 2) It leads to higher cost per bit.
- 3) Flash memory will weaken after it has been written a number of times (typically at least 1 million times).

# **4.SPEED, SIZE COST**

Characteristics	SRAM	DRAM	Magnetis Disk
Speed	Very Fast	Slower	Much slower than
	_		DRAM
Size	Large	Small	Small
Cost	Expensive	Less Expensive	Low price

Memory	Speed	Size	Cost
Registers	Very high	Lower	Very Lower
Primary cache	High	Lower	Low
Secondary cache	Low	Low	Low
Main memory	Lower than Seconadry cache	High	High
Secondary Memory	Very low	Very High	Very High

- The main-memory can be built with DRAM (Figure 8.14)
- Thus, SRAM's are used in smaller units where speed is of essence.
- The Cache-memory is of 2 types:
  - 1) Primary/Processor Cache (Level1 or L1 cache)
  - > It is always located on the processor-chip.
  - 2) Secondary Cache (Level2 or L2 cache)
  - > It is placed between the primary-cache and the rest of the memory.
- The memory is implemented using the dynamic components (SIMM, RIMM, DIMM).
- The access time for main-memory is about 10 times longer than the access time for L1 cache.



### **5.CACHE MEMORIES**

• The effectiveness of cache mechanism is based on the property of "Locality of Reference'.

### **Locality of Reference**

- Many instructions in the localized areas of program are executed repeatedly during some time period
- Remainder of the program is accessed relatively infrequently (Figure 8.15).
- There are 2 types:

### 1) Temporal

> The recently executed instructions are likely to be executed again very soon.

### 2) Spatial

- > Instructions in close proximity to recently executed instruction are also likely to be executed soon.
- If active segment of program is placed in cache-memory, then total execution time can be reduced.
- Block refers to the set of contiguous address locations of some size.
- The cache-line is used to refer to the cache-block.




Figure 8.15 Use of a cache memory.

- The Cache-memory stores a reasonable number of blocks at a given time.
- This number of blocks is small compared to the total number of blocks available in main-memory.
- Correspondence b/w main-memory-block & cache-memory-block is specified by mapping-function.
- Cache control hardware decides which block should be removed to create space for the new block.
- The collection of rule for making this decision is called the Replacement Algorithm.
- •The cache control-circuit determines whether the requested-word currently exists in the cache.
- The write-operation is done in 2 ways: 1) Write-through protocol & 2) Write-back protocol.

### **Write-Through Protocol**

> Here the cache-location and the main-memory-locations are updated simultaneously.

#### **Write-Back Protocol**

- > This technique is to
  - → update only the cache-location &
  - → mark the cache-location with associated flag bit called **Dirty/Modified Bit.**
- ➤ The word in memory will be updated later, when the marked-block is removed from cache.

### **During Read-operation**

- If the requested-word currently not exists in the cache, then read-miss will occur.
- To overcome the read miss, Load-through/Early restart protocol is used.

### Load-Through Protocol

- > The block of words that contains the requested-word is copied from the memory into cache.
- > After entire block is loaded into cache, the requested-word is forwarded to processor.


### **During Write-operation**

- If the requested-word not exists in the cache, then **write-miss** will occur.
  - 1) If **Write Through Protocol** is used, the information is written directly into main-memory.
  - 2) If Write Back Protocol is used,
    - → then block containing the addressed word is first brought into the cache &
    - $\rightarrow$  then the desired word in the cache is over-written with the new information.

### **MAPPING-FUNCTION**

- Here we discuss about 3 different mapping-function:
  - 1) Direct Mapping
  - 2) Associative Mapping
  - 3) Set-Associative Mapping

### **DIRECT MAPPING**



- The block-j of the main-memory maps onto block-j modulo-128 of the cache (Figure 8.16).
- When the memory-blocks 0, 128, & 256 are loaded into cache, the block is stored in cache-block 0. Similarly, memory-blocks 1, 129, 257 are stored in cache-block 1.
- The contention may arise when
  - 1) When the cache is full.

- 2) When more than one memory-block is mapped onto a given cache-block position.
- The contention is resolved by

allowing the new blocks to overwrite the currently resident-block.

- Memory-address determines placement of block in the cache.
- The memory-address is divided into 3 fields:

#### 1) Low Order 4 bit field

> Selects one of 16 words in a block.

### 2) 7 bit cache-block field

> 7-bits determine the cache-position in which new block must be stored.

### 3) 5 bit Tag field

- > 5-bits memory-address of block is stored in 5 tag-bits associated with cache-location.
- As execution proceeds,

5-bit tag field of memory-address is compared with tag-bits associated with cache-location.


If they match, then the desired word is in that block of the cache.

Otherwise, the block containing required word must be first read from the memory.

And then the word must be loaded into the cache.

#### ASSOCIATIVE MAPPING

- The memory-block can be placed into any cache-block position. (Figure 8.17).
- 12 tag-bits will identify a memory-block when it is resolved in the cache.
- Tag-bits of an address received from processor are compared to the tag-bits of each block of cache.
- This comparison is done to see if the desired block is present.



- It gives complete freedom in choosing the cache-location.
- A new block that has to be brought into the cache has to replace an existing block if the cache is full.
- The memory has to determine whether a given block is in the cache.
- Advantage: It is more flexible than direct mapping technique.
- Disadvantage: Its cost is high.

#### **SET-ASSOCIATIVE MAPPING**

- It is the combination of direct and associative mapping. (Figure 8.18).
- The blocks of the cache are grouped into sets.
- The mapping allows a block of the main-memory to reside in any block of the specified set.
- The cache has 2 blocks per set, so the memory-blocks 0, 64, 128...... 4032 maps into cache set

"0".

• The cache can occupy either of the two block position within the set.

#### 6 bit set field

> Determines which set of cache contains the desired block.

### 6 bit tag field

- > The tag field of the address is compared to the tags of the two blocks of the set.
- ➤ This comparison is done to check if the desired block is present.




Figure 8.18 Set-associative-mapped cache with two blocks per set.

- The cache which contains 1 block per set is called **direct mapping**.
- A cache that has "k" blocks per set is called as "k-way set associative cache".
- Each block contains a control-bit called a valid-bit.
- The Valid-bit indicates that whether the block contains valid-data.
- The dirty bit indicates that whether the block has been modified during its cache residency.
  - **Valid-bit=0**  $\square$  When power is initially applied to system.

**Valid-bit=1** □ When the block is loaded from main-memory at first time.

- If the main-memory-block is updated by a source & if the block in the source is already exists in the cache, then the valid-bit will be cleared to "0".
- If Processor & DMA uses the same copies of data then it is called as Cache Coherence Problem.

### Advantages:

- 1) Contention problem of direct mapping is solved by having few choices for block placement.
- 2) The hardware cost is decreased by reducing the size of associative search.

### REPLACEMENT ALGORITHM

• In direct mapping method,

the position of each block is pre-determined and there is no need of replacement strategy.

• In associative & set associative method,

The block position is not pre-determined.

If the cache is full and if new blocks are brought into the cache,

then the cache-controller must decide which of the old blocks has to be replaced.

- When a block is to be overwritten, the block with longest time w/o being referenced is over-written.
- This block is called **Least recently Used (LRU) block** & the technique is called **LRU algorithm**.
- The cache-controller tracks the references to all blocks with the help of block-counter.
- **Advantage:** Performance of LRU is improved by randomness in deciding which block is to be over- written.

Eq:

Consider 4 blocks/set in set associative cache.

- > 2 bit counter can be used for each block.
- ➤ When a 'hit' occurs, then block counter=0; The counter with values originally lower than the referenced one are incremented by 1 & all others remain unchanged.
- ➤ When a **'miss'** occurs & if the set is full, the blocks with the counter value 3 is removed, the new block is put in its place & its counter is set to "0" and other block counters are incremented by 1.

### 6.PERFORMANCE CONSIDERATION

- Two key factors in the commercial success are 1) performance & 2) cost.
- In other words, the best possible performance at low cost.
- A common measure of success is called the Pricel Performance ratio.
- Performance depends on
  - ightarrow how fast the machine instructions are brought to the processor &
  - → how fast the machine instructions are executed.
- To achieve parallelism, interleaving is used.
- Parallelism means both the slow and fast units are accessed in the same manner.

# **Interleaving**

- The main-memory of a computer is structured as a collection of physically separate modules.
- Each module has its own
  - 1) ABR (address buffer register) &
  - 2) DBR (data buffer register).
- So, memory access operations may proceed in more than one module at the same time (Fig 5.25).
- Thus, the aggregate-rate of transmission of words to/from the main-memory can be increased.
- The low-order k-bits of the memory-address select a module.

While the high-order m-bits name a location within the module.

In this way, consecutive addresses are located in successive modules.

- Thus, any component of the system can keep several modules busy at any one time T.
- This results in both
  - → faster access to a block of data and
  - → higher average utilization of the memory-system as a whole.
- To implement the interleaved-structure, there must be 2k modules; Otherwise, there will be gaps of non-existent locations in the address-space.

### **Hit Rate & Miss Penalty**

- The number of hits stated as a fraction of all attempted accesses is called the **Hit Rate**.
- The extra time needed to bring the desired information into the cache is called the Miss Penalty.
- High hit rates well over 0.9 are essential for high-performance computers.
- Performance is adversely affected by the actions that need to be taken when a miss occurs.
- A performance penalty is incurred because
   of the extra time needed to bring a block of data from a slower unit to a faster unit.
- During that period, the processor is stalled waiting for instructions or data.
- We refer to the total access time seen by the processor when a miss occurs as the miss penalty.
- Let h be the hit rate, M the miss penalty, and C the time to access information in the cache.

Thus, the average access time experienced by the processor is




Figure 5.25 Addressing multiple-module memory systems.

 $t_{avg} = hC + (1 - h)M$ 

# **Caches on the processor chips**

- ☐ In high performance processors 2 levels of caches are normally used.
- $\square$  Avg access time in a system with 2 levels of caches is
- $\Box$  T ave = h1c1+(1-h1)h2c2+(1-h1)(1-h2)M

h1- hitrate of Cache 1, h2- hit rate of Cache 2, M – miss penalty, c1- time to access info from cache1, c2- time to access info from cache2.

### Write buffer

Write-through: Each write operation involves writing to the main memory. If the processor has to wait for the write operation to be complete, it slows down the processor. Processor does not depend on the results of the write operation. Write buffer can be included for temporary storage of write requests. Processor places each write request into the buffer and continues execution. If a subsequent Read request references data which is still in the write buffer, then this data is referenced in the write buffer. Write-back: Block is written back to the main memory when it is replaced. If the processor waits for this write to complete, before reading the new block, it is slowed down. Fast write buffer can hold the block to be written, and the new block can be read first.

### 7.VIRTUAL MEMORY

- It refers to a technique that automatically move program/data blocks into the mainmemory when they are required for execution (Figure 8.24).
- The address generated by the processor is referred to as a **virtual/logical address**.
- The virtual-address is translated into physical-address by MMU (Memory Management Unit).
- During every memory-cycle, MMU determines whether the addressed-word is in the memory. If the word is in memory.

Then, the word is accessed and execution proceeds.

Otherwise, a page containing desired word is transferred from disk to memory.

• Using DMA scheme, transfer of data between disk and memory is performed.




Figure 8.24 Virtual memory organization.

### **VIRTUAL MEMORY ADDRESS TRANSLATION**

• All programs and data are composed of fixed length units called **Pages** (Figure 8.25).

The Page consists of a block-of-words. The words occupy contiguous locations in the memory. The pages are commonly range from 2K to 16K bytes in length.

- Cache Bridge speed-up the gap between main-memory and secondary-storage.
- Each virtual-address contains
  - 1) Virtual Page number (Low order bit) and
  - 2) Offset (High order bit).

Virtual Page number + Offset  $\square$  specifies the location of a particular word within a page.




Figure 8.25 Virtual-memory address translation.

- Page-table: It contains the information about
  - → memory-address where the page is stored &
  - $\rightarrow$  current status of the page.
- Page-frame: An area in the main-memory that holds one page.
- Page-table Base Register: It contains the starting address of the page-table.
- Virtual Page Number + Page-table Base register  $\square$  Gives the starting address of the page if that page currently resides in memory.
- Control-bits in Page-table: The Control-bits is used to
  - 1) Specify the status of the page while it is in memory.
  - 2) Indicate the validity of the page.
  - 3) Indicate whether the page has been modified during its stay in the memory.

### TRANSLATION LOOKASIDE BUFFER (TLB)

- The Page-table information is used by MMU for every read/write access (Figure 8.26).
- The Page-table is placed in the memory but a copy of small portion of the page-table is located within MMU. This small portion is called **TLB** (Translation LookAside Buffer).

TLB consists of the page-table entries that corresponds to the most recently accessed pages. TLB also contains the virtual-address of the entry.

- When OS changes contents of page-table, the control-bit will invalidate corresponding entry in TLB.
- Given a virtual-address, the MMU looks in TLB for the referenced-page.
   If page-table entry for this page is found in TLB, the physical-address is obtained immediately. Otherwise, the required entry is obtained from the page-table & TLB is updated.




Figure 8.26 Use of an associative-mapped TLB.

### Page Faults

- Page-fault occurs when a program generates an access request to a page that is not in memory.
- When MMU detects a page-fault, the MMU asks the OS to generate an interrupt.
- The OS
  - → suspends the execution of the task that caused the page-fault and
  - → begins execution of another task whose pages are in memory.
- When the task resumes the interrupted instruction must continue from the point of interruption.
- If a new page is brought from disk when memory is full, disk must replace one of the resident pages. In this case, LRU algorithm is used to remove the least referenced page from memory.
- A modified page has to be written back to the disk before it is removed from the memory. In this case, Write-Through Protocol is used.

## 8.SECONDARY-STORAGE

- The semi-conductor memories do not provide all the storage capability.
- The secondary-storage devices provide larger storage requirements.
- Some of the secondary-storage devices are:
  - 1) Magnetic Disk
  - 2) Optical Disk &
  - 3) Magnetic Tapes.


### MAGNETIC HARD DISK

• Magnetic Disk system consists of one or more **disk** mounted on a common **spindle**.

- A **thin magnetic film** is deposited on each disk (Figure 8.27).
- Disk is placed in a **rotary-drive** so that magnetized surfaces move in close proximity to R/W heads.
- Each **R/W head** consists of 1) Magnetic Yoke & 2) Magnetizing-Coil.
- Digital information is stored on magnetic film by applying current pulse to the magnetizing-coil.
- Only changes in the magnetic field under the head can be sensed during the Read-operation.
- Therefore, if the binary states 0 & 1 are represented by two opposite states,

then a voltage is induced in the head only at 0-1 and at 1-0 transition in the bit stream.

- A consecutive of 0's & 1"s are determined by using the clock.
- Manchester Encoding technique is used to combine the clocking information with data.



- R/W heads are maintained at small distance from disk-surfaces in order to achieve high bit densities.
- When disk is moving at their steady state, the air pressure develops b/w disk surfaces & head. This air pressure forces the head away from the surface.
- The flexible spring connection between head and its arm mounting permits the head to fly at the desired distance away from the surface.

### Winchester Technology

- Read/Write heads are placed in a sealed, air-filtered enclosure called the Winchester Technology.
- The read/write heads can operate closure to magnetic track surfaces because the dust particles which are a problem in unsealed assemblies are absent.

#### **Advantages**

- It has a larger capacity for a given physical size.
- The data intensity is high because the storage medium is not exposed to contaminating elements.
- The read/write heads of a disk system are movable.
- The disk system has 3 parts: 1) Disk Platter (Usually called Disk)
  - 2) Disk-drive (spins the disk & moves Read/write heads)
  - 3) Disk Controller (controls the operation of the system.)

### Organization & Accessing Of Data On A Disk

- Each surface is divided into concentric **Tracks** (Figure 8.28).
- Each track is divided into Sectors.
- The set of corresponding tracks on all surfaces of a stack of disk form a Logical Cylinder.
- The data are accessed by specifying the surface number, track number and the sector number.
- The Read/Write-operation start at sector boundaries.
- Data bits are stored serially on each track.




Figure 8.28 Organization of one surface of a disk.

- Each sector usually contains 512 bytes.
- Sector Header --> contains identification information.

It helps to find the desired sector on the selected track.

- ECC (Error checking code)- is used to detect and correct errors.
- An unformatted disk has no information on its tracks.
- The formatting process divides the disk physically into tracks and sectors.
- The formatting process may discover some defective sectors on all tracks.
- Disk Controller keeps a record of various defects.
- The disk is divided into logical partitions:
  - 1) Primary partition
  - 2) Secondary partition
- Each track has same number of sectors. So, all tracks have same storage capacity.
- Thus, the stored information is packed more densely on inner track than on outer track.

#### **Access Time**

- There are 2 components involved in the time-delay:
  - 1) Seek time: Time required to move the read/write head to the proper track.
  - **2) Latency/Rotational Delay:** The amount of time that elapses after head is positioned over the correct track until the starting position of the addressed sector passes under the R/W head. Seek time + Latency = Disk access time

### Typical Disk

➤ One inch disk-weight = 1 ounce, size -> comparable to match book Capacity -> 1GB

> Inch disk has the following parameter

Recording

surface=20

Tracks=15000

tracks/surface

Sectors=400.

Each sector stores 512 bytes of data Capacity of formatted disk=20x15000x400x512=60x109 =60GB Seek time=3ms

Platter

rotation=10000

rev/min

Latency=3ms

Internet transfer rate=34MB/s

### Data Buffer/Cache

- A disk-drive that incorporates the required SCSI circuit is referred as **SCSI Drive**.
- The SCSI can transfer data at higher rate than the disk tracks.
- A data buffer can be used to deal with the possible difference in transfer rate b/w disk and SCSI bus
- The buffer is a semiconductor memory.
- The buffer can also provide cache mechanism for the disk.
  - i.e. when a read request arrives at the disk, then controller first check if the data is available in the cache/buffer.

If data is available in cache.

Then, the data can be accessed & placed on SCSI bus. Otherwise, the data will be retrieved from the disk.

#### **Disk Controller**

- The disk controller acts as interface between disk-drive and system-bus (Figure 8.13).
- The disk controller uses DMA scheme to transfer data between disk and memory.
- When the OS initiates the transfer by issuing R/W" request, the controllers register will load the following information:
  - 1) **Memory Address:** Address of first memory-location of the block of words involved in the transfer.
  - 2) **Disk Address:** Location of the sector containing the beginning of the desired block of words.
  - **3) Word Count:** Number of words in the block to be transferred.




Figure 8.13 Use of DMA controllers in a computer system.

- The disk-address issued by the OS is a logical address.
- The corresponding physical-address on the disk may be different.
- The controller's major functions are:
  - 1) Seek Causes disk-drive to move the R/W head from its current position to desired track.
  - **2) Read** Initiates a Read-operation, starting at address specified in the disk-address register. Data read serially from the disk are assembled into words and placed into the data buffer for transfer to the main-memory.
  - 3) Write Transfers data to the disk.
  - **4) Error Checking** Computes the error correcting code (ECC) value for the data read from a given sector and compares it with the corresponding ECC value read from the disk.

In case of a mismatch, it corrects the error if possible;

Otherwise, it raises an interrupt to inform the OS that an error has occurred.

Computer Organization (17cs34)	Akshitha K
YYYY	
Don't Of CSE CEC	Mamany System: Page 24