Parameterization



Muhammad Tahir*

Lecture 5

^{*}Professor, Electrical Engineering Department, University of Engineering and Technology Lahore

Contents

- Parameterization in Chisel
- 2 Type Parameters
- 3 Modules with Type Parameters
- 4 Bundle Parameterization Chisel Method: cloneType
- **5** Advanced Parameterization



Parameterization in Chisel

- Powerful feature allowing parameterized hardware generation
- Parameterization using bitwidth as parameter
- Define functions with type parameters
- Bundle parameterization
- Define modules with type parameters
- Advanced parameterization



Parameterization: Counter Example Revisited

```
import chisel3._
import chisel3.stage.ChiselStage
class Counter(size: Int, maxValue: UInt) extends Module {
    val io = IO(new Bundle {
        val result = Output(Bool())
    })
    // 'genCounter' with counter size 'n'
    def genCounter(n: Int, max: UInt) = {
        val count = RegInit(0.U(n.W))
        when (count === max) {
            count := 0. U
        }.otherwise {
            count := count + 1.U
        count
```



Parameterization: Counter Example Revisited Cont'd

```
// genCounter instantiation
val counter1 = genCounter(size, maxValue)
val counter2 = genCounter(size + size, maxValue)
io.result := counter1(size-1) & counter2(0)
}
println((new ChiselStage).emitVerilog(new Counter(8, 255.U))
)
```



Type Parameters

- Generic classes in Scala take a type as a parameter
- A type parameter is specified using square brackets []
- Type parameterization is also termed as generics

```
class uStack[A] {
 private var elements: List[A] = Nil
 def push(x: A) { elements = x :: elements }
 def pop(): A = {
    val elementTop = elements.head
    elements = elements.tail
    elementTop
val stackObj = new uStack[String]
stackObj.push("Hello")
stackObj.push("Trainee")
println(stackObj.pop) // will print Trainee
println(stackObj.pop) // will print Hello
```




Functions with Type Parameters

```
import chisel3._
import chisel3.util._
class Multiply_Acc(gen: UInt) extends Module {
    val io = IO(new Bundle {
        val out = Output(gen)
        val in1 = Input(gen)
        val in2 = Input(gen)
        val in3 = Input(gen)
    })
    io.out := multiply_add(io.in1, io.in2, io.in3)
    def multiply_add[T <: UInt](in_1: T, in_2: T, in_3: T) =</pre>
        in_1 * in_2 + in_3
println(chisel3.Driver.emitVerilog(new Multiply_Acc(UInt(2.W
    ))))
```



Network Switch





Parameterized Module: 2x2 Switch

```
import chisel3._
import chisel3.util._
class switch_2cross2 [T <: Data](parameter:T) extends Module{</pre>
    val io = IO(new Bundle {
                  = Input (parameter)
         val in2 = Input(parameter)
         val out1 = Output(parameter)
         val out2 = Output(parameter)
         val sel = Input(Bool())
    })
    when (io.sel) {
         io.out1 := io.in2
         io.out2 := io.in1
    .otherwise (
         io.out1 := io.in1
         io.out2 := io.in2
println(chisel3.Driver.emitVerilog(new switch_2cross2(UInt(8.W))))
```



Defining Parametrized Bundles

- Define a parameterized class extending the base class Bundle
- This class is used to instantiate the IO interface for the module
- Parameters must be passed while creating an IO module
- These parameters themselves might have been derived from the module class
- Different parameterized fields in a bundle can be defined by invoking cloneType on the parameter.



Parametrized Bundles: Illustration

```
import chisel3._
import chisel3.util._
class IO_Interface[T <: Data] (data_type:T) extends Bundle{</pre>
   val in1 = Input(data_type.cloneType)
   val in2 = Input(data_type.cloneType)
   val out = Output(data_type.cloneType)
   val sel = Input(Bool())
class Adder(size: UInt) extends Module{
   val io = IO(new IO Interface(size))
   io.out := io.in1 + io.in2
println((new chisel3.stage.ChiselStage).emitVerilog(new
    Adder (15.U)))
```



Chisel Method: cloneType

- Constructing copies of bundles for various purposes requires cloning
- Chisel can automatically figure out how to clone bundles in most cases
- For some parameterized bundles, Chisel may not automatically figure out how to clone
- Solution is to create a custom cloneType method in the parameterized bundle



cloneType Example



cloneType Example

```
class Adder(inBundle: Adder_Inputs, outSize: Int) extends Module {
  val io = IO(new Bundle {
    val out = Output (UInt (outSize.W))
    // chiselTypeOf returns the chisel type of the object
    val in bundle = Input(chiselTypeOf(inBundle))
  })
  io.out := io.in_bundle.in1 + io.in_bundle.in2
class Top (in1Size: Int, in2Size: Int, outSize: Int) extends Module {
  val io = IO(new Bundle {
    val out = Output (UInt (outSize.W))
    val in = Input(UInt(in1Size.W))
  1)
  // input bundle instance
  val inBundle = Wire(new Adder_Inputs(in1Size, in2Size))
  inBundle := DontCare
  // module instance
 val m = Module(new Adder(inBundle, outSize))
 m.io.in bundle.in1 := io.in
 m.io.in_bundle.in2 := io.in
  io.out := m.io.out
println((new ChiselStage).emitVerilog(new Top(18, 30, 32)))
```



Class As Parameter

```
import chisel3._
import chisel3.util._
class Parameters (dWidth: Int, aWidth: Int) extends Bundle {
   val addrWidth = UInt(aWidth.W)
   val dataWidth = UInt(dWidth.W)
class DataMem (params: Parameters) extends Module {
   val io = IO(new Bundle{
       val data_in = Input(params.dataWidth)
       val data_out = Output(params.dataWidth)
       val addr
                    = Input(params.addrWidth)
                    = Input(Bool())
       val wr en
   })
   // Make memory of 32 x 32
   val memory = Mem(32, params.dataWidth)
```



Class As Parameter Cont'd

```
io.data_out := 0.U

when(io.wr_en) {
    memory.write(io.addr, io.data_in)
} .otherwise {
    io.data_out := memory.read(io.addr)
}

val params = (new Parameters(32, 5))
println((new chisel3.stage.ChiselStage).emitVerilog(new DataMem(params)))
```



Function As Parameter

Class with function parameters

```
import chisel3._
// class definition with function as parameter
class Operator[T <: Data](n: Int, generic: T)(op: (T, T) =>
   T) extends Module {
    require(n > 0) // "reduce only works on non-empty Vecs"
   val io = IO(new Bundle {
        val in = Input(Vec(n, generic))
        val out = Output(generic)
   })
   io.out := io.in.reduce(op)
```



Function As Parameter Cont'd

Implementing ADD operation

Implementing AND operation



Variance in Scala

- Recall class uStack[A]
 - A is called Type Parameter
 - uStack[Int], uStack[String] are known as Parameterized Types
- Variance in Scala defines inheritance relationship among these Parameterized Types



Types of Variance

- Covariance
 - If 'S' is subtype of 'T' then Set[S] is a subtype of Set[T]
 - Covariance is defined by prefixing Type Parameter with +, e.g. Set[+T], List[+T]
- Contravariance
 - If 'S' is subtype of 'T' then List[T] is a subtype of List[S]
 - Contravariance is defined by prefixing Type Parameter with -, e.g. Set[-T], List[-T]
- Invariance
 - If 'S' is subtype of 'T' then List[S] and List[T] do not have any inheritance relationship i.e. they are unrelated (the default variance relationship).



Reading List I

- Read the relevant sections from Chapter 10 of [Schoeberl, 2019]
- For type parameters and associated variance read Sections 19.3 to 19.6 of [Odersky et al., 2016]



References





