Pointers

Embedded Software Essentials C2M1V3

Pointer Types [S2a]


Pointer type denotes the data type that a pointer will dereference



data_type * pointer_name;


Pointer Types [S2b]

Pointer type denotes the data type that a pointer will dereference



Pointer Types [S2c]

Pointer type denotes the data type that a pointer will dereference




Pointer Size [S3]

 Pointers hold Addresses to a location in memory

- All Pointers are the same length
 - ARM _ 32-bit Pointer Length
- Address Space = 2^{PointerLength}

32-bit ARM Architecture



Pointer Size [S4]

All Pointers are the same length

```
uint8_t * ptr1 = (uint8_t *) 0x00;
uint16_t * ptr2 = (uint16_t *) 0x04;
uint32_t * ptr3 = (uint32_t *) 0x08;
float * ptr4 = (float *) 0x0C;
```

 Pointers Dereference different sized data

```
sizeof(*ptr1) ≠ sizeof(*ptr2) ≠ sizeof(*ptr3) ≠ sizeof(*ptr4)

1 Byte 2 Byte 4 Byte 4 Byte
```

Pointer Operators [S5]

- Dereference Operator = *
 - Accesses data at address

- Address-of Operator = &
 - Provides address of variable

Integers are not addresses

 Cast to explicit address for Peripheral Memory

```
uint32_t var;
uint32_t * ptr = &var;
*ptr = 0xABCD1234;
```

```
uint16_t * ptr = (uint16_t *) 0x480C0000;
```

Casts Integer to address

Null Pointers [S6]

 At time of pointer declaration, you might not know the address
 Use a NULL Pointer for Initialization

- Null Pointers point to nothing
 - Used to check for valid pointer

 Dereferencing a NULL Pointer can cause an exception This pointer will have garbage data

```
uint32_t * ptr;
```

Using un-initialized pointer can potentially corrupt your memory

```
#define NULL ((void*)0)
uint32_t * ptr = NULL;

if (ptr == NULL) {
    /* error! */
}
*ptr = 0xABCD1234;
```

Pointer Example [S7a]

```
typedef struct foo {
  uint8_t varA;
                        At least
  uint8_t varB;
                         32 Bits
  uint16_t varC;
} foo_t;
foo_t varS;
uint8_t Num;
foo_t * varS_ptr = &varS;
                                     Each Pointer is 32-bits
uint8_t * ptr_Num = #
```


Pointer Example [S7b]

```
typedef struct foo {
  uint8 t varA;
  uint8_t varB;
  uint16 t varC;
} foo t;
foo t varS;
uint8_t Num;
foo t * varS ptr = &varS;
uint8_t * ptr_Num = #
```

```
varS_ptr->varA _ Derefences 8-bits
varS_ptr->varB _ Derefences 8-bits
varS ptr->varC _ Derefences 16-bits
*ptr_Num _ Derefences 8-bits
        varS ptr->varC
    Structure Pointer Dereference Operator
```


Pointer Casting [S8a]

Cast pointers to dereference different sizes from same address




Pointer Casting [S8b]

Cast pointers to dereference different sizes from same address



Pointer Casting [S8c]

Cast pointers to dereference different sizes from same address



Pointers in Memory [S9]

- Pointers exist any part of memory
 - Stack, Heap, BSS, Data

- Pointers can reference data in different parts of memory
 - Code, Data, Peripheral

