
VOLTpwn: Attacking x86 Processor Integrity from Software

Zijo Kenjar <u>Tommaso Frassetto</u> Ahmad-Reza Sadeghi

David Gens Michael Franz

Technical University of Darmstadt University of California, Irvine


The Big Picture



Dynamic Voltage and Frequency Scaling

- Modern hardware has:
 - Power constraints (battery)
 - Thermal constraints

- Thus, it allows the OS to control:
 - Voltage
 - Frequency



DVFS and CLKScrew

 CLKscrew leverages DVFS to attack TrustZone on ARM processors

[USENIX Sec. 2017]

CLKSCREW: Exposing the Perils of Security-Oblivious Energy Management

Adrian Tang
Columbia University

Simha Sethumadhavan Columbia University

Salvatore Stolfo *Columbia University*

Abstract

The need for power- and energy-efficient computing has resulted in aggressive cooperative hardware-software energy management mechanisms on modern commodity devices. Most systems today, for example, allow software to control the frequency and voltage of the underlying hardware at a very fine granularity to extend battery life. Despite their benefits, these software-exposed energy management mechanisms pose grave security implications that have not been studied before.

In this work, we present the CLKSCREW attack, a new class of fault attacks that exploit the security-obliviousness of energy management mechanisms to break security. A novel benefit for the attackers is that these fault attacks become more accessible since they can now be conducted without the need for physical access to the devices or fault injection equipment. We demonstrate CLKSCREW on commodity ARM/Android devices. We show that a malicious kernel driver (1) can extract secret cryptographic keys from Trustzone, and (2) can escalate

maximize performance. Take as an example, Dynamic Voltage and Frequency Scaling (DVFS) [47], a ubiquitous energy management technique that saves energy by regulating the frequency and voltage of the processor cores according to runtime computing demands. To support DVFS, at the hardware level, vendors have to design the underlying frequency and voltage regulators to be portable across a wide range of devices while ensuring cost efficiency. At the software level, kernel developers need to track and match program demands to operating frequency and voltage settings to minimize energy consumption for those demands. Thus, to maximize the utility of DVFS, hardware and software function cooperatively and at very fine granularities.

Despite the ubiquity of energy management mechanisms on commodity systems, security is eration in the design of the of known attack

Challenges: DVFS on ARM and x86

ARM

- Fine-grained frequency and voltage control
- Per-core adjustment

Documented interfaces

Intel x86

- Coarse-grained frequency control
 - Pre-defined well-tested frequencies
- Per-processor adjustment (frequency and voltage shared by all cores)
- Undocumented interfaces
- Error detection (Machine Check Architecture)

x86 Frequency and Voltage Control

Frequency + Voltage

- Multiple automatic systems
- OS can select voltage/frequency pair by selecting a P-State
- MSR 0x199 (IA32 PERF CTL)


Voltage Offset

- Voltage offset for overclocking
- MSR 0x150 ("OC Mailbox")


P-State	Frequency
0x1b	2.7 GHz
0x1c	2.8 GHz
0x1d	2.9 GHz
0x1e	3.0 GHz
0x1f	3.1 GHz

63	42	40	39	32	31		0
1	Domain		Command		F	Payload	


VOLTpwn: Threat Model



Trusted Execution Environments




Trusted Execution Environments




Voltage Fault Analysis

P-State	Frequency
0x1b	2.7 GHz
0x1c	2.8 GHz
0x1d	2.9 GHz
0x1e	3.0 GHz
0x1f	3.1 GHz
0x20	3.2 GHz
0x21	3.3 GHz
0x22	3.4 GHz
0x23	3.5 GHz
0x24	3.6 GHz



Step 2: Bit Flip Analysis




Bit Flip Analysis: Vulnerable Code Pattern

```
// vector operation
vpxor %xmm1, %xmm2, %xmm3

// data transfer to memory
vmovdqu %xmm3, (%rsp)
```

[vpxor: vector xor]
[vmovdqu: vector move to memory]

VOLTpwn Attack Setup




Our Stressor


```
1    _loop:
2     push %r10;
3     vpsllq %xmm3, %xmm4, %xmm6
4     vpsllq %xmm3, %xmm5, %xmm7
5     pop %r10;
6     jmp _loop;
```

[vpsllq: vector left shift]

Attacking OpenSSL's HMAC Implementation



Attacking OpenSSL's HMAC Implementation



Intel Responsible Disclosure & Mitigations

- Reported to Intel in August 2019
- Intel's mitigation released in December 2019:
 - BIOS flag to disable voltage interface
 - Microcode update that includes state of that flag in attestation

Concurrent work: Plundervolt

Plundervolt: Software-based Fault Injection Attacks against Intel SGX

Kit Murdock*, David Oswald*, Flavio D. Garcia*, Jo Van Bulck[‡], Daniel Gruss[†], and Frank Piessens[‡]

*University of Birmingham, UK

kxm663@cs.bham.ac.uk, d.f.oswald@bham.ac.uk, f.garcia@bham.ac.uk

†Graz University of Technology, Austria

daniel.gruss@iaik.tugraz.at

‡imec-DistriNet, KU Leuven, Belgium
jo.vanbulck@cs.kuleuven.be, frank.piessens@cs.kuleuven.be

Abstract—Dynamic frequency and voltage scaling features have been introduced to manage ever-growing heat and power consumption in modern processors. Design restrictions ensure frequency and voltage are adjusted as a pair, based on the current load, because for each frequency there is only a certain voltage range where the processor can operate correctly. For this purpose, many processors (including the widespread Intel Core series) expose privileged software interfaces to dynamically regulate processor frequency and operating voltage.

In this paper, we demonstrate that these privileged interfaces can be reliably exploited to undermine the system's security. We present the *Plundervolt* attack, in which a privileged software adversary abuses an undocumented Intel Core voltage scaling interface to corrupt the *integrity* of Intel SGX enclave computations. Plundervolt carefully controls the processor's supply voltage during an enclave computation, inducing predictable faults within the processor package. Consequently, even Intel SGX's memoryption/authentication technology cannot protest

Because of this relationship (and other factors), modern processors keep the clock frequency and supply voltage as low as possible—only dynamically scaling up when necessary. Higher frequencies require higher voltages for the processor to function correctly, so they should not be changed independently. Additionally, there are other types of power consumption that influence the best choice of a frequency/voltage pair for specific situations.

Lowering the supply voltage was also important in the development of the last generations of DRAM. The apply voltage has been gradually recharges in the actual led to the

Conclusions

V0LTpwn: Attacking x86 Processor Integrity from Software Zijo Kenjar¹, Tommaso Frassetto¹, David Gens², Michael Franz², and Ahmad-Reza Sadeghi¹ ¹ Technical University of Darmstadt. Germany

 $\label{eq:control} {\it 2University~of~California,~Irvine} \\$

{dgens, franz}@uci.edu

- VOLTpwn: compromise on integrity of x86 processors and SGX
- Fault analysis of multiple processors in various conditions (more in the paper)
- Up to 99% success rate on real-world code