# MIPS Architecture and Assembly Language Overview

Adapted from: http://edge.mcs.dre.g.el.edu/GICL/people/sevy/architecture/MIPSRef(SPIM).html

[Register Description] [I/O Description]

# **Data Types and Literals**

## Data types:

- Instructions are all 32 bits
- byte(8 bits), halfword (2 bytes), word (4 bytes)
- a character requires 1 byte of storage
- an integer requires 1 word (4 bytes) of storage

#### Literals:

- numbers entered as is. e.g. 4
- characters enclosed in single quotes. e.g. 'b'
- strings enclosed in double quotes. e.g. "A string"

# **Registers**

- 32 general-purpose registers
- register preceded by \$ in assembly language instruction two formats for addressing:
  - using register number e.g. \$0 through \$31
  - using equivalent names <u>e.g.</u> \$t1, \$sp
- special registers Lo and Hi used to store result of multiplication and division
  - not directly addressable; contents accessed with special instruction mfhi ("move from Hi") and mflo ("move from Lo")
- stack grows from high memory to low memory

This is from Figure 9.9 in the Goodman&Miller text

Register Number	Alternative Name	Description	
0	zero	the value 0	
1	\$at	(assembler temporary) reserved by the assembler	
2-3	\$v0 - \$v1	(values) from expression evaluation and function results	
4-7	\$a0 - \$a3	(arguments) First four parameters for subroutine. Not preserved across procedure calls	
8-15	\$t0 - \$t7	(temporaries) Caller saved if needed. Subroutines can use w/out saving.  Not preserved across procedure calls	
16-23	\$s0 - \$s7	(saved values) - Callee saved.  A subroutine using one of these must save original and restore it before exiting.  Preserved across procedure calls	
24-25	\$t8 - \$t9	(temporaries) Caller saved if needed. Subroutines can use w/out saving.	

		These are in addition to \$t0 - \$t7 above.  Not preserved across procedure calls.	
26-27	\$k0 - \$k1	reserved for use by the interrupt/trap handler	
28	\$gp	global <b>p</b> ointer.  Points to the middle of the 64K block of memory in the static data segment.	
29	\$sp	stack pointer Points to last location on the stack.	
30	\$s8/\$fp	saved value / frame pointer Preserved across procedure calls	
31	\$ra	return address	

See also Britton section 1.9, Sweetman section 2.21, Larus Appendix section A.6

# **Program Structure**

- just plain text file with data declarations, program code (name of file should end in suffix .s to be used with SPIM simulator)
- data declaration section followed by program code section

# **Data Declarations**

- placed in section of program identified with assembler directive .data
- declares variable names used in program; storage allocated in main memory (RAM)

## Code

- placed in section of text identified with assembler directive .text
- contains program code (instructions)
- starting point for code e.g.ecution given label main:
- ending point of main code should use exit system call (see below under System Calls)

#### **Comments**

- anything following # on a line
  - # This stuff would be considered a comment
- Template for a MIPS assembly language program:

```
# Comment giving name of program and description of function
# Template.s
# Bare-bones outline of MIPS assembly language program

.data  # variable declarations follow this line
# ...

.text  # instructions follow this line

main:  # indicates start of code (first instruction to execute)
# ...
# End of program, leave a blank line afterwards to make SPIM happy
```

# **Data Declarations**

format for declarations:

```
name: storage_type value(s)
```

- create storage for variable of specified type with given name and specified value
- value(s) usually gives initial value(s); for storage type .space, gives number of spaces to be allocated

Note: labels always followed by colon (:)

```
example
                .word
                                 # create a single integer variable with
var1:
initial value 3
                 .byte
                         'a', 'b' # create a 2-element character array with
array1:
elements initialized
                                     to a and b
arrav2:
                        40
                                 # allocate 40 consecutive bytes, with storage
                .space
uninitialized
                                     could be used as a 40-element character
array, or a
                                     10-element integer array; a comment
should indicate which!
```

## **Load / Store Instructions**

- RAM access only allowed with load and store instructions
- all other instructions use register operands

load:

```
#copy word (4 bytes) at source RAM location to destination register.

#copy byte at source RAM location to low-order byte of destination register,

# and sign-e.g.tend to higher-order bytes
```

#### store word:

```
#store word in source register into RAM destination

#store word in source register into RAM destination

#store byte (low-order) in source register into RAM destination
```

#### load immediate:

```
li register_destination, value
#load immediate value into destination register
```

```
example:
        .data
var1:
        .word
                23
                                 # declare storage for var1; initial value is 23
        .text
_start:
        lw
                $t0, var1
                                          # load contents of RAM location into register
$t0:
      $t0 = var1
                                 # $t1 = 5
                $t1, 5
                                             ("load immediate")
        lί
                $t1, var1
                                         # store contents of register $t1 into RAM:
        sw
var1 = $t1
        done
```

# **Indirect and Based Addressing**

Used only with load and store instructions

#### load address:

```
la $t0, var1
```

• copy RAM address of var1 (presumably a label defined in the program) into register \$t0

## indirect addressing:

```
lw $t2, ($t0)
```

• load word at RAM address contained in \$t0 into \$t2

store word in register \$t2 into RAM at address contained in \$t0

## based or indexed addressing:

```
lw $t2, 4($t0)
```

- load word at RAM address (\$t0+4) into register \$t2
- "4" gives offset from address in register \$t0

```
sw $t2, -12($t0)
```

- store word in register \$t2 into RAM at address (\$t0 12)
- · negative offsets are fine

Note: based addressing is especially useful for:

- arrays; access elements as offset from base address
- stacks; easy to access elements at offset from stack pointer or frame pointer

```
example
                .data
array1:
                .space 12
                                         # declare 12 bytes of storage to hold array of
3 integers
                .text
                                                    load base address of array into
 start:
                la
                        $t0, array1
register $t0
                li
                        $t1, 5
                                         # $t1 = 5
                                                      ("load immediate")
                                         # first array element set to 5; indirect
                sw $t1, ($t0)
```

addressing

## **Arithmetic Instructions**

- most use 3 operands
- all operands are registers; no RAM or indirect addressing
- operand size is word (4 bytes)

```
add
                         $t0,$t1,$t2
                                              $t0 = $t1 + $t2;
                                                                  add as signed (2's complement)
integers
                         $t2,$t3,$t4
                                              $t2 = $t3 \ D \ $t4
                 sub
                                                                "add immediate" (no sub immediate)
                         $t2,$t3,5
$t1,$t6,$t7
                 addi
                                              $t2 = $t3 + 5;
                 addu
                                              $t1 = $t6 + $t7;
                                                                  add as unsigned integers
                 subu
                         $t1,$t6,$t7
                                              $t1 = $t6 + $t7;
                                          #
                                                                  subtract as unsigned integers
                 mult
                         $t3,$t4
                                              multiply 32-bit quantities in $t3 and $t4, and store
64-bit
                                              result in special registers Lo and Hi: (Hi,Lo) = $t3
* $t4
                 div
                         $t5,$t6
                                              Lo = $t5 / $t6
                                                                (integer quotient)
                                              Hi = $t5 \mod $t6
                                                                  (remainder)
                 mfhi
                         $t0
                                              move quantity in special register Hi to $t0:
                                                                                                $t0 =
Ηi
                 mflo
                         $t1
                                              move quantity in special register Lo to $t1:
                                                                                                $t1 =
Lo
                                             used to get at result of product or quotient
                 move
                         $t2,$t3 # $t2 = $t3
```

## **Control Structures**

#### **Branches**

comparison for conditional branches is built into instruction

```
unconditional branch to program label target
h
         target
beq
         $t0,$t1,target
                            #
                                branch to target if
                                                        $t0 = $t1
         $t0,$t1,target
blt
                            #
                               branch to target if
                                                        $t0 < $t1
ble
         $t0,$t1,target
                            #
                               branch to target if
                                                        $t0 <= $t1
         $t0,$t1,target
$t0,$t1,target
                               branch to target if branch to target if
bqt
                            #
                                                        $t0 > $t1
bge
                            #
                                                        $t0 >= $t1
         $t0,$t1,target
                               branch to target if
                                                        $t0 <> $t1
bne
```

#### <u>Jumps</u>

```
j target # unconditional jump to program label target jr $t3 # jump to address contained in $t3 ("jump register")
```

#### Subroutine Calls

subroutine call: "jump and link" instruction

```
jal sub_label # "jump and link"
```

- copy program counter (return address) to register \$ra (return address register)
- jump to program statement at sub\_label

subroutine return: "jump register" instruction

```
jr $ra # "jump register"
```

• jump to return address in \$ra (stored by jal instruction)

Note: return address stored in register \$ra; if subroutine will call other subroutines, or is recursive, return address should be copied from \$ra onto stack to preserve it, since jal always places return address in this register and hence will overwrite previous value

# **System Calls and I/O (SPIM Simulator)**

- used to read or print values or strings from input/output window, and indicate program end
- use syscall operating system routine call
- first supply appropriate values in registers \$v0 and \$a0-\$a1
- result value (if any) returned in register \$v0

The following table lists the possible **syscall** services.

Service	Code in \$v0	Arguments	Results
print_int	1	\$a0 = integer to be printed	
print_float	2	\$f12 = float to be printed	
print_double	3	\$f12 = double to be printed	
print_string	4	\$a0 = address of string in memory	
read_int	5		integer returned in \$v0
read_float	6		float returned in \$v0
read_double	7		double returned in \$v0
read_string	8	\$a0 = memory address of string input buffer \$a1 = length of string buffer (n)	
sbrk	9	\$a0 = amount	address in \$v0
exit	10		

- The print\_string service expects the address to start a null-terminated character string. The directive **.asciiz** creates a null-terminated character string.
- The read\_int, read\_float and read\_double services read an entire line of input up to and including the newline character.
- The read\_string service has the same semantices as the UNIX library routine fgets.
  - It reads up to n-1 characters into a buffer and terminates the string with a null character.
  - If fewer than n-1 characters are in the current line, it reads up to and including the newline and terminates the string with a null character.
- The sbrk service returns the address to a block of memory containing n additional bytes. This would be used for dynamic memory allocation.
- The exit service stops a program from running.

\$a0 = \$t2syscall # call operating system to perform operation e.g. Read integer value, store in RAM location with label int\_value (presumably declared in data section) \$v0, 5 # load appropriate system call code into register \$v0; # code for reading integer is 5 # call operating system to perform syscall operation \$v0, int\_value # value read from keyboard returned in sw register \$v0; # store this in desired location e.g. Print out string (useful for prompts) .data .asciiz "Print this.\n" # declaration for string variable, string1 # .asciiz directive makes string null terminated .text li # load appropriate system call code main: \$v0, 4 into register \$v0; # code for printing string is 4 \$a0, string1 # load address of string to be printed la into \$a0 syscall # call operating system to perform print operation e.g. To indicate end of program, use exit system call; thus last lines of program should be: \$v0, 10 

li syscall