Symbols

C	Speed	of light	(3 ×	10^{8}	m/s).

$$\omega$$
 Angular velocity (m/s).

$$\gamma$$
 (Complex) propogati on constant.

$$\alpha$$
 Attenuation constant.

$$\phi$$
 Phase.

$$\phi_0$$
 Phase offset. If positive, wave leads (left-shifted). If negative, wave lags (right-shifted).

$$e^{-\alpha x}$$
 Attenuation factor $+x$ direction (in a lossy medium).

$$Z_0$$
 Characteristic impedance (Ω) .

$$Z_{\rm L}$$
 Load impedance.

$$z_{\rm L}$$
 Normalized load impedance [eq (10)].

$$L'$$
 The combined inductance of both conductors per unit length, in H/m.

$$G'$$
 The conductance of the insulation medium between the two conductors per unit length, in S/m.

$$R'$$
 The combined resistance of both conductors per unit length, in Ω/m .

$$\epsilon$$
 Permittivity (dielectric insulator).

$$\epsilon_0$$
 Permittivity of free space (8.854 × 10⁻¹² F/m).

$$\epsilon_{\rm r}$$
 Relative permittivity.

$$\epsilon_{\rm eff}$$
 Effective relative permittivity.

$$\mu$$
 Permeability (dielectric insulator).

$$\mu_0$$
 Permeability of free space $(4\pi \times 10^{-7} \text{ H/m})$.

$$\mu_c$$
 Permeability of conducting strip.

$$\sigma$$
 Conductivity (dielectric insulator).

$$\sigma_c$$
 Conductivity of conducting strip.

Equations

$$\omega = 2\pi f = \frac{2\pi}{T}$$

$$\beta = \frac{2\pi}{\lambda}$$

$$u_p = \frac{\lambda}{T} = f\lambda = \frac{\omega}{\beta}$$

$$\phi(x,t) = \omega t - \beta x + \phi_0$$

$$y(x,t) = A\cos(\phi(x,t))$$

$$e^{j\theta} = \cos(\theta) + j\sin(\theta)$$
 Euler's Identity

$$\frac{d\tilde{V}(z)}{dz} = -(R' + j\omega L')\tilde{I}(z)$$
Telegrapher's equations

$$\frac{dI(z)}{dz} = -(G' + j\omega C')\tilde{V}(z)$$

$$\gamma = \sqrt{(R'+j\omega L')(G'+j\omega C')} = \alpha + j\beta$$

$$\alpha = \Re(\gamma); \ \beta = \Im(\gamma)$$

$$\frac{d^2\tilde{I}(z)}{dz^2} - \gamma^2\tilde{I}(z) = 0$$

Wave equations

$$\frac{d^2 \tilde{V}(z)}{dz^2} - \gamma^2 \tilde{V}(z) = 0$$

$$Z_0 = \frac{R' + j\omega L'}{\gamma} = \sqrt{\frac{R' + j\omega L'}{G' + j\omega C'}} = \frac{V_0^+}{I_0^+} = \frac{-V_0^-}{I_0^-}$$

$$\Gamma = \frac{V_0^-}{V_0^+} = \frac{Z_L - Z_0}{Z_L + Z_0} = \frac{Z_L/Z_0 - 1}{Z_L/Z_0 + 1}$$
$$= \frac{z_L - 1}{Z_L/Z_0 + 1}$$

$$z_{\rm L} = \frac{Z_{\rm L}}{Z_{\rm o}}$$

$$V_0^+ = |V_0^+| e^{j\phi^+}; \ V_0^- = |V_0^-| e^{j\phi^-}$$

$$v(x,t) = \Re(\tilde{V}(x)e^{j\omega t})$$
$$= |V_0^+|e^{-\alpha x}\cos(\omega t - \beta x + \phi^+)$$
$$+ |V_0^-|e^{\alpha x}\cos(\omega t + \beta x + \phi^-)$$

$$\epsilon_{\mathrm{r}} = \frac{\epsilon}{\epsilon_{0}}$$

$$c = \frac{1}{\sqrt{c_{\mathrm{r}}^{2} + c_{\mathrm{r}}^{2}}}$$

For coaxial, two-wire, parallel-plate:

$$u_p = \frac{c}{\sqrt{\epsilon_r}}$$

For microstrip:

$$u_p = \frac{c}{\sqrt{\epsilon_{off}}}$$

$$R' = 0 \ (\because \sigma_c = \infty);$$

$$G' = 0 \ (\because \sigma = 0);$$

$$C' = \frac{\sqrt{\epsilon_{\text{eff}}}}{Z_0 c};$$

$$L' = Z_0^2 C';$$

$$\alpha = 0 \ (\because R' = G' = 0);$$

$$\beta = \frac{\omega}{c} \sqrt{\epsilon_{\rm eff}}$$
.

For all TEM lines:

$$L'C' = \mu\epsilon$$

$$\frac{G'}{C'} = \frac{\sigma}{\epsilon}$$

Lossless Line

$$R' \ll \omega L'$$
; $G' \ll \omega C' \to R' = G' \approx 0 \to$

$$\gamma = \alpha + j\beta = j\omega\sqrt{L'C'}$$

From equation (8),

$$Z_0 = \sqrt{\frac{L'}{C'}}$$

From equations (2)/(3) and (26)

$$\lambda = \frac{2\pi}{\beta} = \frac{2\pi}{\omega\sqrt{L'C'}}$$

$$u_p = \frac{\omega}{\beta} = \frac{1}{\sqrt{L'C'}}$$

From equation (23), (26) and (29)

$$\beta = \omega \sqrt{\mu \epsilon}$$

$$u_p = \frac{1}{\sqrt{\mu\epsilon}}$$

Notes

Fundamental Properties of EM waves:

- A monochromatic (single frequency) EM wave consists of electric and magnetic fields that oscillate at the same frequency f.
- The phase velocity of an EM wave in a vacuum is the speed of light. c.
- In vacuum, the wavelength of an EM wave is related to its oscillation frequency f by $\lambda = \frac{c}{f}$.
- For passive transmission lines, α is either zero or positive. The gain region of a laser is an example of an active transmission line with a negative α .
- Microstrip line is considered a *quasi-TEM* because **E** and **F** are not everywhere perfectly orthogonal.
- From equation (12), or a similar equation, the term $...e^{-j\beta x}$ is the **incident wave** (travelling from source to load, or in the positive x direction). The term $...e^{j\beta x}$ is the **reflected wave** (travelling from load to source, or in the negative x direction).