#### WikipediA

# **High-pass filter**

A **high-pass filter** (**HPF**) is an <u>electronic filter</u> that passes <u>signals</u> with a <u>frequency</u> higher than a certain <u>cutoff frequency</u> and <u>attenuates</u> signals with frequencies lower than the cutoff frequency. The amount of <u>attenuation</u> for each frequency depends on the filter design. A high-pass <u>filter</u> is usually modeled as a <u>linear time-invariant system</u>. It is sometimes called a **low-cut filter** or **bass-cut filter**.<sup>[1]</sup> High-pass filters have many uses, such as blocking DC from circuitry sensitive to non-zero average voltages or <u>radio frequency</u> devices. They can also be used in conjunction with a <u>low-pass</u> filter to produce a bandpass filter.

In the optical domain, **high-pass** and **low-pass** have the opposite meanings, with a "high-pass" filter (more commonly "long-pass") passing only *longer* wavelengths (lower frequencies), and vice-versa for "low-pass" (more commonly "short-pass").<sup>[2][3]</sup>

## **Contents**

First-order continuous-time implementation

Discrete-time realization

Algorithmic implementation

**Applications** 

Audio

**Image** 

See also

References

**External links** 

# First-order continuous-time implementation

The simple first-order electronic high-pass filter shown in Figure 1 is implemented by placing an input voltage across the series combination of a <u>capacitor</u> and a <u>resistor</u> and using the voltage across the resistor as an output. The <u>transfer function</u> of this <u>linear time-invariant system</u> is:

$$rac{V_{out}(s)}{V_{in}(s)} = rac{sRC}{1+sRC}.$$

The product of the resistance and capacitance  $(R \times C)$  is the <u>time</u> constant  $(\tau)$ ; it is inversely proportional to the cutoff frequency  $f_c$ , that is,





Figure 1: A passive, analog, firstorder high-pass filter, realized by an RC circuit

$$f_c=rac{1}{2\pi au}=rac{1}{2\pi RC},$$

where  $f_c$  is in <u>hertz</u>,  $\tau$  is in <u>seconds</u>, R is in <u>ohms</u>, and C is in <u>farads</u>. The cutoff frequency is where the pole of the filter levels off the filter's frequency response.

Figure 2 shows an active electronic implementation of a first-order high-pass filter using an <u>operational amplifier</u>. The transfer function of this linear time-invariant system is:

$$rac{V_{out}(s)}{V_{in}(s)} = rac{-sR_2C}{1+sR_1C}.$$



In this case, the filter has a <u>passband</u> gain of  $-R_2/R_1$  and has a cutoff frequency of

Figure 2: An active high-pass filter

$$f_c=rac{1}{2\pi au}=rac{1}{2\pi R_1C},$$

Because this filter is <u>active</u>, it may have <u>non-unity</u> passband gain. That is, high-frequency signals are inverted and amplified by  $R_2/R_1$ .

# **Discrete-time realization**

Discrete-time high-pass filters can also be designed. Discrete-time filter design is beyond the scope of this article; however, a simple example comes from the conversion of the continuous-time high-pass filter above to a discrete-time realization. That is, the continuous-time behavior can be discretized.

From the circuit in Figure 1 above, according to Kirchhoff's Laws and the definition of capacitance:

$$\left\{ egin{array}{ll} V_{
m out}(t) = I(t)\,R & ({
m V}) \ Q_c(t) = C\,\left(V_{
m in}(t) - V_{
m out}(t)
ight) & ({
m Q}) \ I(t) = rac{{
m d}\,Q_c}{{
m d}\,t} & ({
m I}) \end{array} 
ight.$$

where  $Q_c(t)$  is the charge stored in the capacitor at time t. Substituting Equation (Q) into Equation (I) and then Equation (I) into Equation (V) gives:

$$V_{
m out}(t) = \overbrace{C\left(rac{{
m d}\,V_{
m in}}{{
m d}\,t} - rac{{
m d}\,V_{
m out}}{{
m d}\,t}
ight)}^{I(t)} R = RC\left(rac{{
m d}\,V_{
m in}}{{
m d}\,t} - rac{{
m d}\,V_{
m out}}{{
m d}\,t}
ight)$$

This equation can be discretized. For simplicity, assume that samples of the input and output are taken at evenly spaced points in time separated by  $\Delta_T$  time. Let the samples of  $V_{\rm in}$  be represented by the sequence  $(x_1, x_2, \ldots, x_n)$ , and let  $V_{\rm out}$  be represented by the sequence  $(y_1, y_2, \ldots, y_n)$  which correspond to the same points in time. Making these substitutions:

$$y_i = RC \left(rac{x_i - x_{i-1}}{\Delta_T} - rac{y_i - y_{i-1}}{\Delta_T}
ight)$$

And rearranging terms gives the recurrence relation

 $y_i = rac{RC}{RC + \Delta_T} y_{i-1} + rac{RC}{RC + \Delta_T} (x_i - x_{i-1})$ 

That is, this discrete-time implementation of a simple continuous-time RC high-pass filter is

$$y_i = lpha y_{i-1} + lpha (x_i - x_{i-1}) \qquad ext{where} \qquad lpha ext{ } extstyle rac{RC}{RC + \Delta_T}$$

By definition,  $0 \le \alpha \le 1$ . The expression for parameter  $\alpha$  yields the equivalent <u>time constant</u> RC in terms of the sampling period  $\Delta_T$  and  $\alpha$ :

$$RC = \Delta_T \left( rac{lpha}{1-lpha} 
ight).$$

Recalling that

$$f_c = rac{1}{2\pi RC}$$
 so  $RC = rac{1}{2\pi f_c}$ 

then  $\alpha$  and  $f_c$  are related by:

$$lpha = rac{1}{2\pi\Delta_T f_c + 1}$$

and

$$f_c = rac{1-lpha}{2\pilpha\Delta_T}$$
 .

If  $\alpha = 0.5$ , then the RC time constant equal to the sampling period. If  $\alpha \ll 0.5$ , then RC is significantly smaller than the sampling interval, and  $RC \approx \alpha \Delta_T$ .

# Algorithmic implementation

The filter recurrence relation provides a way to determine the output samples in terms of the input samples and the preceding output. The following <u>pseudocode</u> algorithm will simulate the effect of a high-pass filter on a series of digital samples, assuming equally spaced samples:

```
// Return RC high-pass filter output samples, given input samples,
// time interval dt, and time constant RC
function highpass(real[0..n] x, real dt, real RC)
   var real[0..n] y
   var real \alpha := RC / (RC + dt)
   y[0] := x[0]
```

```
for i from 1 to n
    y[i] := α × y[i-1] + α × (x[i] - x[i-1])
return y
```

The loop which calculates each of the n outputs can be refactored into the equivalent:

```
for i from 1 to n
  y[i] := α × (y[i-1] + x[i] - x[i-1])
```

However, the earlier form shows how the parameter  $\alpha$  changes the impact of the prior output y[i-1] and current *change* in input (x[i] - x[i-1]). In particular,

- A large α implies that the output will decay very slowly but will also be strongly influenced by even small changes in input. By the relationship between parameter α and time constant *RC* above, a large α corresponds to a large *RC* and therefore a low corner frequency of the filter. Hence, this case corresponds to a high-pass filter with a very narrow stop band. Because it is excited by small changes and tends to hold its prior output values for a long time, it can pass relatively low frequencies. However, a constant input (i.e., an input with (x[i] x[i-1])=0) will always decay to zero, as would be expected with a high-pass filter with a large *RC*.
- A small α implies that the output will decay quickly and will require large changes in the input (i.e., (x[i] x[i-1]) is large) to cause the output to change much. By the relationship between parameter α and time constant RC above, a small α corresponds to a small RC and therefore a high corner frequency of the filter. Hence, this case corresponds to a high-pass filter with a very wide stop band. Because it requires large (i.e., fast) changes and tends to quickly forget its prior output values, it can only pass relatively high frequencies, as would be expected with a high-pass filter with a small RC.

# **Applications**

#### **Audio**

High-pass filters have many applications. They are used as part of an <u>audio crossover</u> to direct high frequencies to a <u>tweeter</u> while attenuating bass signals which could interfere with, or damage, the speaker. When such a filter is built into a <u>loudspeaker</u> cabinet it is normally a <u>passive filter</u> that also includes a <u>low-pass filter</u> for the <u>woofer</u> and so often employs both a capacitor and <u>inductor</u> (although very simple high-pass filters for tweeters can consist of a series capacitor and nothing else). As an example, the <u>formula above</u>, applied to a tweeter with R=10 Ohm, will determine the capacitor value


for a cut-off frequency of 5 kHz. 
$$C = \frac{1}{2\pi fR} = \frac{1}{6.28 \times 5000 \times 10} = 3.18 \times 10^{-6}$$
, or approx 3.2  $\mu$ F.

An alternative, which provides good quality sound without inductors (which are prone to parasitic coupling, are expensive, and may have significant internal resistance) is to employ <u>bi-amplification</u> with <u>active RC filters</u> or active digital filters with separate power amplifiers for each <u>loudspeaker</u>. Such low-current and low-voltage line level crossovers are called active crossovers.<sup>[1]</sup>

Rumble filters are high-pass filters applied to the removal of unwanted sounds near to the lower end of the <u>audible range</u> or below. For example, noises (e.g., footsteps, or motor noises from <u>record players</u> and <u>tape decks</u>) may be removed because they are undesired or may overload the <u>RIAA</u> equalization circuit of the preamp.<sup>[1]</sup>

High-pass filters are also used for <u>AC</u> coupling at the inputs of many <u>audio</u> power amplifiers, for preventing the amplification of DC currents which may harm the amplifier, rob the amplifier of headroom, and generate waste heat at the <u>loudspeakers voice coil</u>. One amplifier, the <u>professional audio</u> model DC300 made by <u>Crown International beginning</u> in the 1960s, did not have high-pass filtering at all, and could be used to amplify the DC signal of a common 9-volt battery at the input to supply 18 volts DC in an emergency for <u>mixing console power. [4]</u> However, that model's basic design has been superseded by newer designs such as the Crown Macro-Tech series developed in the late 1980s which included 10 Hz high-pass filtering on the inputs and switchable 35 Hz high-pass filtering on the outputs. [5] Another example is the <u>QSC Audio</u> PLX amplifier series which includes an internal 5 Hz high-pass filter which is applied to the inputs whenever the optional 50 and 30 Hz high-pass filters are turned off. [6]

Mixing consoles often include high-pass filtering at each channel strip. Some models have fixed-slope, fixed-frequency high-pass filters at 80 or 100 Hz that can be engaged; other models have sweepable high-pass filters, filters of fixed slope that can be set within a specified frequency range, such as from 20 to 400 Hz on the Midas Heritage 3000, or 20 to 20,000 Hz on the Yamaha M7CL digital mixing console. Veteran systems engineer and live sound mixer Bruce Main recommends that high-pass filters be engaged for most mixer input sources, except for those such as kick drum, bass guitar and piano, sources which will have useful low frequency sounds. Main writes that DI unit inputs (as opposed to microphone inputs) do not need high-pass filtering as they are not subject to modulation by low-frequency stage wash—low frequency sounds coming from the subwoofers or the public



A 75 Hz "low cut" filter from an input channel of a Mackie 1402 mixing console as measured by Smaart software. This high-pass filter has a slope of 18 dB per octave.

address system and wrapping around to the stage. Main indicates that high-pass filters are commonly used for directional microphones which have a proximity effect—a low-frequency boost for very close sources. This low frequency boost commonly causes problems up to 200 or 300 Hz, but Main notes that he has seen microphones that benefit from a 500 Hz high-pass filter setting on the console. [7]

### **Image**

High-pass and low-pass filters are also used in digital <u>image</u> processing to perform image modifications, enhancements, noise reduction, etc., using designs done in either the <u>spatial domain</u> or the <u>frequency domain</u>.<sup>[8]</sup> The <u>unsharp masking</u>, or sharpening, operation used in image editing software is a high-boost filter, a generalization of high-pass.

# See also

- DSL filter
- Band-stop filter
- Bias tee
- Differentiator



Example of high-pass filter applied to the right half of a photograph. Left side is unmodified, Right side is with a high-pass filter applied (in this case, with a radius of 4.9)

# References

- Watkinson, John (1998). The Art of Sound Reproduction (https://books.google.com/books?id=01u \_Vm5i5isC&pg=PA479). Focal Press. pp. 268, 479. ISBN 0-240-51512-9. Retrieved March 9, 2010.
- 2. "RP Photonics Encyclopedia optical filters, dye, etalons, dielectric, dichroic, Lyot, tuners" (https://www.rp-photonics.com/optical\_filters.html). www.rp-photonics.com. Retrieved 2019-05-20.
- 3. "High-pass filter dictionary definition I high-pass filter defined" (https://www.yourdictionary.com/high-pass-filter). www.yourdictionary.com. Retrieved 2019-05-20.
- 4. Andrews, Keith; posting as ssltech (January 11, 2010). "Re: Running the board for a show this big?" (https://web.archive.org/web/20110715123934/http://recforums.prosoundweb.com/index.php/m/462291/0/). Recording, Engineering & Production. ProSoundWeb. Archived from the original (http://recforums.prosoundweb.com/index.php/m/462291/0/) on 15 July 2011. Retrieved 9 March 2010.
- 5. "Operation Manual: MA-5002VZ" (https://web.archive.org/web/20100103130925/http://crownaudio.com/pdf/amps/128313.pdf) (PDF). *Macro-Tech Series*. Crown Audio. 2007. Archived from the original (http://www.crownaudio.com/pdf/amps/128313.pdf) (PDF) on January 3, 2010. Retrieved March 9, 2010.
- 6. "User Manual: PLX Series Amplifiers" (https://web.archive.org/web/20100209153528/http://media. qscaudio.com/pdfs/plxuser.pdf) (PDF). QSC Audio. 1999. Archived from the original (http://media. qscaudio.com/pdfs/plxuser.pdf) (PDF) on February 9, 2010. Retrieved March 9, 2010.
- 7. Main, Bruce (February 16, 2010). "Cut 'Em Off At The Pass: Effective Uses Of High-Pass Filtering". *Live Sound International*. Framingham, Massachusetts: ProSoundWeb, EH Publishing.
- 8. Paul M. Mather (2004). Computer processing of remotely sensed images: an introduction (https://books.google.com/books?id=Idj8Eg-KtMAC&pg=PA181&dq=image+high-pass+low-pass+frequency-domain#v=onepage&q=image%20high-pass%20low-pass%20frequency-domain&f=false) (3rd ed.). John Wiley and Sons. p. 181. ISBN 978-0-470-84919-4.

# **External links**

- Common Impulse Responses (http://www.dspguide.com/ch7/1.htm)
- ECE 209: Review of Circuits as LTI Systems (http://www.tedpavlic.com/teaching/osu/ece209/supp ort/circuits\_sys\_review.pdf), a short primer on the mathematical analysis of (electrical) LTI systems.
- ECE 209: Sources of Phase Shift (http://www.tedpavlic.com/teaching/osu/ece209/lab3\_opamp\_F O/lab3\_opamp\_FO\_phase\_shift.pdf), an intuitive explanation of the source of phase shift in a high-pass filter. Also verifies simple passive LPF <u>transfer function</u> by means of trigonometric identity.

Retrieved from "https://en.wikipedia.org/w/index.php?title=High-pass\_filter&oldid=942546371"

This page was last edited on 25 February 2020, at 09:57 (UTC).

Text is available under the <u>Creative Commons Attribution-ShareAlike License</u>; additional terms may apply. By using this site, you agree to the <u>Terms of Use</u> and <u>Privacy Policy</u>. Wikipedia® is a registered trademark of the <u>Wikimedia Foundation</u>, Inc., a non-profit organization.