

Interrupt

Ramin Zarebidoky (LiterallyTheOne)

16 Nov 2025

Interrupt

Introduction

In the previous session, we learned how to work with analog values in **Arduino Uno**. In this session we will learn about one of the most important aspects of microcontrollers, which is called **Interrupt**. We have different kinds of **Interrupts**, but in this tutorial, we are going to focus on the **External Interrupt**, which we will explain very soon.

What is an External Interrupt?

Interrupt is a special signal. It tells the microcontroller to stop (halt) what he is doing right now and execute the given code. This code, should be in a function called **Interrupt Service Routine Function (ISR Function)**. In **Arduino Uno**, we have 2 external **interrupts**. These **interrupts** are connected to **pin 2** and **pin 3**. So, if we want to work with these interrupts, we should connect a button to one of these two pins.

Setup LEDs

To understand the concept of interrupts better, let's make a routine. The routine that we are going to make, includes 8 LEDs, which are connected like the image below:

You are free to connect the LEDs to any pin that you want, except pins 0 to 3. We connected our LEDs to pin 6 to 13. Now, let's write a code for these LEDs to turn on in a sequence.

```
#include <Arduino.h>

int led_pins[8] = {6, 7, 8, 9, 10, 11, 12, 13};

int current_led = 0;
```




Figure 1: led setup

```

void setup()
{
    for (int i = 0; i < 8; i++)
    {
        pinMode(led_pins[i], OUTPUT);
    }
}

void loop()
{
    digitalWrite(led_pins[current_led], HIGH);
    delay(200);
    digitalWrite(led_pins[current_led], LOW);

    current_led++;
    current_led %= 8;
}

```

In the code above, first we have defined which pins we have for our LEDs in a variable called `led_pins`. Then, we have defined a variable called `current_led`. `current_led` indicates which led should be on at the moment. In the `setup` we have defined all of our `led_pins` to `OUTPUT`, because we want to write values in them. Then, in the `loop` at first we have turned on the first LED and keep it on

for 200ms. After that, we turned that LED off. For the next step, we increment the value of `current_led` and make sure that it doesn't go more than 8. Our output looks like the following:




Figure 2: led setup gif

Now, we are ready to add an interrupt and see its effect.

Interrupt to pause

Right now, our LEDs are getting turned on in a sequence. Our goal is to pause this routine, using an interrupt. To do so, at first let's connect a button to the **pin 2** like below:

As you can see, in the image above, we set the default position of our button to **Closed**. To do so, we can go to the properties of the button and set it to **Normally Closed**. Because, we want to have **5V** by default to the pin and when we press the button, the value of the pin becomes **0V**.

Now, let's learn how we can define an **interrupt** in **Arduino**. To do so, we have to use a function called `attachInterrupt`. This function, takes three arguments:

1. The **pin** that we want the interrupt to work on
2. The **ISR** function
3. The mode

First, let's start with passing the pin as its first argument. To do so, first we




Figure 3: interrupt pause

should change the pin to an **Interrupt** pin using a function called **digitalPinToInterrupt**. For example, if we want our **pin 2** to function as an interrupt, we should write something like below (We are going to fill the ... after):

```
attachInterrupt(digitalPinToInterrupt(2), ... ,...);
```

For the second argument, let's define an empty function, that we are going to fill it later, and pass that function to it. For example, a function like below:

```
void isr_pause()
{}
```

So, now we have:

```
attachInterrupt(digitalPinToInterrupt(2), isr_pause ,...);
```

The only remaining thing is the mode. In **Arduino Uno** we have 4 modes for the interrupts.

Mode	Description	figure
LOW	trigger the interrupt whenever the pin is low.	
CHANGE	trigger the interrupt whenever the pin changes value.	
RISING	trigger when the pin goes from low to high.	
FALLING	trigger when the pin goes from high to low.	

Now, let's put the mode to **RISING**. It means that we are going to have an **interrupt** when leave the button. So, here is the full function call, which we put it in the **setup**.

```
attachInterrupt(digitalPinToInterrupt(2), isr_pause, RISING);
```

Now, it's time to implement the logic. If an interrupt happens, we want the routine to be paused. So, we are going to define an integer variable called **x** with default value of 1. Instead of incrementing **current_led** by 1, we are going to increment it by **x**. It would look like this: **current_led += x**. In your **isr_pause** function, we are going to toggle **x**. So, anytime an interrupt comes, the pausing and resuming happens. The full code, would look like below:

```
#include <Arduino.h>

int led_pins[8] = {6, 7, 8, 9, 10, 11, 12, 13};

int current_led = 0;
int x = 1;

void isr_pause()
{
    x = 1 - x;
}

void setup()
{
```

```

for (int i = 0; i < 8; i++)
{
    pinMode(led_pins[i], OUTPUT);
}

attachInterrupt(digitalPinToInterrupt(2), isr_pause, RISING);

}

void loop()
{
    digitalWrite(led_pins[current_led], HIGH);
    delay(200);
    digitalWrite(led_pins[current_led], LOW);

    current_led += x;
    current_led %= 8;
}

```

And this is going to be our output:

Take note that when we press the button, the button goes up and value of the pin becomes 0




Figure 4: led pause gif

Volatile in Cpp

When we define a variable in **Cpp**, its compiler tends to optimize the usage of it. Sometimes, this optimization would work against us, specially in **Interrupt Service Routines**. Because **ISR** is a hardware event and **Cpp** might not plan for it. To prevent this optimization from happening we can use a keyword called **volatile**. We should put this keyword before the declaration of our variable. For example, `volatile int v;`. This keyword tells **Cpp** not to apply optimization on this variable.

Reset with Interrupt

Now, add another interrupt to **pin 3**. This interrupt would reset the routine from the start. Take note that you might need to use **volatile**.




Figure 5: Reset with Interrupt

Increment pattern

Now, make LEDs with the pattern below. Make sure that the both interrupts work as intended (one for pausing and one for resetting).




Figure 6: Increment Pattern

LEDs dance

Let's make another routine like below. Again, make sure that the both interrupts work as intended.

Conclusion

In this tutorial, we have learned how to work with **External Interrupts**. First, we explained what **External Interrupt** really is. Then, we set up a routine to understand the effect of an **Interrupt**. After that, we learned how to configure an **Interrupt** in **Arduino Uno** and saw how an **Interrupt** works. We explained about **volatile** in **Cpp** and why it's necessary to declare some variables as **volatile**. Then, We added another **Interrupt**. Finally, we have made two more routines to understand the concepts better.




Figure 7: LEDs dance