


Front idlers / Tensioners






Dept.	Technical reference	Technical reference Created by		Approved by			
		DutchDude	21/03/2021				
		Document type		Docum	ent status		
		Title		DWG N	lo.		
		Experimental	Front Towers				
				Davi	Dete effective	l Oh 4	
				Rev.	Date of issue	Sheet 1/5	


Front idler parts






Dept.	Technical reference	Created by			Approved by			
		DutchDude	21/03/2021					
	·	Document type		Docume	ent status			
		Title		DWG No.				
Experimental Front Towers								
				Rev.	Date of issue	Sheet		
				11.64.	Date of issue	2/5		

Front idler parts Top view



Dept.	Technical reference	Created by Appro			oved by		
		DutchDude	21/03/2021				
		Document type		Docume	ent status		
	Title			DWG No.			
		Experimental Fr	ront Towers				
				Rev.	Date of issue	·	Sheet
							3/5

Front idler parts Back view




HARDWARE FOR BOTH FRONT IDLERS

- 2 M5X30 DOWELL PIN (FOR FLANGE BEARINGS)
- 2 M5X20 BOLTS (INTO T-NUTS)
- 2 M3X25 BOLTS (USED TO TENSION)
- 2 T-NUTS (FOR EXTRUSION)
- 4 M5 1MM SPACER (CHECK PAGE 2 FLANGE STACK)
- **4** 625RS 5*16*5mm (FLANGE BEARING)

EXTRA INFO

With an afterburner we suggest to tension the belts to about 110hz using spectroid (app on your phone) to meassure.

When tensioning the belts, losen the two M5X20 bolts. Tighten or losen



Dept.	Technical reference	Created by		Approved by			
		DutchDude 21/0	3/2021				
		Document type		Docume	ent status		
		Title		DWG N	0.		
		Experimental Front T	owers				
				Rev.	Date of issue	Sh	heet
							5/5