Kymatica Devices/RYO 2xVCX

- 1 Ch 1 CV offset knob (acts as vca initial, offset for the four quadrant multiplier or bias for the crossfader.)
- 2 Ch 2 CV offset knob (acts as vca initial, offset for the four quadrant multiplier or bias for the crossfader.)
- **B** Ch 1 Mode switch:
 - Switch A > A; input A and CV input act as Four Quadrand Multiplier.
 - Switch 0 > A; input A and CV input act as normal linear VCA.
 - Switch B > A; CV input controls crossfade from input B to input A.
- 4 Ch 2 mode switch: See 3.
- **6** Ch 1 CV attenuator.
- **6** Ch 2 CV attenuator.
- 🕡 Ch 1 CV input.
- **8** Ch 2 Output.
- **9** Ch 2 CV input.
- Ch 1 A input (dc coupled Works for cv and audio.)
- Mix output normalized to CH 2 B input.
- Ch 2 A input (dc coupled Works for cv and audio.)
- **B** Ch 1 B input (dc coupled Works for cv and audio.)
- Ch 1 output.
- **(b)** Ch 2 B input (dc coupled Works for cv and audio.)

Width: 8 hp

