


# Multi-Band Multi-System GNSS Positioning Module TAU1202 TAU1205

Datasheet V1.1





## Notice, Statement and Copyright

ALLYSTAR Technology offers this document as a service to its customers, to support application and engineering efforts that use the products designed by ALLYSTAR Technology. Products and specifications discussed herein are for reference purposes only. Performance characteristics listed in this document do not constitute a warranty or guarantee of product performance.

ALLYSTAR Technology assumes no liability or responsibility for any claims or damages arising out of the use of this document, or from the use of integrated circuits based on this document, including, but not limited to claims or damages based on infringement of patents, copyrights or other intellectual property rights.

This document contains proprietary technical information which is the property of ALLYSTAR Technology, copying of this document and giving it to others and using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. ALLYSTAR Technology reserves the right to make changes in its products, specifications and other information at any time without notice.

For more recent documents, please visit <a href="www.allystar.com">www.allystar.com</a>.
Copyright © Allystar Technology (Shenzhen) Co., Ltd. 2019. All rights reserved.



# **TABLE OF CONTENT**

TAE	BLE O	F CONTENT	3
1	SYS	TEM OVERVIEW	5
	1.1	Overview	
	1.2	Features	
	1.3	Module photo	5
	1.4	Block diagram	6
	1.5	Specifications	
2	PIN	DESCRIPTION	8
	2.1	Pin assignment	8
	2.2	Detailed pin descriptions	9
3	ELE	CTRICAL CHARACTERISTICS	10
	3.1	Absolute Maximum Rating	10
	3.2	IO Characteristics	
		3.2.1 PRRSTX and PRTRG	10
		3.2.2 Others	10
	3.3	DC Characteristics	11
		3.3.1 Operating Conditions	11
		3.3.2 Power Consumption	
4	HAI	RDWARE DESCRIPTION	12
	4.1	Connecting power	12
	4.2	Antenna design	
	4.3	Reset and mode control	
	4.4	Serial interfaces	13
5	ME	CHANICAL SPECIFICATION	14
6	MI	NIMAL DESIGN	15
7	PRO	DDUCT HANDLING	16
	7.1	ESD Handling Precautions	
	7.1 7.2	ESD protection measures	
	7.2	Moisture sensitivity level	
		·	
8	KE\	/ISION HISTORY	



# List of tables

Table 1 Specifications	<del>(</del>
Table 2 Detailed pin descriptions	
Table 3 Absolute rating	
Table 4 PRRSTX and PRTRG	
Table 5 Others	
Table 6 Operating conditions	
Table 7 Power consumption	
Table 8 Dimensions	
Table o Difficisions	1-

# List of figures

6
8
14
-1



#### 1 SYSTEM OVERVIEW

#### 1.1 Overview

TAU1202/TAU1205 is a high-performance dual-band GNSS positioning module, which is based on the state of art CYNOSURE III architecture. It supports BDS-3 (BeiDou Navigation Satellite System 3). Besides, it is capable of tracking all global civil navigation systems (BDS, GPS, GLONASS, Galileo, IRNSS, QZSS and SBAS). TAU1202/TAU1205 integrates efficient power management architecture, while providing high precision, high sensitivity and low power GNSS solutions which make it suitable for navigation applications on automotive and consumer electronics, as well as fleet management.

#### 1.2 Features

- Supports all civil GNSS systems
- Supports BDS-3 signal: B1C and B2a
- Concurrent reception of L1 and L5 band signals
- Sub-meter position accuracy, superior in multipath mitigation and lower noise in city valley
- Smart jammer detection and suppression
- Highly integrated module, the best cost-effective high precision solution
- Supports single IRNSS mode

## 1.3 Module photo





Figure 1 TAU1202/TAU1205 module photo



# 1.4 Block diagram




Figure 2 Block diagram

# 1.5 Specifications

**Table 1 Specifications** 

Parameter	Specification		
GNSS Tacking channel	40 channels		
		GPS/QZSS: L1C/A, L5C	
		BDS: B1I, B2a	
	TAU1202	GLONASS: L1OF	
		Galileo: E1, E5a	
CNISS recording		SBAS	
GNSS reception		GPS/QZSS: L1C/A, L5C	
	TAU1205	BDS: B1I, B2a	
		Galileo: E1, E5a	
		IRNSS	
		SBAS	
Update rate	Maximum 10Hz		
Position accuracy [1]	GNSS	<1m CEP	
Valasitus 9. Timas a saurasus	GNSS	0.1m/s CEP	
Velocity & Time accuracy	1PPS	20ns	
Time to First Fiv/TTFF\	Hot start	1 sec	
Time to First Fix(TTFF)	Cold start	24 secs	
Consitivity	Cold start	-148dBm	
Sensitivity	Hot start	-155dBm	



Parameter	Specification				
	Reacquisition	-158dBm			
	Tracking & navigation	-162dBm			
Operating limit	Velocity	515 m/s			
Operating limit	Altitude	18,000 m			
	Antenna short circuit protect	ion			
Safety supervision	System clock stop detection				
	Low voltage detection				
	UART	1			
Serial interface	I2C	1			
	CAN [2]	1			
Protocol	NMEA 0183 Protocol Ver. 4.00/4.10,				
Protocol	Cynosure GNSS Receiver Protocol				
	Main voltage	1.8 ~ 3.6V			
Operating condition	Digital I/O voltage	1.8 ~ 3.6V			
	Backup voltage	1.8 ~ 3.6V			
	GPS+QZSS, L1 band	22mA			
Power consumption	GNSS, L1+L5 band	36mA			
	Standby	12uA			
Operating temperature	-40 °C ~ +85 °C				
Storage temperature	-40 °C ~ +85 °C				
Package	10.1mm x 9.7mm x 2.5mm 18-pin stamp hole				
Certification	Rohs & Reach				

<sup>\* [1]</sup> Open sky, dual band, demonstrated with a good external LNA

<sup>\* [2]</sup> Only customized firmware supported



# **2 PIN DESCRIPTION**

# 2.1 Pin assignment




Figure 3 Pin assignment (top view)



# **2.2** Detailed pin descriptions

**Table 2 Detailed pin descriptions** 

Function	Symbol	No.	I/O	Description	
	VDD	8	Power	Main voltage supply. Provide clean and stable supply.	
	GND	1,10,12	VSS	Assure a good GND connection to all GND pins of the	
	GND	1,10,12	V33	module, preferably with a large ground plane.	
				Backup voltage supply. It is recommended to connect	
Power				a backup supply voltage to AVDD_BAK in order to	
	AVDD_BAK	6	Power	enable warm and hot start features. Moreover,	
	/\\DD_B/\\\		100001	AVDD_BAK is a must for the system running.	
				If no backup power is available, connect AVDD_BAK	
				to the main power supply.	
				The connection to the antenna must be routed on	
	RF_IN	11	I	the PCB. Use a controlled impedance of $50\Omega$ from	
Antenna				connect RF_IN to the antenna or the antenna	
Antenna				connector.	
	ANT_BIAS	14	О	RF section output voltage. The ANT_BIAS pin can be	
	ANT_DIAS 14		17 0	used to supply powers to an external active antenna.	
UART	UOUT0	2	0	UARTO serial data output.	
OANT	UIN0	3	I	UARTO serial data input.	
I2C/CAN	CANRX/SDA	16	1/0	I <sup>2</sup> C or CAN data input, leave it floating if not used	
12C/CAIN	CANTX/SCL	17	0	I <sup>2</sup> C or CAN data output, leave it floating if not used	
	PRTRG	18		Mode selection, or the trigger input in deep sleep	
	PRING	10	<b>'</b>	mode to wake up the system	
System	PRRSTX	9	I	External reset, low active	
System	PPS	4	0	Setting for time pulse output(PPS)	
	EXTINT 5			GPIO, Default(EXTINT): a trigger pin to external	
	LATINI	,	•	interrupt, leave it floating if not used.	
Reserved	Reserved	7,13,15,		Reserved, leave it floating if not used	



# **3 ELECTRICAL CHARACTERISTICS**

# 3.1 Absolute Maximum Rating

**Table 3 Absolute rating** 

Symbol	Parameter	Min.	Max.	Unit
VDD	Power input for the main power domain	-0.5	3.63	V
AVDD_BAK	Power input for the backup power domain	-0.5	3.63	V
Tj	Junction temperature	-40	125	°C
T <sub>storage</sub>	Storage temperature	-40	85	°C
T <sub>solder</sub>	Solder reflow temperature		260	°C
Ta	Ambient temperature	-40	85	°C

## 3.2 IO Characteristics

#### 3.2.1 PRRSTX and PRTRG

**Table 4 PRRSTX and PRTRG** 

Symbol	Parameter	Condition	Min.	Тур.	Max.	Unit
lız	Input leakage current				+/-1	uA
VIH	Input high voltage		AVDD_BAK*0. 7		AVDD_BAK	V
VIL	Input low voltage		0		AVDD_BAK*0.3	V
Ci	Input capacitance				10	pF
R <sub>PU</sub>	Pull-up resistance		18		84	kOhm

#### **3.2.2** Others

**Table 5 Others** 

Symbol	Parameter	Condition	Min.	Тур.	Max.	Unit
l <sub>IZ</sub>	Input leakage current				+/-1	uA
ViH	Input high voltage		VDD*0.7		VDD	V
V <sub>IL</sub>	Input low voltage		0		VDD*0.3	V
V	Output high voltage	I <sub>OH</sub> =11.9 mA, VDD=3.3V	2.64			V
V <sub>OH</sub>		I <sub>OH</sub> =2.8 mA, VDD=1.8V	1.53			V
V	Output low voltage	I <sub>OL</sub> =7.9 mA, VDD=3.3V			0.4	V
V <sub>OL</sub>	Output low voltage	I <sub>OL</sub> =3.9 mA, VDD=1.8V			0.45	V
Ci	Input capacitance				11	pF
R <sub>PU</sub>	Pull-up resistance	-	35		84	kOhm



## 3.3 DC Characteristics

# **3.3.1** Operating Conditions

**Table 6 Operating conditions** 

Symbol	Parameter	Min.	Тур.	Max.	Unit
VDD	Power input for the main power domain	1.8	3.3	3.6	V
AVDD_BAK	Power input for the backup power domain	1.8	3.3	3.6	V
ICC <sub>max</sub>	Maximum operating current @ VDD			200	mA
T <sub>env</sub>	Operating temperature	-40		85	°C
T <sub>storage</sub>	Storage temperature	-40		85	°C

## **3.3.2** Power Consumption

**Table 7 Power consumption** 

Symbol	Parameter	Measure Pin	Тур.	Unit
I <sub>CCRX1</sub> <sup>[1]</sup>	Run Mode (GPS+QZSS, L1 only)	VDD <sup>[3]</sup>	22	mA
I <sub>CCRX2</sub> <sup>[2]</sup>	Run Mode (All GNSS, L1+L5)	VDD <sup>[3]</sup>	36	mA
Іссовм	Data backup Mode	AVDD_BAK <sup>[4]</sup>	12	uA
I <sub>CCRTCM</sub>	RTC Mode	AVDD_BAK <sup>[4]</sup>	1.8	uA

<sup>\* [1]</sup> GPS+QZSS, L1 band only, 16 tracking channels, position fixed

<sup>\* [2]</sup> All GNSS, L1 + L5 band, 32 tracking channels, position fixed

<sup>\* [3]</sup> Condition: VDD=3.3V@Room Temperature; All Pins Open.

<sup>\* [4]</sup> Condition: AVDD\_BAK=3.3V@Room Temperature; All Pins Open.



#### 4 HARDWARE DESCRIPTION

## 4.1 Connecting power

TAU1202/TAU1205 positioning module has two power supply pins: VDD and AVDD\_BAK. The VDD pin provides the main supply voltage, and the AVDD\_BAK pin provides the backup supply voltage. In order to ensure the positioning performance, please control the ripple of the module power supply. It is recommended to use the LDO with max output current above 100mA.

If the power for VDD pin is off, the real-time clock (RTC) and battery backed RAM (BBR) are supplied through the AVDD\_BAK pin. Thus, orbit information and time can be maintained and will allow a Hot or Warm start. If no backup battery is connected, the module performs a cold start at every power up if not aiding data are sent to the receiver.

**Note:** If no backup supply is available, connect the AVDD BAK pin to VDD.

## 4.2 Antenna design

There is built-in LNA and SAW in the GNSS module. It is recommended to use an active antenna with gain less than 20dB and the noise figure less than 1.5dB. The module has built-in short circuit detection and open circuit detection function, which can detect the status of normal connection, and send out antenna status prompt message in NMEA data.

- Short circuit protection
  - » The module includes internal short circuit antenna detection. Once an overcurrent is detected at the ANT\_BIAS port, the module will cut off this power supply automatically to prevent permanent damages.
- Open circuit detection
  - » The module can detect an open circuit in the antenna. Users can judge it from antenna status messages.

#### 4.3 Reset and mode control

The operation mode of GNSS module is controlled by PRRSTX (nRESET) and PRTRG(BOOT) pin.

- When system powers up or PRRSTX pin is pulled from "low" to "high", the module will execute an external
  reset (If the power for AVDD\_BAK is always on, this external reset will not affect the ephemeris data in the
  backup domain).
- Drive PRTRG pin to "low" or connect PRTRG to GND directly (not by pull-down resistance) during system power-up or the external reset (PRRSTX from "low" to "high"), system will enter BootROM Command Mode and wait for firmware upgrading after internal system reset finish.
- Keep PRTRG pin floating during system power-up or the external reset (PRRSTX from "low" to "high"), and system will enter User Normal Mode after internal system reset finish.
- When connecting PRRSTX and PRTRG to any host IO, DO NOT use the pull-up or pull-down resistance. Leave PRRSTX and PRTRG pin floating while the module is in normal operation.




## 4.4 Serial interfaces

The module provides a TTL Universal Asynchronous Receiver / Transmitter (UART) interface. The data format is: 1 start bit, 8 data bits, 1 stop bit, no checksum, and the default baud rate is 115200 bps. NMEA data outputs while the module is powered on.

When the module is applied to the specific application, users can shut off the main power in order to further reduce the power consumption. To avoid the high level in serial interface influencing the normal operation, it is highly suggested to cut off the serial port when shut off the main power. Otherwise, please set the serial port to input mode or high impedance state with pull-down resistor.



# **5 MECHANICAL SPECIFICATION**



**Figure 4 Dimensions** 

## **Table 8 Dimensions**

Symbol	Min. (mm)	Typ.(mm)	Max. (mm)
Α	10.0	10.1	10.6
В	9.6	9.7	9.8
С	2.4	2.5	2.6
D	0.55	0.8	0.95
E	1.0	1.1	1.2
F	0.6	0.8	
G	0.4	0.5	0.6
Н	0.7	0.8	0.9
K	0.7	0.8	0.9
M	0.8	0.9	1.0



## 6 MINIMAL DESIGN

This is a minimal design for a TAU1202/TAU1205 GNSS module. When connecting to an active antenna, make sure there is a 39NH(L1) inductance soldered as shown in the following figure. When it is connected to a passive antenna, there is no need for the 39NH inductance. Finally, it needs to make sure that the RF line from RF\_IN pin to antenna connector meets the  $50\Omega$  coplanar waveguide impedance.




Figure 5 Minimal application diagram



#### 7 PRODUCT HANDLING

## 7.1 ESD Handling Precautions

TAU1202/TAU1205 module which contain highly sensitive electronic circuitry are Electrostatic Sensitive Device (ESD). Observe precautions for handling! Failure to observe these precautions may result in severe damage to the GNSS module!

- Unless there is a galvanic coupling between the local GND (i.e. the workbench) and the PCB GND, then the first point of contact when handling the PCB must always be between the local GND and PCB GND.
- Before mounting an antenna patch, connect ground of the device.
- When handling the RF pin, do not come into contact with any charged capacitors and be careful when contacting materials that can develop charges (e.g. patch antenna ~10 pF, coax cable ~50 80 pF/m, soldering iron, ...)
- To prevent electrostatic discharge through the RF input, do not touch any exposed antenna area. If there
  is any risk that such exposed antenna area is touched in non ESD protected work area, implement proper
  ESD protection measures in the design.
- When soldering RF connectors and patch antennas to the receiver's RF pin, make sure to use an ESD safe soldering iron (tip).



## 7.2 ESD protection measures

This series of GNSS positioning modules is sensitive to static electricity. Whenever handling the module, particular care must be exercised to reduce the risk of electrostatic charges. In addition to standard ESD safety practices, the following measures should be taken into account.

- Adds ESD Diodes to the RF input part to prevent electrostatics discharge.
- Do not touch any exposed antenna area.
- Adds ESD Diodes to the UART interface.

## 7.3 Moisture sensitivity level

The Moisture Sensitivity Level (MSL) of the GNSS modules is MSL3.



# 8 REVISION HISTORY

Revision	Date	Author	Status / Comments
V1.0	2019-05-31	Daisy	Start version, first released
V1.1	2019-09-09	Vita Wu	Logo, product photos and wording update





# www.allystar.com



info.gnss@allystar.com



5F, Building No.4, Winlead Intelligent Park, No.3, FaDa road (middle), Bantian Subdistrict, LongGang District, Shenzhen City, Guangdong Province, China.

