## Architetture dei Sistemi di Elaborazione O2GOLOV

Delivery date: 23 November 2023

Laboratory Expected delivery of <a href="mailto:lab\_5.zip">lab\_5.zip</a> must include: This file in pdf format.

**Exercise 1:** 

# **Software Optimizations**

Starting from Exercise 2 of Lab 4, you are required to further speedup the benchmark (my c benchmark) .

For readability, provide the previously used configurations (Cut & Paste).

Parameters	Configuration 1	Configuration 2	Configuration 3	Configuration 4
The_cpu.fetchWidth	12	8	none	12
The_cpu.fetchBufferSi	none	32 none		16
ze				
The_cpu.fetchQueueSi	none	64	none	256
ze				
The_cpu.decodeWidth	8	8	none	12
The_cpu.renameWidth	none	4	none	12
The_cpu.dispatchWidt	none	8	none	12
h				
The_cpu.issueWidth	none	none	none	12
The_cpu.CPU_IntAL	6	6	6	6
U				
The_cpu.numIQEntrie	none	none	32	64
S				
CPU_FP_ALU	none	none	none	1
FloatAdd optLAt				
CPU_FP_ALU	none	none	none	1
FloatCvt optLAt				
CPU_FP_MultDiv	none	none	none	1
FloatMult optLat				
CPU_FP_MultDiv	none	none	none	1
FloatDiv optLat				

Original CPI (no hardware optimization): 2.08310

	Configuration 1	Configuration	Configuration 3	Configuration 4	
		2			
CPI	1.983529	1.946718	0.945976	0.859995	
Speedup (wrt	1.0625	1.0625	2.125	2.428	
Original CPI)					

Despite the hardware enhancements for increasing the CPU performance, remember that <u>optimizing</u> <u>compilers for programs</u> in high-level code also exist. The aim of optimizing compilers is to minimize

or maximize some attributes of an executable computer program (code size, performance, etc.). They are also aware of hardware enhancements to perform very accurate optimizations.

Compilers can be your best friend (or worst enemy!). The more information you provide in your program, the better the optimized program will be.

You can compile your programs with different SW optimization strategies and/or additional features. In the *setup\_default* file:

You can change the line 12.

Simulate the program for different optimization levels and collect statistics. You are required to change the OPTIMIZATION\_FLAGS variable in the *setup\_default*. O0 is the default value, you need to change the optimization value accordingly to the values in parenthesis in the following Table.

#### DO NOT CONFUSE -O3 WITH O3 PROCESSOR.

TABLE1: IPC for different compiler optimization levels and configurations

ABLET. IF C for different complier optimization levels and configurations						
Optimization						
	Opt Ivl 0	Opt Ivl 1	Opt lvl 2	Opt size	Opt Ivl 3	Opt Ivl 2
	(-O0)	(-O1)	(-02)	(-Os)	(-O3)	(-O2fast-
Configuration						math)
	0.48005	0.39644	0.44362	0.41502	0.44362	0.458622
Original Configuration	3.	6	6	7	6	
	0.50415	0.42157	0.45764	0.43592	0.45764	0.467137
Configuration 1	2	0	3	9	3	
	0.51368	0.43390	0.45698	0.43685	0.45698	0.482706
Configuration 2	5	3	0	3	0	
			1.01920	0.92715		0.996838
	1.05711	0.96756	9	0	1.01920	
Configuration 3	6	0			9	
			1.09950	0.99609	1.09950	1.048318
	1.16279		8	6	8	
Configuration 4	7	*				
Program Size [Bytes]	3228	3044	3032	3016	3032	3032

Regarding the Program Size (Code and Data!!), you can retrieve the size from:

```
~/ase_riscv_gem5_sim$ /opt/riscv-2023.10.18/bin/riscv64-unknown-elf-size -format=gnu-radix=10 ./programs/my_c_benchmarls+k/my_c_benchmark.elf
```

For brave and curious guys:

For visualize the enabled optimizations from the compiler perspective, you can run:

By changing the "-O2" parameter with the desired one, you will find the enabled/disabled optimizations.

Here are some possible types of optimizations:

- https://en.wikipedia.org/wiki/Optimizing compiler
- https://gcc.gnu.org/onlinedocs/gcc/Optimize-Options.html


# **Exercise 2:**

Given your benchmark (my\_c\_benchmark.c), select the best optimization to obtain your best angle of optimization, compared to the baseline configuration (riscv o3 custom.py; -00).

1. Based on Table 1 (from Exercise 1), select the best optimization (for example, the green box corresponding to Configuration 1 with -O2).

Optimization	0 1 -1 0	ا ایا خص	ا با احمد	Out size	0 1 -1 2	Omt lul 3
	Opt Ivl 0	Opt Ivl 1	Opt lvl 2	Opt size	Opt Ivl 3	Opt Ivl 2
	(-00)	(-01)	(-02)	(-Os)	(-O3)	(-O2fast-
Configuration						math)
	0.48005	0.39644	0.44362	0.41502	0.44362	0.458622
Original Configuration	3.	6	6	7	6	
	0.50415	0.42157	0.45764	0.43592	0.45764	0.467137
Configuration 1	2	0	3	9	3	
	0.51368	0.43390	0.45698	0.43685	0.45698	0.482706
Configuration 2	5	3	0	3	0	
			1.01920	0.92715		0.996838
	1.05711	0.96756	9	0	1.01920	
Configuration 3	6	0			9	
			1.09950	0.99609	1.09950	1.048318
	1.16279		8	6	8	
Configuration 4	7	*				
Program Size [Bytes]	3228	3044	3032	3016	3032	3032

2. By using **Konata**, overlap the two pipelines (the original obtained with riscv\_o3\_custom.py and the optimized corresponding to the best SW-HW combination) to compute your angle of optimization.




Compute the angle  $\alpha$  (named optimization angle) existing between the traces.

Hint: To load different traces in Konata, load them separately. Afterward, righ-click in the pipeline visualizer and select "transparent mode". You need to adjust the scale!

## 3. To compute the **angle of optimization** $\alpha$ :

$$\alpha = \arctan\left(\frac{{\tiny ClockCycles_{baseline}}}{{\tiny Instructions_{baseline}}}\right) - \arctan\left(\frac{{\tiny ClockCycles_{optimized}}}{{\tiny Instructions_{optimized}}}\right)$$



1. The angle of optimization is equal to: 27.68  $\alpha = \text{atan}(\ 2.522\ )$  -  $\text{atan}(\ 0.8599\ ) = 68.37 - 40\ .69 = 27.68$ 

4. Do you see any visual improvements (for example, a less discontinued pipeline)? Yes, why? No, why? What is happening? How they could be improved?

Comment box: We can see different strong improvements. In particular the optimization code is faster then the baseline so the CPU execute less instruction then the other. Moreover with an increase of values of the pipeline there are less hazards.