



Making an energy-saving stove

1.



Mix the clay with water.

2.




Form the stove.

3.




Leave it in the sun for 3 hours to dry.

4.



Place sticks on top of the stove. Hold it together with the clay mud.

5.



Make cooking holes the size of a saucepan on the top. Leave the stove in the sun for 3 days to dry.

7.



Spread soft clay on the stove. Leave the stove to dry another 3 days.