## Shaft Design Project Code

Machine Design MAE 4300 Professor Larry Gardner

Tyler Black
Daniel Estes
Jonah Frederick
Mason Frederick
Michael Fretz
Travis Slade

Due: 28 January 2025

## 1 Code

```
1 from math import sqrt, pi
  def get_inputs():
      Prompts the user to input the moment, torque, and diameter of the shaft.
      Also allows selection of a stress concentration case.
      Returns:
          m (float): Bending moment in kip-in (kilo pound-inch).
          t (float): Torque in kip-in.
          d (float): Shaft diameter in inches.
12
          case (int): Selected stress concentration case (1-4).
13
14
      m = \textbf{float(input("Input moment (lbf*in):"))} \ / \ 1000 \ \# \ \textit{Convert to kip-in}
      t = float(input("Input torque (lbf*in):")) / 1000 # Convert to kip-in
      d = float(input("Input diameter (in): ")) # Input shaft diameter in
17
      inches
18
      def select_case():
19
20
          Displays the available stress concentration cases and gets user input.
22
          Returns:
              int: Selected case number (1-4).
24
```

```
print("""Stress Concentration Cases:
           1. Wide Radius
27
           2. Sharp Radius
28
           3. Keyway
29
           4. R.R.G""")
30
31
           case = int(input("Select Case: "))
32
           return case if case in {1, 2, 3, 4} else select_case()
34
       case = select\_case()
       return m, t, d, case
36
37
38
  \mathbf{def} \ \mathbf{get}_{\mathbf{k}} \mathbf{f}_{\mathbf{k}} \mathbf{fs} (\mathbf{d}, \ \mathbf{case}):
39
40
       Computes the fatigue stress concentration factors (kf and kfs) based on
41
      the selected case.
42
       Args:
43
           d (float): Shaft diameter in inches.
44
           case (int): Selected stress concentration case.
45
46
       Returns:
47
           kf (float): Fatigue stress concentration factor for bending.
48
           kfs (float): Fatigue stress concentration factor for torsion.
49
       a = 0.009601465
                         # Notch sensitivity coefficient for bending
       a\_s \, = \, 0.00538003 \quad \# \ \textit{Notch sensitivity coefficient for shear}
       \# Stress concentration factors (k, ks) and notch radii (r) based on case
54
       scf = {
           1: (1.7, 1.5, 0.1 * d),
           2: (2.7, 2.2, 0.02 * d)
           3: (2.14, 3, 0.02 * d),
58
           4: (5, 3, 0.01 * d)
60
      k, ks, r = scf[case]
       r = max(r, 1e-9) # Prevent division by zero
63
64
       \# Calculate fatigue stress concentration factors
65
       kf = 1 + (k - 1) / (1 + sqrt(a) / sqrt(r))
66
       kfs = 1 + (ks - 1) / (1 + sqrt(a_s) / sqrt(r))
67
       return kf, kfs
70
  def fatigue_sf(m, t, d, case):
       Computes the fatigue safety factor for the shaft.
74
75
           m (float): Bending moment in kip-in.
77
           t (float): Torque in kip-in.
```

```
d (float): Shaft diameter in inches.
           case (int): Selected stress concentration case.
80
81
       Returns:
82
           n_f (float): Fatigue safety factor.
83
84
       uts = 68 # Ultimate tensile strength in ksi (kilo pounds per square inch)
85
       kf, kfs = get_kf_kfs(d, case)
86
87
       # Calculate bending and torsional stress components
       sigma_b = 2 * kf * m \# Bending stress component
89
       tau = sqrt(3) * kfs * t # Torsional stress component
90
91
       \# Compute endurance limit (Se) using size factor correction
       Se_prime = uts / 2 # Initial endurance limit assumption
       Se = 2 * uts ** (-0.217) * 0.879 * d ** (-0.107) * Se_prime
                                                                       # Modified
      endurance limit
       # Compute fatigue safety factor
96
       n_f = (pi * d ** 3 / 16) / ((sigma_b / Se) + (tau / uts))
97
98
       return n<sub>-</sub>f
99
100
  def yield_sf(m, t, d, case):
       Computes the yield safety factor using von Mises stress.
104
       Args:
           m (float): Bending moment in kip-in.
107
           t (float): Torque in kip-in.
           d (float): Shaft diameter in inches.
           case (int): Selected stress concentration case.
111
       Returns:
           n_y (float): Yield safety factor.
113
114
       sy = 37.5 # Yield strength in ksi
       kf, kfs = get_kf_kfs(d, case)
117
       # Compute bending and torsional stresses
118
       sigma = 32 * m * kf / (pi * d ** 3) # Bending stress in ksi
119
       tau = 16 * t * kfs / (pi * d ** 3) # Torsional stress in ksi
       # Compute von Mises equivalent stress
       sigma_vm = sqrt(sigma ** 2 + 3 * tau ** 2)
124
       # Compute yield safety factor
       n_y = sy / sigma_v m
127
       return n_y
128
130
131 def calc_diameter(m, t, case):
```

```
132
       Computes the required shaft diameter to meet a target safety factor of
133
       1.5.
134
       Args:
135
            m (float): Bending moment in kip-in.
136
            t (float): Torque in kip-in.
            case (int): Selected stress concentration case.
138
       Returns:
140
           d (float): Recommended shaft diameter in inches.
141
142
143
       \mathbf{def} \ \mathbf{f}(\mathbf{d}):
            """Returns the fatigue safety factor for a given diameter."""
145
            return fatigue_sf(m, t, d, case)
147
       \mathbf{def} \ \mathbf{g}(\mathbf{d}):
148
            """Returns the yield safety factor for a given diameter."""
149
            return yield_sf(m, t, d, case)
       d = 0.01 # Initial guess for shaft diameter in inches
       n = 1.5 # Target safety factor
153
154
       \# Iteratively increase diameter until safety factor conditions are met
       while f(d) < n or g(d) < n:
            d \leftarrow 0.001 # Increment diameter in small steps
158
       return d
159
161
   if __name__ = '__main__':
       while True:
            # Get user input
164
            m, t, d, case = get_inputs()
166
            # Compute safety factors
167
            n_f = fatigue_sf(m, t, d, case)
168
            n_y = yield_sf(m, t, d, case)
            d_{rec} = calc_{diameter}(m, t, case)
170
            # Print results
172
            print(f"Fatigue Safety Factor: {n_f:.3f}")
173
            print(f"Yield Safety Factor: {n_y:.3f}")
174
            print(f"Recommended Shaft Diameter (for SF=1.5): {d_rec:.3f} in")
```

shaft\_design.py